

LINE SEIKI

INSTRUCTION MANUAL

G 21 SERIES PRESET COUNTER

G 21 -	0 □□□	4 □□□
	1 □□□	5 □□□
	2 □□□	6 □□□
	3 □□□	

* Before you use G21 series, please read this manual to use this counter correctly.

* Keep this manual carefully.

* Contents of this manual are subject to change without notice.

With reading this instruction manual, use correctly before fixing, operating, maintaining and examining.

Keep the following notices not to cause electric shock, injury and damage of device.

WARNING

To prevent from the dangerous condition of user's death or heavy injury, look through the following warnings.



Supply the voltage between the terminal No. 29 & No. 30 of unit in the range of 85~264VAC. Be sure to confirm the voltage not to cause destruction of the unit by supplying the voltage out of applicable range.



Be sure to confirm if there is problem such like looseness of screw, wrong wiring. etc., after wiring.



Do not take the unit apart or modify.

<REQUESTS>

◇Do not use the unit under the following environment.

- Explosive gas, Inflammable gas, Corrosive gas.

- High humidity, Dewdrop.

- Intensive temperature difference

- Intensive vibration.

◇Do not drop or give the high shock to the counter.

◇Be sure to use load current within nominal.

◇Keep away the wiring from the high voltage or current lines.

◇Do not use the blank terminals as relay terminal.

◇Keep the input signal source, counter itself or it's wiring away from the noise source when the counter is used in the noise. It is effective to make the wireleads for input to be shielded.

◇In case there are surge and noise on power supply, connect the line noise filter with counter.

◇In case of wiring for the communication cable outside, equip the baristor to prevent the counter from the lightning shock.


◇Pay attention to the excessive fastening for the screw of terminal and panel clamer.

FEATURES

- Easy operation by digit keys
- Power supply, 100~240VAC
- Prescale function
- Tachometer function
- Communication function (RS-485)
- Programmable count start value
- DIN 72×72 mm.
- Depth, 77 mm. Compact size
- Dust & Splash proof

MODEL

G 21 - □ □ □ □



SPECIFICATIONS

1) DISPLAY

Upper display : Red LED 10.0 (H) x 5.5 (W)
Lower display: Green LED 8.0 (H) x 4.0 (W)

2) NUMBER OF DIGITS

Upper display : Preset counter 6 digits
Totalizer 6 digits
Tachometer 6 digits
Batch counter 6 digits

Lower display : Preset value 6 digits

3) INDICATOR

Yellow LED : It turns on when the display is totalizer & tachometer.
Green LED : It turns on when the display shows preset value.
Red LED : It turns on when the unit let out the output signal.

4) SETTING WAY

10 keys (numerical keys) operation

5) SETTING RANGE

Preset value (P1~P4) : -99999~99999
Prewarn value (PW) : 0~99999
Batch preset value (PB) : 0~99999

6) PRESCALE

Multiplying: 0. 0 0 0 1~999. 999 Dividing: 1~9999

7) DECIMAL POINT POSITION

0. 0~0. 0 0 0 0

8) COUNT START VALUE

-99999~99999

9) INPUT

• Open collector input
Sink current: 10mA L: 0~6V
• Voltage input
L: 0~4V H: 6~30V (Input impedance 7kΩ)

10) COUNT SPEED

30Hz (Pulse width 1.6ms Duty 1:1)
1kHz (Pulse width 50μs Duty 1:1)
5kHz (Pulse width 100μs Duty 1:1)
8kHz (Pulse width 62.5μs Duty 1:1)

11) TYPE OF INPUT SIGNAL

Add/Subtract/Individual add, subtract/Quadrature

12) OPERATION

Overrun/Auto-reset/Equal/Upper-lower limit
Model with prewarn function, not include Upper-lower limit
Model with batch function, not include Upper-lower limit/Equal

13) OUTPUT

One shot pulse/Latch

14) OUTPUT TIME

10ms~9990ms (Available to set with 10ms in one unit)

15) TYPE OF OUTPUT

• Relay output
1c (250VAC 3A/30VDC 3A resistance load)
• Open collector output
(30VDC 100mA max.)

16) OUTPUT DELAY TIME

6ms max.

17) RESET

Front reset
Remote reset

18) KEY LOCK

Prohibition for front key reset, preset value editing, count start value editing or editing data in program mode.

19) TACHOMETER

1/TAU, Standard sampling (Measuring accuracy: ±0.1%)
What is 1/TAU?

The 1/TAU method of rate calculation is based on accurately measuring the time period between consecutive input pulses. This time period is called "TAU".


20) COMMUNICATION

RS-485 Serial interface

Read count value, preset value or count start value.

Read the condition of reset and preset output condition.

FRONT PANEL FEATURES



- ① Display for count value, tachometer value, and programming items
- ② Display for preset value and programmed data
- ③ Indicator for total counter
- ④ Indicator for tachometer
- ⑤ Indicator for SET 1 ~ 4 level preset
preset value: SET 2 ~ 2 level preset
SET 3 ~ 3 level preset
SET 4 ~ 4 level preset
PW ~ Prewarn
BP ~ Batch preset
- ⑥ Indicator for OUT 1 ~ 4 level preset output
OUT 2 ~ 2 level preset output
OUT 3 ~ 3 level preset output
OUT 4 ~ 4 level preset output
PW ~ Prewarn output
BP ~ Batch output
- ⑦ Digit keys
- ⑧ Reset Key
- ⑨ -WR key
- ⑩ DISP key
- ⑪ ENT/UD key

*The design of front membrane is different according to each models.

ELECTRIC SPECIFICATIONS

- 1) POWER SUPPLY
100~240VAC -15%, +10%
- 2) POWER CONSUMPTION
approx. 7VA
- 3) SENSOR POWER SOURCE
12VDC ±10% 100mA max.
- 4) MEMORY
EEPROM (10 years : can be used 100,000 times)
- 5) OPERATING TEMPERATURE
-10~50°C (NON FREEZING)
- 6) OPERATING HUMIDITY
45~85%RH (NON CONDENSING)
- 7) INSULATION RESISTANCE
100MΩ (at 500VDC) minimum
- 8) TEST VOLTAGE
1500VAC for one (1) minute
- 9) TEST NOISE
Between the terminal on power supply : ±2000V
Between the terminal on signal input : ±500V
- 10) TEST OSCILLATION
Endurance: 10~5Hz, amplitude 1.5mm, 3 hours(1 cycle 3 minutes) to X,Y,Z 3 directions
Operation: 10~55Hz, amplitude 1.5mm, 3 hours(1 cycle 3 minutes) to X,Y,Z 3 directions
- 11) TEST SHOCK
Endurance: 300m/s² (approx 30G) 10 times to X,Y,Z 3 directions
Operation: 100m/s² (approx 10G) 10 times to X,Y,Z 3 directions

12) SIZE

DIN 72×77mm.

13) WEIGHT

approx. 280g

FRONT PANEL FEATURES

INDICATOR FOR TOTALIZER

- Light is turning on while total count is on the display.

INDICATOR FOR TACHOMETER

- Light is turning on while tachometer value is on the display.

INDICATOR FOR OUTPUT

- It shows which preset output is on

INDICATOR FOR PRESET VALUE


- It shows which preset level is on the display.

DIGIT KEYS (1-6 DIGIT)

- These keys are used to input the preset values and enter the program mode with pressing mode keys.

RESET KEY

- The key is used to reset the count, value and output.



MODE KEY

- This key is used to enter the program mode.
- Programming items can be changed by pressing MODE key in the program mode.

DISP KEY

- This key is used when changing the programming items and returning to run mode from program mode.

UPPER DISPLAY

- Shows count values, tachometer values and programming items when the unit is in the program mode.

LOWER DISPLAY


- Shows preset values and programmed data. It shows value below the decimal point of count value by pressing every ENT/UD key.

WIRING AND REAR TERMINALS

REAR TERMINALS

OUT 1				OUT 2			
N.C.	N.O.	COM1		N.C.	N.O.	COM2	
—	C	E	—	—	C	E	—
1	2	3	4	5	6	7	
8	9	10	11	12	13	14	
N.C.	N.O.	COM3		N.C.	N.O.	COM4	
—	C	E	—	—	C	E	—
OUT 3				OUT 4			

<RELAY OUTPUT TYPE>
<OPEN COLLECTOR TR. OUTPUT TYPE>



*CAUTION
• Do not use the blank terminal as relay terminal.
※ OUT 1~4 are different according to each models.
Refer to the LIST FOR OUTPUT TERMINALS shown in the light.


LIST FOR OUTPUT TERMINALS

MODEL	OUT 1	OUT 2	OUT 3	OUT 4
G 2 1 - 0 □□□	OUT	—	—	—
1 □□□	OUT 1	OUT 2	—	—
2 □□□	PREWARN	OUT	—	—
3 □□□	OUT	BATCH	—	—
4 □□□	PREWARN	OUT	BATCH	—
5 □□□	OUT 1	OUT 2	BATCH	—
6 □□□	OUT 1	OUT 2	OUT 3	OUT 4


(— : NOT AVAILABLE)

DIMENSIONS AND MOUNTING

EXTERNAL DIMENSIONS




PANEL CUTOUT : $68^{+0.7}_{-0} \times 138^{+0.7}_{-0}$ mm



MOUNTING

Insert the unit from front side of panel, and hang the nails of panel clamer on both side or upper-lower side of the unit, and fix the unit by fastening the screw.

PANEL WIDTH : Max. 14 mm.



NOTE

- Be sure to turn the power supply off in case of doing the wiring.
- Supply the voltage at the range of 85~264VAC between the terminal 22&23.
- Confirm the looseness of screw, wrong wiring..etc., after wiring.
- Avoid the excessive fastening for terminal of the unit.

- The thickness of panel clamer is approx. 5mm. Make the enough space to arrange other unit on this panel.

- Avoid the excessive fastening for the screw of panel clamer.

SERIAL COMMUNICATION (RS-485)


Use the terminal "No. 25 and 26" in case communication is required.

COMMUNICATION REQUEST

By shorting the terminals between "No. 10" and "GND", it will be available to read the data easily.

KEY LOCK

By shorting the terminals between "No. 19" and "GND", programming or editing selected in KEY LOCK MODE is invalid.




SENSOR POWER SOURCE

Terminal "No. 21" is used as the sensor power source. (12VDC ± 10% 100mA max.)

RUN MODE AND PROGRAM MODE OPERATION

Press [MODE] key with 1 ~ 4 to enter the program mode.
Press [DISP] key when returning to run mode.



DETAILS OF PROGRAM MODE

NOTE : Depending on the models, programming items marked "*" do not apply to all models.

MODE 1)

• COUNT SPEED (C. S.P.C) MODE


Count speed can be selected from below.

8.0 Hz	L.C. 30
1.0 Hz	M.I. 1
5.0 Hz	M.I. 5
8.0 Hz	M.I. 8

• COUNT IN (C. I. n) MODE

Count input method can be selected from below.

AND INPUT (IIP) ... IN A : ADD
(6 digits) write value = 0 → 999999 → error message (I-E-r)
SUBTRACT INPUT (D) ... IN A : SUB
(6 digits) write value = 0 → -999999 → error message (I-E-r)
ADD/SUBTRACT INPUT (IIP) ... IN A : ADD, IN B : SUB,
Error message (I-E-r) → -999999 → 0 → +999999 → (I-E-r)
QUADRATIC INPUT (Q.M.F)
Error message (I-E-r) → 999999 → 0 → -999999 → (I-E-r)



OPERATION (C. R.C.) MODE *

Operation method can be selected from below.

OVER RUN	L.C. 0
AUTO-RESET	R.C. 25
EQUAL	E. 9. u.
UPPER/LOWER *	U.L. 1

UPPER/LOWER limit is not equipped for the model with prework.
EQUAL and UPPER/LOWER limit are not equipped for the model with batch.

• OUTPUT (O. 1 ~ O. 4) MODE *

When OPERATION MODE is set to OVERRUN or AUTO-RESET, HOLD or ONE SHOT can be selected in OUTPUT MODE. When OPERATION MODE is EQUAL or UPPER/LOWER, HOLD is automatically set. Programming of OUTPUT MODE on each preset level is available.

HOLD	HOLD	Hold at the preset value	OVERRUN
ONE SHOT	O.n.E. 5	Programming is available at One shot in 10~999 Days	AUTORESET

• Refer to the following list of output corresponding to each model for the setting.

MODEL	OUT1	OUT2	OUT3	OUT4
C20-0□□	OUT	-	-	-
1C□	OUT1	OUT2	-	-
2C□	PREWARN	OUT	-	-
3C□	OUT	BATCH	-	-
4C□	PREWARN	OUT	BATCH	-
5C□	OUT1	OUT2	BATCH	-
6C□	OUT1	OUT2	OUT3	OUT4

• KEY LOCK (K.O.P. : KEY OPERATION LOCK) MODE

Key operation to be abled or disabled can be selected.

	OPERATION YES	OPERATION NO
FRONT RESET	P.C. 5	P.C. n
CHANGE ON/PRESET VALUE	P.C. P.C.	P.C. P.C.
CHANGE ON/2ND-COUNT VALUE	P.C. 5	P.C. n
CHANGE ON MODE 1	P.C. 1.4	P.C. 1.0
CHANGE ON MODE 2	P.C. 2.4	P.C. 2.0
CHANGE ON MODE 3	P.C. 3.4	P.C. 3.0
CHANGE ON MODE 4	P.C. 4.4	P.C. 4.0

* CNT. ST. VALUE → COUNT START VALUE

• REMOTE RESET (E. r.P.S) MODE *

Remote reset to be abled or disabled can be selected.

	RESET, YES	RESET, NO
PRESET COUNTER	P.C. 5	P.C. n
BATCH COUNTER *	B.C. 5	B.C. n
TOTAL COUNTER	T.C. 5	T.C. n

• REMOTE RESET TIME (r.P.S.t.)

Either can be selected.

1 ms	1
2.0 ms	20

This time means minimum pulse time required for remote reset pulse.


(NOTE)

In the case of resetting remotely with contact input (relay, switch and so on), please select 20ms.

HOW TO PROGRAM PRESET VALUE


In case that 1 level preset value is changed from 100 to 2500:

1. Press DISP key to make the lower display show 1 level preset value. (Indicator "SET" turns on.)



2. Use digit key 1 ~ 6 to edit preset value. (all digits of the lower display turn on, and the digit to be editing is blinking).

* Edit preset value by using digit keys of 1 ~ 6 and the numerical value is shifted as below by pressing digit key.
→ □ → 1 → 2 → → 8 → -



As to the [6] key, the numerical value is shifted as below and the final - is used to edit minus (-) preset value.

→ □ → 1 → 2 → → 8 → -




3. Edited numerical values are memorized automatically when 3 seconds have passed since the last key is pressed. Also, the above values are programmed by pressing [ENT/ED] key (the blinking of digit is finished and the program of preset value.)

* How to set or change the preset value is all the same in any models.

HOW TO PROGRAM COUNT START VALUE

The count start value can be edited in PROGRAM MODE 3.

1. Press [3] key with pressing [MODE] key to enter COUNT SET in PROGRAM MODE 3. (The upper display shows L.S.P.E, and the lower display shows the count start value).



2. Edit the count start value by using digit keys. (same as the program of preset value.)

3. Edited numerical values are memorized automatically when 3 seconds have passed since the last key is pressed. Also, the above values are programmed by pressing [ENT/ED] key (the blinking of digit is finished and the count start value.)

4. The above programmed count start value can be shown on the upper display by pressing front key reset or remote reset on.

BATCH FUNCTION

MODE 1 ~ 3 □□□, 4 □□□, 5 □□□ have batch function.
G 2 1 ~ 3 □□□, 4 □□□: One count is added when the counts reached to the 1 level preset value.
G 2 1 ~ 5 □□□: One count is added when the counts reached to the 2 level preset value.

OPERATION OF PROGRAM MODE

NOTE: Depending on the models, program items marked **※** do not apply to all models.
See the programming details of program mode and list of output.

MODE + 1

PROGRAM ITEM	UPPER DISPLAY	LOWER DISPLAY (PROGRAMMING DETAILS)	OPERATION
COUNT SPEED	C.5Pd	L0.30 H..1 H.5 H.8	[1] key to change the programming details.
COUNT IN	C..n	UP do UPdo Rudd	[1] key to change the programming details.
OPERATION ※	C.Rct	0.run → A.r2S → Eqn. → UL.LL	[1] key to change the programming details.
OUTPUT ※	Out 1 ~ Out 4 ※	◆ When 0.run or A.r2S selected Hold → On2.S ◆ When UL.LL selected UL → LL	[1] key to change the programming details. (program on each level) Set one shot time by numerical keys. [1] key to select (UL) or (LL).
KEY LOCK	OPer	r2S.Y → r2S.n (Reset key) Pr2.Y → Pr2.n (Preset value change) C.5P.Y → C.5P.n (Count start value change) PG1.Y → PG1.n (Program mode 1 change) PG2.Y → PG2.n (Program mode 2 change) PG3.Y → PG3.n (Program mode 3 change) PG4.Y → PG4.n (Program mode 4 change)	[1] key to select yes(Y) or no(n).

MODE + 2

PROGRAM ITEM	UPPER DISPLAY	LOWER DISPLAY (PROGRAMMING DETAILS)	OPERATION
E.r2S ※	E.r2S	PC Y → PC n (Preset counter) bC Y → bC n (Batch counter) tC Y → tC n (Total counter)	[1] key to select yes(Y) or no(n).
r2S.t	r2S.t	1 → 20	[1] key to change the programming details.
F.r2S ※	F.r2S	PC Y → PC n (Preset counter) bC Y → bC n (Batch counter) tC Y → tC n (Total counter)	[1] key to select yes(Y) or no(n).

MODE + 3

PROGRAM ITEM	UPPER DISPLAY	LOWER DISPLAY (PROGRAMMING DETAILS)	OPERATION
COUNT START VALUE	C.5Pd	-99999~0~99999	Enter count start value by digit keys.
COUNTER PRESCALE (MULTIPLYING)	C.PS	0.001~999.999 0.0001~99.9999 0.00001~9.99999	[ENT/UD] key to change decimal point position. Enter prescale value by digit keys.
COUNTER PRESCALE (DIVIDING)	C.dP	1~9999	Enter prescale value by digit keys.
COUNTER DECIMAL POINT	C.dP	0 0.0 0.00 0.000	[1] key to change programming details.
TACHO. PRESCALE (MULTIPLYING)	T.PS	0.001~999.999 0.0001~99.9999 0.00001~9.99999	[ENT/UD] key to change decimal point position. Enter prescale value by numerical keys.
TACHOMETER DECIMAL POINT	T.dP	0 0.0 0.00 0.000	[1] key to change programming details.

MODE + 4


PROGRAM ITEM	UPPER DISPLAY	LOWER DISPLAY (PROGRAMMING DETAILS)	OPERATION
BAUD RATE	bPS	→ 9600 → 4800 → 2400	[1] key to change the programming details.
PARITY BIT	P.b,t	300 ← 600 ← 1200 ←	[1] key to change the programming details.
ID NO.	I d	RanE → EuEn → Odd	Enter ID No. by numeric keys.
DELAY TIME	dEL.t	00~99	[1] key to change the programming details.
SEND DATA	sEnd	0.002 → 0.100	[1] key to select yes(Y) or no(n).
		PC Y → PC n (Preset counter) bC Y → bC n (Batch counter) tC Y → tC n (Total counter) P1 Y → P1 n (Preset value 1) P2 Y → P2 n (Preset value 2) P3 Y → P3 n (Preset value 3) P4 Y → P4 n (Preset value 4) Pn Y → Pn n (Prewarn value) bP Y → bP n (Batch preset value)	

COUNT AND OUTPUT (1)


● G21 - 0□□□, 1□□□, 3□□□, 5□□□, 6□□□ (MODEL FOR 1 LEVEL, 2 LEVEL, 4 LEVEL or WITHOUT PREWARN)

• OVER RUN

OUT1 : ONE SHOT or HOLD
OUT2 : HOLD




OUT1 : ONE SHOT or HOLD
OUT2 : ONE SHOT




• AUTO-RESET

OUT1 : ONE SHOT or HOLD
OUT2 : HOLD




OUT1 : ONE SHOT or HOLD
OUT2 : ONE SHOT



• EQUAL



Output is on while the count value is equal to the counter preset value.



• Output of each preset levels is individual each other. Refer the above drawings.
EQUAL and UPPER/LOWER limit are not selectable on the model with Batch function.

• UPPER/LOWER LIMIT

OUT1 : L_L (LOWER LIMIT)
OUT2 : U_U (UPPER LIMIT)



• For 2 level or 4 level preset type, when output of the last preset level is set at ONE SHOT, all outputs are turned to off by the falling edge of ONE SHOT pulse.


COUNT AND OUTPUT (2)

RESET


G 2 1 - 2 □□□, 4 □□□ (1 level with prewarn)
 Model with prewarn has no UPPER/LOWER output in OPERATION MODE. For G 2 0 - 4 □□□, the model with batch function, EQUAL output is not available and only OVERRUN or AUTO-RESET is available in OPERATION MODE. OUT 1 is prewarn output, OUT 2 is preset output. On the model with batch function, OUT 3 is batch output.

• OVER RUN

OUT1 (Prewarn output) : ONE SHOT or HOLD
 OUT2 (Preset output) : HOLD




OUT1 (Prewarn output) : ONE SHOT or HOLD
 OUT2 (Preset output) : HOLD




- When OUT 2 (Preset output) is set to ONE SHOT, OUT 1 (Prewarn Output) turns to be off by the falling edge of that ONE SHOT pulse.
- Prewarn output is on only when the count value is near to SET 1 (1 level preset value).

• AUTO RESET

OUT1 (PREWARN OUTPUT) : ONE SHOT or HOLD
 OUT2 (PRESET OUTPUT) : HOLD



OUT1 (PREWARN OUTPUT) : ONE SHOT or HOLD
 OUT2 (PRESET OUTPUT) : ONE SHOT




• EQUAL(Only for the model without batch function)

OUT 1 (Prewarn output)

On only when the count value is near to SET 1 (1 level preset value).

OUT 2 (Preset output)

On only when the count value is equal to SET 1.



• Type of reset :

- Front reset
- Remote reset *
- Reset by serial communication command

* Does not count during shorting.

• Subject to be reset:

- Count value(Preset count value) and output
- Total count value
- Batch count value
- Error (Overflow , Underflow)

Reset able or disable are can be selected in the PROGRAM MODE.

Reset of count value(Preset count value) enables all preset outputs to be off.

The determined count start value can be shown on the upper display by reset on.
 The count start value at ex-fact is set to 0.


• BATCH OUTPUT

G 2 1 - 4 □□□ has Batch function.

Batch counter counts 1 when the preset counter reaches 1 level preset value. The batch output turns on when the batch count reaches the batch preset value.

For the batch output, ONE SHOT or HOLD can be selected.

Example : OPERATION MODE is set to AUTO-RESET.



SERIAL COMMUNICATION (1)

The control uses ASCII code with the RS-485 serial specification.

This allows bi-directional communications and addressing of multiple controls on a single two-wire communication bus.

Each unit is individually addressed via a user programmable ID number. Up to 32 G20 counters can be connected directly to the bus.

※ SERIAL COMMAND SUMMARY

RDD	: Read count value/preset value. (display only)
RDI	" (value of integral number)
RDU	" (value of decimal point)
WRD	: Write preset value.
RES	: Reset for count value and condition of over/under flow error.
RDO	: Read output condition.
STP	: Count prohibition.
RSM	: Cancellation for count prohibition.
LTD	: Store count value/preset value in memory of counter.
RLD	: Read stored data by LTD command.

《NOTE》

- It can not be to communicate if the count input pulse speed goes over the max. count speed.
- Use only the character of capital letter in communication.

◆ TRANSMISSION FORMAT

The general command is shown below. Spaces are used for clarify only and must not be transmitted.

> I D # COMMAND (numerical data) CHECKSUM (c r)

Example: To cause the unit #10 to transmit the value of main counter, send the RDD command as follows.

>	1 0	RDD	PC	CE	(c r)
①	②	③	④	⑤	⑥

- Message start character (ASCII 62). Required for all transmission to the control.
- Two digits serial port ID# in decimal. Required for all transmission to the control. Unit ID#10 (decimal) is unit ID#0A (hexadecimal), capital letters must be used.
- RDD command. All serial commands consist of three characters.
- Sub command decides the details for serial command. This command means the read of preset count value by PC.
- Checksum.

CHECK SUM CALCULATION

1	0	R	D	D	P	C
---	---	---	---	---	---	---

$$49 + 48 + 82 + 68 + 68 + 80 + 67 = 462 \text{ (Dec.)}$$

$$= 1CE \text{ (Hex.)}$$

Check sum is the last two hexadecimal charring.

The > start character and carriage return (c r) are not used in calculation.

- ASCII carriage return (13 decimal). Required at the end of all commands.

◆ RESPONSE FORMAT

RESPONSE RECOGNITION FORMAT

The counter does not respond to a command unless the transmitted ID number matches its programmed ID number.

If the ID numbers match and the command and checksum are valid, the control executes the command and transmits a response as shown below.

[A] [DATA] [CHECK SUM] (c r)

[A] is the acknowledge character sent when any valid command is received and executed.

[DATA] is sent in response to request data.

[CHECK SUM] is sent only when data is requested (RDD, RDI or RDU commands).

The checksum is calculated by adding the ASCII values of all preceding characters (including the "A" and spaces). The checksum is the two least significant digits of this sum in hexadecimal.

(c r) is the ASCII carriage return (13 decimal). Transmitted at the end of all responses

Ex 1 : A (c r) = No data requested.

Ex 2 : APC 1 2 3 4 5 6 4 8 (c r) = Count data requested.

ERROR RESPONSE FORMAT

If the ID numbers match but the command is not valid or cannot be executed, the counter ignores the command and responds by sending an ASCII "N" (not acknowledged), followed by one character and carriage return.

※ ERROR CODES

N 0 2 : CHECKSUM ERROR

Received checksum does not match the calculated check sum.

N 0 5 : INVALID DATA

Incorrect number of digit or illegal characters received in data field.

N 1 1 : RESET EDIT IN PROGRESS ON KEY BOARD

Serial preset cannot be sent if the preset is being changed on the key board.

N 1 3 : KEY BOARD PROGRAM MODE IS ACTIVE

Cannot enter serial program mode if in the key board program mode.

N F F : UNDER OVERFLOW or UNDERFLOW FOR COUNT VALUE

It is impossible to communicate under displaying for overflow error or underflow error.

It is possible to communicate by reset command for error cancellation as the exception.

Ex1 : N 0 5 (c r) = Invalid data

◆ RS-485 SERIAL INTERFACE

WAY OF COMMUNICATION Half duplex, Asynchronous

FORMAT

ASCII code

Start bit 1 bit
 Data bit 8 bit (including parity bit) → parity bit 1 bit

BAUD RATE

300 / 600 / 1200 / 2400 / 4800 / 9600 bps (Selection)

PARITY

NON/ODD/EVEN (Selection)

SERIAL COMMUNICATION (2)

◆ EXPLANATION FOR COMMUNICATION COMMAND

1. RDD (XX) : Reading Count value / Preset value

- This requires sub command with two(2) figures (XX). In accordance with required data, sub command is decided.
- The responses are shown as [sub command] [data] [check sum] [cr] in order.
- The decimal point positioning is also shown the same as the display of counter in this response.
- The zero [0] in needless is read as a space.

Example for read : >01RDDPCB(or) = Read preset count value in unit No. 01.

Example for answer: APC -123.45 4D(or) = preset count value -123.45.

Communication sub command. (XX) Contents of command

PC	Preset count value	※ Communication sub command is different according to each models
BC	Batch count value	
TC	Total count value	
TM	Tachometer value	
P1	1 level preset value	
P2	2 level preset value	
P3	3 level preset value	
P4	4 level preset value	
PW	Prewarn value	
BP	Batch preset value	
SO	Items selected for SEND DATA in the PROGRAM MODE	

2. RD I (XX) : Read Count value/Tachometer value(the value of integral)

- This command works the same as RDD command. Only 3 kind of sub command as shown below are available.
- RDI is the command to read the value of integral part in count value or tachometer value.
- RDU is the command to read the value under the decimal point in count value or tachometer value.

Example for send : >10RDUIF0(or) = Read the preset count value in unit No. 10.

Example for response: APC. 12000000 64(or) = Preset count value (under the decimal point): 12.

Communication sub command. (XX) Contents of command

PC	Preset count value	※ Communication sub command is different according to each models
TC	Total count value	
TM	Tachometer value	

4. WRD (XX) : Set the preset value.

- This requires sub command with 2(two)figures (XX). In accordance with the contents of command, sub command is decided as shown below.
- The response is [A] (or) only.
- The decimal point position can not be set by WRD command. The decimal point is shown at the the position set by the program mode.

Example for send : >10WRD1P001234P9(or) = set 1 level preset value in the unit No. (ID No.)10

Communication sub command. (XX) Contents of command

P1	1 level preset value	※ Communication sub command is different according to each models
P2	2 level preset value	
P3	3 level preset value	
P4 PW BP		4 level preset value Prewarn value Batch preset value

5. RES (XX) : Reset

- This requires sub command with two(2) figures (XX). In accordance with the contents of command the sub command is decided as shown below.
- The responses are [A] (or) only.
- This command works same as front reset key operation or reset input.

Example for send: >00RESPCD(or) = Reset preset count value in unit No. (ID No.)00.

Communication sub command. (XX) Contents of command

PC	Preset count value	※ Communication sub command is different according to each models
BC	Batch preset value	
TC	Total count value	
ER	Canceling for error condition(over, under flow)	

6. RDO : Read output condition (respective condition in out 1 ~ out 4)

- The responses are shown [A] [OUT 1 (H/L)] - [OUT 4 (H/L)] [Check sum] (or) in order.

Example for send: >00RDO45(or) = Read output condition in unit No. 00.

Example for response: A1L2H3L4L5L6(or) = The output condition are as shown below in this example for response.

※ OUT 1~OUT 4 is different according to each models.

1 L	OUT 1 → Low
2 H	OUT 2 → High
3 L	OUT 3 → Low
4 L	OUT 4 → Low

7. STP : Count prohibition

- When STP command is sent to the counter, counter does not accept any count input pulse until the counter received RSM command.
- Count prohibition will be cancelled when the power supply of counter is cut off. When the power supply of counter turns on, counter begins to accept the input pulse.
- The response is [A] (or) only.

Example for send: >00STP57(or) = Count prohibition in unit No. 00.

>00RSM52(or) = Cancelation for count prohibition in unit No. 00.

8. RSM : Cancelation for count prohibition

- This requires sub command with two(2) figures. In accordance with the contents of command, sub command is decided as shown below.
- The data which can be authorized by this command is only one (1) item per once. In case this command is carried out newly, new data will be authorized instead of previous data.
- The response is [A] (or) only.
- When the power supply of counter is cut off, the authorized data will be deleted.

Example for send: >00LTDP07(or) = Store preset count value of unit No. 00 in its memory

Communication sub command (XX) Contents of command

PC	Preset count value	※ Communication sub command is different according to each models
BC	Batch count value	
TC	Total count value	
TM	Tachometer value	
P1	1 level preset value	
P2	2 level preset value	
P3	3 level preset value	
P4	4 level preset value	
PW	Prewarn value	
BP	Batch preset value	

9. RLD : Read the data stored by LTD command

- The response is shown as [sub command][data][check sum][or] in order.
- In this response, the decimal point position showed on the display is also sent.
- The zero [0] in needless are sent as a space.
- If the RLD-command is carried out before the data is stored by LTD command, the response will be error code.

Example for send: >00RLD42(or) = Read the stored data of unit No(ID No.) 00 in its memory.

Example for response: APC -123.45 4D(or) = Preset count value -123.45.

◆ EASY COMMUNICATION (COMMUNICATION REQUEST)

● Easy communication (Communication request)

For the way of easy communication, there is the function named communication request in this counter. By shooting the terminal "of communication request" and "END", it reads the data set for SEND DATA in the PROGRAM MODE

Example for set : When the data of the preset count value and 1 level preset value are set for SEND DATA in the PROGRAM MODE.

Example for response: APC 123.00 P1 200.00 5B(or)

The above example shows : Preset count value is 123.00
1 level preset value is 200.00

This manual was last revised July. 5, 2011. 4G21002C
*Subject to change without prior notice.
All Rights Reserved, Copyright ©2011, LINE SEIKI CO., LTD.



LINE SEIKI CO., LTD.

NO.87-7, Chuo-Chuo 2-Chome, Meguro-Ku, Tokyo, 152 Japan
TEL. +81-3-8716-5151 FAX. +81-3-8710-4552