

---

## AIRPLANE FLIGHT MANUAL

### DA 40 NG

---

**Airworthiness Category** : Normal<sup>1</sup>  
**Requirement** : JAR-23  
**Serial Number** : \_\_\_\_\_  
**Registration** : \_\_\_\_\_  
**Doc. No.** : 6.01.15-E  
**Date of Issue** : 01-Apr-2010

Signature : \_\_\_\_\_ 

EASA Project Manager : \_\_\_\_\_ 

Stamp : \_\_\_\_\_ 

Date of Approval : \_\_\_\_\_ 

(EASA App. Date)

- This Airplane Flight Manual is approved with EASA Approval No. 10025781.
- This Airplane Flight Manual is FAA approved for U.S. registered aircraft in accordance with the provisions of 14 CFR Section 21.29, and is required by FAA Type Certificate Data
- Sheet no.: A 47CE.

Intentionally left blank.

**FOREWORD**

We congratulate you on the acquisition of your new DIAMOND DA 40 NG.

Skillful operation of an airplane increases both safety and the enjoyment of flying. Please take the time therefore, to familiarize yourself with your new DIAMOND DA 40 NG.

This airplane may only be operated in accordance with the procedures and operating limitations of this Airplane Flight Manual.

Before this airplane is operated for the first time, the pilot must familiarize himself with the complete contents of this Airplane Flight Manual.

In the event that you have obtained your DIAMOND DA 40 NG second-hand, please let us know your address, so that we can supply you with the publications necessary for the safe operation of your airplane.

This document is protected by copyright. All associated rights, in particular those of translation, reprinting, radio transmission, reproduction by photo-mechanical or similar means and storing in data processing facilities, in whole or part, are reserved.

Copyright © by: DIAMOND AIRCRAFT INDUSTRIES GMBH  
N.A. Otto-Strasse 5  
A-2700 Wiener Neustadt, Austria  
Phone. : +43-2622-26700  
Fax : +43-2622-26780  
E-Mail : [office@diamond-air.at](mailto:office@diamond-air.at)

## **0.1 APPROVAL**

The content of approved chapters is approved by EASA. All other content is approved by DAI under the authority of EASA DOA No. EASA.21J.052 in accordance with Part 21.

## **0.2 RECORD OF REVISIONS**

All revisions of this manual, with the exception of

- Temporary Revisions,
- updates of the modification level (Section 1.1),
- updated mass and balance information (Section 6.3),
- updates of the Equipment Inventory (Section 6.5), and
- updates of the List of Supplements (Section 9.2)

must be recorded in the following table.

The new or amended text is indicated by a vertical black line at the left hand side of the revised page, with the revision number and date appearing at the bottom of the page.

If pages are revised which contain information valid for your particular serial number (modification level of the airplane, weighing data, Equipment Inventory, List of Supplements), then this information must be transferred to the new pages in hand-writing.

Temporary Revisions are used to provide information on systems or equipment until the next 'permanent' Revision of the Airplane Flight Manual. When a 'permanent' Revision covers a Mandatory or Optional Design Change Advisory (MÄM or OÄM), then the corresponding Temporary Revision is superseded. For example: if Revision 5 covers OÄM 40-039, then the Temporary Revision TR OÄM-40-039 is superseded by the 'permanent' Revision 5.

Cover pages of Temporary Revisions, if applicable, are inserted behind the cover page of this manual, all other pages are inserted in front of the affected pages of this manual.

Page 0 - 2	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
------------	--------	-------------	------------------

Rev. No.	Reason	Chapter	Page(s)	Date of Revision	Approval Note	Date of Approval	Date Inserted	Signature
1	<p>MÄM 40-415, 40-432, 40-440, 40-448, 40-460, 40-466, 40-447, 40-514,</p> <p>OÄM 40-311, 40-313, 40-314 &amp; 40-316, 40-321, 40-326, 40-327, 40-329, 40-330, 40-331, 40-333,</p> <p>Corrections</p>	all	all, except cover page	15-Mar-2011	Revision 1 of the AFM Doc. No. 6.01.15-E is approved with EASA Approval No. 10034114.	08-Mar-2011		
2	<p>MÄM 40-434 &amp; OÄM 40-310, MÄM 40-451, MÄM40-321/a  FAA- Approval</p>	0, 1, 2, 5, 6	0-0, 0-0a, 0-3, 0-5, 0-6, 0-9, 0-10, 1-2, 1-3, 2-24, 5-1, 5-31, 5-32, 6-16 through 6-26	15-Jun-2011	Revision 2 of the AFM Doc. No. 6.01.15-E is approved by EASA under project No. 0010005331.			

Intentionally left blank.

### 0.3 LIST OF EFFECTIVE PAGES

Ch.	Page	Date
0	0-0	15-Jun-2011
	0-0a	15-Jun-2011
	0-1	15-Mar-2011
	0-2	15-Mar-2011
	0-3	15-Jun-2011
	0-4	15-Mar-2011
	0-5	15-Jun-2011
	0-6	15-Jun-2011
	0-7	15-Mar-2011
	0-8	15-Mar-2011
	0-9	15-Jun-2011
	0-10	15-Jun-2011
	0-11	15-Mar-2011
	0-12	15-Mar-2011
	0-13	15-Mar-2011
	0-14	15-Mar-2011

Ch.	Page	Date
1	1-1	15-Mar-2011
	1-2	15-Jun-2011
	1-3	15-Jun-2011
	1-4	15-Mar-2011
	1-5	15-Mar-2011
	1-6	15-Mar-2011
	1-7	15-Mar-2011
	1-8	15-Mar-2011
	1-9	15-Mar-2011
	1-10	15-Mar-2011
	1-11	15-Mar-2011
	1-12	15-Mar-2011
	1-13	15-Mar-2011
	1-14	15-Mar-2011
	1-15	15-Mar-2011
	1-16	15-Mar-2011
	1-17	15-Mar-2011
	1-18	15-Mar-2011
	1-19	15-Mar-2011
	1-20	15-Mar-2011

Ch.	Page	Date
2	appr. 2-1	15-Mar-2011
	appr. 2-2	15-Mar-2011
	appr. 2-3	15-Mar-2011
	appr. 2-4	15-Mar-2011
	appr. 2-5	15-Mar-2011
	appr. 2-6	15-Mar-2011
	appr. 2-7	15-Mar-2011
	appr. 2-8	15-Mar-2011
	appr. 2-9	15-Mar-2011
	appr. 2-10	15-Mar-2011
	appr. 2-11	15-Mar-2011
	appr. 2-12	15-Mar-2011
	appr. 2-13	15-Mar-2011
	appr. 2-14	15-Mar-2011
	appr. 2-15	15-Mar-2011
	appr. 2-16	15-Mar-2011
	appr. 2-17	15-Mar-2011
	appr. 2-18	15-Mar-2011
	appr. 2-19	15-Mar-2011
	appr. 2-20	15-Mar-2011
	appr. 2-21	15-Mar-2011
	appr. 2-22	15-Mar-2011
	appr. 2-23	15-Mar-2011
	appr. 2-24	15-Jun-2011
	appr. 2-25	15-Mar-2011
	appr. 2-26	15-Mar-2011
	appr. 2-27	15-Mar-2011

Ch.	Page	Date
2	appr. 2-28	15-Mar-2011
	appr. 2-29	15-Mar-2011
	appr. 2-30	15-Mar-2011
	appr. 2-31	15-Mar-2011
	appr. 2-32	15-Mar-2011



Ch.	Page	Date
3	3-1	15-Mar-2011
	3-2	15-Mar-2011
	3-3	15-Mar-2011
	3-4	15-Mar-2011
	3-5	15-Mar-2011
	3-6	15-Mar-2011
	3-7	15-Mar-2011
	3-8	15-Mar-2011
	3-9	15-Mar-2011
	3-10	15-Mar-2011
	3-11	15-Mar-2011
	3-12	15-Mar-2011
	3-13	15-Mar-2011
	3-14	15-Mar-2011
	3-15	15-Mar-2011
	3-16	15-Mar-2011
	3-17	15-Mar-2011
	3-18	15-Mar-2011
	3-19	15-Mar-2011
	3-20	15-Mar-2011
	3-21	15-Mar-2011
	3-22	15-Mar-2011
	3-23	15-Mar-2011
	3-24	15-Mar-2011
	3-25	15-Mar-2011
	3-26	15-Mar-2011
	3-27	15-Mar-2011
	3-28	15-Mar-2011

Ch.	Page	Date
3	3-29	15-Mar-2011
	3-30	15-Mar-2011
	3-31	15-Mar-2011
	3-32	15-Mar-2011
	3-33	15-Mar-2011
	3-34	15-Mar-2011
	3-35	15-Mar-2011
	3-36	15-Mar-2011
	3-37	15-Mar-2011
	3-38	15-Mar-2011
	3-39	15-Mar-2011
	3-40	15-Mar-2011
	3-41	15-Mar-2011
	3-42	15-Mar-2011
	3-43	15-Mar-2011
	3-44	15-Mar-2011
	3-45	15-Mar-2011
	3-46	15-Mar-2011
	3-47	15-Mar-2011
	3-48	15-Mar-2011

Ch.	Page	Date
4A	4A-1	15-Mar-2011
	4A-2	15-Mar-2011
	4A-3	15-Mar-2011
	4A-4	15-Mar-2011
	4A-5	15-Mar-2011
	4A-6	15-Mar-2011
	4A-7	15-Mar-2011
	4A-8	15-Mar-2011
	4A-9	15-Mar-2011
	4A-10	15-Mar-2011
	4A-11	15-Mar-2011
	4A-12	15-Mar-2011
	4A-13	15-Mar-2011
	4A-14	15-Mar-2011
	4A-15	15-Mar-2011
	4A-16	15-Mar-2011
	4A-17	15-Mar-2011
	4A-18	15-Mar-2011
	4A-19	15-Mar-2011
	4A-20	15-Mar-2011
	4A-21	15-Mar-2011
	4A-22	15-Mar-2011
	4A-23	15-Mar-2011
	4A-24	15-Mar-2011
	4A-25	15-Mar-2011
	4A-26	15-Mar-2011
	4A-27	15-Mar-2011

Ch.	Page	Date
4A	4A-28	15-Mar-2011
	4A-29	15-Mar-2011
	4A-30	15-Mar-2011
	4A-31	15-Mar-2011
	4A-32	15-Mar-2011
	4A-33	15-Mar-2011
	4A-34	15-Mar-2011
	4A-35	15-Mar-2011
	4A-36	15-Mar-2011
	4A-37	15-Mar-2011
	4A-38	15-Mar-2011

Ch.	Page	Date
4B	4B-1	15-Mar-2011
	4B-2	15-Mar-2011
	4B-3	15-Mar-2011
	4B-4	15-Mar-2011
	4B-5	15-Mar-2011
	4B-6	15-Mar-2011
	4B-7	15-Mar-2011
	4B-8	15-Mar-2011
	4B-9	15-Mar-2011
	4B-10	15-Mar-2011
	4B-11	15-Mar-2011
	4B-12	15-Mar-2011
	4B-13	15-Mar-2011
	4B-14	15-Mar-2011
	4B-15	15-Mar-2011
	4B-16	15-Mar-2011
	4B-17	15-Mar-2011
	4B-18	15-Mar-2011
	4B-19	15-Mar-2011
	4B-20	15-Mar-2011
	4B-21	15-Mar-2011
	4B-22	15-Mar-2011

Ch.	Page	Date
5	5-1	15-Jun-2011
	5-2	15-Mar-2011
	5-3	15-Mar-2011
	5-4	15-Mar-2011
	5-5	15-Mar-2011
	5-6	15-Mar-2011
	5-7	15-Mar-2011
	5-8	15-Mar-2011
	5-9	15-Mar-2011
	5-10	15-Mar-2011
	5-11	15-Mar-2011
	5-12	15-Mar-2011
	5-13	15-Mar-2011
	5-14	15-Mar-2011
	5-15	15-Mar-2011
	5-16	15-Mar-2011
	5-17	15-Mar-2011
	5-18	15-Mar-2011
	5-19	15-Mar-2011
	5-20	15-Mar-2011
	5-21	15-Mar-2011
	5-22	15-Mar-2011
	5-23	15-Mar-2011
	5-24	15-Mar-2011
	5-25	15-Mar-2011
	5-26	15-Mar-2011
	5-27	15-Mar-2011

Ch.	Page	Date
5	5-28	15-Mar-2011
	5-29	15-Mar-2011
	5-30	15-Jun-2011
	5-31	15-Jun-2011
	5-32	15-Jun-2011

Ch.	Page	Date
6	6-1	15-Mar-2011
	6-2	15-Mar-2011
	6-3	15-Mar-2011
	6-4	15-Mar-2011
	6-5	15-Mar-2011
	6-6	15-Mar-2011
	6-7	15-Mar-2011
	6-8	15-Mar-2011
	6-9	15-Mar-2011
	6-10	15-Mar-2011
	6-11	15-Mar-2011
	6-12	15-Mar-2011
	6-13	15-Mar-2011
	6-14	15-Mar-2011
	6-15	15-Mar-2011
	6-16	15-Jun-2011
	6-17	15-Jun-2011
	6-18	15-Jun-2011
	6-19	15-Jun-2011
	6-20	15-Jun-2011
	6-21	15-Jun-2011
	6-22	15-Jun-2011
	6-23	15-Jun-2011
	6-24	15-Jun-2011
	6-25	15-Jun-2011
	6-26	15-Jun-2011

Ch.	Page	Date
7	7-1	15-Mar-2011
	7-2	15-Mar-2011
	7-3	15-Mar-2011
	7-4	15-Mar-2011
	7-5	15-Mar-2011
	7-6	15-Mar-2011
	7-7	15-Mar-2011
	7-8	15-Mar-2011
	7-9	15-Mar-2011
	7-10	15-Mar-2011
	7-11	15-Mar-2011
	7-12	15-Mar-2011
	7-13	15-Mar-2011
	7-14	15-Mar-2011
	7-15	15-Mar-2011
	7-16	15-Mar-2011
	7-17	15-Mar-2011
	7-18	15-Mar-2011
	7-19	15-Mar-2011
	7-20	15-Mar-2011
	7-21	15-Mar-2011
	7-22	15-Mar-2011
	7-23	15-Mar-2011
	7-24	15-Mar-2011
	7-25	15-Mar-2011
	7-26	15-Mar-2011
	7-27	15-Mar-2011

Ch.	Page	Date
7	7-28	15-Mar-2011
	7-29	15-Mar-2011
	7-30	15-Mar-2011
	7-31	15-Mar-2011
	7-32	15-Mar-2011
	7-33	15-Mar-2011
	7-34	15-Mar-2011
	7-35	15-Mar-2011
	7-36	15-Mar-2011
	7-37	15-Mar-2011
	7-38	15-Mar-2011
	7-39	15-Mar-2011
	7-40	15-Mar-2011
	7-41	15-Mar-2011
	7-42	15-Mar-2011
	7-43	15-Mar-2011
	7-44	15-Mar-2011
	7-45	15-Mar-2011
	7-46	15-Mar-2011
	7-47	15-Mar-2011
	7-48	15-Mar-2011

Ch.	Page	Date
8	8-1	15-Mar-2011
	8-2	15-Mar-2011
	8-3	15-Mar-2011
	8-4	15-Mar-2011
	8-5	15-Mar-2011
	8-6	15-Mar-2011
	8-7	15-Mar-2011
	8-8	15-Mar-2011
	8-9	15-Mar-2011
	8-10	15-Mar-2011
	8-11	15-Mar-2011
	8-12	15-Mar-2011

Ch.	Page	Date
9	9-1	15-Mar-2011
	9-2	15-Mar-2011
	9-3	15-Mar-2011
	9-4	15-Mar-2011

## **0.4 TABLE OF CONTENTS**

	Chapter
<b>GENERAL</b>	
(a non-approved chapter) .....	1
<b>OPERATING LIMITATIONS</b>	
(an approved chapter) .....	2
<b>EMERGENCY PROCEDURES</b>	
(a non-approved chapter) .....	3
<b>NORMAL OPERATING PROCEDURES</b>	
(a non-approved chapter) .....	4A
<b>ABNORMAL OPERATING PROCEDURES</b>	
(a non-approved chapter) .....	4B
<b>PERFORMANCE</b>	
(a non-approved chapter) .....	5
<b>MASS AND BALANCE / EQUIPMENT LIST</b>	
(a non-approved chapter) .....	6
<b>DESCRIPTION OF THE AIRPLANE AND ITS SYSTEMS</b>	
(a non-approved chapter) .....	7
<b>AIRPLANE HANDLING, CARE AND MAINTENANCE</b>	
(a non-approved chapter) .....	8
<b>SUPPLEMENTS</b> .....	9

Intentionally left blank.



# CHAPTER 1

## GENERAL

	Page
1.1 INTRODUCTION .....	1-2
1.2 CERTIFICATION BASIS .....	1-4
1.3 WARNINGS, CAUTIONS AND NOTES .....	1-4
1.4 DIMENSIONS .....	1-5
1.5 DEFINITIONS AND ABBREVIATIONS .....	1-7
1.6 UNITS OF MEASUREMENT .....	1-15
1.6.1 CONVERSION FACTORS .....	1-15
1.6.2 CONVERSION CHART LITER / US GALLON .....	1-17
1.7 THREE-VIEW DRAWING .....	1-18
1.8 SOURCE DOCUMENTATION .....	1-19
1.8.1 ENGINE AND ENGINE INSTRUMENTS .....	1-19
1.8.2 PROPELLER .....	1-20

## 1.1 INTRODUCTION

This Airplane Flight Manual has been prepared in order to provide pilots and instructors with all the information required for the safe and efficient operation of the airplane.

The Airplane Flight Manual includes all the data which must be made available to the pilot according to the JAR-23 requirement. Beyond this, it contains further data and operating instructions which, in the manufacturer's opinion, could be of value to the pilot.

This Airplane Flight Manual is valid for all serial numbers. Equipment and modification level (design details) of the airplane may vary from serial number to serial number. Therefore, some of the information contained in this manual is applicable depending on the respective equipment and modification level. The exact equipment of your serial number is recorded in the Equipment Inventory in Section 6.5. The modification level is recorded in the following table (as far as necessary for this manual).

Modification	Source	Installed	
Exhaust Pipe with Muffler	MÄM 40-434 or OÄM 40-310	<input type="checkbox"/> yes	<input type="checkbox"/> no
Garmin G1000 Avionics System	MÄM 40-447	<input type="checkbox"/> yes	<input type="checkbox"/> no
Long Range Tanks	OÄM 40-130	<input type="checkbox"/> yes	<input type="checkbox"/> no
Baggage Tray (Extended Baggage Compartment)	OÄM 40-164	<input type="checkbox"/> yes	<input type="checkbox"/> no
Baggage Tube	Basic Design	<input type="checkbox"/> yes	<input type="checkbox"/> no
Winter Baffle Fresh Air Inlet	OÄM 40-183	<input type="checkbox"/> yes	<input type="checkbox"/> no
Nose Landing Gear Tie-down	OÄM 40-200	<input type="checkbox"/> yes	<input type="checkbox"/> no
Conventional Cockpit DA 40 NG Club	OÄM 40-321	<input type="checkbox"/> yes	<input type="checkbox"/> no
Emergency Axe	OÄM 40-326	<input type="checkbox"/> yes	<input type="checkbox"/> no

Page 1 - 2	Rev. 2	15-Jun-2011	Doc. # 6.01.15-E
------------	--------	-------------	------------------

Modification	Source	Installed	
Retrofit with Autopilot KAP 140	OÄM 40-329	<input type="checkbox"/> yes	<input type="checkbox"/> no
Retrofit without Autopilot GFC 700	OÄM 40-330	<input type="checkbox"/> yes	<input type="checkbox"/> no
Short Baggage Extension	OÄM 40-331	<input type="checkbox"/> yes	<input type="checkbox"/> no
DA 40 NG without Autopilot GFC 700	OÄM 40-333	<input type="checkbox"/> yes	<input type="checkbox"/> no

This Airplane Flight Manual must be kept on board the airplane at all times. Its designated place is the side bag of the forward left seat.

### CAUTION

The DA 40 NG is a single engine airplane. When the operating limitations and maintenance requirements are complied with, it has the high degree of reliability which is required by the certification basis. Nevertheless, an engine failure is not completely impossible. For this reason, flights during the night, on top, under instrument meteorological conditions (IMC), or above terrain which is unsuitable for a landing, constitute a risk. It is therefore highly recommended to select flight times and flight routes such that this risk is minimized.

## **1.2 CERTIFICATION BASIS**

This airplane has been type certified in accordance with the procedures established by EASA. The certification basis is JAR-23, published on 11-Mar-1994 and additional requirements as laid down in CRI A-01.

## **1.3 WARNINGS, CAUTIONS AND NOTES**

Special statements in the Airplane Flight Manual concerning the safety or operation of the airplane are highlighted by being prefixed by one of the following terms:

### **WARNING**

means that the non-observation of the corresponding procedure leads to an immediate or important degradation in flight safety.

### **CAUTION**

means that the non-observation of the corresponding procedure leads to a minor or to a more or less long term degradation in flight safety.

### **NOTE**

draws the attention to any special item not directly related to safety but which is important or unusual.

## 1.4 DIMENSIONS

### NOTE

All dimensions shown below are approximate.

#### Overall Dimensions

Span	:	11.63 m	38 ft 2 in
Length	:	8.06 m	26 ft 5 in
Height	:	1.97 m	6 ft 6 in

#### Wing

Airfoil	:	Wortmann FX 63-137/20 - W4	
Wing area	:	13.244 m <sup>2</sup>	142.6 sq.ft.
Mean aerodynamic chord (MAC)	:	1.171 m	3 ft 10 in
Aspect ratio	:	10.223	
Dihedral	:	5°	
Leading edge sweep	:	1°	

#### Aileron

Area (total, left + right)	:	0.654 m <sup>2</sup>	7.0 sq.ft.
----------------------------	---	----------------------	------------

#### Wing Flaps

Area (total, left + right)	:	1.56 m <sup>2</sup>	16.8 sq.ft.
----------------------------	---	---------------------	-------------

Horizontal Tail

Area	:	2.34 m <sup>2</sup>	25.2 sq.ft.
Elevator area	:	0.665 m <sup>2</sup>	7.2 sq.ft.
Angle of incidence	:	-3.0° relative to longitudinal axis of airplane	

Vertical Tail

Area	:	1.60 m <sup>2</sup>	17.2 sq.ft.
Rudder area	:	0.47 m <sup>2</sup>	5.1 sq.ft.

Landing Gear

Track	:	2.97 m	9 ft 9 in
Wheelbase	:	1.68 m	5 ft 6 in
Nose wheel	:	5.00-5; 6 PR, TT, 120 mph	
Main wheel	:	15x6.0-6; 6 PR, TT, 160 mph	

## 1.5 DEFINITIONS AND ABBREVIATIONS

### (a) Airspeeds

- CAS: Calibrated Airspeed. Indicated airspeed, corrected for installation and instrument errors. CAS equals TAS at standard atmospheric conditions (ISA) at MSL.
- IAS: Indicated Airspeed as shown on an airspeed indicator.
- KCAS: CAS in knots.
- KIAS: IAS in knots.
- TAS: True Airspeed. The speed of the airplane relative to the air. TAS is CAS corrected for errors due to altitude and temperature.
- $V_O$ : Operating Maneuvering Speed. Full or abrupt control surface movement is not permissible above this speed.
- $V_{FE}$ : Maximum Flaps Extended Speed. This speed must not be exceeded with the given flap setting.
- $V_{NE}$ : Never Exceed Speed in smooth air. This speed must not be exceeded in any operation.
- $V_{NO}$ : Maximum Structural Cruising Speed. This speed may be exceeded only in smooth air, and then only with caution.

- $v_s$  Stalling Speed, or the minimum continuous speed at which the airplane is still controllable in the given configuration.
- $v_{s0}$ : Stalling Speed, or the minimum continuous speed at which the airplane is still controllable in the landing configuration.
- $v_x$ : Best Angle-of-Climb Speed.
- $v_y$ : Best Rate-of-Climb Speed.

(b) Meteorological Terms

ISA: International Standard Atmosphere. Conditions at which air is identified as an ideal dry gas. The temperature at mean sea level is 15°C (59°F), air pressure at MSL is 1,013.25 hPa (29.92 inHg); the temperature gradient up to the altitude at which the temperature reaches -56.5°C (-69.7°F) is -0.0065°C/m (-0.00357°F/ft), and above this 0°C/m (0°F/ft).

MSL: Mean Sea Level.

OAT: Outside Air Temperature.

QNH: Theoretical atmospheric pressure at MSL, calculated from the elevation of the measuring point above MSL and the actual atmospheric pressure at the measuring point.

Density Altitude:

Altitude in ISA conditions at which the air density is equal to the current air density.

Indicated Pressure Altitude:

Altitude reading with altimeter set to 1,013.25 hPa (29.92 inHg).



**Pressure Altitude:**

Altitude above MSL, indicated by a barometric altimeter which is set to 1,013.25 hPa (29.92 inHg). The pressure altitude is the indicated pressure altitude corrected for installation and instrument errors.

In this Airplane Flight Manual altimeter instrument errors are regarded as zero.

**Wind:** The wind speeds which are shown as variables in the diagrams in this manual should be regarded as headwind or tailwind components of the measured wind.

**(c) Flight Performance and Flight Planning**

**AGL:** Above ground level.

**Demonstrated Crosswind Component:**

The speed of the crosswind component at which adequate maneuverability for take-off and landing has been demonstrated during type certification.

**MET:** Weather, weather advice.

**NAV:** Navigation, route planning.

(d) Mass and Balance

**CG:** Center of Gravity, also called 'center of mass'. Imaginary point in which the airplane mass is assumed to be concentrated for mass and balance calculations. Its distance from the Datum Plane is equal to the Center of Gravity Moment Arm.

**Center of Gravity Moment Arm:**

The Moment Arm which is obtained if one divides the sum of the individual moments of the airplane by its total mass.

**Center of Gravity Limits:**

The Center of Gravity range within which the airplane, at a given mass, must be operated.

**DP:** Datum Plane; an imaginary vertical plane from which all horizontal distances for center of gravity calculations are measured.

**Empty Mass:**

The mass of the airplane including unusable fuel, all operating consumables and the maximum quantity of oil.

**Maximum Take-off Mass:**

The maximum permissible mass for take-off.

**Maximum Landing Mass:**

The highest mass for landing conditions at the maximum descent velocity. This condition was used in the strength calculations to determine the landing gear loads during a particularly hard landing.

**Maximum Zero Fuel Mass:**

The highest permissible mass with empty fuel tanks.

**Moment Arm:**

The horizontal distance from the Datum Plane to the Center of Gravity of a component.

**Moment:** The mass of a component multiplied by its moment arm.

**Usable Fuel:**

The quantity of fuel available for flight planning.

**Unusable Fuel:**

The quantity of fuel remaining in the tank which cannot be used for flight.

**Useful Load:**

The difference between take-off mass and empty mass.

**(e) Engine**

**CT:** Coolant Temperature.

**EECU:** Electronic Engine Control Unit.

**GT:** Gearbox Temperature.

**LOAD:** Engine output power in percent of take-off power.

■ **MED:** Main Engine Display.

**OP:** Oil Pressure (oil pressure in the lubrication system of the engine).

**OT:** Oil Temperature (oil temperature in the lubrication system of the engine).

**RPM:** Revolutions per minute (rotational speed of the propeller).

■ **SED:** Secondary Engine Display.

■ **FT:** Fuel Temperature.

(f) Designation of the Circuit Breakers on the Instrument Panel

ADC: Air Data Computer.

ADF: Automatic Direction Finder.

AHRS: Attitude and Heading Reference System.

■ ANNUN: Annunciator Panel.

AV/CDU FAN:

Avionic-, CDU-Cooling Fans.

AV. BUS: Avionic Bus.

AUDIO: Audio Panel / Marker Beacon Receiver.

AUTOPILOT:

Autopilot System.

■ COM: COM Radio.

COM1: COM Radio No. 1.

COM2: COM Radio No. 2.

■ DG: Directional Gyro.

DME: Distance Measuring Equipment.

EECU A: ECU A.

EECU B: ECU B.

ENG INST: Engine Instruments.

ESS TIE: Bus Interconnection.

■ FAN/OAT: Fan / Outside Air Temperature.

FLAPS: Flap System.

FLOOD: Flood Light.

FUEL PUMP A:

ECU A Fuel Pump.

FUEL PUMP B:

ECU B Fuel Pump.

■ GPS: Global Positioning System.

GPS/NAV1: Global Positioning System and NAV Receiver No. 1.

GPS/NAV2: Global Positioning System and NAV Receiver No. 2.

HORIZON: Artificial Horizon (Attitude Gyro).

- INST.1: Engine Instrument.
- INST. LT: Instrument Lights.
- LANDING: Landing Light.
- MAIN TIE: Bus Interconnection.
- MASTER CONTROL:
  - Master Control (Avionics Relay).
- MFD: Multi Function Display.
- NAV: NAV Receiver.
- PFD: Primary Flight Display.
- PITOT: Pitot Heating System.
- POSITION: Position Lights.
- PWR: Power.
- START: Starter.
- STROBE: Strobe Lights (= Anti Collision Lights).
- T & B: Turn and Bank Indicator.
- TAS: Traffic Advisory System.
- TAXI/MAP: Taxi Light / Map Lights.
- WX500: Stormscope.
- XFR PUMP: Fuel Transfer Pump.
- XPDR Transponder.

(g) Equipment

ELT: Emergency Locator Transmitter.

(h) Design Change Advisories

MÄM: Mandatory Design Change Advisory.

OÄM: Optional Design Change Advisory.

(i) Miscellaneous

ACG: Austro Control GmbH (formerly BAZ, Federal Office of Civil Aviation).

ATC: Air Traffic Control.

CFRP: Carbon Fiber Reinforced Plastic.

EASA: European Aviation Safety Agency.

GFRP: Glass Fiber Reinforced Plastic.

GIA: Garmin Integrated Avionics.

JAR: Joint Aviation Requirements.

## 1.6 UNITS OF MEASUREMENT

### 1.6.1 CONVERSION FACTORS

Dimension	SI-Units	US Units	Conversion
Length	[mm] millimeter	[in] inch	$[mm] / 25.4 = [in]$
	[m] meter	[ft] feet	$[m] / 0.3048 = [ft]$
	[km] kilometer	[NM] nautical mile	$[km] / 1.852 = [NM]$
Volume	[l] liter	[US gal] US gallon	$[l] / 3.7854 = [US\ gal]$
		[qts] US quarts	$[l] / 0.9464 = [qts]$
Speed	[km/h] kilometer per hour	[kt] knot	$[km/h] / 1.852 = [kt]$
	[m/s] meter per second	[mph] mile per hour	$[km/h] / 1.609 = [mph]$
		[fpm] feet per minute	$[m/s] \times 196.85 = [fpm]$
Speed of rotation	[RPM] revolutions per minute		--
Mass	[kg] kilogram	[lb] pound	$[kg] \times 2.2046 = [lb]$
Force, weight	[N] newton	[lbf] pound force	$[N] \times 0.2248 = [lbf]$
Pressure	[hPa] hecto-pascal	[inHg] inches of mercury	$[hPa] = [mbar]$
	[mbar] millibar	[psi] pound per square inch	$[hPa] / 33.86 = [inHg]$
	[bar] bar		$[bar] \times 14.504 = [psi]$
Temperature	[°C] degree Celsius	[°F] degree Fahrenheit	$[°C] \times 1.8 + 32 = [°F]$
			$([°F] - 32) / 1.8 = [°C]$

Dimension	SI-Units	US Units	Conversion
Intensity of electric current	[A] ampère		--
Electric charge (battery capacity)	[Ah] ampère-hour		--
Electric potential	[V] volt		--
Time	[sec] second		--




**1.6.2 CONVERSION CHART LITER / US GALLON**

Liter	US Gallon
5	1.3
10	2.6
15	4.0
20	5.3
25	6.6
30	7.9
35	9.2
40	10.6
45	11.9
50	13.2
60	15.9
70	18.5
80	21.1
90	23.8
100	26.4
110	29.1
120	31.7
130	34.3
140	37.0
150	39.6
160	42.3
170	44.9
180	47.6

US Gallon	Liter
1	3.8
2	7.6
4	15.1
6	22.7
8	30.3
10	37.9
12	45.4
14	53.0
16	60.6
18	68.1
20	75.7
22	83.3
24	90.9
26	98.4
28	106.0
30	113.6
32	121.1
34	128.7
36	136.3
38	143.8
40	151.4
45	170.3
50	189.3

**1.7 THREE-VIEW DRAWING**



## **1.8 SOURCE DOCUMENTATION**

This section lists documents, manuals and other literature that were used as sources for the Airplane Flight Manual, and indicates the respective publisher. However, only the information given in the Airplane Flight Manual is valid.

### **1.8.1 ENGINE AND ENGINE INSTRUMENTS**

Address: Austro Engine GmbH  
Rudolf Diesel-Str. 11  
A-2700 Wiener Neustadt  
AUSTRIA

Phone: +43-2622-23 000  
Fax: +43-2622-23 000 - 2711  
Internet: [www.austroengine.at](http://www.austroengine.at)

Documents: Operation Manual AE300,  
E4.01.01

Maintenance Manual AE300,  
E4.08.04

Installation Manual AE300,  
E4.02.01

**1.8.2 PROPELLER**

Address: mt-propeller  
Airport Straubing Wallmühle  
D-94348 ATTING  
GERMANY

Phone: +49-9429-9409-0  
E-mail: sales@mt-propeller.com  
Internet: www.mt-propeller.de

Documents: E-124, Operation and Installation Manual  
Hydraulically controlled variable pitch propeller  
MTV -5, -6, -9, -11, -12, -14, -15, -16, -21, -22, -25

## CHAPTER 2

# OPERATING LIMITATIONS

	Page
2.1 INTRODUCTION .....	2-2
2.2 AIRSPEED .....	2-3
2.3 AIRSPEED INDICATOR MARKINGS .....	2-4
2.4 POWER-PLANT LIMITATIONS .....	2-5
2.5 ENGINE INSTRUMENT MARKINGS .....	2-9
2.6 WARNING, CAUTION AND STATUS LIGHTS .....	2-10
2.7 MASS (WEIGHT) .....	2-14
2.8 CENTER OF GRAVITY .....	2-16
2.9 APPROVED MANEUVERS .....	2-17
2.10 MANEUVERING LOAD FACTORS .....	2-18
2.11 OPERATING ALTITUDE .....	2-19
2.12 FLIGHT CREW .....	2-19
2.13 KINDS OF OPERATION .....	2-20
2.14 FUEL .....	2-24
2.15 LIMITATION PLACARDS .....	2-25
2.16 OTHER LIMITATIONS .....	2-31
2.16.1 TEMPERATURE .....	2-31
2.16.2 BATTERY CHARGE .....	2-31
2.16.3 EMERGENCY SWITCH .....	2-31
2.16.4 DOOR LOCKING DEVICE .....	2-31
2.16.5 ELECTRONIC EQUIPMENT .....	2-32
2.16.6 SMOKING .....	2-32
2.16.7 USE OF THE SUN VISORS .....	2-32

## **2.1 INTRODUCTION**

Chapter 2 of this Airplane Flight Manual includes operating limitations, instrument markings, and placards necessary for the safe operation of the airplane, its power-plant, standard systems and standard equipment.

The limitations included in this Chapter are approved.

### **WARNING**

Operation of the airplane outside of the approved operating limitations is not permissible.

## 2.2 AIRSPEED

	Airspeed		KIAS	Remarks
$V_O$	Operating maneuvering speed	up to 1080 kg (2381 lb)	101 KIAS	Do not make full or abrupt control surface movement above this speed.
		above 1080 kg (2381 lb) to 1180 kg (2601 lb)	108 KIAS	
		above 1180 kg (2601 lb)	113 KIAS	
$V_{FE}$	Max. flaps extended speed	LDG	98 KIAS	Do not exceed these speeds with the given flap setting.
		T/O	110 KIAS	
$V_{NO}$ = $V_C$	Max. structural cruising speed		130 KIAS	Do not exceed this speed except in smooth air, and then only with caution.
$V_{NE}$	Never exceed speed in smooth air		172 KIAS	Do not exceed this speed in any operation.

### 2.3 AIRSPEED INDICATOR MARKINGS

Marking	IAS	Significance
White arc	58 KIAS - 98 KIAS	Operating range with flaps fully extended
Green arc	62 KIAS - 130 KIAS	Normal operating range.
Yellow arc	130 KIAS - 172 KIAS	'Caution' range - "Only in smooth air".
Red line	172 KIAS	Maximum speed for all operations - $V_{NE}$ .



## 2.4 POWER-PLANT LIMITATIONS

a) Engine manufacturer : Austro Engine

b) Engine designation : E4-A

c) RPM limitations (shown as propeller RPM)

Maximum take-off (RPM) : 2300 RPM max. 5 min

Max. continuous power (RPM) : 2100 RPM

Max. overspeed : 2500 RPM max. 20 sec

d) Engine power

Max. take-off power : 100% (123.5 kW) max. 5 min

Max. continuous power : 92% (114 kW)

e) Oil pressure

Minimum at idle : 0.9 bar

Minimum at max.

continuous conditions : 2.5 bar

Maximum : 6.5 bar

Normal range : 2.5 bar - 6.0 bar

f) Oil quantity

Minimum : 5.0 l

Maximum : 7.0 l

Maximum oil consumption : 0.1 liter/hour

g) Oil temperature

Minimum	:	- 30 °C
Maximum	:	140 °C
Normal range	:	50 °C - 135 °C

h) Gearbox temperature

Minimum	:	- 30 °C
Minimum (full load)	:	35 °C
Maximum	:	120 °C

**NOTE**

A cautionary (yellow) gearbox temperature range is not imposed by the engine manufacturer. However, there is a delay between power changes and gearbox temperature. Therefore, a cautionary range has been added to the gearbox temperature instrument solely to make the pilot attentive to the gearbox temperature approaching the maximum allowable limit. There is no specific time limit associated with operating in the cautionary gearbox temperature range.

i) Coolant temperature

Minimum (at start-up)	:	- 30 °C
Minimum (full load)	:	60 °C
Maximum	:	105 °C

## j) Fuel temperature

Minimum : - 25 °C  
Maximum : 60 °C

## k) Fuel pressure (absolute pressure)

Minimum : 4 bar

**NOTE**

The fuel pressure is not indicated; a fuel pressure warning will illuminate on the PFD (if G1000 is installed) or SED (if installed) if the pressure is below the limit.

Maximum : 7 bar

**NOTE**

The fuel pressure is not indicated; the fuel pressure caution ECU A/B FAIL on the PFD (if G1000 is installed) or ECU A/B on the White Wire annunciator panel (if installed) will illuminate if the pressure is above the limit.

## l) Voltage

Minimum : 24.1 V  
Maximum : 32.0 V

## m) Amperage

Maximum : 70 A

- n) Propeller manufacturer : mt-Propeller
- o) Propeller designation : MTV-6-R/190-69
- p) Propeller diameter : 190 cm (6 ft 3 in)
- q) Prop. pitch angle (@ 0.75 R) : Low Pitch  $14.5^{\circ} \pm 0.2^{\circ}$   
High Pitch  $35^{\circ} \pm 1.0^{\circ}$
- r) Governor : mt-Propeller P-853-16 electrical governor
- s) Oil specification : SHELL HELIX ULTRA 5W30  
SHELL HELIX ULTRA 5W40
- t) Gearbox oil (propeller gearbox) : SHELL SPIRAX GSX 75W-80
- u) Coolant : Distilled water / Cooler protection (BASF  
Glysantin Protect Plus / G48) 1/1. The freezing  
point of the coolant is - 38°C (-36°F).

### CAUTION

If the coolant or gearbox oil level is low the reason must be determined and the problem must be corrected by authorized personnel.

- v) Maximum restart altitude : 16,400 ft pressure altitude  
for immediate restarts  
  
10,000 ft pressure altitude  
for restarts within 2 minutes

## 2.5 ENGINE INSTRUMENT MARKINGS

Engine instrument markings and their color code significance are shown in the table below:

Indi- cation	Red arc/bar = lower prohibited range	Yellow arc/bar = caution range	Green arc/bar = normal operating range	Yellow arc/bar = caution range	Red arc/bar = upper prohibited range
RPM	--	--	up to 2100 RPM	2100 to 2300 RPM	above 2300 RPM
Oil pressure	below 0.9 bar	0.9 to 2.5 bar	2.5 to 6.0 bar	6.0 to 6.5 bar	above 6.5 bar
Oil temp.	below -30°C	-30° to 50°C	50° to 135°C	135° to 140°C	above 140°C
Coolant temp.	below -30°C	-30° to 60°C	60° to 95°C	95° to 105°C	above 105°C
Gearbox temp.	below -30°C	-30° to 35°C	35° to 115°C	115° to 120°C	above 120°C
Load	--	--	up to 92%	92 - 100%	--
Fuel temp.	below -25°C	-25° to -20°C	-20° to 55°C	55° to 60°C	above 60°C
Ammeter	--	--	up to 60A	60 to 70A	above 70A
Volt- meter	below 24.1V	24.1 to 25V	25 to 30V	30 to 32V	above 32V
Fuel qty.	below 1 US gal	--	1 to 14 US gal	--	--

## 2.6 WARNING, CAUTION AND STATUS LIGHTS

The following tables show the color and significance of the warning, caution and advisory alert lights. There are two variants: G1000 annunciation or SED, MED and 'White Wire' annunciator panel.

### Color and Significance of the Warning Lights (Red)

Warning Alerts (Red)		Meaning / Cause
G1000 installed	SED, MED, White Wire installed	
WARNING	WARNING	One of the warnings listed below is being indicated.
ENG TEMP	-	Engine coolant temperature is in the upper red range (too high / > 105 °C).
OIL TEMP	-	Engine oil temperature is in the upper red range (too high / > 140 °C).
OIL PRES	-	Engine oil pressure is in the lower red range (too low / < 0.9 bar).
L/R FUEL TEMP	-	Fuel temperature is in the upper red range (too high / > 60 °C).
GBOX TEMP	-	Engine gearbox temperature is in the upper red range (too high / > 120 °C).
FUEL PRESS	FUELPRESS	Engine fuel pressure is low.
ALTN AMPS	-	Engine alternator output is in the upper red range (too high / > 70 A).
ALTN FAIL	ALTERNATOR	Engine alternator has failed.
STARTER	START	Engine starter is engaged.

Warning Alerts (Red)		Meaning / Cause
G1000 installed	SED, MED, White Wire installed	
DOOR OPEN	DOORS	Canopy and/or rear door are/is not closed and locked.
ATTITUDE FAIL	-	Display system is not receiving attitude reference information from the AHRS; accompanied by the removal of sky/ground presentation and a red X over the attitude area.
AIRSPEED FAIL	-	Display system is not receiving airspeed input from the air data computer; accompanied by a red X through the airspeed display.
ALTITUDE FAIL	-	Display system is not receiving altitude input from the air data computer; accompanied by a red X through the altimeter display.
VERT SPEED FAIL	-	Display system is not receiving vertical speed input from the air data computer; accompanied by a red X through the vertical speed display.
HDG	-	Display system is not receiving valid heading input from the AHRS; accompanied by a red X through the digital heading display.
Red X	-	A red X through any display field, such as com frequencies, nav frequencies, or engine data, indicates that display field is not receiving valid data.

Color and Significance of the Caution Lights (Amber)

Caution Alerts (Amber)		Meaning / Cause
G1000 installed	SED, MED, White Wire installed	
CAUTION	CAUTION	One of the cautions below is being indicated.
ECU A FAIL	ECU A	A fault has occurred in the engine ECU A or ECU A is being tested during FADEC-test procedure during the 'Before Take-Off Check'.
ECU B FAIL	ECU B	A fault has occurred in the engine ECU B or ECU B is being tested during FADEC-test procedure during the 'Before Take-Off Check'.
FUEL LOW	LOW FUEL	Left fuel quantity is low.
VOLTS LOW	LOW VOLTS	Engine bus voltage is too low (< 25 V).
COOL LVL	WATERLEV	Engine coolant level is low.
PITOT FAIL	PITOT	Pitot heat has failed.
PITOT HT OFF	-	Pitot heat is OFF.
LOI	-	GPS integrity is insufficient for the current phase of flight.
AHRS ALIGN: Keep Wings Level	-	The AHRS (Attitude and Heading Reference System) is aligning.
-	ENGINE	Engine limit exceeded.



Color and Significance of the Status Lights (White)

Advisory Alerts (White)		Meaning / Cause
G1000 installed	SED, MED, White Wire installed	
GLOW ON	GLOW	Engine glow plug active.
FUEL XFER	FUEL TRANS	Fuel transfer from auxiliary to main tank is in progress.
PFD FAN FAIL	-	Cooling fan for the PFD is inoperative.
MFD FAN FAIL	-	Cooling fan for the MFD is inoperative.
GIA FAN FAIL	-	Cooling fan for the GIAs is inoperative.

## 2.7 MASS (WEIGHT)

Value	Mass (Weight)	
	kg	lb
Maximum take-off mass	1280	2822
Maximum landing mass	1216	2681
Minimum flight mass	940	2072
Maximum zero fuel mass	1200	2646
Standard:		
Max. load in baggage compartment (between rear seats and baggage frame)	30	66
Max. load in baggage tube compartment (if installed)	5	11
Max. load in short baggage extension (if OÄM 40-331 is installed)	15	33
Extended baggage compartment (if OÄM 40-164 is installed):		
Max. load in cockpit baggage compartment (behind rear seats)	45	100
Max. load in extended baggage compartment (behind cabin baggage compartment)	18	40
Max. load in cockpit baggage compartment and extended baggage compartment	45	100

### WARNING

Exceeding the mass limits will lead to an overstressing of the airplane as well as to a degradation of flight characteristics and flight performance.

### NOTE

The maximum landing mass is the highest mass for landing conditions at the maximum descent velocity. This condition was used in the strength calculations to determine the landing gear loads during a particularly hard landing.

**NOTE**

In some countries the beginning of a flight is defined by starting the engine. In those countries a maximum ramp mass 4 kg (9 lb) above the maximum take-off mass is approved. At the time of lift-off the maximum permitted take-off mass must not be exceeded.

**NOTE**

The maximum zero fuel mass is the highest mass with empty fuel tanks.

## **2.8 CENTER OF GRAVITY**

### Datum Plane

The Datum Plane (DP) is a plane which is normal to the airplane's longitudinal axis and in front of the airplane as seen from the direction of flight. The airplane's longitudinal axis is parallel with the upper surface of a 600:31 wedge which is placed on top of the rear fuselage in front of the vertical stabilizer. When the upper surface of the wedge is aligned horizontally, the Datum Plane is vertical. The Datum Plane is located 2.194 meter (86.38 in) forward of the most forward point of the root rib on the stub wing.

### Center of Gravity Limitations

The center of gravity (CG position) for flight conditions must be between the following limits:

Most forward CG:

2.40 m (94.5 in) aft of DP from 940 kg to 1080 kg (2072 lb to 2381 lb)

2.46 m (96.9 in) aft of DP at 1280 kg (2822 lb)

linear variation between these values

Most rearward CG:

2.53 m (99.6 in) aft of DP from 940 kg (2072 lb) to 1280 kg (2822 lb)

### **WARNING**

Exceeding the center of gravity limitations reduces the controllability and stability of the airplane.

## **2.9 APPROVED MANEUVERS**

The airplane is to be operated in the Normal Category in accordance with JAR 23.

### Approved Maneuvers

- 1) All normal flight maneuvers;
- 2) Stalling (with the exception of dynamic stalling); and
- 3) Lazy Eights, Chandelles, as well as steep turns and similar maneuvers, in which an angle of bank of not more than 60° is attained.

### **CAUTION**

Aerobatics, spinning, and flight maneuvers with more than 60° of bank are not permitted in the Normal Category.

### **CAUTION**

Intentional negative g-maneuvers are not permitted.

## 2.10 MANEUVERING LOAD FACTORS

### **WARNING**

The table below shows structural limitations. Exceeding the maximum load factors will lead to an overstressing of the airplane.

### **CAUTION**

Intentional negative g-maneuvers are not permitted.

	at $v_o$	at $v_{NE}$	with flaps in T/O or LDG position
Positive	3.8	3.8	2.0
Negative	-1.52	0	0

## **2.11 OPERATING ALTITUDE**

The maximum operating altitude is 16,400 ft (5,000 m) pressure altitude.

## **2.12 FLIGHT CREW**

Minimum crew : 1 (one person)

Maximum number of occupants : 4 (four persons)

## **2.13 KINDS OF OPERATION**

Provided that national operational requirements are met, the following kinds of operation are approved:

- Daytime flights according to Visual Flight Rules (VFR)
- With the appropriate equipment: night flights according to Visual Flight Rules (NVFR)
- With the appropriate equipment: flights according to Instrument Flight Rules (IFR)
- Take-off and landing on paved surfaces
- Take-off and landing on unpaved surfaces

Flights into known or forecast icing conditions are prohibited.

Flights into known thunderstorms are prohibited.

### Minimum Operational Equipment (Serviceable)

The following table lists the minimum serviceable equipment required by JAR-23. Additional minimum equipment for the intended operation may be required by national operating rules and also depends on the route to be flown.

### **NOTE**

Many of the items of minimum equipment listed in the following table are integrated in the G1000 (if installed).

Page 2 - 20	Rev. 1	15-Mar-2011	EASA approved	Doc. # 6.01.15-E
-------------	--------	-------------	------------------	------------------



	For daytime VFR flights	In addition for night VFR flights	In addition for IFR flights
Flight & navigation instruments	<ul style="list-style-type: none"> <li>Airspeed indicator</li> <li>Altimeter</li> <li>Magnetic compass</li> <li>1 headset, used by pilot in command</li> </ul>	<ul style="list-style-type: none"> <li>Vertical speed indicator (VSI)</li> <li>Attitude gyro</li> <li>Turn &amp; bank indicator</li> <li>Directional gyro</li> <li>VHF radio (COM)</li> <li>VOR receiver</li> <li>Transponder (XPDR)</li> <li>GPS receiver (part of G1000, if installed)</li> <li>Second headset (if PM 1000 intercom is installed)</li> </ul>	<ul style="list-style-type: none"> <li>Second airspeed indicator (on PFD and backup, if G1000 is installed)</li> <li>Second altimeter</li> <li>Second attitude gyro (on PFD and backup, if G1000 is installed)</li> <li>Second VHF radio (COM)</li> <li>VOR-LOC-GP receiver</li> <li>Second GPS receiver (part of G1000, if installed)</li> </ul>

	For daytime VFR flights	In addition for night VFR flights	In addition for IFR flights
Engine instruments	<ul style="list-style-type: none"> <li>• Fuel qty.</li> <li>• Oil press.</li> <li>• Oil temp.</li> <li>• Coolant temp.</li> <li>• Coolant level indicator</li> <li>• Gearbox temp.</li> <li>• Load</li> <li>• Prop. RPM</li> <li>• Fuel temp. left &amp; right tank</li> <li>• Fuel flow</li> <li>• Fuel pressure warning</li> <li>• ECU A/B Caution</li> <li>• ENGINE Caution (if White Wire annunciator panel is installed)</li> </ul>	<ul style="list-style-type: none"> <li>• Ammeter</li> <li>• Voltmeter</li> </ul>	
Lighting		<ul style="list-style-type: none"> <li>• Position lights</li> <li>• Strobe lights (anti collision lights)</li> <li>• Landing light</li> <li>• Instrument lighting</li> <li>• Flood light</li> <li>• Flashlight</li> </ul>	

	For daytime VFR flights	In addition for night VFR flights	In addition for IFR flights
Other operational minimum equipment	<ul style="list-style-type: none"> <li>• Stall warning system</li> <li>• Alternate means for fuel quantity indication (see Section 7.9)</li> <li>• Safety belts for each occupied seat</li> <li>• Airplane Flight Manual</li> </ul>	<ul style="list-style-type: none"> <li>• Pitot heating system</li> <li>• Alternate static valve</li> </ul>	<ul style="list-style-type: none"> <li>• Emergency battery (for backup attitude gyro and flood light)</li> </ul>

### NOTE

A list of approved equipment can be found in Chapter 6.

### Engine Systems and Equipment

All engine systems and equipment must be functional prior to airplane take-off. Any engine system or equipment failure must be corrected before next flight.

## **2.14 FUEL**

- | Approved fuel grades: JET A (ASTM D 1655),
- | JET A-1 (ASTM D 1655),
- | TS-1 (GOST 10227-86),
- | and blends of the above listed fuel grades.

### **NOTE**

A minimum cetane number of 37 determined acc. to EN ISO 5165/ASTM D613 is recommended.

### **NOTE**

Use only uncontaminated fuel from reliable sources.

#### **Standard Tank Configuration:**

Total fuel quantity : 2 x 15.0 US gal (2 x 56.8 liter)  
Usable fuel : 2 x 14.0 US gal (2 x 53.0 liter)

#### **Long Range Tank (if installed) Configuration :**

Total fuel quantity : 2 x 20.5 US gal (2 x 77.6 liter)  
Usable fuel : 2 x 19.5 US gal (2 x 73.8 liter)  
Max. indicated fuel quantity : 14 US gal (53 liter) per tank  
Max. permissible difference  
between right and left tank : 9 US gal (approx. 34 liter)

### **CAUTION**

If an indicator shows 14 US gal, then 19.5 US gal must be assumed for the calculation of the difference between right and left tank.

## 2.15 LIMITATION PLACARDS

- All *limitation* placards relevant for the base DA 40 NG airplane are shown below. A list of all placards is included in the Airplane Maintenance Manual (Doc. No. 6.02.15), Chapter 11.

### On the Instrument Panel:

THIS AIRPLANE MAY ONLY BE OPERATED IN ACCORDANCE WITH THE AIRPLANE FLIGHT MANUAL IN THE "NORMAL" CATEGORY IN NON-ICING CONDITIONS. PROVIDED THAT NATIONAL OPERATIONAL REQUIREMENTS ARE MET AND THE APPROPRIATE EQUIPMENT IS INSTALLED AND OPERATIONAL, THIS AIRPLANE IS APPROVED FOR THE FOLLOWING KINDS OF OPERATION: DAY VFR, NIGHT VFR, IFR. ALL AEROBATIC MANEUVERS INCLUDING SPINNING ARE PROHIBITED. FOR FURTHER OPERATIONAL LIMITATIONS REFER TO THE AIRPLANE FLIGHT MANUAL.

**OPERATING MANEUVERING SPEED:**

$V_0 = 113$  KIAS (ABOVE 1180 KG / 2601 LB)

$V_0 = 108$  KIAS (ABOVE 1080 KG / 2381 LB TO 1180 KG / 2601 LB)

$V_0 = 101$  KIAS (UP TO 1080 KG / 2381 LB)

### On the Instrument Panel, Next to the Fuel Quantity Indication:

#### Long Range Tank (if installed):

**max. usable fuel: 2 x 19.5 US gal**

- \* Max. indicated fuel quantity: 2 x 14 US gal
- \* Refer to AFM to use entire tank capacity
- \* Max. difference LH/RH tank: 9 US gal

Next to Each of the Two Fuel Filler Necks:

**WARNING**  
**APPROVED FUEL**  
**JET-A1**  
**or see Airplane Flight Manual**


Next to the Essential Bus Switch:

**Ess. Bus NOT for normal operation. See AFM.**


In the Cowling, on the Door for the Oil Filler Neck:

**OIL**  
**SHELL HELIX**  
**ULTRA**  
**5W30**  
or see Airplane  
Flight Manual

Next to the Flap Selector Switch:




On the Fuel Valve:



Next to the Baggage Compartment:




Baggage Tube Compartment:




Baggage Tray (if OÄM 40-164 installed, extended baggage compartment):








*If Short Baggage Extension (OÄM 40-331) is carried out:*



On the Left Sidewall, Next to the Instrument Panel:



Beside the Door Locking Device:

**EMERGENCY EXIT:**

The keylock must be  
unlocked during flight

On Fuel Cooler Inlet Baffle (if installed):

Remove at Outside  
Temperatures above  
20 °C / 68 °F

On the Instrument Panel:

— NO SMOKING —

## **2.16 OTHER LIMITATIONS**

### **2.16.1 TEMPERATURE**

The airplane may only be operated when its temperature prior to operation is not less than -20 °C (-4 °F).

With the airplane cold soaked and its temperature below -20 °C (-4 °F) the use of an external pre-heater for the engine and pilot compartment prior to operation is mandatory.

- The airplane may only be operated with the fuel cooler inlet baffle installed when the outside air temperature at take-off does not exceed 20 °C (68 °F).

### **2.16.2 BATTERY CHARGE**

Take-off for a Night VFR or IFR flight with an empty main battery is not permitted.

The use of an external power supply for engine starting with an empty airplane main battery is not permitted if the subsequent flight is intended to be a Night VFR or an IFR flight. In this case the airplane main battery must be charged first.

### **2.16.3 EMERGENCY SWITCH**

IFR flights are not permitted when the seal on the emergency switch is broken.

### **2.16.4 DOOR LOCKING DEVICE**

The canopy and the passenger door must not be key locked during operation of the airplane.

### **2.16.5 ELECTRONIC EQUIPMENT**

The use and switching on of electronic equipment other than that which is part of the equipment of the airplane is not permitted, as it could lead to interference with the airplane's avionics.

Examples of undesirable items of equipment are:

- Mobile telephones
- Remote radio controls
- Video screens employing CRTs
- Minidisc recorders when in the record mode

This list is not exhaustive.

The use of laptop computers, including those with CD-ROM drives, CD and minidisc players in the replay mode, cassette players and video cameras is permitted. All this equipment however should be switched off for take-off and landing.

### **2.16.6 SMOKING**

Smoking in the airplane is not permitted.

### **2.16.7 USE OF THE SUN VISORS**

- The sun visors (if installed, OÄM 40-327) may only be used during cruise. During all other phases of flight the sun visors must be locked in the fully upward position.

Page 2 - 32	Rev. 1	15-Mar-2011	EASA approved	Doc. # 6.01.15-E
-------------	--------	-------------	------------------	------------------

# CHAPTER 3 EMERGENCY PROCEDURES

	Page
3.1 INTRODUCTION .....	3-3
3.1.1 GENERAL .....	3-3
3.1.2 CERTAIN AIRSPEEDS IN EMERGENCIES .....	3-4
3.2 INSTRUMENT INDICATIONS IN PROHIBITED (RED) RANGE ...	3-5
3.2.1 ENGINE TEMPERATURE .....	3-5
3.2.2 OIL TEMPERATURE .....	3-7
3.2.3 OIL PRESSURE .....	3-9
3.2.4 GEARBOX TEMPERATURE .....	3-10
3.2.5 L/R FUEL TEMPERATURE .....	3-11
3.2.6 FUEL PRESSURE .....	3-12
3.2.7 ALTERNATOR AMPS .....	3-13
3.2.8 ALTERNATOR FAIL .....	3-14
3.3 ENGINE PROBLEMS .....	3-15
3.3.1 ENGINE PROBLEMS ON GROUND .....	3-15
3.3.2 ENGINE PROBLEMS DURING TAKE-OFF .....	3-16
3.3.3 ENGINE TROUBLESHOOTING IN FLIGHT .....	3-18
3.3.4 ENGINE FAILURE IN FLIGHT .....	3-21
3.3.5 RESTARTING THE ENGINE IN FLIGHT .....	3-22
3.3.6 DEFECTIVE RPM REGULATING SYSTEM .....	3-24
3.3.7 FUEL TRANSFER PUMP FAILURE .....	3-28
3.4 FAILURES IN THE ELECTRICAL SYSTEM .....	3-30
3.4.1 COMPLETE FAILURE OF THE ELECTRICAL SYSTEM ..	3-30
3.4.2 HIGH CURRENT .....	3-31
3.4.3 STARTER MALFUNCTION .....	3-32

3.5	SMOKE AND FIRE .....	3-33
3.5.1	SMOKE AND FIRE ON GROUND .....	3-33
3.5.2	SMOKE AND FIRE DURING TAKE-OFF .....	3-35
3.5.3	SMOKE AND FIRE IN FLIGHT .....	3-38
3.6	GLIDING .....	3-40
3.7	EMERGENCY LANDINGS .....	3-41
3.7.1	EMERGENCY LANDING WITH ENGINE OFF .....	3-41
3.7.2	LANDING WITH A DEFECTIVE TIRE ON THE MAIN LANDING GEAR .....	3-43
3.7.3	LANDING WITH DEFECTIVE BRAKES .....	3-44
3.8	RECOVERY FROM AN UNINTENTIONAL SPIN .....	3-45
3.9	OTHER EMERGENCIES .....	3-46
3.9.1	ICING .....	3-46
3.9.2	SUSPICION OF CARBON MONOXIDE CONTAMINATION IN THE CABIN .....	3-47
3.9.3	UNLOCKED DOORS .....	3-48

**NOTE**

Procedures for uncritical system faults are given in Chapter  
4B - ABNORMAL OPERATING PROCEDURES.

## **3.1 INTRODUCTION**

### **3.1.1 GENERAL**

This Chapter contains checklists as well as the description of recommended procedures to be followed in the event of an emergency. Engine failure or other airplane-related emergencies are most unlikely to occur if the prescribed procedures for pre-flight checks and airplane maintenance are followed.

If, nonetheless, an emergency does arise, the guidelines given here should be followed and applied in order to clear the problem.

As it is impossible to foresee all kinds of emergencies and cover them in this Airplane Flight Manual, a thorough understanding of the airplane by the pilot is, in addition to his knowledge and experience, an essential factor in the solution of any problems which may arise.

### **WARNING**

In each emergency, control over the flight attitude and the preparation of a possible emergency landing have priority over attempts to solve the current problem ("first fly the aircraft"). Prior to the flight the pilot must consider the suitability of the terrain for an emergency landing for each phase of the flight. For a safe flight the pilot must constantly keep a safe minimum flight altitude. Solutions for various adverse scenarios should be thought over in advance. Thus it should be guaranteed that the pilot is at no time shocked by an engine failure and that he can act calmly and with determination.

### 3.1.2 CERTAIN AIRSPEEDS IN EMERGENCIES

Event		KIAS
Airspeed for best glide angle (Flaps UP)		88 KIAS
Airspeed for emergency landing with engine off	Flaps UP	83 KIAS
	Flaps T/O	78 KIAS
	Flaps LDG	77 KIAS



## **3.2 INSTRUMENT INDICATIONS IN PROHIBITED (RED) RANGE**

### **3.2.1 ENGINE TEMPERATURE**

Engine coolant temperature is in the upper red range (too high / above 105 °C).

Coolant temperatures above the limit value of 105 °C can lead to a total loss of power due to engine failure.

- Check for COOL LVL (if G1000 is installed) or WATERLEV (if SED is installed) caution message (low coolant level).

*COOL LVL (if G1000 is installed) or WATERLEV (if SED is installed) Caution Message Not Displayed:*

During climb:

- Reduce power by 10 % or more as required.
- Increase airspeed by 10 KIAS or more as required.
- If the coolant temperature does not reach the green range within 60 seconds, reduce power as far as possible and increase airspeed.

**CONTINUED**

During cruise:

- Reduce power, or
- Increase airspeed, if necessary by initiating a descent.
- Check coolant temperature in green range.

### CAUTION

If high coolant temperature is indicated and the COOL LVL (if G1000 is installed) or WATERLEV (if SED is installed) caution message is not displayed, it can be assumed that there is no technical defect in the cooling system and that the above mentioned procedure can decrease the temperature(s). This might not be the case if the coolant temperature does not return to the green range. In this case perform a precautionary landing on the nearest suitable airfield. Prepare for an engine failure in accordance with 3.3.4 - ENGINE FAILURE IN FLIGHT.

*COOL LVL (if G1000 is installed) or WATERLEV (if SED is installed) Caution Message Displayed:*

- Reduce power.
- Expect loss of coolant.

### WARNING

A further increase in coolant temperature must be expected. Prepare for an engine failure in accordance with 3.3.4 - ENGINE FAILURE IN FLIGHT.

**END OF CHECKLIST**

**3.2.2 OIL TEMPERATURE**

Engine oil temperature is in the upper red range (too high / above 140 °C).

Oil temperatures above the limit value of 140 °C can lead to a total loss of power due to engine failure.

- Check oil pressure.

*If the Oil Pressure Is Outside of the Green Range (Lower Limit):*

- Reduce power.
- Expect loss of engine oil.

**WARNING**

A further increase in oil temperature must be expected.  
Prepare for an engine failure in accordance with 3.3.4 -  
ENGINE FAILURE IN FLIGHT.

*If the Oil Pressure Is Within the Green Range:*

- Reduce power.
- Increase airspeed.

**CONTINUED**

**CAUTION**

If high oil temperature is announced and the oil pressure indication is within the green range, it can be assumed that there is no technical defect in the engine oil system and that the above mentioned procedure can decrease the temperature(s). This might not be the case if the oil temperature does not return to the green range. In this case perform a precautionary landing on the nearest suitable airfield. Prepare for an engine failure in accordance with 3.3.4 - ENGINE FAILURE IN FLIGHT.

**END OF CHECKLIST**

**3.2.3 OIL PRESSURE**

Engine oil pressure is in the lower red range (too low / below 0.9 bar).

Oil pressures below the limit value of 0.9 bar can lead to a total loss of power due to engine failure.

- Reduce power.
- Expect loss of oil.

**WARNING**

Land at the nearest suitable airfield. Prepare for an engine failure in accordance with 3.3.4 - ENGINE FAILURE IN FLIGHT.

**END OF CHECKLIST**

### **3.2.4 GEARBOX TEMPERATURE**

Engine gearbox temperature is in the upper red range (too high / above 120 °C).

Gearbox temperatures above the limit value of 120 °C can lead to a total loss of power due to engine failure.

- Reduce power.
- Increase airspeed.

### **CAUTION**

At high ambient temperature conditions and/or at low airspeeds with high power settings, it can be assumed that there is no technical defect in the gearbox and that the above mentioned procedure will decrease the temperature(s). This might not be the case if the gearbox temperature does not return to the green range. In this case perform a precautionary landing on the nearest suitable airfield. Prepare for an engine failure in accordance with 3.3.4 - ENGINE FAILURE IN FLIGHT.

**END OF CHECKLIST**

**3.2.5 L/R FUEL TEMPERATURE**

Fuel temperature is in the upper red range (too high / above 60 °C).

Fuel temperatures above the limit value of 60 °C can lead to a noticeable reduction of the high pressure pump efficiency.

- Reduce power.
- Increase airspeed.

**CAUTION**

At high ambient temperature conditions and/or at low airspeeds with high power settings and low fuel quantities, it can be assumed that the above mentioned procedure will decrease the temperature(s). If the fuel temperature does not return to the green range, perform a precautionary landing on the nearest suitable airfield.

**NOTE**

Increased fuel temperature can occur when the fuel quantity in the main tank is low. The fuel temperature can be decreased by transferring fuel from the auxiliary to the main tank.

**END OF CHECKLIST**

**3.2.6 FUEL PRESSURE**

Engine fuel pressure is low.

1. Fuel quantity ..... check
2. Fuel valve ..... check ON
3. Fuel pumps ..... ON

*If FUEL PRESS (if G1000 is installed) or FUELPRESS (if SED is installed) Warning Remains:*

4. Fuel valve ..... EMERGENCY
5. Fuel pumps ..... OFF

*If FUEL PRESS (if G1000 is installed) or FUELPRESS (if SED is installed) Warning Still Remains:*

**WARNING**

Imminent engine failure must be expected. Prepare for an engine failure in accordance with 3.3.4 - ENGINE FAILURE IN FLIGHT.

**END OF CHECKLIST**



■ **3.2.7 ALTERNATOR AMPS**

■ Engine alternator output is in the upper red range (too high / above 70 A).

1. ESSENTIAL BUS . . . . . ON

2. ENGINE SYSTEM DISPLAY

■ (if G1000 is installed) . . . . . select by pressing ENGINE and  
SYSTEM softkey on MFD

3. Circuit breakers . . . . . check IN

■ 4. Ammeter/Voltmeter . . . . . monitor

5. Land on the nearest suitable airfield.

**END OF CHECKLIST**

### **3.2.8 ALTERNATOR FAIL**

Engine alternator has failed.

The batteries are the last remaining source of electrical power for about 30 minutes.

1. Circuit breakers . . . . . check
2. ESSENTIAL BUS . . . . . ON
3. Electrical equipment . . . . . switch OFF all equipment which  
is not needed
4. Land on the nearest suitable airfield.

### **WARNING**

The ECU which is absolutely necessary for engine operation needs electrical power. It is recommended to switch off all electrical consumers and to land as soon as possible. Be prepared for an engine failure and an emergency landing. For a severe electrical failure a ECU backup battery system is installed.

### **CAUTION**

For cases in which the battery capacity is not sufficient to reach a suitable airfield, an emergency battery is installed, serving as an additional back-up system for the backup attitude gyro (artificial horizon) and flood light. This battery is switched on with the EMERGENCY switch, located on the top left side of the instrument panel.

**END OF CHECKLIST**

### **3.3 ENGINE PROBLEMS**

#### **3.3.1 ENGINE PROBLEMS ON GROUND**

1. POWER lever ..... IDLE
2. Brakes ..... as required

#### **NOTE**

If considered necessary, the engine must be shut down. Otherwise the cause of the problem must be established in order to re-establish engine performance.

#### **CAUTION**

If the oil pressure is in the red range, the engine must be shut down immediately.

#### **WARNING**

If the problem cannot be cleared, the airplane must not be flown.

**END OF CHECKLIST**

**3.3.2 ENGINE PROBLEMS DURING TAKE-OFF**

(a) Take-Off Can Still Be Aborted (Sufficient Runway Length Available)

*Land Straight Ahead:*

1. POWER lever ..... IDLE

*On the Ground:*

2. Brakes ..... as required

**WARNING**

If sufficient time is remaining, the risk of fire in the event of a collision can be reduced as follows:

- Fuel valve ..... OFF
- ENGINE MASTER ..... OFF
- ELECTRIC MASTER ..... OFF

**END OF CHECKLIST**

(b) Take-Off Can No Longer Be Aborted

- 1. Airspeed ..... immediate pitch down to avoid  
airspeed reduction

**WARNING**

If, in the event of an engine problem occurring during take-off, the take-off can no longer be aborted and a safe height has not been reached, then a straight-ahead emergency landing should be considered. Do not attempt to turn back to the airfield. Turning back can be fatal.

*If Time Allows:*

- 2. POWER lever ..... check MAX
- 3. Fuel pumps ..... check ON
- 5. VOTER switch ..... check AUTO

**WARNING**

If the problem does not clear itself immediately, and the engine is no longer producing sufficient power, then an emergency landing must be carried out in accordance with 3.7.1 - EMERGENCY LANDING WITH ENGINE OFF.

**END OF CHECKLIST**

### 3.3.3 ENGINE TROUBLESHOOTING IN FLIGHT

#### **WARNING**

Control over the flight attitude has priority over attempts to solve the current problem ("first fly the airplane").

1. Airspeed ..... 88 KIAS
2. POWER lever ..... MAX

#### **NOTE**

If the loss of power was due to unintentional setting of the POWER lever, you may adjust the friction lock and continue your flight.

#### **|** If ECU A and ECU B Cautions Appear Simultaneously

**|** - If the indicated LOAD remains unchanged, and

**|** - if the perceived thrust is reduced, and

**|** - if the engine noise level changes or the engine is running rough:

**|** 3. POWER lever ..... IDLE for 1 second

**|** 4. POWER lever ..... slowly increase to 1975 RPM

**|** *If the engine shows a power loss during the POWER lever increase:*

**|** 5. POWER lever ..... IDLE for 1 second

**|** 6. POWER lever ..... slowly increase, stop prior to the  
previously observed engine  
power loss RPM

#### **|** **CONTINUED**

Page 3 - 18	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
-------------	--------	-------------	------------------

**WARNING**

Do not increase the POWER lever past the propeller speed of 1975 RPM or the setting determined in step 6. An increase of engine power beyond this setting leads into another power loss.

**NOTE**

With this power setting the engine can provide up to 65 % load at the maximum propeller speed of 1975 RPM.

7. Land at the next suitable airfield.

Otherwise:

Depending on the situation the following attempts can be made to restore normal engine operation:

3. Circuit breakers . . . . . check / reset if necessary

If normal engine operation is restored continue flight and land as soon as possible.

*Otherwise:*

4. VOTER switch . . . . . swap between ECU A and B

If either ECU A or B setting restores normal engine operation then maintain ECU setting and land as soon as possible.

**CONTINUED**

*Otherwise:*

5. VOTER switch ..... switch back to AUTO to retain ECU redundancy

If normal engine operation is restored continue flight and land as soon as possible.

*Otherwise:*

6. Fuel valve ..... EMERGENCY

If normal engine operation is restored continue flight and land as soon as possible. Remain within maximum allowable lateral imbalance.

*Otherwise:*

7. Fuel valve ..... NORMAL  
8. Alternate air ..... OPEN  
9. POWER lever ..... apply power as required

If normal engine operation is restored continue flight and land as soon as practicable.

If normal engine operation could not be restored by following the procedures in this section prepare for 3.3.4 - ENGINE FAILURE IN FLIGHT and land as soon as possible.

**END OF CHECKLIST**



**3.3.4 ENGINE FAILURE IN FLIGHT**

**WARNING**

Control over the flight attitude has priority over attempts to solve the current problem ("first fly the airplane").

**NOTE**

As long as there is no major mechanical engine defect, the propeller will continue to windmill.

- 1. Airspeed ..... 88 KIAS
- 2. Flaps ..... UP

*If the Remaining Altitude is Sufficient for an Restart Attempt:*

Try to restart the engine, refer to 3.3.5 - RESTARTING THE ENGINE IN FLIGHT.

*If the Remaining Altitude is NOT Sufficient for an Restart Attempt:*

Carry out an emergency landing in accordance with 3.7.1 - EMERGENCY LANDING WITH ENGINE OFF.

**END OF CHECKLIST**

**3.3.5 RESTARTING THE ENGINE IN FLIGHT**

**NOTE**

With a failed engine the propeller continues to windmill. A stopped propeller indicates a major mechanical engine defect. Starter assisted restart shall not be considered.

Maximum restart altitude:

- 16,400 ft pressure altitude . . . . . for immediate restarts
- 10,000 ft pressure altitude . . . . . for restarts within two minutes

**NOTE**

If the engine is allowed to cool down for more than two minutes, a successful restart may not be possible.

- 1. Airspeed . . . . . 88 KIAS
- 2. POWER lever . . . . . IDLE
- 3. VOTER switch . . . . . check AUTO
- 4. Fuel valve . . . . . check NORMAL
- 5. Alternate air . . . . . as required
- 6. Fuel quantity . . . . . check
- 7. Fuel transfer pump . . . . . as required
- 8. ELECTRIC MASTER . . . . . check ON
- 9. ENGINE MASTER . . . . . check ON

**CONTINUED**

*If Engine Does Not Start:*

- 10. Fuel valve ..... EMERGENCY

*If Engine Does Not Start Adopt Glide Configuration:*

- 11. Flaps ..... UP
- 12. Airspeed ..... 88 KIAS

**NOTE**

The glide ratio is 9.7; i.e., for every 1000 ft (305 m) of altitude loss the maximum horizontal distance traveled in still air is 1.59 NM (2.94 km). During this the propeller will continue to windmill.

Carry out an emergency landing in accordance with 3.7.1 - EMERGENCY LANDING WITH ENGINE OFF.

**CAUTION**

Engine restart following an engine fire should only be attempted if it is unlikely that a safe emergency landing can be made. It must be expected that engine restart is impossible after an engine fire.

- 13. AVIONIC MASTER ..... ON, if required

**END OF CHECKLIST**

**3.3.6 DEFECTIVE RPM REGULATING SYSTEM**

**WARNING**

In case of defective RPM regulating system, reduced engine performance should be anticipated.

**CAUTION**

Following a failure of the governor the RPM should be adjusted with the POWER lever.

**CAUTION**

The POWER lever should be moved slowly, in order to avoid over-speeding and excessively rapid RPM changes. The light wooden propeller blades produce more rapid RPM changes than metal blades.

(a) Oscillating RPM

1. Power setting ..... change

*If the Problem Does Not Clear:*

2. VOTER switch ..... swap between ECU A and B

*If the Problem Does Not Clear:*

3. VOTER switch ..... AUTO
4. Land on the nearest suitable airfield.

**END OF CHECKLIST**

Page 3 - 24	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
-------------	--------	-------------	------------------

(b) Propeller Overspeed

**CAUTION**

Climb performance will be reduced.

**NOTE**

The propeller now works like a fixed pitch propeller. RPM is controlled by the engine power setting. Flight to the nearest airfield can be continued with a lower power setting and at a lower airspeed. Climb and go-around may not be possible under all conditions.

- 1. POWER lever . . . . . reduce to not exceed 2300 RPM
- 2. Airspeed . . . . . 88 KIAS
- 3. Flaps . . . . . check UP

*After RPM has Stabilized Below 2300 RPM:*

- 4. Airspeed . . . . . as required, do not exceed 2300 RPM
- 5. POWER lever . . . . . as required, do not exceed 2300 RPM

*If the Problem Does Not Clear:*

- 6. VOTER switch . . . . . swap between ECU A and B

**NOTE**

If selecting ECU A or ECU B does not solve the problem, switch back to AUTO. Keep controlling the climb/sink rate with the POWER lever and do not exceed 2300 RPM.

**CONTINUED**

*If the Problem Does Not Clear:*

7. Land on the nearest suitable airfield.

*If an Increased Climb Rate is Required:*

8. Flaps ..... T/O position
9. Airspeed ..... 72 KIAS
10. POWER lever ..... as required, do not exceed 2300 RPM

**END OF CHECKLIST**

(c) Propeller Underspeed

1. POWER lever ..... as required

*If the Problem Does Not Clear*

2. VOTER switch ..... swap between ECU A and B

*If the Problem Does Not Clear:*

3. VOTER switch ..... AUTO
4. POWER lever ..... as required

**WARNING**

Due to this problem the propeller RPM will drop. There may be no climb performance and no go-around power available.

5. Land on the nearest suitable airfield.

**END OF CHECKLIST**

**3.3.7 FUEL TRANSFER PUMP FAILURE**

1. Fuel quantity . . . . . check

*If Main Tank Fuel Quantity Low:*

2. Fuel valve . . . . . EMERGENCY
3. Fuel pumps . . . . . OFF

**WARNING**

The fuel valve must be switched back to NORMAL before the auxiliary tank indication reads zero! Otherwise, the engine will stop during flight when the auxiliary tank is empty.

**WARNING**

When the fuel pump takes in air (e.g. when the fuel valve is not switched back and the auxiliary tank is empty), an inspection of the pump is necessary prior to next flight.

**CAUTION**

When set to EMERGENCY, fuel is transferred from the auxiliary tank to the main tank at a rate of approximately 45 US gal/h (170 liter/h).

4. AUX tank . . . . . monitor quantity
5. MAIN tank . . . . . monitor quantity

**CONTINUED**



**NOTE**

AUX tank quantity must not be less than 1 US gal and  
MAIN tank quantity must not be more than 14 US gal.

- 6. Fuel valve ..... NORMAL
- 7. Land as soon as practicable.

**END OF CHECKLIST**

### **3.4 FAILURES IN THE ELECTRICAL SYSTEM**

#### **3.4.1 COMPLETE FAILURE OF THE ELECTRICAL SYSTEM**

1. Circuit breakers . . . . . check IN
2. ESSENTIAL BUS . . . . . ON

*If There Is Still No Electrical Power Available:*

2. EMERGENCY switch (if installed) . . . . . ON
3. Flood light, if necessary . . . . . ON
4. POWER . . . . . set based on lever positions  
and engine noise
5. Prepare landing with flaps in the given position. Refer to 4B.5 - FAILURES IN FLAP  
OPERATING SYSTEM.
6. Land on the nearest suitable airfield.

#### **WARNING**

Engine stoppage may occur, depending on the failure mode.  
A backup battery is installed for the ECU to provide electrical  
power solely to ECU B and its system for at least 30 minutes.

#### **NOTE**

The backup artificial horizon and the flood light will have  
electrical power for at least 1.5 hours.

1. If G1000 is installed make use of the stand-by airspeed indicator and altimeter. Engine  
power can be set via visual reference of the POWER lever position.

**END OF CHECKLIST**

Page 3 - 30	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
-------------	--------	-------------	------------------

**3.4.2 HIGH CURRENT**

■ If HIGH CURRENT (> 70 A) is indicated on the G1000 (if installed) or SED (if installed):

- 1. ESSENTIAL BUS ..... ON
- 2. ENGINE SYSTEM DISPLAY
- (if G1000 is installed) ..... select by pressing ENGINE and
- SYSTEM softkey on MFD
  
- 3. Circuit breakers ..... check IN
- 4. Ammeter/Voltmeter ..... monitor
- 5. Land on the nearest suitable airfield.

**END OF CHECKLIST**

### **3.4.3 STARTER MALFUNCTION**

If the starter does not disengage from the engine after starting (Starter engaged warning (STARTER) on the G1000 (if installed) or START on the White Wire annunciator (if installed) illuminates after the engine has started):

*On Ground:*

1. POWER lever ..... IDLE
2. ENGINE MASTER ..... OFF
3. ELECTRIC MASTER ..... OFF

Terminate flight preparation!

*In Flight:*

Land as soon as possible.

**END OF CHECKLIST**

**3.5 SMOKE AND FIRE**

**3.5.1 SMOKE AND FIRE ON GROUND**

(a) Engine Fire When Starting on the Ground

- 1. Fuel valve ..... OFF
- 2. Fuel transfer pump ..... OFF
- 3. ENGINE MASTER ..... OFF
- 4. Fuel pumps ..... OFF
- 5. ELECTRIC MASTER ..... OFF

*After Standstill:*

- 6. Canopy ..... open
- 7. Airplane ..... evacuate immediately

**END OF CHECKLIST**

(b) Electrical Fire with Smoke on the Ground

1. ELECTRIC MASTER ..... OFF

*If the Engine Is Running:*

2. POWER lever ..... IDLE
3. ENGINE MASTER ..... OFF
4. Fuel pumps ..... OFF

*When the Engine Has Stopped:*

6. Canopy ..... open
7. Airplane ..... evacuate immediately

**END OF CHECKLIST**

**3.5.2 SMOKE AND FIRE DURING TAKE-OFF**

(a) If Take-Off Can Still Be Aborted

- 1. POWER lever ..... IDLE
- 2. Cabin heat ..... OFF
- 3. Brakes ..... apply - bring the airplane to a stop
- 4. Fuel valve ..... OFF
- 5. Fuel transfer pump ..... OFF
- 6. ENGINE MASTER ..... OFF
- 7. Fuel pumps ..... OFF
- 8. ELECTRIC MASTER ..... OFF

*After Standstill:*

- 9. Canopy ..... open
- 10. Airplane ..... evacuate immediately

**END OF CHECKLIST**

(b) If Take-Off Cannot Be Aborted

1. Cabin heat . . . . . OFF
2. If possible, fly along a short-cut traffic circuit and land on the airfield.

**WARNING**

If, in the event of an engine problem occurring during take-off, the take-off can no longer be aborted and a safe height has not been reached, then a straight-ahead emergency landing should be carried out. Do not attempt to turn back to the airfield. Turning back can be fatal. Refer to 3.3.2 - ENGINE PROBLEMS DURING TAKE-OFF.

*After Climbing to a Height From Which the Selected Landing Area Can Be Reached Safely:*

3. Fuel valve . . . . . OFF
4. Fuel transfer pump . . . . . OFF
5. Cabin heat . . . . . OFF
6. ENGINE MASTER . . . . . OFF
7. Fuel pumps . . . . . OFF
8. ELECTRIC MASTER . . . . . OFF
9. Emergency windows . . . . . open if necessary
10. Carry out an emergency landing with engine off. Allow for increased landing distance due to the flap position. Refer to 3.7.1 - EMERGENCY LANDING WITH ENGINE OFF.

**CONTINUED**

Page 3 - 36	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
-------------	--------	-------------	------------------



**CAUTION**

In case of extreme smoke development, the front canopy may be unlatched during flight. This allows it to partially open, in order to improve ventilation. The canopy will remain open in this position. Flight characteristics will not be affected significantly.

*When Airplane Has Stopped:*

- 11. Canopy ..... open
- 12. Airplane ..... evacuate immediately

**END OF CHECKLIST**

**3.5.3 SMOKE AND FIRE IN FLIGHT**

**WARNING**

In the event of smoke or fire, prepare to land the airplane without delay while completing fire suppression and/or smoke evacuation procedures. If it cannot be visually verified that the fire has been completely extinguished, whether the smoke has cleared or not, land immediately.

**(a) Engine Fire in Flight**

1. Cabin heat . . . . . OFF
2. Select appropriate emergency landing area.

*When it Seems Certain That the Landing Area Will Be Reached:*

3. Fuel valve . . . . . OFF
4. POWER lever . . . . . MAX
5. Emergency windows . . . . . open if required
6. Land immediately. Refer to 3.7.1 - EMERGENCY LANDING WITH ENGINE OFF.

**CAUTION**

In case of extreme smoke development, the front canopy may be unlatched during flight. This allows it to partially open, in order to improve ventilation. The canopy will remain open in this position. Flight characteristics will not be affected significantly.

*When Airplane Has Stopped:*

7. Canopy . . . . . open
8. Airplane . . . . . evacuate immediately

**END OF CHECKLIST**

Page 3 - 38	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
-------------	--------	-------------	------------------

(b) Electrical Fire with Smoke in Flight

- 1. EMERGENCY switch (if installed) . . . . . ON
- 2. AVIONIC MASTER . . . . . OFF
- 3. ELECTRIC MASTER . . . . . OFF
- 4. Cabin heat . . . . . OFF
- 5. Emergency windows . . . . . open if required
- 6. Land immediately. Refer to 3.7.1 - EMERGENCY LANDING WITH ENGINE OFF.

**WARNING**

Switching OFF the ELECTRIC MASTER will lead to total failure of all electronic and electric equipment. Also affected from this is the attitude gyro (artificial horizon).

- However, by switching the EMERGENCY switch ON, if installed, the emergency battery, if installed will supply power to the attitude gyro (artificial horizon) and the flood light.

In case of extreme smoke development, the front canopy may be unlatched during flight. This allows it to partially open, in order to improve ventilation. The canopy will remain open in this position. Flight characteristics will not be affected significantly.

*When Airplane Has Stopped:*

- 7. Canopy . . . . . open
- 8. Airplane . . . . . evacuate immediately

**END OF CHECKLIST**

### **3.6 GLIDING**

1. Flaps ..... UP
2. Airspeed ..... 88 KIAS

#### **NOTE**

The glide ratio is 9.7; i.e., for every 1000 ft (305 m) of altitude loss the maximum horizontal distance traveled in still air is 1.59 NM (2.94 km). During this the propeller will continue to windmill.

#### **NOTE**

For operation without wheel fairings the glide ratio is reduced to 9.4; i.e., for every 1000 ft (305 m) of altitude loss the maximum horizontal distance traveled in still air is 1.54 NM (2.85 km). During this the propeller will continue to windmill.

**END OF CHECKLIST**

### **3.7 EMERGENCY LANDINGS**

#### **NOTE**

For all airspeed tables in the following sections apply linear variations between weights.

#### **3.7.1 EMERGENCY LANDING WITH ENGINE OFF**

1. ENGINE MASTER ..... check OFF
2. Fuel transfer pump ..... OFF
3. Fuel pumps ..... OFF
4. Fuel valve ..... OFF
5. AVIONIC MASTER ..... OFF
6. Safety harnesses ..... check fastened and tightened

*When Sure of Making Landing Area:*

7. FLAPS ..... T/O or LDG, as required

#### **NOTE**

Extending the flaps to LDG will increase drag and incur a high sink rate. When the landing area can be reached safely, landing with flaps LDG is advisable.

**CONTINUED**

8. Approach speed . . . . . see table below:

**NOTE**

If the landing mass exceeds 1216 kg (2681 lb), the landing constitutes an abnormal operating procedure. Refer to Section 4B.7 - LANDING WITH HIGH LANDING MASS.

<b>Flaps</b>	<b>940 kg (2072 lb)</b>	<b>1000 kg (2205 lb)</b>	<b>1080 kg (2381 lb)</b>	<b>1160 kg (2557 lb)</b>	<b>1216 kg (2681 lb)</b>	<b>up to 1280 kg (2822 lb)</b>
T/O	68 KIAS	70 KIAS	73 KIAS	76 KIAS	77 KIAS	78 KIAS
LDG	66 KIAS	69 KIAS	72 KIAS	74 KIAS	76 KIAS	77 KIAS

9. ELECTRIC MASTER . . . . . OFF

10. Touch down . . . . . lowest practical speed

**END OF CHECKLIST**

**3.7.2 LANDING WITH A DEFECTIVE TIRE ON THE MAIN LANDING GEAR****CAUTION**

A defective (e.g. burst) tire is not usually easy to detect. The damage normally occurs during take-off or landing, and is hardly noticeable during fast taxiing. It is only during the roll-out after landing or at lower taxiing speeds that a tendency to swerve occurs. Rapid and determined action is then required.

1. Advise ATC.
2. Land the airplane at the edge of the runway that is located on the side of the intact tire, so that changes in direction which must be expected during roll-out due to the braking action of the defective tire can be corrected on the runway.
3. Land with one wing low. The wing on the side of the intact tire should be held low.
4. Direction should be maintained using the rudder. This should be supported by use of the brake. It is possible that the brake must be applied strongly - if necessary to the point where the wheel locks. The wide track of the landing gear will prevent the airplane from tipping over a wide speed range. There is no pronounced tendency to tip even when skidding.

**END OF CHECKLIST**

### 3.7.3 LANDING WITH DEFECTIVE BRAKES

In general, a landing on grass is recommended in order to reduce the landing run due to the greater rolling resistance.

#### **WARNING**

If sufficient time is remaining, the risk of fire in the event of a collision can be reduced as follows after a safe touch-down:

- Fuel valve . . . . . OFF
- ENGINE MASTER . . . . . OFF
- Fuel pumps . . . . . OFF
- ELECTRIC MASTER . . . . . OFF

**END OF CHECKLIST**



### 3.8 RECOVERY FROM AN UNINTENTIONAL SPIN

#### CAUTION

Steps 1 to 4 must be carried out **immediately** and **simultaneously**.

1. POWER lever ..... IDLE
2. Ailerons ..... neutral
3. Rudder ..... full deflection against  
direction of spin
4. Elevator (control stick) ..... fully forward

*When Rotation Has Stopped:*

5. Flaps ..... UP
6. Rudder ..... neutral
7. Elevator (control stick) ..... pull carefully
8. Return the airplane from a descending into a normal flight attitude. Do not exceed the 'never exceed speed',  $v_{NE} = 172$  KIAS.

**END OF CHECKLIST**

### **3.9 OTHER EMERGENCIES**

#### **3.9.1 ICING**

##### Unintentional Flight Into Icing Conditions

1. Leave the icing area (by changing altitude or turning back, in order to reach zones with a higher ambient temperature).
2. Pitot heating ..... ON
3. Cabin heat ..... ON
4. Cabin air ..... DEFROST
5. POWER lever ..... increase power, in order to prevent ice build-up on the propeller blades  
apply power changes periodically
  
6. Alternate air ..... OPEN
7. Emergency windows ..... open if required

#### **CAUTION**

Ice build-up increases the stalling speed.

8. ATC ..... advise if an emergency is expected

#### **CAUTION**

When the Pitot heating fails expect loss of airspeed indication.

**END OF CHECKLIST**



**3.9.2 SUSPICION OF CARBON MONOXIDE CONTAMINATION IN THE CABIN**

Carbon monoxide (CO) is a gas which is developed during the combustion process. It is poisonous and without smell. Since it occurs however usually together with flue gases, it can be detected. Increased concentration of carbon monoxide in closed spaces can be fatal. The occurrence of CO in the cabin is possible only due to a defect. If a smell similar to exhaust gases is noticed in the cabin, the following measures should be taken:

- 1. Cabin heat . . . . . OFF
- 2. Ventilation . . . . . open
- 3. Emergency windows . . . . . open
- 4. Forward canopy . . . . . unlatch, push up and lock in 'Cooling Gap' position

**CAUTION**

The maximum demonstrated airspeed for opening the front canopy in flight is 117 KIAS.

**NOTE**

In case of suspicion of carbon monoxide contamination in the cabin, the front canopy may be unlatched during flight. This allows it to partially open, in order to improve ventilation. The canopy will remain open in this position. Flight characteristics will not be affected significantly.

**END OF CHECKLIST**

**3.9.3 UNLOCKED DOORS**

1. Airspeed ..... reduce immediately
2. Canopy ..... check visually if closed
3. Rear door ..... check visually if closed

Canopy Unlocked

4. Airspeed ..... below 140 KIAS
5. Land at next suitable airfield.

**END OF CHECKLIST**

Rear Door Unlocked

4. Airspeed ..... below 140 KIAS
5. Land at the next suitable airfield.

**WARNING**

Do not try to lock the rear door in flight. The safety latch may disengage and the door opens. Usually this results in a separation of the door from the airplane.

**NOTE**

If the rear door has been lost the airplane can be safely flown to the next suitable airfield.

**END OF CHECKLIST**

## CHAPTER 4A

# NORMAL OPERATING PROCEDURES

	Page
4A.1 INTRODUCTION .....	4A-2
4A.2 AIRSPEEDS FOR NORMAL OPERATING PROCEDURES .....	4A-2
4A.3 FLIGHT CHARACTERISTICS .....	4A-3
4A.4 DAILY CHECK .....	4A-3
4A.5 CHECKLISTS FOR NORMAL OPERATING PROCEDURES ....	4A-4
4A.5.1 PRE-FLIGHT INSPECTION .....	4A-4
4A.5.2 BEFORE STARTING ENGINE .....	4A-12
4A.5.3 STARTING ENGINE .....	4A-14
4A.5.4 BEFORE TAXIING .....	4A-17
4A.5.5 TAXIING .....	4A-19
4A.5.6 BEFORE TAKE-OFF .....	4A-20
4A.5.7 TAKE-OFF .....	4A-25
4A.5.8 CLIMB .....	4A-27
4A.5.9 CRUISE .....	4A-28
4A.5.10 FUEL TRANSFER .....	4A-29
4A.5.11 DESCENT .....	4A-30
4A.5.12 APPROACH & LANDING .....	4A-31
4A.5.13 GO-AROUND .....	4A-33
4A.5.14 AFTER LANDING .....	4A-34
4A.5.15 ENGINE SHUT-DOWN .....	4A-35
4A.5.16 POST FLIGHT INSPECTION .....	4A-36
4A.5.17 PARKING .....	4A-36
4A.5.18 FLIGHT IN RAIN .....	4A-37
4A.5.19 REFUELING .....	4A-37
4A.5.20 FLIGHT AT HIGH ALTITUDE .....	4A-37

## 4A.1 INTRODUCTION

Chapter 4A contains checklists and describes procedures for the normal operation of the airplane.

## 4A.2 AIRSPEEDS FOR NORMAL OPERATING PROCEDURES

### NOTE

For all airspeed tables in the following Sections apply linear variations between weights.

<b>Flight Mass</b>	<b>940 kg (2072 lb)</b>	<b>1080 kg (2381 lb)</b>	<b>1280 kg (2822 lb)</b>
Airspeed for rotation (Take-off run, $v_R$ ) (Flaps T/O)	56 KIAS	60 KIAS	67 KIAS
Airspeed for take-off climb (best rate-of-climb speed $v_Y$ ) (Flaps T/O)	72 KIAS	72 KIAS	72 KIAS
Airspeed for cruise climb (Flaps UP)	88 KIAS	88 KIAS	88 KIAS

<b>Flight Mass</b>	<b>940 kg (2072 lb)</b>	<b>1080 kg (2381 lb)</b>	<b>1216 kg (2681 lb)</b>
Approach speed for normal landing (Flaps LDG)	66 KIAS	72 KIAS	76 KIAS
Minimum speed during go-around (Flaps T/O)	72 KIAS	72 KIAS	72 KIAS

### **4A.3 FLIGHT CHARACTERISTICS**

The DA 40 NG is to be flown with "the feet on the pedals", meaning that coordinated flight in all phases and configurations shall be supported by dedicated use of the rudder and ailerons together.

### **4A.4 DAILY CHECK**

Before the first flight of a day it must be ensured that the following checks are performed:

- On-condition check of the canopy, the rear door for cracks and major scratches.
- On-condition check of the lever arms of the canopy and the hinges of the rear door.
- Visual inspection of the locking bolts for proper movement with no backlash.
- Visual inspection of the rear door safety hook.
- Tire inflation pressure check :     main wheels:   3.3 bar (48 PSI)  
  nose wheel :   3.1 bar (45 PSI)
- Visual inspection of the spinner and its attachment (including screws).

## 4A.5 CHECKLISTS FOR NORMAL OPERATING PROCEDURES

### 4A.5.1 PRE-FLIGHT INSPECTION

#### I. Cabin Check

- a) MET, NAV, Mass & CG . . . . . flight planning completed
- b) Airplane documents . . . . . complete and up-to-date
- c) ELECTRIC MASTER . . . . . OFF, pull out key
- d) ENGINE MASTER . . . . . check OFF
- e) VOTER switch . . . . . check AUTO
- f) Fuel valve . . . . . locked, in NORMAL position
- g) Front canopy & rear door . . . . . clean, undamaged,  
check locking mechanism function
- h) All electrical equipment . . . . . OFF
- i) Circuit breakers . . . . . check all IN (if one has popped:  
investigate)
- j) POWER lever . . . . . check condition, freedom of  
movement, full travel and friction  
adjustment
- k) POWER lever . . . . . IDLE
- l) ELECTRIC MASTER . . . . . ON
- m) Fuel quantity . . . . . check, use alternate mean

#### **NOTE**

If the fuel quantity indicator reads 14 US gal, the correct fuel quantity must be determined with the fuel quantity measuring device. If this measurement is not carried out, the fuel quantity available for flight planning is 14 US gal.

**CONTINUED**

Page 4A - 4	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
-------------	--------	-------------	------------------



- n) Position lights, strobe lights (ACL) . . . . . check OFF
- o) Taxi lights, landing lights . . . . . check OFF
- p) ELECTRIC MASTER . . . . . OFF
- q) Foreign objects . . . . . check
- r) Controls and trim . . . . . free and correct
- s) Baggage . . . . . stowed and secured
- t) Emergency axe (if installed) . . . . . stowed and secured

**END OF CHECKLIST**

II. Walk-Around Check, Visual Inspection

**CAUTION**

A visual inspection means: examination for damage, cracks, delamination, excessive play, load transmission, correct attachment and general condition. In addition control surfaces should be checked for freedom of movement.

**CAUTION**

In low ambient temperatures the airplane should be completely cleared of ice, snow and similar accumulations.

**CAUTION**

Prior to flight, remove such items as control surfaces gust lock, Pitot cover, tow bar, etc.

*1. Left Main Landing Gear:*

- a) Landing gear strut or fairing (if installed) . . . . visual inspection
- b) Wear, tread depth of tire . . . . . check
- c) Tire, wheel, brake . . . . . visual inspection
- d) Brakes . . . . . check for leaks
- e) Slip marks . . . . . visual inspection
- f) Chocks . . . . . remove

**CONTINUED**

Page 4A - 6	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
-------------	--------	-------------	------------------

2. Left Wing:

- a) Entire wing surface ..... visual inspection
- b) Step ..... visual inspection
- █ c) Air intake on lower wing surface ..... visual inspection
- █ d) Winter baffle of air intake on lower
- █ wing surface (if installed) ..... consider removal depending on
- █ outside air temperature and verify
- █ proper mounting
- e) Openings on lower surface ..... check for foreign objects and
- for traces of fuel (if tank is full,
- fuel may spill over through the
- tank vent)
- f) Tank drain ..... drain to check for water and
- sediment (drain until free of
- contamination)
- g) Stall warning ..... check function (suction)
- h) Tank filler ..... check closed
- (for fuel qty. check use
- alternate means)
- i) Tank air outlet in lower surface ..... visual inspection
- █ j) Pitot probe ..... clean, orifices clear, attachment
- █ secure (no loose or missing screws)
- k) Landing/taxi light ..... visual inspection
- l) Winglet ..... visual inspection
- m) Position light, strobe light (ACL) ..... visual inspection
- n) Tie-down ..... check, clear
- █ o) 2 stall strips on wing ..... visual inspection
- p) Aileron and linkage ..... visual inspection
- q) Aileron hinges and safety pin ..... visual inspection

**CONTINUED**

- r) Foreign objects in aileron paddle . . . . . visual inspection
- s) Trim tab . . . . . visual inspection
- t) Flap and linkage . . . . . visual inspection
- u) Flap hinges and safety pin . . . . . visual inspection
- v) Static discharger . . . . . visual inspection
- w) Fuel cooler inlet baffle (if installed) . . . . . verify that the outside air temperature permits the use
- x) Fuel cooler inlet baffle (if installed) . . . . . check for improper mounting or obvious damage

*3. Fuselage, Left Side:*

- a) Canopy, left side . . . . . visual inspection
- b) Door lock (if installed) . . . . . unlocked, key removed
- c) Rear cabin door & window . . . . . visual inspection
- d) Fuselage skin . . . . . visual inspection
- e) Antennas . . . . . visual inspection
- f) Static source . . . . . check for blockage

*4. Empennage:*

- a) Stabilizers and control surfaces . . . . . visual inspection
- b) Hinges . . . . . visual inspection
- c) Elevator trim tab . . . . . visual inspection, check for movement and safety wire
- d) Rudder tab . . . . . visual inspection
- e) Tie-down . . . . . check, clear
- f) Tail skid and lower fin . . . . . visual inspection
- g) Static dischargers . . . . . visual inspection

**CONTINUED**

### 5. Fuselage, Right Side:

- a) Fuselage skin . . . . . visual inspection
- b) Static source . . . . . check for blockage
- c) Rear window . . . . . visual inspection
- d) Canopy, right side . . . . . visual inspection

### 6. Right Wing:

- a) Flap and linkage . . . . . visual inspection
- b) Flap hinges and safety pin . . . . . visual inspection
- c) Aileron and linkage . . . . . visual inspection
- d) Aileron hinges and safety pin . . . . . visual inspection
- e) Foreign objects in aileron paddle . . . . . visual inspection
- f) Wing let . . . . . visual inspection
- g) Position light, strobe light (ACL) . . . . . visual inspection
- h) Tie-down . . . . . check, clear
- i) Entire wing surface . . . . . visual inspection
- j) 2 stall strips on wing . . . . . visual inspection
- k) Tank air outlet in lower surface . . . . . visual inspection
- l) Tank filler . . . . . visual check (for fuel qty. check use alternate means)
- m) Openings on lower surface . . . . . check for foreign objects and for traces of fuel (if tank is full, fuel may spill over through the tank vent)
- n) Tank drain . . . . . drain to check for water and sediment (drain until free of contamination)
- o) Step . . . . . visual inspection
- p) Static discharger . . . . . visual inspection

**CONTINUED**

7. *Right Main Landing Gear:*

- a) Landing gear strut or fairing (if installed) . . . . visual inspection
- b) Wear, tread depth of tires . . . . . check
- c) Tire, wheel, brake . . . . . visual inspection
- d) Brakes . . . . . check for leaks
- e) Slip marks . . . . . visual inspection
- f) Chocks . . . . . remove

8. *Front Fuselage:*

- a) Engine oil level . . . . . check dipstick  
(inspection door on left side)
- b) Gearbox oil level . . . . . check visually  
(inspection door on left side)
- c) Cowling . . . . . visual inspection
- d) 4 air intakes on front cowling . . . . . check
- e) 2 air intakes on RH fuselage and cowling . . . check
- f) 1 air intake on LH fuselage . . . . . check
- g) Propeller . . . . . visual inspection

**WARNING**

Never rotate the propeller by hand.

- f) Spinner including attachment screws . . . . . visual inspection
- g) Nose landing gear strut . . . . . visual inspection
- h) Tie-down (if installed) . . . . . check, clear
- i) Tire and wheel . . . . . visual inspection,  
check slip marks

**CONTINUED**

Page 4A - 10	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
--------------	--------	-------------	------------------

- j) Wear, tread depth of tire ..... check
- █ k) Wheel fairing (if installed) ..... visual inspection
- l) Tow bar ..... removed
- m) Chocks ..... remove
- n) Exhaust ..... visual inspection

**WARNING**

The exhaust can cause burns when it is hot.

*Underside:*

- p) Antennas ..... visual inspection
- q) Gascolator ..... pull down on drain to check for  
water and sediment (drain until  
free of contamination)
- r) Venting pipes ..... check for blockage
- s) Fuselage underside ..... check for excessive contamination  
particularly by oil, fuel or other fluids

**END OF CHECKLIST**

**4A.5.2 BEFORE STARTING ENGINE**

1. Pre-flight inspection . . . . . complete
2. Rudder pedals . . . . . adjusted and locked
3. Passengers . . . . . instructed
4. Safety harnesses . . . . . all fastened
5. Rear door . . . . . closed and locked
6. Door lock (if installed) . . . . . unlocked, key removed
7. Front canopy . . . . . Position 1 or 2 (“cooling gap”)
8. Canopy lock (if installed) . . . . . unlocked, key removed

**CAUTION**

When operating the canopy, pilots / operators are to ensure that there are no obstructions between the canopy and the mating frame, for example seat belts, clothing, etc. When operating the locking handle do NOT apply undue force.

**NOTE**

A slight downward pressure on the canopy may be required to ease the handle operation.

9. Parking brake . . . . . set
10. Flight controls . . . . . free movement
11. Trim wheel . . . . . T/O
12. POWER lever . . . . . check IDLE
13. Friction device on POWER lever . . . . . adjusted
14. Alternate air . . . . . check CLOSED
15. Alternate static valve . . . . . check CLOSED

**CONTINUED**

Page 4A - 12	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
--------------	--------	-------------	------------------



- 16. VOTER switch . . . . . check AUTO
- 17. Fuel pumps . . . . . check OFF
- 18. AVIONIC MASTER . . . . . check OFF
- 19. ELECTRIC MASTER . . . . . ON
- █ 20. G1000 (if installed) . . . . . wait until power-up completed.  
Press ENT on MFD to  
acknowledge

**NOTE**

- █ If the G1000 avionics system is installed, the engine instruments are only available on the MFD after item 20 has been completed.
- █ 21. White Wire annunciator panel (if installed) . . . check and press acknowledge button
- █ 22. COOL LVL caution on G1000 (if installed) or  
█ WATERLEV caution on SED (if installed) . . check OFF
- 23. Fuel temperature . . . . . check

**WARNING**

Never rotate the propeller by hand.

**END OF CHECKLIST**

**4A.5.3 STARTING ENGINE**

**CAUTION**

Do not operate the engine starter motor for more than 10 seconds, because of possible overheating of the starter motor.

- If the STARTER annunciation on the G1000 (if installed) or START on the White Wire annunciator panel (if installed) comes on after the engine has started and the START KEY has been released, set the ENGINE MASTER to OFF and investigate the problem.

**WARNING**

If the oil pressure has not moved from the red range within 3 seconds after starting, set the ENGINE MASTER switch to OFF and investigate problem.

**NOTE**

- At low ambient temperatures it is possible that the engine will not start at the first attempt. In this case wait 60 seconds between the start attempts.

1. Strobe lights (ACL) . . . . . ON
2. ENGINE MASTER . . . . . ON

**CONTINUED**

- 3. Annunciators / GLOW ON (if G1000 is installed) or GLOW (if White Wire annunciator panel is installed) . . . . . check ON

**NOTE**

GLOW ON (if G1000 is installed) or GLOW (if White Wire annunciator panel is installed) is indicated only when the engine is cold.

- 4. Annunciators / engine indications . . . . . check

**WARNING**

Before starting the engine the pilot must ensure that the propeller area is free, and no persons can be endangered.

*After the GLOW ON (if G1000 is installed) or GLOW (if White Wire annunciator panel is installed) indication is extinguished:*

- 5. START KEY . . . . . START as required / release when engine has started.
- 6. Annunciators / engine indications . . . . . check OK/normal range
- 7. Annunciators / STARTER (if G1000 is installed) or START (if White Wire annunciator panel is installed) . . . check OFF

**CONTINUED**

- 8. Annunciators / Oil pressure ..... check OK
- 9. Circuit breakers ..... check all IN
- 10. Idle RPM ..... check, 710 ±30 RPM  
(above 7,000 ft pressure altitude  
idle RPM might be higher)
- 11. Warm up ..... IDLE for 2 minutes, then  
at 50% load until:  
oil temperature  
reaches 50°C (122°F)  
and the coolant temperature  
reaches 60 °C (140°F)

**END OF CHECKLIST**

**4A.5.4 BEFORE TAXIING**

- 1. AVIONIC MASTER ..... ON
- 2. Electrical equipment ..... ON as required
- 3. Flight instruments and avionics ..... set as required
- 4. Flood light ..... ON, test function, as required
- 5. Pitot heating ..... ON, check annunciation and observe an increase in alternator load
- 6. Pitot heating ..... OFF
- 7. Strobe lights (ACLs) ..... check ON
- 8. Position lights, landing and taxi lights ..... as required

**CAUTION**

When taxiing at close range to other airplanes, or during night flight in clouds, fog or haze, the strobe lights should be switched OFF. The position lights must always be switched ON during night flight.

- 9. Primary flight display (PFD) (if G1000 and autopilot GFC 700 are installed) ..... NO AUTOPILOT ANNUNCIATIONS
  - 10. Autopilot disconnect tone (if autopilot GFC 700 is installed) ..... NOTE

**CONTINUED**

**NOTE**

- If the G1000 avionics system and the autopilot GFC 700 are installed, the AFCS automatically conducts a preflight self-test upon initial power application. The preflight test is indicated by a white boxed PFT on the PFD. Upon successful completion of the preflight test, the PFT is removed, the red AFCS annunciation is removed, and the autopilot disconnect tone sounds. If AFCS annunciation remains on or a failure of the preflight test is indicated terminate flight preparation and investigate the problem.
  
- 11. MANUAL ELECTRIC TRIM - TEST as follows (if G1000 and autopilot GFC 700 are installed):  
  
Press the AP DISC button down and hold while commanding trim.  
Manual electric trim should not operate either nose up or nose down.
  
- 12. AUTOPILOT (if G1000 and autopilot GFC 700 are installed) . . . . . engage by pressing AP button
  
- 13. AP DISC switch (if G1000 and autopilot GFC 700 are installed) . . . . . press. verify that the autopilot disconnects, check tone
  
- 14. TRIM . . . . . set to take-off position manually

**END OF CHECKLIST**

**4A.5.5 TAXIING**

1. Parking brake . . . . . release
2. Brakes . . . . . test
3. Flight instrumentation and avionics . . . . . check for correct indications
4. Fuel pumps . . . . . check OFF

**CAUTION**

When taxiing on a poor surface select the lowest possible RPM to avoid damage to the propeller from stones or similar items.

**END OF CHECKLIST**

**4A.5.6 BEFORE TAKE-OFF**

1. Position airplane into wind if possible.
2. Parking brake . . . . . set
3. Safety harnesses . . . . . fastened
4. Rear door . . . . . check closed and locked

**CAUTION**

When operating the canopy, pilots/operators must ensure that there are no obstructions between the canopy and the mating frame, for example seat belts, clothing, etc. When operating the locking handle do NOT apply undue force.

A slight downward pressure on the canopy may be required to ease the handle operation.

5. Front canopy . . . . . closed and locked
6. Door warning (DOOR OPEN (if G1000 is installed) DOORS (if White Wire annunciator panel is installed) . . . . . check no indication
7. Annunciators / engine indications . . . . . check OK / normal range  
(except oil pressure may be in the yellow range with a warm engine and POWER lever set to IDLE)
8. Circuit breakers . . . . . check pressed in
9. Longitudinal trim . . . . . set T/O
10. Fuel valve . . . . . check NORMAL
11. FLAPS . . . . . check function & indicator / set T/O
12. Flight controls . . . . . unrestricted free movement, correct sense

**CONTINUED**



- 13. Pitot heating . . . . . ON, if required
- 14. Landing light . . . . . ON, if required

*ECU / Fuel Pump Test Sequence:*

**CAUTION**

| If the ECU A/B FAIL (if G1000 is installed) or ECU A/B (if  
 | White Wire annunciator panel is installed) indicators do not  
 illuminate during the test sequence there is a malfunction in  
 the engine control system. Terminate flight preparation.

| The whole test procedure must be completed without any  
 | error (ECU A/B FAIL (if G1000 is installed) or ECU A/B (if  
 | White Wire annunciator panel is installed) extinguished after  
 test completion). In case the test procedure aborts with an  
 | error indication (one or both ECU A/B FAIL (if G1000 is  
 | installed) or ECU A/B (if White Wire annunciator panel is  
 | installed) indicators remain ON) terminate flight preparation,  
 even if the engine seems to run smoothly after the test  
 procedure.

**CAUTION**

During the test sequence the engine will produce thrust therefore the parking brake must be set.

**CONTINUED**

**NOTE**

The engine oil temperature has to be in the green range before starting the test sequence. Releasing the ECU TEST BUTTON or manipulating the POWER lever before the test sequence is completed will abort the test sequence. During the following ECU and fuel pump test, a shake of the engine might occur.

1. POWER lever . . . . . IDLE
2. Propeller RPM . . . . . check below 1000 RPM
3. Fuel pumps . . . . . check OFF
4. VOTER switch . . . . . check AUTO

**NOTE**

If the VOTER switch is not in the AUTO position, the ECU test will not start.

5. All engine temperatures . . . . . check in the green range
6. Parking brake . . . . . check set
7. ECU TEST button . . . . . press and hold

**NOTE**

The ECU test consists of the following sequence: the propeller RPM will increase to above 1900 RPM. This is followed by a slight RPM drop, than a recovery before returning to idle RPM. At this point the ECU switches back to the other ECU channel and the sequence is repeated. At the end of the test, the control of the engine is returned to the initially active ECU channel. A slight shake of the engine may occur during ECU switching.

**CONTINUED**

Page 4A - 22	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
--------------	--------	-------------	------------------

- 8. ECU A/B FAIL (if G1000 is installed) or  
ECU A/B (if White Wire annunciator  
panel is installed) lights ..... verify both OFF

Test sequence completed.

- 9. ECU TEST button ..... release

**NOTE**

By switching between ECU A and B the two independent electrical fuel pumps are switched over as well.

- 10.VOTER switch ..... ECU A
- 11.Engine ..... check running without a change  
(shake may occur)
- 12.VOTER switch ..... AUTO
- 13.Engine ..... check running without a change  
(shake may occur)
- 14.VOTER switch ..... ECU B
- 15.Engine ..... check running without a change  
(shake may occur)
- 16.VOTER switch ..... AUTO

**CAUTION**

Running the engine with the VOTER switch on ECU A or ECU B, other than for this test or in an emergency is prohibited. The engine control system redundancy is only given with the VOTER switch set to AUTO.

**CONTINUED**

*Available Power Check:*

1. POWER lever . . . . . MAX for 10 seconds
2. Annunciators . . . . . check OK / normal range
3. Instruments . . . . . check within normal range
4. RPM . . . . . stabilizes at 2200 to 2300 RPM
5. LOAD indication . . . . . stabilizes at 88% to 100%

**CAUTION**

The load indications in the table below are minimum values to be indicated with the airplane stationary in no wind conditions. If the engine does not stabilize at the target RPM and the required load indication, terminate flight preparation.

Altitude [ft]	OAT								
	-35°C -31°F	-20°C -4°F	-10°C 14°F	0°C 32°F	10°C 50°F	20°C 68°F	30°C 86°F	40°C 104°F	50°C 122°F
<b>0</b>							95%	92%	90%
<b>2000</b>							95%	92%	/
<b>4000</b>	96%						95%	92%	/
<b>6000</b>							95%	92%	/
<b>8000</b>							95%	94%	91%
<b>10000</b>				94%	93%	91%	88%	/	/

6. POWER lever . . . . . IDLE
7. Engine instruments . . . . . check in green range

**NOTE**

With the POWER lever in IDLE the oil pressure may be in the low yellow range. This is acceptable to continue flight.

8. Fuel pumps . . . . . ON
9. Parking brake . . . . . release

**END OF CHECKLIST**

**4A.5.7 TAKE-OFF**

Normal Take-Off Procedure

1. Transponder . . . . . as required
2. POWER lever . . . . . MAX

**WARNING**

The proper performance of the engine at MAX should be checked early in the take-off procedure, so that the take-off can be aborted if necessary.

3. Elevator . . . . . neutral
4. Rudder . . . . . maintain direction

**NOTE**

In strong crosswinds steering can be augmented by use of the toe brakes. It should be noted, however, that this method increases the take-off roll, and should not generally be used.

**NOTE**

For soft field take-off hold elevator back pressure during take-off roll until nose lift-off. Accelerate to initial climb speed after lift-off.

5. Nose wheel lift-off ( $v_R$ ) . . . . . see table below:

<b>940 kg (2072 lb)</b>	<b>1000 kg (2205 lb)</b>	<b>1100 kg (2425 lb)</b>	<b>1200 kg (2646 lb)</b>	<b>1280 kg (2822 lb)</b>
56 KIAS	58 KIAS	61 KIAS	64 KIAS	67 KIAS

**CONTINUED**

**NOTE**

A spurious activation of the stall warning during take-off in crosswind conditions, operation on unpaved surfaces and gusty conditions may occur.

6. Airspeed for initial climb . . . . . see table below:

940 kg (2072 lb)	1000 kg (2205 lb)	1100 kg (2425 lb)	1200 kg (2646 lb)	1280 kg (2822 lb)
62 KIAS	65 KIAS	67 KIAS	70 KIAS	72 KIAS

*Above a Safe Height:*

- 7. Landing light . . . . . OFF
- 8. Fuel pumps . . . . . OFF
- 9. POWER lever . . . . . reduce to 92% load

**END OF CHECKLIST**

#### **4A.5.8 CLIMB**

##### Procedure for Take-off Climb

1. Flaps ..... T/O
2. Airspeed ..... 72 KIAS
3. POWER lever ..... 92% or maximum 2100 RPM
4. Annunciations / engine indications ..... monitor
5. Rudder ..... as required

#### **CAUTION**

If the oil temperature and/or coolant temperature reaches the yellow range during climb, flight should be continued with an airspeed increased by 5 kt and power reduced by 10 % (reduced climb rate) for better engine cooling.

#### **NOTE**

Operating in the gearbox cautionary range is permitted. However, prolonged operation is not recommended.

#### **END OF CHECKLIST**

##### Cruise Climb

1. Flaps ..... UP
2. Airspeed ..... 88 KIAS
3. POWER lever ..... 92% or maximum 2100 RPM
4. Annunciations / engine indications ..... monitor
5. Rudder ..... as required

#### **END OF CHECKLIST**

**4A.5.9 CRUISE**

1. Flaps ..... UP
2. POWER lever ..... up to 92% or maximum 2100 RPM
3. Trim ..... as required
4. Fuel transfer ..... repeat as required (in accordance with 4A.5.10 - FUEL TRANSFER)

**NOTE**

The engine manufacturer recommends a cruise power setting of 75 %.

**NOTE**

Proper operation of the transfer pump must be checked by monitoring the fuel quantities (increasing in the MAIN tank, decreasing in the AUX tank, approx. 1 US gal per minute).

**END OF CHECKLIST**



**4A.5.10 FUEL TRANSFER**
**CAUTION**

During normal operation fuel is taken from the main tank only. Therefore fuel must be transferred from the auxiliary tank to the main tank by activating the fuel transfer pump. The transfer rate is approximately 60 US gal/h (227 liter/h).

1. Fuel transfer switch ..... ON

**NOTE**

The transfer pump turns off automatically to avoid overfilling the main tank. The switch remains in its position. If the pump is not turned off, it will continue pumping each time the fuel level in the main tank drops, but only as long as there is fuel in the auxiliary tank. The fuel transfer status light is illuminated only while the pump is running.

2. Fuel transfer switch ..... OFF, if required

**NOTE**

If the fuel transfer status light starts to blink, the fuel transfer pump must be switched off.

**END OF CHECKLIST**

**4A.5.11 DESCENT**

1. POWER lever ..... as required
2. Airspeed ..... as required
3. Trim ..... as required
- 4. Annunciations / engine indications ..... monitor

**END OF CHECKLIST**

**4A.5.12 APPROACH & LANDING**

*Approach:*

**NOTE**

If the landing mass exceeds 1216 kg (2681 lb), the landing constitutes an abnormal operating procedure. Refer to Section 4B.7 - LANDING WITH HIGH LANDING MASS.

1. Safety harnesses . . . . . check fastened and tightened
2. Controls . . . . . no interference by foreign objects
3. Landing light . . . . . as required
4. Fuel pumps . . . . . ON
5. Parking brake . . . . . check released
6. Trim . . . . . as required

*Before Landing:*

7. Airspeed . . . . . see table below:

Flaps	940 kg (2072 lb)	1000 kg (2205 lb)	1080 kg (2381 lb)	1160 kg (2557 lb)	1216 kg (2681 lb)
T/O	68 KIAS	70 KIAS	73 KIAS	76 KIAS	77 KIAS
LDG	66 KIAS	69 KIAS	72 KIAS	74 KIAS	76 KIAS

8. FLAPS . . . . . as required
9. POWER lever . . . . . as required
10. Trim . . . . . as required

**CONTINUED**

11. Final approach speed ..... see table below:

Flaps	940 kg (2072 lb)	1000 kg (2205 lb)	1080 kg (2381 lb)	1160 kg (2557 lb)	1216 kg (2681 lb)
LDG	66 KIAS	69 KIAS	72 KIAS	74 KIAS	76 KIAS

**NOTE**

Higher approach speeds result in a significantly longer landing distance during flare.

**CAUTION**

In conditions such as (e.g.) strong wind, danger of wind shear or turbulence a higher approach speed should be selected.

**END OF CHECKLIST**

**4A.5.13 GO-AROUND**

1. POWER lever ..... MAX
2. Airspeed ..... 72 KIAS
3. Flaps ..... T/O

*Above a Safe Height:*

4. Airspeed ..... 88 KIAS
5. Flaps ..... UP

**END OF CHECKLIST**

**4A.5.14 AFTER LANDING**

1. POWER lever ..... IDLE
2. Brakes ..... as required
3. Transponder ..... OFF / STBY
4. Pitot heating ..... OFF
5. Avionics ..... as required
6. Lights ..... as required
7. Flaps ..... UP
8. Fuel pumps ..... OFF

**END OF CHECKLIST**

**4A.5.15 ENGINE SHUT-DOWN**

- 1. Parking brake . . . . . set
- 2. POWER lever . . . . . up to 10 % load for 1 minute
- 3. Engine indications . . . . . check
- 4. ELT . . . . . check not transmitting on  
121.5 MHz
- 5. AVIONIC MASTER . . . . . OFF
- 6. Electrical consumers . . . . . OFF
- 7. ENGINE MASTER . . . . . OFF
- 8. Strobe . . . . . OFF

**CAUTION**

After turning the ENGINE MASTER OFF, wait until the engine indications on the G1000 MFD (if installed) or MED (if installed) disappear prior to switching the ELECTRIC MASTER OFF. This ensures that engine and flight data can be written to non-volatile memory before removing electrical power.

- 9. ELECTRIC MASTER . . . . . OFF

**CAUTION**

Do not shut down an engine by placing the FUEL VALVE in the OFF position. The high pressure fuel pump can otherwise be damaged.

**NOTE**

Before shut-down the engine must run for at least 1 minute with the POWER lever set up to 10% load to avoid heat damage of the turbo charger.

**END OF CHECKLIST**

**4A.5.16 POST FLIGHT INSPECTION**

1. Record any problem found in flight and during the post-flight check in the log book.
2. Park the airplane.
3. If necessary, moor the airplane.

**END OF CHECKLIST**

**4A.5.17 PARKING**

1. Parking brake ..... release, use chocks
2. Airplane ..... moor, if unsupervised for  
extended period
3. Pitot probe ..... cover

**END OF CHECKLIST**



**4A.5.18 FLIGHT IN RAIN****NOTE**

Performance deteriorates in rain; this applies particularly to the take-off distance and to the maximum horizontal speed. The effect on the flight characteristics is minimal. Flight through very heavy rain should be avoided because of the associated visibility problems.

**4A.5.19 REFUELING****CAUTION**

Before refueling, the airplane must be connected to electrical ground. Grounding points: unpainted areas on steps, left and right.

**4A.5.20 FLIGHT AT HIGH ALTITUDE**

At high altitudes the provision of oxygen for the occupants is necessary. Legal requirements for the provision of oxygen should be adhered to.

Also see Section 2.11 - OPERATING ALTITUDE.

Intentionally left blank.

## CHAPTER 4B

### ABNORMAL OPERATING PROCEDURES

	Page
4B.1 PRECAUTIONARY LANDING .....	4B-2
4B.2 INSTRUMENT INDICATIONS OUTSIDE OF GREEN RANGE ...	4B-4
4B.2.1 RPM .....	4B-4
4B.2.2 COOLANT TEMPERATURE .....	4B-5
4B.2.3 OIL TEMPERATURE .....	4B-6
4B.2.4 OIL PRESSURE .....	4B-7
4B.2.5 GEARBOX TEMPERATURE .....	4B-8
4B.2.6 FUEL TEMPERATURE .....	4B-9
4B.2.7 VOLTAGE .....	4B-10
4B.2.8 CURRENT .....	4B-10
4B.3 CAUTION-ALERTS .....	4B-11
4B.3.1 ECU A FAILURE .....	4B-11
4B.3.2 ECU B FAILURE .....	4B-12
4B.3.3 FUEL QUANTITY LOW .....	4B-13
4B.3.4 COOLANT LEVEL .....	4B-15
4B.3.5 PITOT HEATING FAILURE .....	4B-16
4B.3.6 ENGINE CAUTION (IF WHITE WIRE ANNUNCIATOR PANEL IS INSTALLED) .....	4B-16
4B.4 CANOPY IN COOLING GAP POSITION .....	4B-17
4B.5 FAILURES IN FLAP OPERATING SYSTEM .....	4B-18
4B.6 LIGHTNING STRIKE .....	4B-20
4B.7 LANDING WITH HIGH LANDING MASS .....	4B-21

## **4B.1 PRECAUTIONARY LANDING**

### **NOTE**

A landing of this type is only necessary when there is a reasonable suspicion that due to operational factors such as fuel shortage, weather conditions, etc. the possibility of endangering the airplane and its occupants by continuing the flight cannot be excluded. The pilot is required to decide whether or not a controlled landing in a field represents a lower risk than the attempt to reach the nearest airfield under all circumstances.

### **NOTE**

If no level landing area is available, a landing on an upward slope should be sought.

1. Select appropriate landing area.
2. Consider wind.
3. Approach:

If possible, the landing area should be overflown at a suitable height in order to recognize obstacles. The degree of offset at each part of the circuit will allow the wind speed and direction to be assessed.

4. ATC ..... advise

Perform procedures according to Normal Procedures 4A.5.12 - APPROACH & LANDING.

5. Touchdown ..... with the lowest possible airspeed

**CONTINUED**

Page 4B - 2	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
-------------	--------	-------------	------------------

**CAUTION**

If sufficient time is remaining, the risk of fire in the event of a collision with obstacles can be reduced as follows after a safe touch-down:

- 6. ENGINE MASTER ..... OFF
- 7. Fuel valve ..... OFF
- 8. ELECTRIC MASTER ..... OFF

**END OF CHECKLIST**

## I **4B.2 INSTRUMENT INDICATIONS OUTSIDE OF GREEN RANGE**

### **4B.2.1 RPM**

#### High RPM

1. Reduce power.
2. Keep RPM within the green range using the POWER lever.

#### **NOTE**

An RPM in the yellow range is permissible for up to 5 minutes if required, e.g. for go-around or take-off.

If the above mentioned measures do not solve the problem refer to Section 3.3.6 - DEFECTIVE RPM REGULATING SYSTEM.

3. Land at the nearest suitable airfield.

**END OF CHECKLIST**

**4B.2.2 COOLANT TEMPERATURE****(a) High Coolant Temperature**

Proceed according to:

Section 3.2.1 - ENGINE TEMPERATURE.

**(b) Low Coolant Temperature**

- - Check for COOL LVL (if G1000 is installed) or WATERLEV (if SED is installed) caution message (low coolant level).

**NOTE**

During an extended descent from high altitudes with a low power setting coolant temperature may decrease. In this case an increase in power and a decrease in airspeed can help.

- *COOL LVL (if G1000 is installed) or WATERLEV (if SED is installed) Caution Message Displayed:*

- Reduce power.
- Expect loss of coolant.

**WARNING**

A further decrease in coolant temperature must be expected. Prepare for an engine failure in accordance with Section 3.3.3 - ENGINE TROUBLESHOOTING IN FLIGHT.

**END OF CHECKLIST**

**4B.2.3 OIL TEMPERATURE**

a) High Oil Temperature

Proceed according to:

Section 3.2.2 - OIL TEMPERATURE.

(b) Low Oil Temperature

**NOTE**

During an extended descent from high altitudes with a low power setting oil temperature may decrease. In this case an increase in power can help.

- Increase power.
- Reduce airspeed.

**END OF CHECKLIST**



**4B.2.4 OIL PRESSURE****(a) High Oil Pressure**

- Check oil temperature.
- Check coolant temperature.

**|** *If the Temperatures are in the Lower Green Range:*

- |** - Increase power  
**|** - Reduce airspeed  
**|**

**|** *If the Oil Pressure Is Still Outside of the Green Range:*

**WARNING**

**|** Land at the nearest suitable airfield. Prepare for an engine  
**|** failure in accordance with Section 3.3.4 - ENGINE FAILURE  
**|** IN FLIGHT.  
**|**

*If the Temperatures are Outside of the Green Range:*

- Reduce power.

**WARNING**

Land at the nearest suitable airfield. Prepare for an engine  
failure in accordance with Section 3.3.4 - ENGINE FAILURE  
IN FLIGHT.

**(b) Low Oil Pressure**

Proceed according to:

Section 3.2.3 - OIL PRESSURE.

**END OF CHECKLIST**

#### **4B.2.5 GEARBOX TEMPERATURE**

##### High Gearbox Temperature

Proceed according to:

Section 3.2.4 - GEARBOX TEMPERATURE.

#### **NOTE**

A cautionary (yellow) gearbox temperature range is not imposed by the engine manufacturer. However, there is a delay between power changes and gearbox temperature. Therefore, a cautionary range has been added to the G1000 (if installed) or MED (if installed) gearbox temperature instrument solely to make the pilot attentive to the gearbox temperature approaching the maximum allowable limit. There is no specific time limit associated with operating in the cautionary gearbox temperature range.

**END OF CHECKLIST**

**4B.2.6 FUEL TEMPERATURE****(a) High Fuel Temperature**

Proceed according to:

Section 3.2.5 - L/R FUEL TEMPERATURE.

**(b) Low Fuel Temperature**

- Increase power.
- Reduce airspeed.

**CAUTION**

At low ambient temperature conditions and/or at high airspeeds with low power settings, it can be assumed that the above mentioned procedure will increase the temperature(s). If the fuel temperature does not return to the green range perform a precautionary landing on the nearest suitable airfield. Prepare for an engine failure in accordance with Section 3.3.4 - ENGINE FAILURE IN FLIGHT.

**END OF CHECKLIST**

**4B.2.7 VOLTAGE**

(a) Low Voltage Indication on the Ground with Engine Running

- Terminate flight preparation.

(b) Low Voltage During Flight

1. Circuit breakers . . . . . check
2. Electrical equipment . . . . . OFF if not needed

█ *If Low Voltage Condition Still Exists:*

- Follow procedure in Section 3.2.8 - ALTERNATOR FAIL.

**NOTE**

█ This procedure is applicable if either the voltmeter is out of  
█ the green range or VOLTS LOW (if G1000 is installed) or  
█ LOW VOLTS (if White Wire annunciator panel is installed)  
█ is indicated.

**END OF CHECKLIST**

█ **4B.2.8 CURRENT**

█ This caution is indicated when the consumption of electric power exceeds 60 A.

- █ 1. Electrical equipment . . . . . switch OFF as necessary and  
█ possible to reduce electric load

█ *If the problem does not clear:*

- █ 2. Land on nearest suitable airfield.

█ **END OF CHECKLIST**

Page 4B - 10	Rev. 1	15-Mar-2011	Doc. # 6.01.15-E
--------------	--------	-------------	------------------

**4B.3 CAUTION-ALERTS**

**| 4B.3.1 ECU A FAILURE**

- | \*** Engine ECU A has failed or
- | \*** is being tested during FADEC test procedure before take-off check.

(a) ECU A Caution on the Ground

- Terminate flight preparation.

(b) ECU A Caution During Flight

**NOTE**

In case of a failure in the electronic ECU (Engine Control Unit) 'A' the system automatically switches to ECU 'B'.

1. VOTER switch ..... check AUTO
2. If the ECU caution remains ..... land at the nearest suitable airfield

**NOTE**

If additional engine problems are observed refer to Section 3.3.3 - ENGINE TROUBLESHOOTING IN FLIGHT.

**END OF CHECKLIST**

**I 4B.3.2 ECU B FAILURE**

- I \*** Engine ECU B has failed or
- I \*** is being tested during FADEC test procedure before take-off check.

(a) ECU B Caution on the Ground

- Terminate flight preparation.

(b) ECU B Caution During Flight

**NOTE**

In case of a failure in the electronic ECU (Engine Control Unit) 'B' the system automatically switches to ECU 'A'.

1. VOTER switch . . . . . check AUTO
2. If the ECU caution remains . . . . . land at the nearest suitable airfield

**NOTE**

If additional engine problems are observed refer to Section 3.3.3 - ENGINE TROUBLESHOOTING IN FLIGHT.

**END OF CHECKLIST**

**4B.3.3 FUEL QUANTITY LOW**

Left fuel quantity is low.

1. Fuel transfer pump . . . . . ON
2. Fuel quantity . . . . . check

**CAUTION**

As soon as the amount of usable fuel in the main tank is low, a caution message is displayed. The indication is calibrated for straight and level flight. The caution message may be triggered during turns which are flown with slip, or while taxiing in curves.

*If FUEL LOW (if G1000 is installed) or LOW FUEL (if White Wire Annunciator Panel is installed) Caution Is Caused By Un-Coordinated Flight:*

**CAUTION**

Prolonged un-coordinated flight can cause fuel starvation to the engine resulting in a loss of power.

3. Return to coordinated flight (not more than approx. half a ball sideslip, 3° - 5° bank)

*If the Caution Does Not Extinguish:*

- Expect loss of fuel.
4. Fuel valve . . . . . EMERGENCY
  5. Fuel transfer pump . . . . . OFF

**CONTINUED**

Doc. # 6.01.15-E	Rev. 1	15-Mar-2011	Page 4B - 13
------------------	--------	-------------	--------------

*If the Caution Does Not Extinguish:*

- Be prepared for an emergency landing.
- Proceed in accordance with Section 3.7.1 - EMERGENCY LANDING WITH ENGINE OFF.

**WARNING**

If air enters the high pressure fuel pump (e.g. empty fuel tank), an inspection of the pump is necessary prior to next flight.

**END OF CHECKLIST**



**I 4B.3.4 COOLANT LEVEL****I** Engine coolant level is low.

A low coolant caution alert may indicate a loss of coolant. This will subsequently lead to decreased engine cooling capability/loss of engine power due to engine failure.

1. Annunciations / engine instruments . . . . . monitor

Refer to Section 4B.2.2 - COOLANT TEMPERATURE.

**NOTE**

The indication is calibrated for straight and level flight. The caution message may be triggered during turns which are flown with slip, or while taxiing in curves.

**END OF CHECKLIST**

**4B.3.5 PITOT HEATING FAILURE**

Pitot heating system has failed.

*If in Icing Conditions:*

1. Expect loss of airspeed indication.
2. Leave icing zone / refer to Section 3.9.1 - ICING.

**END OF CHECKLIST**

**4B.3.6 ENGINE CAUTION (IF WHITE WIRE ANNUNCIATOR PANEL IS INSTALLED)**

Engine limit exceeded.

1. Engine indications ..... check
2. Acknowledge button ..... press

**NOTE**

If an indication is near the end of the green range, it may happen that it switches over to the yellow or red range for a short time. This will also cause the ENGINE caution light to illuminate.

**NOTE**

If an indication is outside of the green range, proceed in accordance with 4B.2 - INSTRUMENT INDICATIONS OUTSIDE OF THE GREEN RANGE.

**END OF CHECKLIST**

**4B.4 CANOPY IN COOLING GAP POSITION****CAUTION**

If take-off was inadvertently done with the canopy in the cooling gap position, do not attempt to close the canopy in flight. Land the airplane and close the canopy on ground.

**4B.5 FAILURES IN FLAP OPERATING SYSTEM**

Failure in Position Indication or Function

1. FLAPS position . . . . . check visually
2. Airspeed . . . . . keep in white range  
(max. 98 KIAS)
3. FLAPS switch . . . . . re-check all positions

Modified Approach Procedure Depending on the Available Flap Setting

**NOTE**

For landing distances with an abnormal flap position refer to 5.3.12 - LANDING DISTANCE - ABNORMAL FLAP POSITION.

(a) *Only UP Available:*

Airspeed . . . . . see table below:

<b>940 kg (2072 lb)</b>	<b>1000 kg (2205 lb)</b>	<b>1080 kg (2381 lb)</b>	<b>1160 kg (2557 lb)</b>	<b>1216 kg (2681 lb)</b>	<b>up to 1280 kg (2822 lb)</b>
71 KIAS	73 KIAS	78 KIAS	81 KIAS	82 KIAS	83 KIAS

**NOTE**

If the landing mass exceeds 1216 kg (2681 lb), the landing constitutes an abnormal operating procedure. Refer to Section 4B.7 - LANDING WITH HIGH LANDING MASS.

Land at a flat approach angle, use POWER lever to control airplane speed and rate of descent.

**CONTINUED**

(b) *Only T/O Available:*

Airspeed ..... see table below:

<b>940 kg (2072 lb)</b>	<b>1000 kg (2205 lb)</b>	<b>1080 kg (2381 lb)</b>	<b>1160 kg (2557 lb)</b>	<b>1216 kg (2681 lb)</b>	<b>up to 1280 kg (2822 lb)</b>
68 KIAS	70 KIAS	73 KIAS	76 KIAS	77 KIAS	78 KIAS

**NOTE**

If the landing mass exceeds 1216 kg (2681 lb), the landing constitutes an abnormal operating procedure. Refer to Section 4B.7 - LANDING WITH HIGH LANDING MASS.

Land at a flat approach angle, use POWER lever to control airplane speed and rate of descent.

(c) *Only LDG Available:*

Perform normal landing.

**END OF CHECKLIST**

## **4B.6 LIGHTNING STRIKE**

1. Airspeed ..... as low as practicable, do not exceed  $v_o$  (refer to Section 2.2)
2. Grasp airplane controls firmly
- 3. Autopilot (if installed) ..... disengage (check)
- 4. PFD (if G1000 is installed) / backup instruments ..... verify periodically
5. Continue flight below  $v_o$  (refer to Section 2.2)
6. Land on the next suitable airfield

### **CAUTION**

Due to possible damage to the airplane obey the following instructions:

- Avoid abrupt or full control surface movements.
- Avoid high g-loads on the airframe.
- Avoid high yaw angles.
- Avoid turbulent air as far as possible (e.g. lee effects).
- Do not fly into areas of known or forecast icing.

**END OF CHECKLIST**

**4B.7 LANDING WITH HIGH LANDING MASS**

**NOTE**

The maximum landing mass given in Chapter 2 is the highest mass for landing conditions at the maximum descent velocity. This velocity was used in the strength calculations to determine the landing gear loads during a particularly hard landing.

Perform landing approach and landing according to Chapter 4A, but maintain an increased airspeed during landing approach.

Approach speed . . . . . 77 KIAS up to 1280 kg (2822 lb),  
flaps LDG

**WARNING**

Damage of the landing gear can result from a hard landing with a flight mass above the maximum landing mass.

**END OF CHECKLIST**

Intentionally left blank.



## CHAPTER 5

# PERFORMANCE

	Page
5.1 INTRODUCTION .....	5-2
5.2 USE OF THE PERFORMANCE TABLES AND DIAGRAMS .....	5-2
5.3 PERFORMANCE TABLES AND DIAGRAMS .....	5-3
5.3.1 AIRSPEED CALIBRATION .....	5-3
5.3.2 FUEL FLOW DIAGRAM .....	5-6
5.3.3 PRESSURE ALTITUDE - DENSITY ALTITUDE .....	5-7
5.3.4 INTERNATIONAL STANDARD ATMOSPHERE .....	5-8
5.3.5 STALLING SPEEDS .....	5-9
5.3.6 WIND COMPONENTS .....	5-11
5.3.7 TAKE-OFF DISTANCE .....	5-12
5.3.8 CLIMB PERFORMANCE - TAKE-OFF CLIMB .....	5-16
5.3.9 CLIMB PERFORMANCE - CRUISE CLIMB .....	5-18
5.3.10 CRUISING (TRUE AIRSPEED TAS) .....	5-20
5.3.11 LANDING DISTANCE - FLAPS LDG .....	5-22
5.3.12 LANDING DISTANCE - ABNORMAL FLAP POSITION ..	5-25
5.3.13 GRADIENT OF CLIMB ON GO-AROUND .....	5-28
5.3.14 GLIDE .....	5-30
5.3.15 APPROVED NOISE DATA .....	5-31

## **5.1 INTRODUCTION**

The performance tables and diagrams on the following pages are presented so that, on the one hand, you can see what performance you can expect from your airplane, while on the other they allow comprehensive and sufficiently accurate flight planning. The values in the tables and the diagrams were obtained in the framework of the flight trials using an airplane and power-plant in good condition, and corrected to the conditions of the International Standard Atmosphere (ISA = 15 °C / 59 °F and 1,013.25 hPa / 29.92 inHg at sea level).

The performance diagrams do not take into account variations in pilot experience or a poorly maintained airplane. The performances given can be attained if the procedures quoted in this manual are applied, and the airplane has been well maintained.

Where appropriate, any flight performance degradation resulting from the absence of wheel fairings is given as a percentage or different value.

## **5.2 USE OF THE PERFORMANCE TABLES AND DIAGRAMS**


In order to illustrate the influence of a number of different variables, the performance data is reproduced in the form of tables or diagrams. These contain sufficiently detailed information so that conservative values can be selected and used for the determination of adequate performance data for the planned flight.

### 5.3 PERFORMANCE TABLES AND DIAGRAMS

#### 5.3.1 AIRSPEED CALIBRATION


## AIRSPEED INDICATOR SYSTEM

FLAPS UP




### AIRSPEED INDICATOR SYSTEM

FLAPS T/O



## AIRSPEED INDICATOR SYSTEM

FLAPS LDG




**5.3.2 FUEL FLOW DIAGRAM**

**NOTE**


The fuel calculations on the FUEL CALC portion of the G1000 MFD do not use the airplane's fuel quantity indicators. The values shown are numbers which are calculated from the last fuel quantity update done by the pilot and actual fuel flow data. Therefore, the endurance and range data is for information only, and must not be used for flight planning.

**DA 40 NG - FUEL FLOW**



### 5.3.3 PRESSURE ALTITUDE - DENSITY ALTITUDE


Conversion from pressure altitude to density altitude.



- Example:
1. Set 1,013.25 hPa on altimeter and read pressure altitude (900 ft).
  2. Establish ambient temperature (+21 °C).
  3. Read off density altitude (1800 ft).

Result: From a performance calculation standpoint the airplane is at 1800 ft.

**5.3.4 INTERNATIONAL STANDARD ATMOSPHERE**





### 5.3.5 STALLING SPEEDS

#### NOTE

Close to a stall, the disturbed air flow has an influence on the airspeed calibration and therefore on the indicated airspeed. Magnitude and direction of the airspeed error is dependent on the flap setting.

Mass 1280 kg (2822 lb)		Bank Angle			
		0°	30°	45°	60°
Flaps	UP	66 KIAS	68 KIAS	74 KIAS	88 KIAS
	T/O	62 KIAS	65 KIAS	71 KIAS	84 KIAS
	LDG	60 KIAS	63 KIAS	69 KIAS	82 KIAS


Mass 1216 kg (2681 lb)		Bank Angle			
		0°	30°	45°	60°
Flaps	UP	64 KIAS	67 KIAS	73 KIAS	87 KIAS
	T/O	60 KIAS	64 KIAS	69 KIAS	82 KIAS
	LDG	59 KIAS	62 KIAS	68 KIAS	81 KIAS

Mass 1080 kg (2381 lb)		Bank Angle			
		0°	30°	45°	60°
Flaps	UP	60 KIAS	63 KIAS	69 KIAS	82 KIAS
	T/O	56 KIAS	60 KIAS	66 KIAS	78 KIAS
	LDG	57 KIAS	59 KIAS	64 KIAS	76 KIAS

Mass 980 kg (2161 lb)		Bank Angle			
		0°	30°	45°	60°
Flaps	UP	57 KIAS	58 KIAS	63 KIAS	75 KIAS
	T/O	54 KIAS	57 KIAS	62 KIAS	74 KIAS
	LDG	55 KIAS	55 KIAS	60 KIAS	71 KIAS

Mass 940 kg (2072 lb)		Bank Angle			
		0°	30°	45°	60°
Flaps	UP	55 KIAS	57 KIAS	62 KIAS	74 KIAS
	T/O	53 KIAS	56 KIAS	61 KIAS	72 KIAS
	LDG	54 KIAS	54 KIAS	58 KIAS	69 KIAS

**5.3.6 WIND COMPONENTS**



Example: Flight direction : 360°  
 Wind : 32°/30 kt  
 Result: Crosswind component : 16 kt  
 Max. demonstrated crosswind component : 25 kt

**5.3.7 TAKE-OFF DISTANCE**

- Conditions:
- POWER lever ..... MAX
  - Flaps ..... T/O
  - Nose wheel lift-off ..... airspeed see table below:

<b>940 kg (2072 lb)</b>	<b>1000 kg (2205 lb)</b>	<b>1100 kg (2425 lb)</b>	<b>1200 kg (2646 lb)</b>	<b>1280 kg (2822 lb)</b>
56 KIAS	58 KIAS	61 KIAS	64 KIAS	67 KIAS

- Airspeed for initial climb ..... airspeed see table below:

<b>940 kg (2072 lb)</b>	<b>1000 kg (2205 lb)</b>	<b>1100 kg (2425 lb)</b>	<b>1200 kg (2646 lb)</b>	<b>1280 kg (2822 lb)</b>
62 KIAS	65 KIAS	67 KIAS	70 KIAS	72 KIAS

- Runway ..... level, asphalt surface

<b>Values for ISA and MSL, at 1280 kg (2822 lb)</b>	
Take-off distance over a 50 ft (15 m) obstacle	584 m (1916 ft)
Take-off ground roll	389 m (1276 ft)

**NOTE**

The rate of climb with a power setting of 100 % is 712 ft/min (3.61 m/s) at MSL and ISA standard conditions.

**WARNING**

Poor maintenance condition of the airplane, deviation from the given procedures as well as unfavorable outside conditions (high temperature, rain, unfavorable wind conditions, including cross-wind) will increase the take-off distance.

**CAUTION**

For a safe take-off the available runway length must be at least equal to the take-off distance over a 50 ft (15 m) obstacle.

**CAUTION**

The figures in the following NOTE are typical values. On wet ground or wet soft grass covered runways the take-off roll may become significantly longer than stated below. In any case the pilot must allow for the condition of the runway to ensure a safe take-off.

**NOTE**

For take-off from dry, short-cut grass covered runways, the following corrections must be taken into account, compared to paved runways (typical values, see CAUTION above):

- Grass up to 5 cm (2 in) long: 10 % increase in take-off roll.
- Grass 5 to 10 cm (2 to 4 in) long: 30 % increase in take-off roll.
- Grass longer than 10 cm (4 in): at least 45 % increase in take-off roll.

**NOTE**

For wet grass, an additional 20 % increase in take-off ground roll must be expected.

**NOTE**

For soft ground, an additional increase in take-off ground roll of at least 50 % must be expected.

**NOTE**


An uphill slope of 2 % (2 m per 100 m or 2 ft per 100 ft) results in an increase in the take-off distance of approximately 17 %. The effect on the take-off roll can be greater.

**NOTE**

For operation without wheel fairings an increased take-off distance over a 50 ft (15 m) obstacle of 30 m (100 ft) and an increased take-off ground roll of 20 m (66 ft) must be expected.

||  
||  
||  
||  
||

DA 40 NG - TAKE-OFF DISTANCES



### 5.3.8 CLIMB PERFORMANCE - TAKE-OFF CLIMB

- Conditions:
- POWER lever ..... 92% or max. 2100 RPM
  - Flaps ..... T/O
  - Airspeed ..... 72 KIAS

#### **NOTE**

The graph on the following page shows the *rate* of climb. The *gradient* of climb cannot easily be determined with a graph, but it can be calculated using the following formulae:

$$\text{Gradient [\%]} = \frac{\text{ROC [fpm]}}{\text{TAS [KTAS]}} \cdot 0.95$$


$$\text{Gradient [\%]} = \frac{\text{ROC [m/s]}}{\text{TAS [KTAS]}} \cdot 190$$

#### **NOTE**

For operation without wheel fairings a climb rate decreased by 20 ft/min must be expected.



# DA 40 NG - CLIMB PERFORMANCE - TAKE OFF CLIMB



**5.3.9 CLIMB PERFORMANCE - CRUISE CLIMB**

- Conditions: - POWER lever . . . . . 92% or max. 2100 RPM
- Flaps . . . . . UP
- Airspeed . . . . . 88 KIAS

**NOTE**

The graph on the following page shows the *rate* of climb. The *gradient* of climb cannot easily be determined with a graph, but it can be calculated using the following formulae:

$$\text{Gradient [\%]} = \frac{\text{ROC [fpm]}}{\text{TAS [KTAS]}} \cdot 0.95$$


$$\text{Gradient [\%]} = \frac{\text{ROC [m/s]}}{\text{TAS [KTAS]}} \cdot 190$$

**NOTE**



For operation without wheel fairings a climb rate decreased by 40 ft/min must be expected.

# DA 40 NG - CLIMB PERFORMANCE - CRUISE CLIMB




**5.3.10 CRUISING (TRUE AIRSPEED TAS)**

**NOTE**

For operation without wheel fairings a performance reduction of 4% TAS at all power settings must be expected.

DA 40 NG - CRUISING (TRUE AIRSPEED / TAS)



### 5.3.11 LANDING DISTANCE - FLAPS LDG

- Conditions:
- POWER lever ..... IDLE
  - Flaps ..... LDG
  - Approach speed ..... see table below:

Flaps	940 kg (2072 lb)	1000 kg (2205 lb)	1080 kg (2381 lb)	1160 kg (2557 lb)	1216 kg (2681 lb)	1280 kg (2822 lb)
LDG	66 KIAS	69 KIAS	72 KIAS	74 KIAS	76 KIAS	77 KIAS

- Runway ..... level, asphalt surface

Values for ISA and MSL, at 1280 kg (2822 lb)	
Landing distance over a 50 ft (15 m) obstacle	632 m (2074 ft)
Landing ground roll	303 m (994 ft)

Values for ISA and MSL, at 1216 kg (2681 lb)	
Landing distance over a 50 ft (15 m) obstacle	635 m (2083 ft)
Landing ground roll	286 m (938 ft)

### WARNING

Poor maintenance condition of the airplane, deviation from the given procedures as well as unfavorable outside conditions (high temperature, rain, unfavorable wind conditions, including cross-wind) will increase the landing distance.

**CAUTION**

For a safe landing the available runway length must be at least equal to the landing distance over a 50 ft (15 m) obstacle.

**CAUTION**

The figures in the following NOTE are typical values. On wet ground or wet soft grass covered runways the landing distance may become significantly longer than stated below. In any case the pilot must allow for the condition of the runway to ensure a safe landing.

**NOTE**

For landings on dry, short-cut grass covered runways, the following corrections must be taken into account, compared to paved runways:

- Grass up to 5 cm (2 in) long: 30 % increase in landing roll.
- Grass longer than 5 cm (2 in): at least 45 % increase in landing roll.

**NOTE**

For wet grass or soft ground, an additional 15 % increase in landing ground roll must be expected.


**NOTE**

A downhill slope of 2 % (2 m per 100 m or 2 ft per 100 ft) results in an increase in the landing distance of approximately 12 %. The effect on the landing roll can be greater.

**NOTE**

Higher approach speeds result in a significant longer landing distance during flare.

DA 40 NG - LANDING DISTANCES - FLAPS LDG





**5.3.12 LANDING DISTANCE - ABNORMAL FLAP POSITION**

- Conditions:
- POWER lever ..... IDLE
  - Flaps ..... UP
  - Approach speed ..... see table below:

Flaps	940 kg (2072 lb)	1000 kg (2205 lb)	1080 kg (2381 lb)	1160 kg (2557 lb)	1216 kg (2681 lb)	1280 kg (2822 lb)
UP	71 KIAS	73 KIAS	78 KIAS	81 KIAS	82 KIAS	83 KIAS

- Runway ..... level, asphalt surface

Values for ISA and MSL, at 1280 kg (2822 lb)	
Landing distance over a 50 ft (15 m) obstacle	771 m (2530 ft)
Landing ground roll	355 m (1165 ft)

Values for ISA and MSL, at 1216 kg (2681 lb)	
Landing distance over a 50 ft (15 m) obstacle	776 m (2546 ft)
Landing ground roll	331 m (1086 ft)

**WARNING**

Poor maintenance condition of the airplane, deviation from the given procedures as well as unfavorable outside conditions (high temperature, rain, unfavorable wind conditions, including cross-wind) will increase the landing distance.

**CAUTION**

For a safe landing the available runway length must be at least equal to the landing distance over a 50 ft (15 m) obstacle.

**CAUTION**

The figures in the following NOTE are typical values. On wet ground or wet soft grass covered runways the landing distance may become significantly longer than stated below. In any case the pilot must allow for the condition of the runway to ensure a safe landing.

**NOTE**

For landings on dry, short-cut grass covered runways, the following corrections must be taken into account, compared to paved runways:

- Grass up to 5 cm (2 in) long: 40 % increase in landing roll.
- Grass longer than 5 cm (2 in): at least 60 % increase in landing roll.

**NOTE**

For wet grass or soft ground, an additional 20 % increase in landing ground roll must be expected.


**NOTE**

A downhill slope of 2 % (2 m per 100 m or 2 ft per 100 ft) results in an increase in the landing distance of approximately 10 %. The effect on the landing roll can be greater.

**NOTE**

Higher approach speeds result in a significant longer landing distance during flare.

DA 40 NG - LANDING DISTANCES - ABNORMAL FLAP POSITION



**5.3.13 GRADIENT OF CLIMB ON GO-AROUND**

Landing Mass 1216 kg (2681 lb)

**NOTE**

For operation without wheel fairings a reduction of the constant gradient of climb to 6.0% (equals 3.4° climb angle) or 452 ft/min must be expected.

Conditions:

- POWER lever . . . . . MAX
- Flaps . . . . . LDG
- Airspeed: . . . . . 76 KIAS

Value for ISA and MSL, at 1216 kg (2681 lb)	
Constant gradient of climb	6.6 % (equals 3.8° climb angle) or 492 ft/min

Landing Mass above 1216 kg (2681 lb) up to 1280 kg (2822 lb)

**NOTE**

A landing with a mass between 1216 kg (2681 lb) and 1280 kg (2822 lb) is admissible. It constitutes an abnormal operating procedure. Refer to Section 4B.8.

**NOTE**



For operation without wheel fairings a reduction of the constant gradient of climb to 4.9% (equals 2.8° climb angle) or 380 ft/min must be expected.

Conditions:

- POWER lever ..... MAX
- Flaps ..... LDG
- Airspeed: ..... 77 KIAS

Value for ISA and MSL, at 1280 kg (2822 lb)	
Constant gradient of climb	5.5 % (equals 3.1° climb angle) or 420 ft/min

**5.3.14 GLIDE**

The following table shows the glide ratio and the resulting maximum horizontal distance in nautical miles per 1000 ft (305 m) of altitude loss in a glide traveled in still air.

	<b>Glide ratio</b>	<b>Maximum horizontal distance per 1000 ft (305 m) altitude loss</b>
Windmilling propeller	1 : 9.7	1.59 NM (2.94 km)

Conditions:

- Flaps ..... UP
- Airspeed ..... 88 KIAS

**CAUTION**

The propeller will keep windmilling under all expected conditions. Do not attempt to stop the propeller intentionally.

**NOTE**

In case of stationary propeller the given numbers are conservative.

**NOTE**

For operation without wheel fairings the glide ratio is reduced to 9.4; i.e., for every 1000 ft (305m) of altitude loss the maximum horizontal distance traveled in still air is 1.54 NM (2.85 km). During this the propeller will continue to windmill.

**5.3.15 APPROVED NOISE DATA**

ICAO Annex 16 Chapter X ..... 74.5 dB(A)

CS-36 Subpart C ..... 74.5 dB(A)

■ If the Exhaust Pipe with Muffler MÄM 40-434 or OÄM 40-310 is installed:

■ ICAO Annex 16, Chapter X ..... 71.5 dB(A)

■ CS-36 Subpart C ..... 71.5 dB(A)

I

Intentionally left blank.



## CHAPTER 6

# MASS AND BALANCE / EQUIPMENT LIST

	Page
6.1 INTRODUCTION .....	6-2
6.2 DATUM PLANE .....	6-3
6.3 MASS AND BALANCE REPORT .....	6-3
6.4 FLIGHT MASS AND CENTER OF GRAVITY .....	6-5
6.4.1 MOMENT ARMS .....	6-7
6.4.2 LOADING DIAGRAM .....	6-8
6.4.3 CALCULATION OF LOADING CONDITION .....	6-9
6.4.4 PERMISSIBLE CENTER OF GRAVITY RANGE .....	6-13
6.4.5 PERMISSIBLE MOMENT RANGE .....	6-14
6.5 EQUIPMENT LIST AND EQUIPMENT INVENTORY .....	6-15

## **6.1 INTRODUCTION**

In order to achieve the performance and flight characteristics described in this Airplane Flight Manual and for safe flight operation, the airplane must be operated within the permissible mass and balance envelope.

The pilot is responsible for adhering to the permissible values for loading and center of gravity (CG). In this, he should note the movement of the CG due to fuel consumption. The permissible CG range during flight is given in Chapter 2.

The procedure for determining the flight mass CG position is described in this Chapter. Over and above this there is a comprehensive list of the equipment approved for this airplane (Equipment List), as also a list of that equipment installed when the airplane was weighed (Equipment Inventory).

Before the airplane is delivered the empty mass and the corresponding CG position are determined, and entered in Section 6.3 - MASS AND BALANCE REPORT.

### **NOTE**

Following equipment changes the new empty mass and the corresponding CG position must be determined by calculation or by weighing.

Following repairs or repainting the new empty mass and the corresponding CG position must be determined by weighing.

Empty mass, empty mass CG position, and the empty mass moment must be certified in the Mass and Balance Report by an authorized person.

## NOTE

Refer to Section 1.6 - UNITS OF MEASUREMENT for conversion of SI units to US units and vice versa.

## **6.2 DATUM PLANE**

The Datum Plane (DP) is a plane which is normal to the airplane's longitudinal axis and in front of the airplane as seen from the direction of flight. The airplane's longitudinal axis is parallel with the upper surface of a 600:31 wedge which is placed on top of the rear fuselage in front of the vertical stabilizer. When the upper surface of the wedge is aligned horizontally, the Datum Plane is vertical. The Datum Plane is located 2.194 meter (86.38 in) forward of the most forward point of the root rib on the stub wing.

## **6.3 MASS AND BALANCE REPORT**

The empty mass and the corresponding CG position established before delivery are the first entries in the Mass and Balance Report. Every change in permanently installed equipment, and every repair to the airplane which affects the empty mass or the empty mass CG must be recorded in the Mass and Balance Report.

For the calculation of flight mass and corresponding CG position (or moment), the *current* empty mass and the corresponding CG position (or moment) in accordance with the Mass and Balance Report must always be used.

Condition of the airplane for establishing the empty mass:

- Equipment as per Equipment Inventory (see Section 6.5)
- Including brake fluid, lubricant (1.0 liter / 1.06 qts), coolant (7.5 liter / 7.93 qts), gearbox oil (2.1 liter / 2.22 qts), engine oil (7.0 liter / 7.4 qts), plus unusable fuel (2.0 US gal / approx. 7.6 liter).

### MASS AND BALANCE REPORT

(Continuous report on structural or equipment changes)

DA 40 NG			Serial No.:	Registration:			Page No.:					
Date	Entry No.		Description of Part or Modification	Changes in Mass						Current Empty Mass		
	IN	OUT		Addition (+)			Subtraction (-)					
				Mass	Moment Arm	Moment	Mass	Moment Arm	Moment			
				[kg]	[m]	[kgm]	[kg]	[m]	[kgm]	[kg]	[m]	[kgm]
			upon delivery	/	/	/	/	/	/			

## **6.4 FLIGHT MASS AND CENTER OF GRAVITY**

The following information enables you to operate your DA 40 NG within the permissible mass and balance limits. For the calculation of the flight mass and the corresponding CG position the following tables and diagrams are required:

- 6.4.1 - MOMENT ARMS
- 6.4.2 - LOADING DIAGRAM
- 6.4.3 - CALCULATION OF LOADING CONDITION
- 6.4.4 - PERMISSIBLE CENTER OF GRAVITY RANGE
- 6.4.5 - PERMISSIBLE MOMENT RANGE

The diagrams should be used as follows:

1. Take the empty mass and the empty mass moment of your airplane from the Mass and Balance Report, and enter the figures in the appropriate boxes under the column marked 'Your DA 40 NG' in Table 6.4.3 - CALCULATION OF LOADING CONDITION.
2. Read the fuel quantity indicators to determine the fuel quantity. If an indicator shows 14 US gal, up to 19.5 US gal can be in the Long Range Tank. In this case, the exact quantity must be determined with the alternate means for fuel quantity indication.
3. Multiply the individual masses by the moment arms quoted to obtain the moment for every item of loading and enter these moments in the appropriate boxes in Table 6.4.3 - CALCULATION OF LOADING CONDITION.
4. Add up the masses and moments in the respective columns. The total moments may be rounded to whole numbers. The CG position is calculated by dividing the total moment by the total mass (using row 6 for the condition with empty fuel tanks, and row 8 for the pre take-off condition). The resulting CG position must be inside the limits.

As an illustration the total mass and the CG position are entered on Diagram 6.4.4 - PERMISSIBLE CENTER OF GRAVITY RANGE. This checks graphically that the current configuration of the airplane is within the permissible range.

5. Graphical method:


Diagram 6.4.2 - LOADING DIAGRAM is used to determine the moments. The masses and moments for the individual items of loading are added. Then Diagram 6.4.5 - PERMISSIBLE MOMENT RANGE is used to check whether the total moment associated with the total mass is in the admissible range.

The result found with the graphical method is however inaccurate. In doubtful cases the result must be verified using the exact method given above.


### 6.4.1 MOMENT ARMS

The most important lever arms aft of the Datum Plane:

- Front seats : 2.30 m 90.6 in
- Rear seats : 3.25 m 128.0 in
- Wing tank (Standard & Long Range) : 2.63 m 103.5 in
- Baggage in standard compartment : 3.65 m 143.7 in
  - Baggage in baggage tube : 4.32 m 170.1 in
- Baggage in short baggage extension  
(if OÄM 40-331 is installed): 3.97 m 156.3 in
- Baggage in baggage extension (if OÄM 40-164 is installed):
  - Forward part : 3.89 m 153.1 in
  - Aft part : 4.54 m 178.7 in



**6.4.2 LOADING DIAGRAM**





### 6.4.3 CALCULATION OF LOADING CONDITION

#### a) Standard Tank Configuration

CALCULATION OF LOADING CONDITION	DA 40 NG (Example)		Your DA 40 NG	
	Mass [kg] [lb]	Moment [kgm] [in.lb]	Mass [kg] [lb]	Moment [kgm] [in.lb]
1. Empty mass (from Mass and Balance Report)	900 1,984	2,180.8 189,253		
2. Front seats Lever arm: 2.30 m (90.6 in)	150 331	345.0 29,989		
3. Rear seats Lever arm: 3.25 m (128.0 in)	0 0	0 0		
4. Standard baggage comp. Lever arm: 3.65 m (143.7 in)	20 44	73.0 6,323		
5. Baggage tube Lever arm: 4.32 m (170.1 in)	0 0	0 0		
6. Short baggage extension (OÄM 40-331 carried out) Lever arm: 3.97 m (156.3 in)	0 0	0 0		
7. Forward extended baggage compartment (OÄM 40-164 carried out) Lever arm: 3.89 m (153.1 in)	0 0	0 0		
8. Aft extended baggage compartment (OÄM 40-164 carried out) Lever arm: 4.54 m (178.7 in)	0 0	0 0		


CALCULATION OF LOADING CONDITION	DA 40 NG (Example)		Your DA 40 NG	
	Mass [kg] [lb]	Moment [kgm] [in.lb]	Mass [kg] [lb]	Moment [kgm] [in.lb]
9. Total mass and total moment with empty fuel tanks (Total of 1.-8.)	1,070 2,359	2,598.8 225,565		
10. On-board usable fuel (0.84 kg/liter) (7.01 lb/US gal) Lever arm: 2.63 m (103.5 in)	89 196	234.1 20,286		
11. Total mass and total moment with full fuel tanks (Total 9. plus 10.)	1,159 2,555	2,832.9 245,851		
<p>12. The total moments from rows 9 and 11 2,598.8 and 2,832.9 kgm) (225,565 and 245,851 in.lb) must be divided by the related total mass (1,070 and 1,159 kg respectively) (2,359 and 2,555 lb) and then located in Diagram 6.4.4 - PERMISSIBLE CENTER OF GRAVITY RANGE.</p> <p>As in our example CG positions (2.429 m and 2.444 m respectively) (95.62 and 96.22 in) and masses fall into the permitted area, this loading condition is allowable.</p>				

b) Long Range Tank Configuration

CALCULATION OF LOADING CONDITION	DA 40 NG (Example)		Your DA 40 NG	
	Mass [kg]	Moment [kgm]	Mass [kg]	Moment [kgm]
	[lb]	[in.lb]	[lb]	[in.lb]
1. Empty mass (from Mass and Balance Report)	900 1,984	2,180.8 189,253		
2. Front seats Lever arm: 2.30 m (90.6 in)	150 331	345.0 29,989		
3. Rear seats Lever arm: 3.25 m (128.0 in)	0 0	0 0		
4. Standard baggage comp. Lever arm: 3.65 m (143.7 in)	20 44	73.0 6,323		
5. Baggage tube Lever arm: 4.32 m (170.1 in)	0 0	0 0		
6. Short baggage extension (OÄM 40-331 carried out) Lever arm: 3.97 m (156.3 in)	0 0	0 0		
7. Forward extended baggage compartment (OÄM 40-164 carried out) Lever arm: 3.89 m (153.1 in)	0 0	0 0		
8. Aft extended baggage compartment (OÄM 40-164 carried out) Lever arm: 4.54 m (178.7 in)	0 0	0 0		

CALCULATION OF LOADING CONDITION	DA 40 NG (Example)		Your DA 40 NG	
	Mass [kg] [lb]	Moment [kgm] [in.lb]	Mass [kg] [lb]	Moment [kgm] [in.lb]
9. Total mass and total moment with empty fuel tanks (Total of 1.-8.)	1,070 2,359	2,598.8 225,565		
10. On-board usable fuel (0.84 kg/liter) (7.01 lb/US gal) Lever arm: 2.63 m (103.5 in)	124 273	326.1 28,256		
11. Total mass and total moment with full fuel tanks (Total 9. plus 10.)	1,194 2,632	2,924.9 253,821		
<p>12. The total moments from rows 9 and 11 (2,598.8 and 2,924.9 kgm) (225,565 and 253,821 in.lb) must be divided by the related total mass (1,070 and 1,194 kg respectively) (2,359 and 2,632 lb) and then located in Diagram 6.4.4 - PERMISSIBLE CENTER OF GRAVITY RANGE.</p> <p>As in our example CG positions (2.429 m and 2.450 m respectively) (95.62 and 96.44 in) and masses fall into the permitted area, this loading condition is allowable.</p>				

**6.4.4 PERMISSIBLE CENTER OF GRAVITY RANGE**



The CG's shown in the diagram are from the examples in Tables 6.4.3 - CALCULATION OF LOADING CONDITION a) and b), rows 6 and 8.

The flight CG position must be within the following limits:

Most forward CG:

2.40 m (94.5 in) aft of DP from 940 kg to 1080 kg (2072 lb to 2381 lb)


2.46 m (96.9 in) aft of DP at 1280 kg (2822 lb)

linear variation between these values

Most rearward CG:

2.53 m (99.6 in) aft of DP from 940 kg (2072 lb) to 1280 kg (2822 lb)

**6.4.5 PERMISSIBLE MOMENT RANGE**



## **6.5 EQUIPMENT LIST AND EQUIPMENT INVENTORY**

All equipment approved for installation in the DA 40 NG is shown in the *Equipment List* below.

The items of equipment installed in your particular airplane are indicated in the appropriate column. The set of items marked as 'installed' constitutes the *Equipment Inventory*.

### **NOTE**

The equipment listed below cannot be installed in any arbitrary combination. The airplane manufacturer must be contacted before removing or installing equipment, with the exception of replacing a unit by an identical unit.

Airplane Serial No.:		Registration:		Date:		Mass		Lever Arm	
Description	Type	Part No.	Manufacturer	S/N	installed	lb	kg	in	m
<b>AVIONICS COOLING</b>									
Avionics cooling fan	SAFE 328	305 467-00	Sandia Aerospace						
Avionics cooling fan	Cyclone 21-3	CRB-122253	Lone Star Aviation						
PFD cooling fan	SAFE 128	305 468-00	Sandia Aerospace						
MFD cooling fan	SAFE 128	305 468-00	Sandia Aerospace						
<b>AUTOPILOT SYSTEM</b>									
Pitch servo	GSA 81	011-00878-00	Garmin						
Pitch servo mount	GSM 85	011-00894-07	Garmin						
Roll servo	GSA 81	011-00878-00	Garmin						
Roll servo mount	GSM 85	011-00894-07	Garmin						
Pitch trim servo	GSA 81	011-00878-00	Garmin						
Pitch trim servo mount	GSM 85	011-00894-04	Garmin						
Control stick		DA4-2213-12-90	Diamond Aircraft						
CWS switch		031-00514-0000	Bendix/King						
AP-Disc switch		031-00428-0000	Bendix/King						
Trim switch assy		200-09187-0000	Bendix/King						
<b>ELECTRICAL POWER</b>									
Main battery	RG24-15		Concorde						
Emergency battery		D60-2560-91-00	Diamond Aircraft						
ECU backup battery (2 pcs.)	LC-R127R2P		Panasonic						
External power connector		DA4-2443-10-00	Diamond Aircraft						





Airplane Serial No.:		Registration:		Date:		Mass		Lever Arm	
Description	Type	Part No.	Manufacturer	S/N	installed	lb	kg	in	m
Additional alternator		ES-10024B-2	Kelly Aerospace						
Alternator pulley		D44-2416-00-34X01	Diamond Aircraft						
Gear box fan assy		D44-2416-20-00	Diamond Aircraft						
Prop. flange pulley support		D44-2416-00-52_1	Diamond Aircraft						
Additional alternator V-belt		ISO 4184 XPZ	Diamond Aircraft						
Additional alternator regulator		VR2000-28-1	Electrosystems Inc.						
<b>CABIN COOLING SYSTEM</b>									
Cabin cooling central unit		D44-2151-00-00	Diamond Aircraft						
<b>EQUIPMENT</b>									
Safety belt, pilot	5-01-0 Series	5-01-1C0710	Schroth			2.110	0.960	92.520	2.350
Safety belt, co-pilot	5-01-0 Series	5-01-1C5710	Schroth			2.110	0.960	92.520	2.350
Safety belt, LH pax	5-01-0 Series	5-01-1B5710	Schroth			2.250	1.020	126.800	3.220
Safety belt, RH pax	5-01-0 Series	5-01-1B0710	Schroth			2.250	1.020	126.800	3.220
Safety belt, pilot	5-01-0 Series	5-01-2G0710	Schroth			2.110	0.960	92.520	2.350
Safety belt, co-pilot	5-01-0 Series	5-01-2G5710	Schroth			2.110	0.960	92.520	2.350
Safety belt, LH pax	5-01-0 Series	5-01-2H5710	Schroth			2.250	1.020	126.800	3.220
Safety belt, RH pax	5-01-0 Series	5-01-2H0710	Schroth			2.250	1.020	126.800	3.220
Safety belt, pilot	5-01-0 Series	5-01-2G0701	Schroth			2.110	0.960	92.520	2.350
Safety belt, co-pilot	5-01-0 Series	5-01-2G5701	Schroth			2.110	0.960	92.520	2.350
Safety belt, LH pax	5-01-0 Series	5-01-2H5701	Schroth			2.250	1.020	126.800	3.220
Safety belt, RH pax	5-01-0 Series	5-01-2H0701	Schroth			2.250	1.020	126.800	3.220

Airplane Serial No.:		Registration:		Date:		Mass		Lever Arm	
Description	Type	Part No.	Manufacturer	S/N	installed	lb	kg	in	m
Safety belt, pilot	5-01-0 Series	5-01-1C0701	Schroth			2.110	0.960	92.520	2.350
Safety belt, co-pilot	5-01-0 Series	5-01-1C5701	Schroth			2.110	0.960	92.520	2.350
Safety belt, LH pax	5-01-0 Series	5-01-1B5701	Schroth			2.250	1.020	126.800	3.220
Safety belt, RH pax	5-01-0 Series	5-01-1B0701	Schroth			2.250	1.020	126.800	3.220
ELT unit	ME406	453-6603	Artex			2.064	0.936	179.700	4.565
ELT remote switch		345-6196-04	Artex						
ELT antenna		110-773	Artex			0.251	0.114	152.800	3.880
Buzzer		452-6505	Artex						
Winter baffle		DA4-2157-00-00							
Nose gear tie-down		DA4-1001-00-00							
<b>SAFETY EQUIPMENT</b>									
Fire extinguisher		HAL 1	AIR Total						
First aid kit									
Emergency axe		G45912	Fiskars						
<b>FLIGHT CONTROLS</b>									
Flaps actuator assy		43055	Krutz						
Flap control unit		DAI-9031-10-01	Krutz						
Stall warning horn assy	"A"	DA4-2739-10-00	Diamond Aircraft						
Stall warning horn assy	"B"	DA4-2739-10-00X01	Diamond Aircraft						
Stall warning horn assy	"C"	DA4-2739-10-00X02	Diamond Aircraft						
Stall warning horn assy	"D"	DA4-2739-10-00X03	Diamond Aircraft						



Airplane Serial No.:	Registration:		Manufacturer	Date:		Mass		Lever Arm	
	Type	Part No.		S/N	installed	lb	kg	in	m
Description	"E"	DA4-2739-10-00X04	Diamond Aircraft						
Stall warning horn assy	"F"	DA4-2739-10-00X05	Diamond Aircraft						
<b>FUEL</b>									
Fuel transfer pump		5100-00-9	Dukes Inc.						
<b>INDICATING / REC. SYSTEM</b>									
Primary flight display (PFD)	GDU 1040	011-00972-03	Garmin			6.400	2.900	70.080	1.780
Primary flight display (PFD)	GDU 1040	011-00972-10	Garmin			6.400	2.900	70.080	1.780
Primary flight display (PFD)	GDU 1040	011-00972-02	Garmin			6.400	2.900	70.080	1.780
Multi function display (MFD)	GDU 1044	011-01078-01	Garmin			6.400	2.900	70.080	1.780
Multi function display (MFD)	GDU 1044	011-01078-10	Garmin			6.400	2.900	70.080	1.780
Multi function display (MFD)	GDU 1040	011-00972-02	Garmin			6.400	2.900	70.080	1.780
Multi function display (MFD)	GDU 1040	011-00972-03	Garmin			6.400	2.900	70.080	1.780
Multi function display (MFD)	GDU 1040	011-00972-10	Garmin			6.400	2.900	70.080	1.780
Flight timer		85094-12	Hobbs						
Digital chronometer with OAT	M803-28V		Davtron						
Annunciator panel		WW-IDC004	White Wire						
<b>HYDRAULIC</b>									
Master cylinder		10-54A	Cleveland						
Parking valve		60-5D	Cleveland						
Brake assembly		30-239B	Cleveland						



Airplane Serial No.:		Registration:		Date:		Mass		Lever Arm	
Description	Type	Part No.	Manufacturer	S/N	installed	lb	kg	in	m
LIGHTS									
Map / Reading light assy crew		W1461.0.010	Rivoret						
Cabin Light		W1461.0.010	Rivoret						
Strobe / Pos. light assy LH	A600-PR-D-28	01-07900006-05	Whelen			0.800	0.363	103.800	2.638
Strobe / Pos. light assy RH	A600-PG-D-28	01-07900006-07	Whelen			0.800	0.363	103.800	2.638
Strobe light power supply LH/RH	A490ATS-CF-14/28	01-07700062-05	Whelen						
Taxi light	7034601	01-0770346-01	Whelen			0.990	0.449	79.920	2.030
Landing light	7034601	01-0770346-01	Whelen			0.990	0.449	79.920	2.030
Glareshield lamp assy		DA4-3311-10-02	Diamond Aircraft						
Glareshield lamp assy		DA4-3311-10-01	Diamond Aircraft						
Glareshield light inverter		APVL328-4-1-L-5QF	Quantaflex						
Glareshield light inverter		APVL328-8-3-L-18QF	Quantaflex						
Placards inverter		APVL328-4-1-L-15QF	Quantaflex						
Map / reading light		RL6980-1	Birk Aerosystems						
Instr. / Radio lights dimmer		WW-LCM002	White Wire						
COMMUNICATION / NAVIGATION									
COMM #1 antenna	DMC63-1/A		DM			0.400	0.180	177.100	4.500
COMM #2 antenna	DMC63-2		DM			0.400	0.180	155.100	3.940
Audio panel / Marker / ICS	GMA 1347	011-00809-00	Garmin						
Headset, pilot	Echelon 100		Telex						
Headset, pilot	HMEC25-KAP-2	025-230-715	Sennheiser						
Headset, co-pilot	Echelon 100		Telex						
Headset, co-pilot	HMEC25-KAP-2	025-230-715	Sennheiser						



Airplane Serial No.:		Registration:		Date:		Mass		Lever Arm	
Description	Type	Part No.	Manufacturer	S/N	installed	lb	kg	in	m
Headset, LH pax	Echelon 100		Telex						
Headset, LH pax	HMEC25-KAP-2	025-230-715	Sennheiser						
Headset, RH pax	Echelon 100		Telex						
Headset, RH pax	HMEC25-KAP-2	025-230-715	Sennheiser						
Speaker	FRS8 / 4 Ohms		Visaton						
Handmic	100 TRA	62800-001	Telex						
Pitot / Static probe, heated	AN5814-2	PST-305	Aeroinstruments						
Alternate static valve		DA4-3111-51-00	Diamond Aircraft						
Backup altimeter		5934PD-3	United Instruments			0.496	0.225	70.080	1.780
Backup airspeed indicator	8025	8025-B890	United Instruments			0.680	0.308	70.080	1.780
Backup artificial horizon	4300	4300-206	Mtd Continent Instr.			2.500	1.134	70.080	1.780
Magnetic compass		PG2C-28V	SIRS Navigation						
OAT probe	GTP 59	011-00978-00	Garmin						
Digital air data system	GDC74A	011-00882-00	Garmin			1.690	0.770	70.080	1.780
Digital air data system	GDC 74A	011-00882-10	Garmin			1.690	0.770	70.080	1.780
Integrated avionics #1	GIA 63	011-00781-01	Garmin			5.290	2.400	154.900	3.935
Integrated avionics #1	GIA 63W	011-01105-01	Garmin			5.290	2.400	154.900	3.935
Integrated avionics #2	GIA 63	011-00781-01	Garmin			5.290	2.400	154.900	3.935
Integrated avionics #2	GIA 63W	011-01105-01	Garmin			5.290	2.400	154.900	3.935
Transponder	GTX 33	011-00779-10	Garmin			3.100	1.410	153.100	3.890
Attitude / Heading reference system GRS 77	GRS 77	011-00868-10	Garmin			2.800	1.270	154.900	3.935
Attitude / Heading reference system GRS 77	GRS 77	011-00868-00	Garmin			2.800	1.270	154.900	3.935
Magnetometer	GMU 44	011-00870-00	Garmin			0.350	0.160	103.800	2.638
VOR / LOC / GS antenna	CI 157P		Comant						



Airplane Serial No.:		Registration:		Date:		Mass		Lever Arm	
Description	Type	Part No.	Manufacturer	S/N	installed	lb	kg	in	m
Dual VOR / dual GS duplexer	CI 1125		Comant						
Transponder antenna	KA 60	071-01591-0001	Bendix/King						
Transponder antenna	KA 61	071-00221-0010	Bendix/King						
Marker antenna	CI 102		Comant						
GPS #1 antenna	GA 56	011-00134-00	Garmin			0.470	0.210	104.100	2.645
GPS #1 antenna	GA 36	013-00244-00	Garmin			0.470	0.210	104.100	2.645
GPS #2 antenna	GA 56	011-00134-00	Garmin			0.470	0.210	104.100	2.645
GPS #2 antenna	GA 36	013-00244-00	Garmin			0.470	0.210	104.100	2.645
DME	KN 63	066-1070-01	Bendix/King			2.800	1.270	141.100	3.580
DME antenna	KA 60	071-01591-0001	Bendix/King						
DME antenna	KA 61	071-00221-0010	Bendix/King						
Stormscope	WX-500	805-11500-001	L-3						
Stormscope antenna	NY-163	805-10930-001	L-3						
ADF receiver	RA 3502-(01)	0505.757-912	Becker						
ADF / RMI converter	AC 3504-(01)	0856.010-912	Becker						
ADF antenna	AN 3500	0832.601-912	Becker						
COM/NAV	SL 30	430-6040-303	Garmin						
Intercom	PM1000II	11922	PS Engineering						
Transponder	GTX 328	011-01684-00	Garmin						
Altitude digitizer	SAE5-35	305154-00	Sandia Aerospace						
P/S probe heater fail sensor		DA4-3031-01-00	Diamond Aircraft						
Altimeter inHg/mbar, primary		5934PD-3	United Instruments						
Altimeter inHg/mbar, secondary		5934PD-3	United Instruments						
Airspeed indicator		8025-B890	United Instruments						
Vertical speed indicator		7000	United Instruments						



Airplane Serial No.:	Registration:		Date:	Mass		Lever Arm			
	Type	Part No.		Manufacturer	S/N	installed	lb	kg	in
Magnetic compass		C2400L4P	Airpath						
Directional gyro, free	AIM2051BLD	505-0031-931	L-3 Communications						
Altitude indicator	AIM1100-28L(0F)	504-0111-936	L-3 Communications						
Altitude indicator	AIM1100-28LK(0F)	504-0111-938	L-3 Communications						
Altitude indicator	AIM1100-28LK(2F)	504-0111-941	L-3 Communications						
Turn coordinator	1394T100-3Z		Mid Continent						
Turn coordinator	1394T100-12RB		Mid Continent						
GPS antenna	GA56	011-00134-00	Garmin						
<b>ENGINE</b>									
Engine	E4-A	E4A-00-000-000	Austro Engine						
Engine control unit	EECU-E4-01	E4A-92-100-000 Iss: 02()	Austro Engine						
ECU software		Refer to DAI Service Bulletin MSB-40NG-002	Austro Engine						
<b>ENGINE STARTING</b>									
Glow plug control unit		E4A-94-200-000	Austro Engine						
Starter		E4A-93-000-000	Austro Engine						
<b>ELECTRICAL POWER</b>									
Alternator		E4A-91-000-000	Austro Engine						
Alternator regulator		E4A-91-100-000	Austro Engine						



Airplane Serial No.:		Registration:		Date:		Mass		Lever Arm	
Description	Type	Part No.	Manufacturer	S/N	installed	lb	kg	in	m
ENGINE FUEL PUMPS									
Fuel pumps (2x)		0-580-054-001	Bosch						
ENGINE INDICATING									
Engine / Airframe unit	GEA 71	011-00831-00	Garmin						
Main engine display		A1A-10-100-000-010	Austro Engine						
Secondary engine display		A1A-10-200-000-010	Austro Engine						
ENGINE EXHAUST									
Exhaust pipe		D44-7806-10-01	Diamond Aircraft						
Exhaust pipe with muffler		D44-7806-20-00	Diamond Aircraft						
Exhaust pipe with muffler		D44-7806-20-00_1	Diamond Aircraft						
PROPELLER									
Propeller	MTV-6-R/190-69		mt-propeller						
Governor		P-853-16	mt-propeller						
FUEL TANK SYSTEM									
Fuel probe assy., LH inboard		D4D-2817-13-00x01	Diamond Aircraft						
Fuel probe assy., RH inboard		D4D-2817-13-00x01	Diamond Aircraft						
Alternate means for fuel qty.		D4D-2807-90-00	Diamond Aircraft						
Long range tank		D4D-2807-11-00	Diamond Aircraft						
Long range tank		D4D-2807-12-00	Diamond Aircraft						
Standard tank		D4D-2817-11-00	Diamond Aircraft						
Standard tank		D4D-2817-12-00	Diamond Aircraft						





Airplane Serial No.:	Registration:		Date:		Mass		Lever Arm			
	Description	Type	Part No.	Manufacturer	S/N	installed	lb	kg	in	m
AIRPLANE FLIGHT MANUAL			Doc. No. 6.01.15-E	Diamond Aircraft						

Place: \_\_\_\_\_ Date: \_\_\_\_\_ Signature: \_\_\_\_\_



Intentionally left blank.

## CHAPTER 7

# DESCRIPTION OF THE AIRPLANE AND ITS SYSTEMS

	Page
7.1 INTRODUCTION .....	7-2
7.2 AIRFRAME .....	7-2
7.3 FLIGHT CONTROLS .....	7-3
7.4 INSTRUMENT PANEL .....	7-8
7.5 LANDING GEAR .....	7-14
7.6 SEATS AND SAFETY HARNESSSES .....	7-16
7.7 BAGGAGE COMPARTMENT .....	7-16
7.8 CANOPY, REAR DOOR, AND CABIN INTERIOR .....	7-17
7.9 POWER PLANT .....	7-20
7.9.1 ENGINE, GENERAL .....	7-20
7.9.2 OPERATING CONTROLS .....	7-21
7.9.3 PROPELLER .....	7-24
7.9.4 FUEL SYSTEM .....	7-26
7.9.5 COOLING SYSTEM .....	7-34
7.9.6 TURBO CHARGER SYSTEM .....	7-35
7.9.7 OIL SYSTEMS .....	7-36
7.10 ELECTRICAL SYSTEM .....	7-37
7.10.1 GENERAL .....	7-38
7.10.2 ENGINE CONTROL UNIT / ECU .....	7-45
7.11 PITOT-STATIC SYSTEM .....	7-47
7.12 STALL WARNING SYSTEM .....	7-47

## **7.1 INTRODUCTION**

Chapter 7 contains a description of the airplane and its systems, together with operating instructions.

For details about optional equipment see Chapter 9.

## **7.2 AIRFRAME**

### Fuselage

The GFRP fuselage is of semi monocoque molded construction. The fire protection on the firewall is of a special fire-resistant matting, which is covered on the engine side by stainless steel cladding. The two main bulkheads are GFRP/CFRP items.

### Wings

The wings have a front and rear spar; each wing has a top shell and a bottom shell - a 'fail-safe' concept. The wings, as well as the ailerons and flaps, are made of GFRP/CFRP, and are principally of sandwich construction. An aluminum fuel tank is installed in each of the wings.

### Empennage

The airplane has a 'T' tail of GFRP semi monocoque construction. Both the stabilizers have twin spars and a skin with no sandwich. Rudder and elevator are of sandwich construction.

### **7.3 FLIGHT CONTROLS**

The ailerons, elevator and wing flaps are operated through control rods, while the rudder is controlled by cables. The flaps are electrically operated. Elevator forces can be balanced by a trim tab on the elevator, which is operated by a Bowden cable.

#### Ailerons

Construction: GFRP/CFRP composite sandwich.

Hinges: There are 4 hinges, which are hinge pins mounted in an aluminum bracket. They are secured in position by a roll pin. The absence of this roll pin can lead to the loss of the hinge pin and a consequent loss of flight safety.

Operation: A rod-end bearing is screwed into a steel push rod and locked by means of a jam nut which has locking varnish applied to it. Damage to this varnish can indicate a twisting and thus a change to the adjustment. The connection between the rod-end bearing and the control horn is a bolt, the nut of which is likewise sealed with locking varnish.

The aluminum control horn is attached to the aileron with 3 screws.

Flaps

**Construction:** GFRP/CFRP composite sandwich.

**Hinges:** There are 6 hinges, which are hinge pins mounted in an aluminum bracket. They are secured in position by a roll pin. The absence of this roll pin can lead to the loss of the hinge pin and a consequent loss of flight safety. Another aluminum fitting is located at the fuselage and is attached to a torsion tube. The torsion tube is located in the fuselage, creating a connection between the left and right flaps.

**Operation:** A rod-end bearing is screwed into a steel push rod and locked by means of a jam nut which has locking varnish applied to it. Damage to this varnish can indicate a twisting and thus a change to the adjustment. The connection between the rod-end bearing and the control horn is a bolt, the nut of which is likewise sealed with locking varnish.

The flap control horn is attached to the flap with 3 screws.

The flaps are driven by an electric motor and have 3 settings:

- Cruise (UP), totally retracted
- Take-off (T/O), and
- Landing (LDG).

The flaps are operated by means of a 3-position flap selector switch on the instrument panel. The positions of the switch correspond to the positions of the flaps, the cruise position of the switch being at the top. If the switch is moved to another position, the flaps continue to travel automatically until they have reached the position selected on the switch. The UP and LDG positions are additionally protected by a limit switch to guard against over-running the end positions.

The electrical flap drive has an automatic circuit breaker which can also be operated manually.

*Flap Position Indicator:*

The current flap position is indicated by means of three lights beside the flap selector switch.

When the upper light (green) is illuminated, the flaps are in the cruise position (UP);

when the center light (white) is illuminated, the flaps are in take-off position (T/O);

when the lower light (white) is illuminated, the flaps are in landing position (LDG).

When two lights are illuminated simultaneously, the flaps are between the two indicated positions. This is the case only when the flaps are traveling.

Elevator

Construction: GFRP sandwich.

Hinges: 5 hinges.

Operation: Steel push-rods;

Two of the bellcrank bearings are accessible to visual inspection next to the lower hinge of the rudder. The elevator horn and its bearing, as well as the connection to the push-rod, can be visually inspected at the upper end of the rudder.

Rudder

Construction: GFRP sandwich.

Hinges: Upper hinge: One bolt.

Lower hinge: Bearing bracket including rudder stops, held by 4 screws to the rear web of the vertical stabilizer. The mating part on the rudder is a bracket which is attached to the rudder by 2 bolts. The bolts and nuts are accessible to visual inspection.

Operation: Steel cables, the eyes of which are connected to the bolts on the bracket.



### Elevator Trim

The trim control is a black wheel in the center console to the rear of the power lever. To guard against over-rotating, the trim wheel incorporates a friction device. A mark on the wheel shows the take-off (T/O) position.

Turn wheel to the front = nose down

Turn wheel to the rear = nose up

### Pedal Adjustment

#### **NOTE**

The pedals may only be adjusted on the ground!

The pedals are unlocked by pulling the black handle which is located behind the rear attachment.


#### *Forward Adjustment:*


Whilst keeping the handle pulled, push the pedals forward with your feet. Release the handle and allow the pedals to lock into place.

#### *Rearward Adjustment:*


Using the unlocking handle, pull the pedals back to the desired position. Release the handle and push the pedals forward with your feet until they lock into place.

## 7.4 INSTRUMENT PANEL





**Instrument Panel with G1000**



Instrument Panel with SED, MED and White Wire Annunciator Panel

**Major Instruments and Controls**

1	Electric Master key switch	21	ELT control unit
2	Fuel Transfer switch	22	Accessory power socket
3	Pitot Heat switch		
4	Avionics Master switch	24	Primary Flight Display (PFD)
5	Essential Bus switch	25	Audio amplifier / Intercom / Marker beacon receiver
6	Fuel pumps switch	26	Multi Function Display (MFD)
7	ECU Test button	27	Airspeed Indicator
8	ECU Voter switch	28	Attitude Gyro (artificial horizon)
9	Engine Master switch	29	Altimeter
10	Rotary buttons for instrument lighting and flood light	30	Vertical Speed Indicator (VSI)
11	Light switches	31	Directional Gyro
12	Emergency switch	32	Turn & Bank indicator
13	Circuit breakers*	33	Intercom
14	Flap selector switch	34	Annunciator panel
15	Alternate static valve	35	Main Engine Display (MED)
16	Ventilation nozzles	36	Secondary Engine Display (SED)
17	Backup airspeed indicator	37	Chronometer with OAT Indicator
18	Backup artificial horizon	38	COM/NAV
19	Backup altimeter	39	Transponder
20	Emergency compass		

\*) Designations and abbreviations used to identify the circuit breakers are explained in Section 1.5 - DEFINITIONS AND ABBREVIATIONS of the AFM.

**NOTE**

The figures on previous pages show the typical DA 40 NG installation position for the equipment. The actual installation may vary due to the approved equipment version.

### Cockpit Ventilation

Ventilation in the front is provided by the movable ventilation over nozzles (16) in the instrument panel. Furthermore there are spherical nozzles in the roll bar on the left and right side next to the front seats as well as on the central console above the passengers' heads. The spherical nozzles are opened and closed by twisting.

Unconditioned ambient air is supplied to the interior through an inlet on the bottom surface of the left wing. To increase cabin temperatures when operating at low outside air temperatures, a ventilation inlet baffle may be installed at the inlet. With the baffle installed, the rear cabin ventilation nozzles on the left and right hand side and in the central console above the passengers' heads will be inoperative.

The ventilation inlet baffle consists of a metal plate with rubber edging and is attached to the bottom LH wing by a camloc.

### Heating



Heating is operated using two levers located on the small center console under the instrument panel.

Right lever:

up	=	heating ON
down	=	heating OFF

Central lever (air distribution lever):

up	=	airflow to canopy (DEFROST)
down	=	airflow to floor (FLOOR)



## **7.5 LANDING GEAR**

The landing gear consists of a main landing gear of spring steel struts, and a free-castering nose wheel which is spring-loaded by an elastomer package.

The wheel fairings are removable. When flying without wheel fairings, it should be noted that there is a reduction in some areas of performance (see Chapter 5).

### Wheel Brakes


Hydraulically operating disk brakes act on the wheels of the main landing gear. The wheel brakes are individually operated by means of toe pedals.

### Parking Brake

The lever is located on the small center console under the instrument panel, and is in the upper position when the brakes are released. To operate the parking brake pull the lever downwards until it catches. Brake pressure is built up by multiple operation of the toe brake pedals, and is maintained until the parking brake is released. To release, the lever is pushed upwards.



Hydraulic System Schematic



## 7.6 SEATS AND SAFETY HARNESSSES

To increase passive safety, the seats are constructed using a carbon fiber/Kevlar hybrid material and GFRP. The seats are removable to allow the maintenance and inspection of the underlying controls. Covers on the control sticks prevent loose objects from falling into the area of the controls.

The seats have removable furnishings and are equipped with energy-absorbing foam elements.

■ The seats are fitted with three-point safety harnesses. The harnesses are fastened by inserting the belt clip into the belt lock, and are opened by pressing the red release on the belt lock.

The backs of the rear seats can be laid forward after pulling upwards on the knob of the locking bolt.

## 7.7 BAGGAGE COMPARTMENT

The baggage compartment is behind the seat backs of the rear seats. Without a baggage net, no baggage may be loaded.

■ As options, a baggage tube or a baggage extension (OÄM 40-164) or a short baggage extension (OÄM 40-331) may be installed.

### **NOTE**

■ If OÄM 40-331 is installed, make sure that the baggage does not block the air vents in the back wall of the short baggage extension.

## **7.8 CANOPY, REAR DOOR, AND CABIN INTERIOR**

### Front Canopy

The front canopy is closed by pulling down on the canopy frame and locking it with the handle on the left hand side of the canopy frame. On locking, steel bolts catch into mating holes in polyethylene blocks.

"Cooling gap" position: A second setting allows the bolts to lock in, leaving a gap under the forward canopy.

The canopy can be key-locked by a locking mechanism on the left side near the canopy lever by turning the key clockwise. The closed and locked canopy can be opened from inside by pulling the lever inside the opening handle.

### **WARNING**

The airplane may be operated with the front canopy in the "cooling gap" position on the ground only. Before take-off the front canopy must be completely closed and latched, but not key-locked.

Do not key-lock the front canopy before flight to assure emergency evacuation from outside.

A window on the left and right hand side of the canopy can be opened for additional ventilation or as emergency window.

Rear Door

The rear door is closed in the same way, by pulling down on the frame and locking it with the handle. A gas pressure damper prevents the door from dropping; in strong winds the assembly must be held. The rear door is protected against unintentional opening by an additional lever.

The door can be locked by a locking mechanism on the left side near the door opening lever by turning the key clockwise. The closed and locked door can be opened from inside by pulling the lever inside the opening handle. For a better handling an additional handle is mounted.

**WARNING**

Before starting the engine the door must be closed and latched, but not key-locked.

Do not key-lock the door before flight in order to assure emergency evacuation from outside.

### Emergency Axe

If OÄM 40-326 is incorporated an emergency axe is installed on the floor panel under the pilot's seat (see Figure below).


If the canopy can not be opened in case of an emergency use the emergency axe to break through the canopy.

### **WARNING**

Make sure not to harm other persons by using the emergency axe.

### **WARNING**

Beware of sharp edges and fragments of the broken canopy.



## 7.9 POWER PLANT

### 7.9.1 ENGINE, GENERAL

The installed Austro Engine E4-A engine has the following specifications:

- Liquid-cooled four-cylinder four-stroke engine with wet sump lubrication
- Inline construction
- Common rail direct injection
- Propeller speed reducing gear 1:1.69
- Digital engine control with integrated propeller governor (using the gearbox oil system)
- Turbo charger with intercooler

Displacement:

Max. power: 123.5 kW (165.6 DIN-HP) at 2300 RPM  
at sea level and ISA

Max. continuous power: 114.0 kW (152.8 DIN-HP) at 2100 RPM  
at sea level and ISA

The indications for monitoring important engine parameters during operation are integrated within the Garmin G1000 display (if installed) or on the MED and SED (if installed). The engine can only be operated with the ENGINE MASTER switch ON. The engine has an EECU (Electrical Engine Control Unit) which receives its electrical power from the generator when the engine is running. When the engine is not running, the ECU receives its electrical power from the battery.

## 7.9.2 OPERATING CONTROLS

### POWER lever

The engine performance is controlled by the power lever, situated on the large center console. 'Front' and 'rear' are defined in relation to the direction of flight.

This lever is used to set the desired engine power LOAD (%)

Lever forward (MAX) = Full power

Lever to rear (IDLE) = Idle

The ECU controls manifold pressure, injected fuel quantity and propeller speed according to the desired engine power preselected with the power lever.

The propeller governor is attached to the top rear side of the gearbox and uses gearbox oil for propeller pitch regulation. Following a loss of oil pressure the propeller blades go to the low pitch stop (maximum RPM), thus allowing continuation of the flight according to 3.3.6 - DEFECTIVE RPM REGULATING SYSTEM.

### ELECTRIC MASTER

The key can be switched into three positions:

- OFF**        Disconnecting battery power.
- ON**         Connecting battery power to the power distribution system.
- START**     Starting the engine.

### ENGINE MASTER

The engine can only be cranked with the ENGINE MASTER switched to ON. To shut down the engine the ENGINE MASTER is switched to OFF.

### ECU VOTER

For normal operation the switch is set to AUTO. The engine is controlled by either ECU A or ECU B. In case of a failure of the active electrical engine control unit (ECU) there is an automatic switch-over to the other ECU. If the automatic switch over fails, switch over can be done manually by switching to ECU A or ECU B. This procedure should only be applied in an emergency.



ECU TEST*POWER lever at IDLE:*

By pushing and holding the button until the end of the procedure, the self-test of each engine control unit is started. The procedure is possible on the ground only. Otherwise the test will not start. During the procedure the ECU performs a switch from ECU A to ECU B or ECU B to ECU A, whichever is active at the moment, with the propeller cycling. The propeller RPM is monitored automatically by the ECU. When switching from one ECU to the other, a slight shake of the engine may occur. Finally the ECU switches back. After that both caution lights must extinguish and the engine must run without a change.

Alternate Air

In the event of power loss because of icing or blockage of the air filter, there is the possibility of drawing air from the engine compartment. The ALTERNATE AIR operating lever is located under the instrument panel on the left side of the center console. To open the alternate air source the lever is pulled to the rear. The alternate air source is closed, with the lever being in the forward position.

Placard on the lever, forward position:

**ALTERNATE AIR**

Placard on the lever, visible when lever is in the rearward position (alternate air open):

**ALTERNATE AIR  
ON**

### 7.9.3 PROPELLER


An mt-Propeller MTV-6-R/190-69 hydraulically regulated 3-bladed constant speed propeller is installed. The propeller has wood-composite blades with fiber-reinforced plastic coating and metal leading edge protection; in the region of the propeller hub the leading edge is coated with adhesive PU tape. These blades combine the lowest weight whilst minimizing vibration.

#### Propeller Control

The propeller pitch is controlled by the P-853-16 mt-propeller governor. The pitch is set by the ECU via an electro-mechanical actuator on the governor. To change the blade pitch angle, gearbox oil is pumped into the propeller hub which leads to an increase in pitch and a lower propeller RPM. When oil leaves the propeller hub pitch is reduced and RPM will increase.

In flight depending on the power setting the propeller pitch is adjusted such that the required RPM will be obtained as shown in the following diagram.

Propeller Setpoint Curve




*Ground Operation:***CAUTION**

Operation on the ground at high RPM should be avoided as far as possible, as the blades could suffer stone damage. For this reason a suitable site for engine runs should be selected, where there are no loose stones or similar items.


**WARNING**

Never rotate the propeller by hand.

**7.9.4 FUEL SYSTEM**




**Standard Tank Schematic**




**Long Range Tank Schematic**

**Normal Fuel Supply & Normal Fuel Transfer**



**Emergency Fuel Supply & Emergency Fuel Transfer**



Fuel is stored in the fuel tanks which are located in the wings. Normally fuel is taken from the MAIN tank (left wing).

The fuel is injected with high pressure directly into the combustion chambers. The injection nozzles (one per cylinder) are supplied with fuel by the common rail. Pressure inside the rail is generated by a high pressure pump which receives fuel from two independent low pressure fuel pumps. Both pumps are powered electrically. Depending on the power setting the rail pressure is controlled by the ECU through an electric valve.

Fuel that is not injected into the combustion chambers is routed through the AUX fuel tank (right wing) and fed back into the MAIN fuel tank (left wing). This way hot fuel from the rail is cooled and cold fuel in both tanks is heated.

With the help of an electrical transfer pump fuel can be transferred from the AUX tank (right wing) to the MAIN tank (left wing) manually.

The transfer pump is switched off automatically when the auxiliary tank is empty or the main tank is full.

If fuel transfer with the transfer pump becomes impossible for any reason, fuel can also be taken directly from the AUX tank (right wing) by switching the fuel valve to the EMERGENCY position. As the return line goes back into the MAIN tank (left wing), fuel will then be transferred from right to left fuel tank.

As an option additional long range tanks may be installed.

## CAUTION

Switching the fuel valve to the EMERGENCY position will start the transferring of fuel with the help of the electrically driven and engine driven fuel pumps from the auxiliary tank through the fuel return line to the main tank at a rate of approximately 45 US gal/h (170 liter/h) with FUEL PUMPS switch in OFF position. The fuel valve must be switched back to the NORMAL position before the auxiliary tank indication reads zero. If the fuel valve is not switched back to the NORMAL position, the engine will stop running as soon as the auxiliary tank is empty.

### Fuel Pumps

The engine is supplied with fuel by two parallel installed independent low pressure electrically driven fuel pumps. During normal operation one of the two fuel pumps is always working. In case of a low fuel pressure, the ECU switches automatically to the second fuel pump. During landing and take-off, or in case of a low fuel pressure both fuel pumps can be activated with the FUEL PUMPS switch. If both fuel pumps are set to ON the fuel pressure increases.

Each fuel pump is electrically connected to an ECU BUS and protected by a 7.5 A circuit breaker.

## NOTE

By switching between ECU A and B the two independent electrical fuel pumps are switched over as well. In case of an emergency both pumps can be activated simultaneously by pushing the FUEL PUMPS switch to the ON position.



### Fuel Valve

The fuel valve is located at the center console. The selectable positions are NORMAL, EMERGENCY and OFF. The desired position is reached by turning the valve handle while pulling up the safety latch on the valve handle. This is to ensure that a selection is not made unintentionally.

### Standard Fuel Tanks

#### *Main Tank (Left Wing):*

The main tank consists of an aluminum chamber and a filler tube which are connected by a flexible hose. There are two tank vents. One includes a check valve with a capillary and one includes a pressure relief valve, which operates at 150 mbar (2 PSI) and allows fuel and air to flow to the outside at higher internal pressure. The relief pressure valve protects the tank against high pressure if the tank will be overfilled in case of a fuel transfer failure. The check valve with capillary allows air to enter the tank but prevents flow of fuel to the outside. The capillary equalizes the air pressure during climb. The hose terminations are situated on the underside of the wing, approximately 2 meter (7 ft) from the wing tip.

#### *Auxiliary Tank (Right Wing):*

The auxiliary tank consists of an aluminum chamber and a filler tube which are connected by a flexible hose. There are two tank vents. One includes a check valve with a capillary and one includes a capillary. The check valve with capillary allows air to enter the tank during descent but prevents flow of fuel to the outside. The capillary equalizes the air pressure during climb. The second capillary is installed for additional safety. The hose terminations are situated on the underside of the wing, approximately 2 meter (7 ft) from the wing tip.

In each tank a coarse filter (finger filter) is fitted before the outlet. To allow draining of the tank, an outlet valve (drain valve) is installed at the lowest point of the fuel tank.

A gascolator is located at the bottom side of the fuselage which is the lowest point of the entire fuel system. A drain valve (pull to drain) is mounted to the gascolator, to allow the remove of water and sediment which has collected in the fuel system.

A capacity probe measures the fuel quantity in each tank. The indication is non-linear, therefore proportional calculations to determine the remaining fuel quantity or direct calculations of fuel consumption are not possible. Information about the fuel consumption can be found in Chapter 5 - PERFORMANCE.

Long Range Tank (if installed)

The tank chamber has a capacity of approx. 5 US gal (19 liter). The ventilation system of the main and the auxiliary tank remains unchanged.

When the fuel quantity indicator reads zero, only the unusable fuel remains in the tank. The useable capacity of each tank is 19.5 US gal, the maximum quantity that can be indicated is 14 US gal. Up to an actual quantity of 14 US gal the indication is correct. At an actual quantity above 14 US gal the indication remains at 14 US gal.

**NOTE**


When the fuel quantity indicator reads 14 US gal, the correct fuel quantity must be determined with the alternate mean for fuel quantity indication. If this measurement is not carried out, the fuel quantity available for flight planning is 14 US gal.

Alternate Means For Fuel Quantity Indication

The alternate means for fuel quantity indication allows the fuel quantity in the tank to be determined during the pre-flight inspection. It functions according to the principle of communicating containers. The fuel quantity measuring device has a recess which fits the airfoil of the wing. With this recess the device is held against the stall strip at the leading edge of the wing. The exact position is marked by a bore in the stall strip. Then the metal connector is pressed against the drain of the tank. The amount of fuel in the tank can now be read off from the vertical ascending pipe.

For an exact indication the airplane must stand on a horizontal ground.

The designated place for the fuel quantity measuring device is the bag on the rear side of the pilot seat.




### 7.9.5 COOLING SYSTEM


The engine is liquid cooled. The liquid cooling system consists of a radiator circuit (coolant heat exchanger) and a bypass circuit (cabin heat exchanger). The radiator circuit is only open during hot coolant temperatures. This assures that a cold engine will warm up quickly. Upon reaching approximately 80°C (126°F) coolant temperature the radiator circuit is activated by a thermostatic valve.

Integrated in the bypass circuit is a coolant to air heat exchanger (cabin heat exchanger) which provides warm air for the cabin heat system.

An coolant expansion tank allows coolant expansion and pressure adjustment. The coolant system is protected against overpressure by means of a pressure relief valve.



### 7.9.6 TURBO CHARGER SYSTEM



The intake air is compressed in the compressor which is driven by the turbine, and is subsequently cooled down in the intercooler. Cooling the air increases engine efficiency and power through the higher density of cold air. The exhaust system contains a manifold which collects exhaust gases from the outlets of the cylinders and feeds them to the turbine of the turbo charger. Behind the turbine the exhaust gases are guided through an exhaust pipe and exits at the bottom cowling opening. Excess exhaust gases bypass the turbine. The bypass is controlled by the ECU through the waste gate valve. A manifold pressure sensor behind the compressor allows the ECU to calculate the correct position of the waste gate valve. This prevents excessive manifold pressures at low density altitudes.

### 7.9.7 OIL SYSTEMS

The engine has two separate oil systems.

#### Lubrication System (Engine and Turbo Charger)

The engine lubrication is a wet sump lubrication system. Oil is cooled by a separate cooler on the underside of the engine.

A dip-stick is provided to check the oil quantity through an inspection door on the LH side of the upper cowling. If required, oil can also be filled in there (for specified oil types refer to 2.4 - POWER-PLANT LIMITATIONS).

#### Gearbox and Propeller Governor System


The second oil circuit lubricates the gear and serves the governor system and the regulation of the propeller.

Gear oil quantity can be checked via an inspection glass which can be reached through an inspection door on the LH side of the upper cowling.

### **CAUTION**

If the gear oil quantity is too low, an unscheduled maintenance is necessary (for specified oil types refer to 2.4 - POWER-PLANT LIMITATIONS).

### 7.10 ELECTRICAL SYSTEM



Electrical System Schematic

### 7.10.1 GENERAL

The DA 40 NG has a 28 Volt DC system, which can be sub-divided into:

- Power generation
- Storage
- Distribution
- Consumers

#### Power Generation

Power generation is provided by a 70 Ampère alternator (generator) which is mounted on the bottom left side of the engine. The alternator is driven by a flat-belt.

The power output line of the alternator is connected to the ENG ECU bus via a 100 A fuse, which is installed in the instrument panel. The power output line also runs through the current sensor, which provides an indication of the power being supplied to the electrical system by the alternator including the current for battery charging.

In the event of a main battery failure the field of the alternator is energized by two 12 V, 7.2 Ah sealed-lead-acid batteries (ECU backup batteries) which are installed behind the first ring frame. The ENGINE MASTER switch connects the ECU backup battery to the alternator voltage regulator via a 10 A fuse.

#### *Alternator Control:*

The alternator control unit includes a comprehensive set of diagnostic functions that will warn the operator using a warning message (ALTN FAIL on the G1000 system (if installed) or ALTERNATOR on the White Wire annunciator panel (if installed)) in case of over- or undervoltage as well as a couple of other internal warning levels.



### Storage

Main battery power is stored in a 24 V, 13.6 Ah lead-acid battery mounted behind the baggage compartment frame. The main battery is connected to the battery bus via the battery-relay which is installed in the relay junction box behind the baggage compartment frame.

The battery relay is controlled with the ELECTRIC MASTER key switch which is located in the center of the instrument panel.

In addition, two 12 V, 7.2 Ah sealed-lead-acid batteries (ECU backup-batteries) are installed behind the first ring frame as a further source of electrical power for the Engine Control Unit (ECU B only).

Under normal operating conditions the ECU backup batteries are charged by the ECU bus. In the event of an alternator failure and a depleted main battery the ECU backup batteries automatically supply electrical power to ECU B via a 32 A fuse. This prevents the engine from stopping in the unlikely event of an alternator failure and a totally discharged main battery.

In addition, a non-rechargeable dry battery is installed in the IFR model as a further source of power for the attitude gyro (artificial horizon) and the flood light. When the EMERGENCY switch is set to ON, these two systems are supplied with power for 1 hour, independent of all other electrical consumers. During each 100 hour inspection, this battery is checked for proper functioning. Every 2 years or after use (broken seal on the switch) the battery pack must be replaced.

### Distribution

Electrical power is distributed via the hot battery bus, the battery bus 1, the battery bus 2, the ECU-bus, the main bus, the essential bus and the avionic bus.

#### *Hot Battery Bus:*

The hot battery bus is directly connected to the main-battery installed in the relay junction box and cannot be disconnected from the main battery. The hot battery bus provides power to the accessory power plug and ELT which are protected by their own fuses.

#### *Battery Bus 1:*

The battery bus 1 is connected to the main-battery via the battery-relay which can be controlled by the ELECTRIC MASTER key switch. The battery bus 1 provides power to the battery bus 2 and heavy duty power to the starter.

The battery bus 1 is also connected to the power input line of the external power plug.

#### *Battery Bus 2:*

The battery bus 2 is connected to the battery bus 1 via a 100 A fuse and provides power to the ECU bus via a 80 A fuse. It also provides power to the main bus via the power relay which can be controlled by the ELECTRIC MASTER key switch and the ESSENTIAL BUS switch. The ELECTRIC MASTER key switch must be set to ON and the ESSENTIAL BUS switch must be set to OFF to connect the battery bus to the main bus.

#### *ECU Bus:*

The ECU bus is connected to the battery bus 2 via a 80 A fuse and provides power for the ECU A and ECU B and their fuel pumps. It is also connected to the power output line of the alternator via a 100 A fuse. It also provides power for charging the ECU backup-battery. The ENGINE MASTER switch must be set to ON to activate the ECU A and ECU B to the ECU bus.

*Main Bus:*

The main bus is connected to the battery bus via the power-relay. It provides power to the consumers directly connected to the main bus and the avionic bus via the avionic master-relay. The AVIONIC MASTER switch must be set to ON to connect the main bus to the avionic bus. Under normal operating conditions the main bus is also connected to the essential bus via the essential tie-relay. In the event of an alternator failure the pilot must switch ON the ESSENTIAL BUS switch (refer to Section 3.4 - FAILURES IN THE ELECTRICAL SYSTEM). This separates the main bus from the battery bus and the essential bus and the equipment connected to the main bus no longer has power.

*Essential Bus:*

Under normal operating conditions the essential bus is connected to the main bus via the essential tie-relay. The essential bus provides power to the consumers connected to the essential bus. The AVIONIC MASTER switch must be set to ON to connect the essential bus to the avionic bus. In the event of an alternator failure the pilot must switch ON the ESSENTIAL BUS switch (refer to Section 3.4 - FAILURES OF THE ELECTRICAL SYSTEM). This separates the essential bus from the main bus. The essential bus is then connected to the battery bus 2 which provides battery power for a limited time to the equipment essential for safe flight and landing.

Consumers

The individual consumers (e.g. radio, electrical fuel transfer pump, position lights, etc.) are connected to the appropriate bus via automatic circuit breakers.

Designations and abbreviations used to identify the circuit breakers are explained in Section 1.5 - DEFINITIONS AND ABBREVIATIONS.

### Voltmeter

The voltmeter shows the voltage of the essential bus. Under normal operating conditions the alternator voltage is shown, otherwise it is the voltage of the main battery.

### Ammeter

The ammeter displays the intensity of current which is supplied to the electrical system by the alternator, including the current for battery charging.

### Landing and Taxi Lights

Landing and taxi lights are built into the left wing, and are each operated by means of a switch (LANDING, TAXI) on the row of switches on the instrument panel.

### Position and Strobe Lights


Combined position and strobe lights (anti collision lights) are installed on both wing tips. Each system is operated by a switch (POSITION, STROBE) on the row of switches on the instrument panel.

### Flood Light

A two-dimensional light emitter is mounted above the instrument panel. It illuminates the instrument panel as well as all levers, switches, etc. With a rotary button (FLOOD) in the left-hand section of the instrument panel the flood light is switched on and its brightness is adjusted.

Instrument Lighting

With a rotary button (INSTRUMENT) in the left-hand section of the instrument panel the internal lighting of the instruments is switched on and its brightness is adjusted.



Pitot Heating

The Pitot probe, which provides measurement for the Pitot-static system, is electrically heated. The heating is activated with a switch (PITOT) on the row of switches on the instrument panel. The temperature is automatically kept constant by means of a thermal switch on the Pitot probe, and as an additional safety measure a thermal fuse is built in. If this thermal fuse is activated, the Pitot heating can no longer be switched on. PITOT FAIL on the G1000 (if installed) or PITOT on the White Wire annunciator panel (if installed) will be displayed, if the thermal fuse or the thermal switch is activated and the PITOT HT is set to ON. The PITOT HT OFF indication on the G1000 (if installed) is on if the Pitot heating is switched off.

### 7.10.2 ENGINE CONTROL UNIT / ECU

#### Engine Control and Regulation

The Electrical ECU is used to control the engine actuator (e.g. fuel injector) according to the engine sensor information. The ECU monitors, controls and regulates all important parameters for engine operation.

Sensors installed are:

- Oil temperature (lubrication system engine) / OIL TEMP (G1000, if installed),  
OT (MED, if installed)
- Oil pressure (lubrication system engine) / OIL PRES (G1000, if installed),  
OP (MED, if installed)
- Coolant temperature / COOLANT TEMP (G1000, if installed),  
CT (MED, if installed)
- Gearbox temperature / GEARBOX (G1000, if installed),  
GT (MED, if installed)
- Camshaft RPM (twice)
- Crankshaft RPM (twice)
- Fuel pressure in the common rail
- Manifold pressure
- Manifold air temperature
- Ambient air pressure
- Propeller governor / oil pressure
- POWER lever position (twice)
- Voltage
- Starter switch signal
- Fuel pressure
- VOTER switch signal
- ECU TEST switch signal

In accordance with the received signals and a comparison with the programmed characteristic diagrams the necessary inputs are calculated and transmitted by the following signal lines to the engine:

- Signal for propeller governor pressure valve
- Signal for the rail-pressure regulation valve
- Signal for each of the 4 injection nozzles
- Activation of the glow plugs
- Signal for the waste gate valve

■ The following alerts are displayed on the PFD of the G1000 (if installed) or White Wire annunciator panel (if installed):

- Glow sparks active
- Status ECU A
- Status ECU B
- - Low fuel pressure warning (on the G1000, if installed)

The Electrical ECU consists of two similar ECUs. A VOTER switch is integrated in the Electrical ECU and proposes an ECU to control the engine regarding the ECU operating hours or in case of a failure the ECU with better engine control capability.

■ A fault in one of the ECUs is indicated by a caution message (ECU A/B FAIL on the PFD (if G1000 is installed) or ECU A/B on the White Wire annunciator panel (if installed)). After the indication of the ECU A/B FAIL or ECU A/B caution message, the engine must be serviced.



### **7.11 PITOT-STATIC SYSTEM**

Total pressure is measured at the leading edge of a Pitot probe under the left wing. Static pressure is measured through the static ports in the rear fuselage. To protect against dirt and condensation there are filters in the system. The Pitot probe is electrically heated.

With the alternate static valve, the static pressure in the cabin can be used as static pressure source in the event of a failure of the static system.

### **7.12 STALL WARNING SYSTEM**

If airspeed drops, suction on the orifice at the leading edge of the left wing will increase until the stall warning horn, located in the instrument panel, will sound. The horn becomes progressively louder the closer one gets to stalling speed. Suction at an orifice on the left wing leading edge activates the horn via a hose. The orifice for the stall warning in the left wing is marked by a red ring.

**Airplane  
Description**



**DA 40 NG AFM**

Intentionally left blank.

## CHAPTER 8

# AIRPLANE HANDLING, CARE AND MAINTENANCE

	Page
8.1 INTRODUCTION .....	8-2
8.2 AIRPLANE INSPECTION INTERVALS .....	8-2
8.3 AIRPLANE ALTERATIONS OR REPAIRS .....	8-3
8.4 GROUND HANDLING / ROAD TRANSPORT .....	8-3
8.4.1 GROUND HANDLING WITHOUT TOW BAR .....	8-3
8.4.2 GROUND HANDLING WITH TOW BAR .....	8-4
8.4.3 PARKING .....	8-6
8.4.4 MOORING .....	8-8
8.4.5 JACKING .....	8-8
8.4.6 ALIGNMENT .....	8-8
8.4.7 ROAD TRANSPORT .....	8-9
8.5 CLEANING AND CARE .....	8-10
8.5.1 PAINTED SURFACES .....	8-10
8.5.2 CANOPY AND REAR DOOR .....	8-10
8.5.3 PROPELLER .....	8-11
8.5.4 ENGINE .....	8-11
8.5.5 INTERIOR SURFACES .....	8-11
8.6 GROUND DE-ICING .....	8-12

## **8.1 INTRODUCTION**

Chapter 8 contains the manufacturer's recommended procedures for proper ground handling and servicing of the airplane. The Airplane Maintenance Manual (Doc. No. 6.02.15) lists certain inspection and maintenance requirements which must be followed if the airplane is to retain a new plane performance and reliability.

## **8.2 AIRPLANE INSPECTION INTERVALS**

Inspections are scheduled every 100, 200 and 1000 hours. Independent of the flight hours an annual inspection must be performed every year. The respective inspection checklists are prescribed in the Airplane Maintenance Manual, Chapter 05.

For maintenance work on engine and propeller, the currently effective Operator's Manuals, Service Instructions, Service Letters and Service Bulletins of Austro Engine and mt-propeller must be followed. For airframe inspections, the currently effective checklists/manuals, Service Bulletins and Service Instructions of the manufacturer must be followed.

### **CAUTION**

Unscheduled maintenance checks are required after:

- Hard landings
- Propeller strike
- Engine fire
- Lightning strike
- Occurrence of other malfunctions and damage

Unscheduled maintenance checks are described in the Airplane Maintenance Manual (Doc. No. 6.02.15; Section 05-50).

### **8.3 AIRPLANE ALTERATIONS OR REPAIRS**

Alterations or repairs of the airplane may be carried out only according to the Airplane Maintenance Manual, Doc. No. 6.02.15, and only by authorized personnel.

### **8.4 GROUND HANDLING / ROAD TRANSPORT**

#### **8.4.1 GROUND HANDLING WITHOUT TOW BAR**

During forward traversing the nose wheel will follow the movement of the airplane. Change in direction is achieved by pulling on the propeller near the spinner. To traverse in the rear direction, the tail section of the airplane should be pushed down until the nose wheel is clear of the ground. This method can also be used to turn the airplane around its main landing gear.

#### **8.4.2 GROUND HANDLING WITH TOW BAR**

For pushing or pulling the airplane on the ground, it is recommended to use the tow bar which is available from the manufacturer. The tow bar is bent apart and engaged in the appropriate holes in the nose wheel fairing as shown on the picture below. The arresting knob must be fully engaged.



**WARNING**

The tow bar must be removed before starting the engine.

**CAUTION**

The tow bar may only be used for moving the airplane on the ground by hand. After moving the airplane, the tow bar must be removed.

**NOTE**

When moving the airplane rearward, the tow bar must be held firmly to prevent abrupt sideward deflection of the nose wheel.

### **8.4.3 PARKING**

For short term parking, the airplane must be positioned into the wind, the parking brake must be engaged and the wing flaps must be in the retracted position. For extended and unattended parking, as well as in unpredictable wind conditions, the airplane must be anchored to the ground or placed in a hangar. Parking in a hangar is recommended.

#### **Control Surfaces Gust Lock**

The manufacturer offers a control surfaces gust lock which can be used to block the primary controls. It is recommended that the control surfaces gust lock be used when parking outdoors, because otherwise the control surfaces can hit the stops in strong tail wind. This can lead to excessive wear or damage.

### **WARNING**

The control surfaces gust lock must be removed before flight.

The control surfaces gust lock is installed as follows:

1. Move the rudder pedals fully rearward.
2. Engage the control surfaces gust lock with the pedals.
3. Engage the stick, wrap straps around stick once.
4. Attach the locks and tighten the straps.

For removal, reverse the sequence.

### **NOTE**

It is recommended to cover the canopy when the airplane is parked outdoors, in direct sunlight, at outside air temperatures above +25 °C (77 °F), in order to prevent excessive heat generation within the instrument panel which can cause damage to the equipment. Such a canopy cover is available from Diamond Aircraft Industries, P/N: S\_30172.





#### **8.4.4 MOORING**

The tail fin of the airplane has a hole which can be used to tie-down the airplane to the ground. Also on each wing near the wing tip, an eyelet with a metric M8 thread can be installed and used as tie-down points.

#### **8.4.5 JACKING**

The airplane can be jacked at the two jackpoints located on the lower side of the fuselage's LH and RH root ribs as well as at the tail fin.

#### **8.4.6 ALIGNMENT**

For alignment push down on the tail section at the fuselage/vertical tail junction until the nose wheel is clear of the ground. With the nose wheel free, the airplane can be turned around the main landing gear. After turning the airplane into the correct position, release the tail section slowly until the nose wheel is back on the ground.

### **8.4.7 ROAD TRANSPORT**

For transporting the airplane on the road it is recommended that an open trailer be used. All airplane components must be stored on a cushioned surface and secured to avoid any movement during transportation.

#### **NOTE**

Disassembling and Assembling of the airplane is a maintenance action and requires qualified personnel.

##### *1. Fuselage:*

The fuselage should stand on the main and nose landing gear. It must be ensured that the fuselage will not move in any direction. Furthermore, it must be ensured that the propeller has sufficient clearance so that it cannot be damaged due to fuselage movement during transportation.

##### *2. Wings:*

For transportation, both wings must be removed from the fuselage. To avoid any damage, the wings must be stored in an upright position on the leading edge with the root rib area positioned on an upholstered profiled surface with a width of at least 400 mm (1.3 ft). The outside wing area (approximately 3 m (10 ft) from the root rib area) must be placed on an upholstered profiled surface with a minimum width of 300 mm (1 ft).

The wings must be secured to avoid any sliding movement to the rear.

##### *3. Horizontal Stabilizer:*

The horizontal stabilizer must be stored flat on the trailer and secured with straps, or in an upright position sitting on the leading edge on a profiled surface. All storing surfaces must be upholstered with felt or cellular rubber.

## **8.5 CLEANING AND CARE**

### **CAUTION**

The airplane must be kept clean. The bright surface prevents the structure from overheating.

### **CAUTION**

Excessive dirt deteriorates the flight performance.

#### **8.5.1 PAINTED SURFACES**

The entire surface of the airplane is painted with a white weatherproof two component paint. Nevertheless, it is recommended to protect the airplane against moisture and dampness. It is also recommended not to store the airplane outside for long periods of time.

Dirt, insects, etc. can be removed with water alone and if necessary with a mild detergent. An automotive paint cleaner can be used for stubborn spots. For best results, clean the airplane after the day's flying is ended, so that the dirt will not become ingrained.

Oil stains, exhaust stains, etc. on the lower fuselage skin can be removed with a cold detergent. Before starting, ensure that the detergent does not affect the surface finish. Use commercial automotive preservatives without silicone additives to conserve the paint finish.

#### **8.5.2 CANOPY AND REAR DOOR**

The canopy and rear door should be cleaned with 'Plexiklar' or any other acrylic glass detergent if available; otherwise use lukewarm water. Final cleaning should be done with a clean piece of chamois-leather or soft cloth. Never rub or polish dry acrylic glass.

### **8.5.3 PROPELLER**

Damage and malfunctions during operation must be inspected by authorized personnel.

#### Surface

The manufacturer uses PU paint or acrylic paint which is resistant to almost any solvent. The blades may be treated with commercial automotive cleaning agents or preservatives. The penetration of moisture into the wooden core must be avoided by all means. Should doubts arise, an appropriately rated inspector must be consulted.

### **8.5.4 ENGINE**

Engine cleaning is part of the scheduled inspections.

### **8.5.5 INTERIOR SURFACES**

The interior should be cleaned using a vacuum cleaner. All loose items (pens, bags etc.) should be removed or properly stored and secured.

All instruments can be cleaned using a soft dry cloth, plastic surfaces should be wiped clean using a damp cloth without any cleaning agents.

### **CAUTION**

The PFD and MFD displays use a lens coated with a special anti-reflective coating that is very sensitive to skin oils, waxes, and abrasive cleaners. CLEANERS CONTAINING AMMONIA WILL HARM THE ANTI-REFLECTIVE COATING. It is very important to clean the lens using a clean, lint-free cloth and an eyeglass lens cleaner that is specified as safe for anti-reflective coatings.

## **8.6 GROUND DE-ICING**

Approved de-icing fluids are:

<b>Manufacturer</b>	<b>Name</b>
„Kilfrost“	TKS 80
„Aeroshell“	Compound 07
Any source	AL-5 (DTD 406B)

1. Remove any snow from the airplane using a soft brush.
2. Spray de-icing fluid onto ice-covered surfaces using a suitable spray bottle.
3. Use a soft piece of cloth to wipe the airplane dry.

## CHAPTER 9 SUPPLEMENTS

	Page
9.1 INTRODUCTION .....	9-2
9.2 LIST OF SUPPLEMENTS .....	9-3

## **9.1 INTRODUCTION**

Chapter 9 contains information concerning additional (optional) equipment of the DA 40 NG.

Unless otherwise stated, the procedures given in the Supplements must be applied in addition to the procedures given in the main part of the Airplane Flight Manual.

All approved supplements are listed in the List of Supplements in this Chapter.

The Airplane Flight Manual contains exactly those Supplements which correspond to the installed equipment according to the Equipment Inventory of Section 6.5.

### **NOTE**

The listed Supplements cannot be installed in any arbitrary combination.



## 9.2 LIST OF SUPPLEMENTS

Airplane S/N:		Registration:		Date:	
Sup. No.	Title	Rev. No.	Date	applicable	
				YES	NO
A01	Garmin G1000 Avionics System	0	15 Mar 2011	<input type="checkbox"/>	<input type="checkbox"/>
A02	Intercom PM 1000 II	0	15 Mar 2011	<input type="checkbox"/>	<input type="checkbox"/>
A05	Conventional Cockpit DA 40 NG Club (SED, MED, White Wire Annunciator Panel)	0	15 Mar 2011	<input type="checkbox"/>	<input type="checkbox"/>
A13	Autopilot System KAP 140 Bendix/King	1	15 Mar 2011	<input type="checkbox"/>	<input type="checkbox"/>
A29	Garmin Transponder GTX 328	0	15 Mar 2011	<input type="checkbox"/>	<input type="checkbox"/>
A30	Garmin COM/NAV SL 30	0	15 Mar 2011	<input type="checkbox"/>	<input type="checkbox"/>
S04	ELT ME 406	0	01 Apr 2010	<input type="checkbox"/>	<input type="checkbox"/>
S06	G1000 Synthetic Vision Technology	1	15 Mar 2011	<input type="checkbox"/>	<input type="checkbox"/>
S07	Recirculating Cabin - Air Cooling	2	15 Mar 2011	<input type="checkbox"/>	<input type="checkbox"/>

Intentionally left blank.