

INTRODUCTION

Welcome to the GEODOS system.

GEODOS is a SURVEYING SOFTWARE PACKAGE for the hand held computer PSION Organiser II model XP and LZ. The examples in this manual are made for model XP. The only difference between XP and LZ is the display functions.

This manual describes how to handle GEODOS. The manual is designed to be used in the field and contains instructions and examples of the different surveying methods.

The first chapter describes the most important and commonly used functions in order to quickly get the user more easily acquainted with the system.

Please start by reading the first 15 pages (chapters 1-4) in the "Operating Manual" for the PSION computer.

The introduction example on page 10 in this manual will give You a quick idea of how to handle the MENU, which is the key feature to the whole system.

There are also descriptions with training examples for each program. Most of the programs contain common functions, error messages and routines. They will not be repeated on each page, so start by reading chapter "General instructions" on page 14 before you run the different programs.

You will soon recognise the logic in the system. The different programs access common databases called JOB-files. A JOB-file may contain coordinates, survey-data, roadline-elements such as straight, arc, transition curve data etc.

You will soon discover that you are working with an advanced software package contained in a very powerful computer.

GEODOS is being developed continuously with the help from you the USER. Small differences may therefore occur between the version of the manual and the programs. You are very welcome to come with your own suggestions regarding how to improve the GEODOS system. Together we will continue to develop the GEODOS-system.

Welcome to the team.

PARTILLE, SWEDEN SEP 1994

VIKER DATA AB
Box 181
S-433 23 PARTILLE
Sweden

INDEX. -----	Page -----
Introduction	1
Index	2
Geodos-functions, preview	3
Getting started	6
Keyboard functions	8
Introduction example	10
Description of the database (JOB-files)	11
Handling the MENU.	12
Enter a JOB.	13
General instructions and messages	14
Program descriptions with training samples	
PREG Point registration	16
POLSO Polar setout	18
POLMS Polar measurement	20
EDIT Edit JOB-files	24
RCTSO Rectangular set out	26
RCTMS Rectangular measurement	28
2PRES Two point resection	30
ARES Angular resection	32
FREST Free station measurement	34
TRVRS Traverse measurement	36
AINT Angle intersection	40
DINT Distance intersection	42
HTRNS Helmert transformation	44
AREA Area calculation	46
CHECK Check measurement printout	48
PRINT Print coordinate-list	50
SEND Transmit JOB-files	52
RECIV Receive JOB-files	54
JBDIR JOB-directory listing	56
ERASE Erase JOB-files	57
TRIG Trigonometric height-/dist-diff	58
RLDES Road-line design	60
RLREG Road-line registration	62
RLSO Road-line set out	66
DIGI Digitizing	68
PLOT Plotting	70
CODTAB Code table for plot/transfer	72
CSDATA Calculate survey data	74
ZSTN Height determ. of station-point	75
REFLIN Definition of reference-line	76
PROFILE Calculation of ground section	78
VOLUME Volume calculations	82
USER Resetting own user parameters	84
COPY Copy of JOB files	86
TAKE CARE OF YOUR DATA	87
USER PROGRAMMING	88
GEODOS DATA BASE description	89

GEODOS ver 5 and 6 contains the following programs.

PREG POINT REGISTRATION
Entering Pno,Code,North-,East- and Height-coordinates.

POLSO POLAR SETOUT
Calculate polar set-out data in 3 dimensions.
Totalstations can be used on line.

POLMS POLAR MEASUREMENT
Coordinate-calculation or survey data collection.
Possibility to eccentric corrections. After surveydata-
collection calculation can be made with program
"CSDTA" below.

EDIT EDIT JOB
Search, Edit, Erase, Insert in the JOB-file.

ORTSO RECTANGULAR SETOUT
Calculation of rectangular set-out data in 3 dimensions
from north-,east- and height-coordinates.

ORTMS RECTANGULAR MEASUREMENT
Calculation of coordinates in 3 dimensions from
rectangular dimensions e.g. from design drawings.

2PRES TWO POINT RESECTION
Determination of free station coordinates in three
dimensions from two known points.

ARES ANGLE RESECTION
Determination of free station coordinates in three dim.
by angle measurement toward three or four known points.

FREST FREE STATION
Determination of free station coordinates in three dim.
by angle and distance measurement to optional number
of known points. (Helmert transformation).

TRVRS TRAVERSE MEASUREMENT
Coordinate calculation of traverse measurement in three
dim. Closed or unclosed.

AINTE ANGLE INTERSECTION
Calculation of coordinates in three dimensions from
two or three standpoints. Average and deviations.
Different totalstations can be on line connected (RMS).

DINT DISTANCE INTERSECTION (Trilateration)
Coordinate-calculation (North,East) from two distances
from two known station points.

HTRNS HELMERT TRANSFORMATION
Transformation of all data in a JOB from one grid system to another. The program searches for points with common names in two different JOBS. These are used as common points to build the transformation formula.

AREA AREA CALCULATION
Calculation of bearings, distances and area within polygon

CHECK CHECK MEASUREMENT PRINTING
Comparison of coordinates between two JOB-files. Points with the same names will be compared and coordinate-differences will be printed out or displayed.

PRINT PRINT JOB
Printout coordinate-list of whole or part of a JOB.

SEND DATA-TRANSMISSION of JOB-files to or from optional
RECIV computer-systems. Software for implementation under
MSDOS is included.

JBDIR JOB DIRECTORY
Listing of existing JOBS in the computer.

ERASE ERASE JOB-files.

TRIG Calculation of distance and height. (Cosine theorem)

RLDES ROAD-LINE DESIGN
Calculation of intersection-, tangent-, and center-points from paralell-distances and radius from existing road lines.

RLREG ROAD-LINE REGISTRATION
Definition of roadline in three dimensions (PLANE, PROFILE, and SECTION) for setting out ("RLSO"). Road-line can be defined as follow:
PLANE: Straight, Arc and Transition-curve)
PROFILE: Slant and vertical-curve
SECTION: Any number of design-points in section.

RLSO ROAD-LINE SETOUT
Calculation of polar set out of optional section point and off-set. Heights will be interpolated from design profile and section if present.

DIGI DIGITIZING
Input of coordinates by digitizing with XPLAN 360i PLANIX-5000 or DIGICORD. Optional input of heights.

PLOT PLOTTING
Automatic plotting with HP-GL compatible plotter of grid net, coordinate text, points, point names, height-text and lines. Optional scale and format.

CODTAB CODE-TABLE
Create, Edit, and Print out table. Code-table is used for translation of field codes to transfer codes and plot symbols.

CSDATA CALCULATE SURVEY DATA
Calculation of polar survey data stored with program "POLMS".

STNH STANDPOINT-HEIGHT
Determination of instrument height by measuring vertical angles to known height-points.

REFLIN REFERENCE LINE DEFINITION
Definition of baseline for direct calculation of rectangular dimensions. Works in combination with "POLSO" and "POLMS". Reference line can either be STRAIGHT LINE, ARC or TRANSITION CURVE (Roadline).

PROF PROFILE CALCULATION.
Calculation of profile data (Length, Offset and Height) from a reference line and offset limit. The program is scanning the database and creates a new file with the profile data. Plot of profile and sections.

VOLUME VOLUME CALCULATION.
Calculation of volume from the 3D database along optional reference line.

APROG ADDITIONAL PROGRAM.
Optional program entry. You can add your own software to the GEODOS-system.

USER This is a PROCEDURE FILE for setting/resetting certain system parameters with which the calculation programs work.

GEODOS-PC Software for MSDOS computers to transform GEODOS data to and from other surveying systems, DXF-files etc. Coordinate calculations and transformations.

GETTING STARTED

Insert the battery with the positive terminal first.

Insert the GEODOS-pack in port B:

Insert the DATA-pack (RAM-pack) in port C:

Switch ON by pressing ON/CLEAR twice.

The Main Menu will be displayed:

```
-----  
GEODOS FIND SAVE  
DIARY CALC PROG  
-----
```

Check that GEODOS is available as follows:

```
Cursor on "G" in GEODOS      -----  
Press "EXE"                  Display: "*GEODOS* ver5.xx  
                               JOB=C:  
Press "EXE"                  -----
```


Display shows "A:TMPJOB" a short while. You have now entered the GEODOS-menu:

```
-----  
PREG POLSO POLMS  
EDIT ORTSO ORTMS etc  
-----
```

Press ON/CLEAR to return to the Main Menu.

When the battery requires changing, ensure first that PSION is switched off. Remove the RAM-pack to ensure no loss of important data if you make any mistake during the change. When You have safely installed the new battery and checked the functions , switch off and reinsert the RAM-pack.

PSION, seen from the back.



To connect the battery, slide it into the opening, making sure that the smaller, positive, terminal enters first. If the battery only slides in half way, then you have tried to put it in the wrong way round. Turn the battery over so that the other metal contact slides into the battery connector first, and try again.

KEYBOARD


There are 36 keys on the keyboard. Each key has up to four functions. The numeric keyboard has a blue background. When using programs within GEODOS, the keyboard is default set to numeric, with the exception of Pcode. If you so desire, you can change this with USER, page 80.

1. ON/CLEAR Step back one level in the MENU-structure.
Finish programs and JOB:s
2. MODE Used in GETTING STARTED to complete the
main menu.
3. ARROWS Move the cursor across menu or results.
Stop and turn when results are displayed
scrolling.
4. CAP,NUM To be used in combination with SHIFT to switch
the keyboard. You normally don't need these in
GEODOS.
5. SHIFT Used to access the characters marked above each
key. In GEODOS the programs take care of this,
You need it only when you mix characters and
figures in pointname and code.
- 6 DEL Delete last character keyed in from keyboard.
7. SPACE Important function in GEODOS. To be used in
combination with "EXE" to return to previous
state or to complete entry in data input.
8. EXE The most important key. EXECUTE.
9. Y / N Answer Yes or No to question "Y/N ?".
- 10 ON+Q "Escape Quit" to stop unwanted loops etc.
Press keys simultaneously until program stops.

If a question mark (?) is displayed during input,
the program demands a numerical input.

In program "EDIT" some keys have special functions which You can read about on page 24.

GEODOS, common KEY functions.



INTRODUCTION EXAMPLE.

This is a basic example that describes, step for step, how to start a program in GEODOS. Compare with the instructions on pages 16-19.

1. Press <ON>	----- GEODOS FIND SAVE DIARY CALC PROG -----	
2. Press <EXE> Key in "EXAMPLE" Press <EXE>	*GEODOS* ver5.99 JOB= ----- CREATE NEW JOB Y/N ? -----	
3. Press <Y>	-----	
4. Press <EXE>	COORDINATES SURVEYDATA FREE SPACE 935 PNT -----	
5. Press <EXE>	PREG POLSO POLMS EDIT ORTSO ORTMS -----	Select prog "PREG"
6. Press <EXE>	**** GEODOS *** * POINT REG *	
7. Type 101 <EXE> " PP <EXE> " 1254.208 <EXE> " 2012.292 <EXE> " 48.342 <EXE> Press <EXE> " <EXE> Type 1474.381 <EXE> " 2037.436 <EXE> " 48.455 <EXE> Press <SPACE> <EXE>	----- Pno=1= Cod== N= E= Z=0.000= Pno=102= Cod=PP= N= E= Z=48.342= Pno=103= -----	PSION suggest latest PNO+1 and same CODE and Z coord. as previous.
8. Press < -> ><EXE>	PREG POLSO POLMS EDIT ORTSO ORTMS -----	Finish "PREG"
9. Press <EXE>	**** GEODOS **** * POL SETOUT *	
10. Press 101 <EXE>	STATION Pno=102= -----	You now select prog "POLSO"
11. Press Arrow Keys " " " " <EXE>	Pno=101 Cod=PP N= 1254.208 E= 2012.292... -----	PSION suggests point number. Scan with the arrow keys if You want to look at coord
12. Press <EXE>	MANUAL-INPUT WILD-TC WILD-TD... -----	Select input media.
13. Press <EXE>	CHECK SURVEYDATA Y/N ?	<N> for fast without control

DESCRIPTION OF JOB-FILES

The GEODOS-programs access databases called JOB-files.

When you start GEODOS you will be asked for JOB-name.
GEODOS ver5.xx (ver6.xx for LZ)
JOB=C:

Enter JOB-name with max EIGHT CHARACTERS (A-Z, 0-9).
The first character must always be a letter.

If you only press <EXE> a temporary JOB-file will be created called "A:TMPJOB". Previous TMPJOB will be deleted.

You can store a JOB in the internal memory (A:) or in the datapack (C:). Default is C:. If you want to store in A: you must type "A:" before the JOB-name (e.g. A:HELLO).

You can store data in a special JOB-file called "C:PBANK". From this file data can be read from any other JOB-file. Add only a "*" to the pointnumber when you search. (e.g. *12345)

Your JOB-files are safer in the DATA-packs if you e.g have to change the battery or if you accidentally reset the internal memory.

You can easily copy JOB-files from one device to another with the function COPY in the main menu. See page 86.

You can handle an optional number of JOB:s within the memory capacity, which makes about 800-1000 POINTS per 32K memory.

A JOB-file contains records which are called "POINTS".
A Point-record is as follows:

- | | | |
|---------|------------------------|-----------------|
| 1. Pno= | Pointnumber | (Max 12 char.) |
| 2. Cod= | Point information code | (" " ") |
| 3. N= | Northing coordinate | (Real value) |
| 4. E= | Easting coordinate | (" ") |
| 5. Z= | Height coordinate | (" ") |
| 6. D= | Quality value. | (" ") |
| 7. Rem= | Remark | (Max 254 char.) |

By survey data collection:

1. Pno= As above
2. Code= " "
3. Ha= Horizontal angle (Ih, instr.height at stn)
4. Va= Vertical angle
5. Sd= Slope distance
6. Th= Target height
7. Rem= Remark

Totally there is enough room for about 800-1000 points per 32K memory. This depends on how many characters Pno, Code and Remark and also how many digits the coordinates comprise of.

PROGRAM START, GEODOS-MENU

When You switch on PSION, you normally enter the Main Menu. After you have plugged in the GEODOS program pack it has the following appearance:

```
-----  
GEODOS FIND SAVE  
DIARY  CALC PROG  
-----
```

The cursor is in position GEODOS, PRESS ONLY <EXE>. PSION asks for JOB-name:

```
-----  
*GEODOS* ver5.99  
*JOB=  
-----
```

If you only want to use a temporary JOB, PRESS <EXE>:

You are now in the GEODOS environment. There are 33 routines contained in the GEODOS MAIN MENU. The first six are now visible in the display, with the cursor on "P" of PREG

```
-----  
PREG  POLSO POLMS  
EDIT  ORTSO ORTMS  
-----  
2PRES ARES  FREST  
TRVRS AINT  DINT  
HTRNS AREA  CHECK  
PRINT SEND  RECIV  
JBLST ERASE TRIG  
RLDES RLREG RLSO  
DIGI  PLOT  CODTAB  
CSDTA ZSTN  REFLIN  
PROF  VOLUM APROG
```

Just move the cursor with the arrow keys to selected a program and press <EXE>. You can also use the first letter in the program name for accessing the program quickly. If the first letter is unique the program starts directly.

PSION always answers with the program header e.g:

```
-----  
**** GEODOS ****  
*  POINT REG  *  
-----
```

Continue : press <EXE>.
Quit : press ON/CLEAR.

GEODOS ver5.99
*JOB=

Enter a GEODOS JOB

INSTRUCTIONS

You can store and work with a JOB in either internal memory A: or in the datapack in port C:. It is safer to store data in C: which has its own battery and is removable. Default is to store in C:. If you want to store in A:, You have to enter A: previous to the JOB-name. (e,g. (JOB=A:TEST)).

You can work in a temporary JOB if you press only <EXE>. Your JOB is then automatically called A:TMPJOB. All data will be erased in the previous "TMPJOB" when you enter it this way.

You can use MENU-technic. Press <X>. You will enter a menu containing all existing JOB-files. Use the arrow-keys and <EXE> to choose JOB. Be aware that there is a limit of 256 characters in each menu.

DISPLAY

COMMENTS

Example 1

GEODOS ver5.99
*JOB=TEST

Program version is displayed
Enter JOB-name.
JOB-file will be stored in the datapack.

CREATE NEW JOB
Y/N?
COORDINATES
SURVEYDATA

When you enter a NEW JOB, you must choose if it will contain COORDINATES or raw SURVEYDATA. You can not mix coordinates and rawdata. If you choose surveydata you can key in an INFORMATION BLOCK = one text string and four numerical data. This data IS NOT USED IN GEODOS calc. but will be transmitted by SEND (page 52) Press just <EXE> if you do not want it.

INFO 0
>

INFO 1 etc....

Example 2.
GEODOS* ver5.99
JOB=X
MENU WORKING..
A:TMPJOB.....

Enter <X>

If there are many JOB-files it can take some seconds.

A:TMPJOB(3p)
A:FURULUND(123p)
C:TEST(456p)
C:EXEMPEL(45p)
.....(236)

You can now use the arrow keys. Press <EXE> for your choice. If you have many JOBS, dots may appear on the last line. Each dot is a JOB. You will get the names in a new menu if you choose the dot line.

Example 3
GEODOS ver 5.99
*JOB=
A:TMPJOB

Press <EXE>

Data will be stored in a temporary file
Previous TMPJOB will be deleted.

GENERAL INSTRUCTIONS

The following messages are general. They will not be specially described in the following program instructions.

DISPLAY	INSTRUCTIONS
**** GEODOS *** * PROGRAM *	After program selection from the menu, the program name is displayed. Press <EXE> to continue or <ON/CLEAR> to escape.
(SURVEYDATA)	The following programs have access to SURVEYDATA POLMS, EDIT, SEND, RECIV, ERASE, CSDTA.
Y/N ?	Press Yes<Y> or No<N> WITHOUT pressing <EXE>.
Pno=101=	Enter POINT NAME. Maximum 12 characters. It is an advantage to use only numbers .PSION then suggests the previous number incremented Press <EXE> to accept.
Pno=100>10 Pno=195<5	You can change the incremental value directly by using the keys ">" or "<" after the number. followed by the value. (See also USER page 82)
P=1 PP EXISTS Y/N ? Diff N=0.002... OK Y/N ? KEEP NEW MEAN	The point name must be unique. You can measure to an existing point. Then you will get the difference and you can choose to keep the old coordinates, change to new or store the mean value. Select in the MENU.
Cod=PP=	Enter point code. PSION suggests same code as previous. The keyboard is, as standard, set to CHARACTER input. Use <SHIFT> for numerical input. You can go back to PNO by pressing <SHIFT> <EXE> if you want to correct.
ex. STATION Pno=#101=	Enter station point name. PSION suggests the previous station. Press <EXE> if you accept. If the point does not exist, you will be asked to enter code and coordinates that will be stored in the JOB-file and you can continue the computation. You can access points from the special POINTBANK (C:PBANK). Enter an asterisk (*) before the number (ex. *101)
101 HC F,L,R,X +EXE	If you enter <+>, you can choose a point in the JOB-file with the following keys: <F>=first,<L>=last,<R>=previous,<X>=next. Press <EXE>.
Pno=101 COD=TP N=1234.567 E=2345.678 Z=12.345 D=0.012	When you enter known points or a result from coordinate calculations, Pno and Code are displayed. Use the arrow keys to display the coordinates.

Stn=1 Back=2 Ha=0.0.. If you keep the station point number you
Y/N ? can choose to keep your station establishment.

CREATE NEW JOB Confirm when you enter a NEW JOB-file.
Y/N ?

HEIGHT MEAS If you answer No<N>, You will not get any
Y/N ? further questions concerning height measurement

WORKING... PSION works with larger computations.
Mostly You get answers immediately, but large
transformations, traverse computations etc.
may take a few seconds.

N=0.002 E=0.041.. Standard deviation from the meaned result is
DIFF OK Y/N ? displayed scrolling. You can stop the scroll,
change direction with the horizontal arrows.

DEVIATION Warning regarding use of point with large dev-
0.465 OK Y/N ? iation. You can continue or quit. The limit is
set to 0.1. You can change this parameter in
the USER file. See page 82.

KEEP CHANGE Menu to select action when measuring a point
MEAN that exists in the JOB file.

UTM-projection This questions appears only if the UTM-flag is
Y/N ? activated in the USER-file. After You have
answered Yes, the distances will be scale
corrected to the UTM coordinate system.

PSION will be automatically switched off after approximately
5 min if you don't press any keys. When you restart it returns
to the state where it was when it was switched off.

If PSION appears to have locked, try with <ON/CLEAR> <Q>. If that
does not work you can try removing the battery and replacing it.
Data in the internal memory (A:) could be deleted. Do not remove
the RAM pack during computation.

Be careful when connecting unknown peripheral equipment such as
plotter, printer, computer etc with own power supply. In some
cases you can lose data in the RAM-pack. Use FLASH EPROM if you
want safer data storage.

Be sure that PSION and the peripheral equipment are
compatible.

IT IS YOU AND YOU ALONE WHO IS RESPONSIBLE FOR YOUR DATA.

Do not forget the possibility of making BACKUP-copies of your
JOB-files.

* * * G E O D O S * * *

FUNCTION

* * POINT - REG * *

Manual input of point-
codes and coordinates.

INSTRUCTIONS

Automatic incrementation of point NUMBER plus duplication of previous chosen point CODE

Optional input of height values.

It is an advantage to use this program to allow manual input during program running of known points unnecessary.

You can also use the calculation programs directly and enter your known points manually.

A point may also be ORIGIN of a FIGURE, that is a JOB with local coordinates.

DISPLAY

COMMENTS.

Press <EXE>

Pno=101=

Enter point number. Maximum 12 characters.
<SPACE> <EXE> = Back to the MENU.

Cod=PP=

COD=/HOUSE/50

Enter Code. Maximum 12 characters.

If you enter slash before the code, the code refers to a JOB that contains a figure with local coordinates. You can enter a rotation angle after another slash. In this example the figure "HOUSE" will be rotated 50 gon. See also POLSO page 18.

The keyboard is set to numeral for PNO, and characters for CODE. You can change this in the USER-file, see page 82.
You can also use the SHIFT key on the keyboard.

PSION suggests previous pointnumber +1 and the last entered code.

If you accept the values within "=" in the display, just press <EXE>.

N=

Enter Northing.

E=

Enter Easting.

Z=

Enter Height coordinate. <EXE> = Z=0.00.

You can edit the single characters during input. Use <ARROWS> and . If you already entered with <EXE>, You can step back to previous record with <SPACE> <EXE> and change.

P=2 PP

EXIST OK Y/N ?


ERASE P=2 PP

OK Y/N ?

In the same jobfile it is not allowed to use the point number more than once. If you answer <N> you will be asked whether or not to delete the existing point with the same number/name.

EXAMPLE:

Pno	Code	Northing	Easting	Elevation
101	TRP	1254.208	2012.292	48.342
102	TRP	1474.381	2037.436	48.455
103	TRP	1549.570	2422.217	58.369
104	TRP	1198.366	2351.108	49.988
105	TRP	1369.334	2226.645	50.560
401	HC	1189.332	2134.935	40.000
402	HC	1300.101	2181.088	40.000
403	HC	1280.870	2227.242	40.000
404	HC	1243.948	2211.858	40.000
405	HC	1224.717	2258.011	40.000
406	HC	1178.563	2238.781	40.000
407	HC	1197.794	2192.627	40.000
408	HC	1170.101	2181.089	40.000
501	HC	1310.101	2351.088	37.000
502	HC	1370.101	2351.088	37.000
503	HC	1370.101	2431.088	37.000
504	HC	1310.101	2431.088	37.000



* * * G E O D O S * * *

Function

* * POL SETOUT * *

Calculation of polar
setting out data in
three dimensions.

INSTRUCTIONS

You can enter the setting out point with either POINT NUMBER or if printer is connected with SEARCH RADIUS and PNO-series or CODE. Height diff (Dh) and vertical angle (Vv) will be corrected for earth curvarure and refraction. The distances can be corrected for UTM-projection.(Optional).

With some total stations, data can be sent to the instrument for relative setting out data, e.g. count down to zero. You can get "3D ZERO SETOUT" in PSION by using "CHECK SURV-DATA". If You have used "REFLIN" just enter A- och B-values relative reference line instead of point number.

DISPLAY

COMMENTS.

MANUAL
GEOD-400....

Select total station. <EXE>=manual input.

UTM-projection
Y/N ?

Enter <Y> if You want to project correct distances. (Only if the UTM-flag is set to 1)

STATION
Pno=104=

Enter station point. PSION suggests a point in the JOB-file. If You accept, just press <EXE>.

Pno=104
Cod=PP

PSION answers by showing data for the point. You can use the arrow keys to examine the coordinates.

HEIGHT MEAS
Y/N ?

Enter <Y> to calcualte height setting out data

Ih=

Enter instr.height and target height.

Sh=

<EXE> = 0.00

REF OBJECT

Enter reference object.

Pno=

Ha=345.9401

Bearing and distance to reference object is displayed.

Hd=417.821

REF READING

Enter angle reading to reference object.

Ha=345.9401

PSION suggests BEARING. With some total stations data can be sent directly to the instrument

AIM

Than just aim and press <EXE>

PRESS <EXE>

DIST SEARCH

Only if printer is connected.

OK Y/N?

Press <Y> if You want to use "search radius" otherwise <N>. Enter radius from Station.

R=

ALL PNO CODE

MENU to select points by PNO-series or CODE. within search radius.

OBJECT

Enter PNO for single point to set out.

Pno=406

Press <SPACE> <EXE> to quit.

A=0.000=
B=0.000=
Z=41.345=

If you use "REFLINE", enter A= (along line) and B= (perpendicular to the line.) For previous data press <EXE>. Use brackets "<" and ">" to add or subtract value. The suggested Z value is interpolated along the reference line

Cod=/HOUSE/50
FIG HOUSE/50
SELECT PNT
1 2 3 4 5 6

If you have stored figure JOB=C:HOUSE, a MENU will appear that contains the figure points. Select the point to set out. The local coordinates will be transformed in 3D and setoutdata will be calculated in current coord system.


Ha=288.8907
Hd=114.059
Dh=-11.502
Vd=106.3981
Sd=114.638
N=1178.563
E=2238.781
Z=40.000

The result is displayed two lines at a time. Use the arrow keys to look at the different setting out data.

You can control the positions of the emplaced point. Press <C>. You then measure in the set out point. If you choosed "CHECK SURV-DATA" this will take place automatically. Press <T> to change target height. Press <R> to change REFERENCE LINE Press <Q> to quit from REFERENCE LINE

dL=0.023
Sm=0.001
dZ=0.015

Set out check. Distance, offset, and height difference. Press <EXE> for adjustment and another check or <ON> for next point.



* * * G E O D O S * * *

FUNCTION

* * POLAR MEAS * *

Polar measurement with
coordinate calculation or
survey data collection.
Se also program REFLIN.

INSTRUCTION

Radial surveying in two or three dimensions.
Height measurement is corrected for earth curvature and refraction

You can enter survey data manually or receive directly on line
from different totalstations.

Possibility to make eccentric target calculations.

You can select direct coordinate calculation or just data
collection for later calculation with program "CSDATA"
see page 74. .

DISPLAY COMMENTS.

STATION Previous station establishment is default.
Pno=#101= Just press <EXE> if you want to keep that.
Otherwise give a new point name.

MANUAL-INPUT Menu to select totalstation. You can design
GDM-I/O GDM-SER your own menu.
GEOD-220 GEOD-140 For further information see pages 23,82 and 83.
WILD-TC WILD-TD
SOKKIA SOKSETC
TOPCON NIKON
PTSIII PTS2/110...

CHECK SURV-DATA Answer <Y> if you during measurement want to
Y/N ? check or edit survey data.

SLOPE DIST
Y/N ? Press <Y> for slope dist or <N> for
horisontal distance measurement.

HEIGHT MEAS
Y/N? Press <Y> for height measurements else <N>.

Ih= Enter instrument height above point.
Th= Enter target height. <EXE>=0.000

REF OBJECT Enter reference object point number
Pno=102=102.

Ha=345.9401 Bearing and distance is displayed.
Hd=417.821 (Horizontal angle and horisontal distance)

REF READING Enter back reading. PSION suggest BEARING..
Ha=345.9401= With some total stations data can be send
AIM directly to the instrument. Than just aim.
Press <EXE> and press <EXE>.

START ELEM NO Elm=1=	If you use reference ROADLINE you can enter start element for fast searching.
Pno=101=406A	Enter POINT NUMBER for survey point. PSION suggests previous number + selected increment. Press <SPACE><EXE> to QUIT.
Cod=HC	Enter CODE for survey object. Psion suggests same as previous. Use <SHIFT> to change key mode
406A HC 0.00 Ha=342.9500 Va=105.8380 Sd=114.540 Th=0.000=1.000	Enter angle and distance. If You make mistakes use resp <SPACE> <EXE> for immediately corrections. Enter target height. <EXE> to accept previous value.
OK Pno=406A Cod= Th=1.000 Ha=342.9500 Va=105.8380 Sd=114.540 Fhd= A=0.000 B=0.000 CPNT EDIT NOTE	This is a menu where you may edit the data. Data is not yet stored. You may adjust the data with eccentric target measurement. Press <A> or if required. "Fhd=" means Fixed Horizontal Distance to a vertical perpendicular plane.
A=0.000= B=0.000=	Enter distances. A=along sight line. B=perpendicular to sight line Sign rules: <+>= Add A to the distance B: Object to the right of the sight line.
Th=	If You wish to change the target height press <T>. Enter target height.
CPNT B-102 REF-LEVEL DIST/B-C Z=0.000= Sd=0.000=	If you selected "CPNT" in the "CHECK-menu", measure to the inner prism. (point B) MENU to select Z-value on intersection surface or distance to point C from point B. Enter Z value on reference surface or Enter slope distance B-C. If you are in survey data collection mode data will be recalculated to point C.
**** GEODOS *** * EDIT JOB *	You may EDIT already stored data during surveying. Press <E> to enter POINT EDIT program. see page 24. Press <ON/CLEAR> to continue with program. Press <EXE>.
A= B= DZ= SA= LB=	If You have defined a reference line (REFLIN) A and B will be displayed. If you selected height measurement, height difference (DZ), slope A-distance and B-distance will also be displayed. To change reference line for next point press <R>. Press <Q> to exit routine.
*** GEODOS *** ** REF LINE **	See program "REFLIN".

EXAMPLE

Stn 104 Ih=1.500

102 Ha= 0.0000

406A Ha=342.9500 Va=105.8380 Sd=114.540 Th=1.000

N=1178.562 E=2238.782 Z=40.000


501A Ha= 54.0485 Va=100.0000 Sd=111.735 Th=1.310

N=1310.101 E=2351.088 Z=50.179

402A Ha=398.5900 Va=103.3680 Sd=185.100 Th=1.310

A=10.49 B=-31.62

N=1299.929 E=2181.287 Z=40.392



* * * G E O D O S * * *

FUNCTION

* * TOTALSTATION * *

Measurement with TOTAL STATION

INSTRUCTIONS

When you start measurement or set out programs, total stations can be used. It is important to select the correct instrument from the MENU and that you are using the correct link and cable. The TSTN-link is a specially manufactured interface for each single instrument type. It fits in PSIONs TOP PORT. The communication parameters will automatically be SETUP for the different instruments. All instruments except Geodimeter uses RS232 communication. Details how to connect the different instruments are delivered together with the TSTN-link interface. Put in "DMH" value in the "USER"-file if you will automatically correct the vertical angle when the distance meter is placed on top of the theodolite, e.g. when aiming with laser beam. Station establishment is stored and can be used in other JOB:s

DISPLAY

COMMENTS

MANUAL-INPUT MENU for total station selection.
GDM-400 GDM-220 You can use the first letter of the name
GDM-140 GDM-SER for fast selection.
WILD-TC WILD-TD You can design your own total station menu.
WILD-T2 SOKKIA.. Press <EXE>. (See page 80-81.)
xxxx CONNECTED The total station is now properly connected to
PRESS (EXE) PSION.
CHECK SURV-DATA Answer <Y> if you wish to DISPLAY or EDIT
Y/N ? surveydata before calculation or storing.
 This is recommended for safe data collecting.
 If you answer <N>, the data is stored directly
 for faster measurement.
OK Pno=12 Cod=TP If you choose CHECK, after each measurement
Th=1.650 you will see the data before it is stored.
Ha=123.4567 You than can EDIT the data in the order you
Va=99.2345 wish. <O>=STORE, <ON>=Cancel current measurement
Sd=145.656 <F>=Fixed horisontal distance to measure at a
FHL= perpendicular vertical surface with angles.
 <A>=Radial dimension along sight line
A=0.000 B=0.000 =Offset from sight line (--left)
CPNT EDIT NOTE <C>=Eccentric meas. with 2 prism. see page 21.
 <E>=Edit previous data in the JOB file.
 <N>=Note (Remark)
123 HC 1.50 Current pointnumber, code and target height
AIM press<EXE> is displayed. If you didn't choose "CHECK"
 you can change this data by pressing <ON>
 and then continue measurement with automatically
 increasing point numbering.

For SETTING OUT some totalstations use internal programs. Data than will be sent automatically to the instrument. If you selected "CHECK", automatic set out check will take place at all intrument types. Instruments with SERVO-motors will aim automatically

* * * G E O D O S * * *

FUNCTION

* * POINT EDIT * *

List and edit data in JOB-files.

INSTRUCTIONS


Some keys have special functions for listing and editing work:

<F> Go to FIRST point.
<L> Go to LAST point.
<R> Step one point BACKWARD.
<X> Step one point FORWARD.
<S> SEARCH point by name.
<T> SEARCH line element by number.
<H> LIST Road line profile data.
<V> LIST Volume data.
 DELETE current point.
<I> INSERT new point.
<P> Display total number of points in the JOB-file.
<C> Copy point from other JOB file.
<M> Show MAX and MIN coordinates in the JOB file.
<N> Sort points in NUMERICAL ORDER (Only Pno= 0-32568).
<E> EDIT current POINT-record. Step to edit position
 with arrow keys. Use to delete characters, or
 it is also possible to insert characters directly.
<A> List points position along current REFERENCE LINE.
<D> Distance, Bearing and height diff between points.
<ON> QUIT. Back to GEODOS-menu.

DISPLAY

COMMENTS

Pno=101 Press <F>. First point in JOB-file is displayed
Cod=PP Use arrow keys to display all data.
Pno=402A Press <L>. Last point in JOB-file is displayed
Cod=HH Press <R>. Previous point is displayed.
Pno=501A Press <X> or <EXE> to move to next point.
Cod=HH Press <S> or <T>
Pno= Elm= Enter point name or element number to search.
Pno=102
Sec=1234.567 Press <A>. Data along REFERENCE LINE if it
Of=-12.345 is defined. See REFLIN.
Cod=PP Press
DELETE P=102 You can regret by pressing <N>
Y/N ? Press <I>
Pno== Enter new point number, code and coordinates
 Press <P>
POINTS=8 Total number of points in the JOB-file.
 Press <C>
COPY Key in JOB file name from which you wish to
JOB=C: copy the point, and then the point name.
 Press <N>
SORT Y/N ? Answer <Y> if you wish to carry out sort.
 Press <M>
MIN-MAX Min and Max coordinates are displayed scrolling
 Press <E>
 You can now edit single characters in a record.



* * * G E O D O S * * *

FUNCTION

* * ORT SETOUT * *

Rectangular setting out
data calculation in three
dimensions.

INSTRUCTIONS

Selectable horizontal or slope distance along baseline.
Height difference is calculated from baseline vertical to
the "setting out" object.

DISPLAY

COMMENTS

BASEPOINT
Pno=1=401

Enter base point no 401

Pno=401
Cod=HH

Use arrow keys if you wish to examine coord.
Press <EXE>.

TARG-POINT
Pno=402=402

Enter target point (End point on baseline)
If you wish to enter BEARING instead, press
<SPACE> <EXE>.

Pno=402
Cod=HH

Ha=25.1333
Hd=120.000

Bearing and distance are displayed.
Press <EXE>.

OBJECT
Pno=401=405

Enter setting out object number
405

Pno=405
Kod=HH

Press <EXE>.

A= 80.000
B= 100.000
DZ= 13.333
SA= 81.104
SB= 100.885

Horizontal distance along baseline.
Horizontal perpendicular distance
Height difference to the baseline.
Slope distance along baseline.
Slope perpendicular distance.

EXAMPLE

Basepoint

401 HH N=1189.332 E=2134.934 Z=40.000


Target point

402 HH N=1300.101 E=2181.088 Z=60.000

Ha=25.1333 Hd=120.000

Object

405 HH A=80.001 B=100.000 DZ=13.333 SA=81.104 SB=100.885



```

* * * G E O D O S * * *      FUNCTION
* *   ORTOG   MEAS   * *      Coordinate calculation (transform)
                                in two or three dimensions
                                from rectangular measurements or
                                drawing dimensions.
-----
INSTRUCTIONS
-----
You can enter accumulative distances.

Distance along the baseline (A=) can be slope distance.
Height interpolation along the baseline as default.
-----
DISPLAY          COMMENTS
-----
BASEPOINT        Enter base point no 401
Pno=1=401

Pno=401
Cod=PP

TARG-POINT       Enter target point (end point) no 402
Pno=402=402      If You want to enter BEARING, press
                  <SPACE> <EXE>.

Pno=402
Cod=PP

Ha=25.1333       Bearing(Ha), hor distance(Hd), height diff(DZ)
Hd=120.000       vertical angle,(Va) and slope distance (Sd)
DZ=19.999        are displayed.
Va=89.4868
Sd=121.655

HEIGHTS          Press <Y> if you wish to store heights.
Y/N?

SLOPE DIST       Press <Y> if you wish to enter slope distance
Y/N ?            along baseline (A=). You will not get this
                  question if the baseline is horizontal.

Pno==407         Enter point number and code of the point
Cod=HH           to be calculated.
A=0.000=80.00    Enter distances. A=along baseline, B=perp. to
B=0.000=100.00   baseline. Previous values are default.
Z=53.333=        To work with accumulative distances,
                  use ">" resp "<" to add or sustract distances.
                  The Z value is interpolated along the baseline.
                  <EXE>=accept, or you can enter new Z value.

Pno=407
Cod=HH
N=1224.716       Point record will be displayed and stored.
E=2258.011       Use arrow keys to display coordinates.
Z=53.333.

```

Basepoint

Target point

Ha=25.1333 Hd=120.000 Dh=19.999 Va=89.4868 Sd=121.655

Measured point

N=1224.715 E=2258.010 Z=53.333

N=1224.716 E=2258.011 Z=53.333

Note that \mathbf{Z} is interpolated along the baseline



```

* * * G E O D O S * * *      FUNCTION
* *      2P RESECT      * *      Two point resection.
                                One or two distances + incl angle
                                Calculation of Northing, Easting
                                and optional height.
-----
INSTRUCTION
-----
Calculation of station coordinates in three dimensions.
When you measure two distances, adjustment of the distances
will be done. The ANGLE WILL NOT BE ADJUSTED.
There are no geometric restrictions. It does not matter
if the angle is small or great. The station point can lie
exactly on the straight line. If you measure only one distance
it must be towards OBJECT 2.
-----
DISPLAY.      COMMENTS
-----
MANUAL-INPUT      Select total station.
GDM-400...

SLOPE DIST      Select slope or horizontal distance measurement
Y/N ?
HEIGHT MEAS      Answer <Y> if you wish to calculate height
Y/N ?            of the station point.

Ih=              Enter instrument height. <EXE>=0.00.
                  The instrument axis will then be determined.
Th=              Enter target height. You can also enter this
                  later on during measurement.

OBJECT nr 1      Enter point number for first object.
Pno=101=

Ha=              Enter horizontal angle 1.
Va=              Enter vertical angle
Sd=              Slope distance. Enter "0" if not measured.
Th=0.000=        Target height, enter if applicable.

OBJECT nr 2      Enter point number for object 2.
                  etc.
                  You must measure distance to object 2.
WORKING...        Calculating is now in progress.

dD=-0.005 OK      Distance difference.
dH=-0.003 Y/N ?   Height difference.
                  Press <Y> if You accept.

STORE            Enter point number and code to store the newly.
Pno=105=          calculated point.
Cod=PP=

Pno=105          The new point also will be stored as station
Cod=PP...         establishment that can be used in POLMS, POLUT
                  and ROAD SETOUT.

```

EXAMPLE


Survey data:

Stn 510A		Ih=1.536				
101	PP	Ha= 0.0027	Va=107.9431	Sd=391.442	Th=1.502	
103	PP	Ha=123.5792	Va=111.4985	Sd=215.318	Th=1.498	

Result:

$dD=-0.006$ $dH=-0.004$

510A	HJP	N=1340.052	E=2391.091	Z=97.009	D=0.007
------	-----	------------	------------	----------	---------



* * * G E O D O S * * *

* * ANG RESECT * *

FUNCTION

Angle intersection calculation.
Measurement to three or four
known points. Optional height
measurement.

INSTRUCTION

Be aware of "the dangerous circle". A bad result will be achieved if you are standing on the circle through the three known points. You will get risk factors that shows the expected accuracy by the different resections. The mean value will be weighted according to intersection angles.

DISPLAY COMMENTS.

MANUAL-INPUT Select total station <EXE>=manual input
GEOD-400...

HEIGHT MEAS Press <Y> för height measurement.

Y/N ?

Ih= Enter instr.height above point to be determined
 <EXE> (Ih=0) if You want to determine only
 the instrument axis.

Th= Enter target height. You can change it during
 measurement.

OBJECT 1 Enter point number for the known point.
Pno=101=

Pno=101 The point will be displayed if it exists
Cod=PP otherwise input code and coordinates as usual.

Ha= Enter horizontal angle.

Va= " vertical angle.

Th=0.000= " target height.

OBJECT 2 As above.

Pno=102=

INT 1 Ha=64 For each resection, the angle and expected
Risk=10mm/100m accuracy are displayed. The value shows what
 will happen by an angle deviation of 0.001 gon.

1 N=1369.336... Coordinates for the different resections are
2 N=1369.335... displayed. Also the weight that is used for the
3 N=1369.320... mean value calculation.

N=0.012 E=0.014..Standard deviation will be displayed scrolling.
Diff OK Y/N ? dz and dr (3D radial). You can stop and view
 the data with the arrow keys.

STORE Enter point name and code to store the new
Pno=105= point in the JOB-file.

Cod=PP=

Pno=105... The point will be stored as station establishment


EXAMPLE

Survey data

Stn 105		Ih=1.585			
101	PP	Ha= 0.0056	Va=100.6064	Th=1.501	
102	PP	Ha= 63.6420	Va=100.6491	Th=1.495	
103	PP	Ha=183.9739	Va= 98.1553	Th=1.498	
104	PP	Ha=291.3167	Va=100.2031	Th=1.510	

Result:

		N=0.012	E=0.014	Z=0.008	dR=0.020
105	PP	N=1369.326	E=2226.656	Z=50.573	D=0.020



* * * G E O D O S * * *

* * FREE STN * *

FUNCTION

Free station calculation in
two or three dimensions.

Angle and distance measurement
to two or several known objects.

----- INSTRUCTIONS. -----

Coordinate calculation by HELMERT TRANSFORMATION.

You can EDIT the measurements and recalculate during execution.
Height adjustments by average calculation.

----- DISPLAY COMMENTS. -----

MANUAL	Select total station <EXE>=manual .
GEOD-400...	
SLOPE DIST	Press <Y> for slope distance measurement.
Y/N ?	
HEIGHT MEAS	Press <Y> for height measurement.
Y/N ?	
Ih=	Enter instr.height above point.<EXE>=instr.axis
Th=	Enter target height. You can change it during measurement.
OBJECT nr 1	Enter point number for resp. objects.
Pno=101=	Press <SPACE><EXE> to QUIT.
Ha=	Enter horizontal angle.
Va=	Enter vertical angle.
Sd=	Enter slope distance.
Pno=102=	As above.
WORKING...	Calculation in progress.
4 KNOWN POINTS	Your known points are displayed scrolling.
101 102 103 104..	Press <EXE>.
DEVIATION	
P=101 D=0.014..	Deviations for each point are displayed
N=0.013 E0.005..	scrolling.
Z=0.002	Press <EXE> for each point.
	At the end of the calculation the point with the biggest deviation is displayed again.
DIST.ERROR/100m	Errors shown contain scale factor with relation to metre unit per 100m. When measuring from free station position the factor can be used to carry out precise distance measurement. Note that the +- sign is the ERROR. Correction is carried out using the opposite sign.
STORE QUIT	MENU for selection as follows:
DELETE ADD	STORE Point OK, store in JOB-file.
	QUIT Quit without storing.
	DELETE Delete measurement to certain point and recalculate.
	ADD Add measurement to another point and recalculate.
STORE	Enter point number and code to store the point
Pno=105=	that also will be stored as station eastablishment

STORE

Pno=105= - Enter point number and code for station-
Cod=TRP= - point to store.

EXAMPLE

Input data:


Stn 105		Ih=1.585				
101	TRP	Ha= 0.0056	Va=100.6064	Sd=243.320	Th=1.501	
102	TRP	Ha= 63.6420	Va=100.6491	Sd=216.420	Th=1.507	
103	TRP	Ha=183.9739	Va= 98.1553	Sd=266.071	Th=1.498	
104	TRP	Ha=291.3167	Va=100.2031	Sd=211.475	Th=1.498	

Result deviations.

101	N-0.013	E 0.005	Z-0.002	R 0.014
102	N 0.011	E-0.001	Z 0.007	R 0.013
103	N-0.001	E 0.001	Z-0.005	R 0.005
104	N 0.002	E-0.005	Z-0.001	R 0.005

Coordinates

105	N=1369.330	E=2226.645	Z=50.573	D=0.014
-----	------------	------------	----------	---------



* * * G E O D O S * * *

FUNCTION

* * TRAVERSE * *

Calculation and adjustment
of traverse in three
dimensions.

INSTRUCTIONS

Start in a JOB-file that contains your known points.
Survey data will be stored in a special JOB-file during
measurement. You can edit survey data and recalculate.
Coordinate calculation is done at the same time.
When you measure vertical angle and distance to back object
the deviation will be displayed. You can then select correction
of the station coordinates immediately. This allows you to use
the "hanging" traverse points for e.g. setting out work.
The point codes will be automatic set to PP(fly) and PP(adj)
respectively for the new points.
The start and close points must be stored previously in the JOB
file before you start the adjustment. Use program "PREG".

DISPLAY COMMENTS

SURV DATA Enter JOB name for storage survey data.
JOB=C:

new JOB Y/N? Press <Y> to start a new traverse. If you
continue an existing traverse PSION remembers
the previous station point number and displays
it when you continue with the next station.

MEASURE ADJUST MENU. When You have finished the measurement or
PRINT changed survey data, you can select adjustment
or print out.

MANUAL-INPUT Select total station <EXE>=manual
GDM-400...

SLOPE DIST Y/N? Press <Y> if you enter slope distances.
HEIGHT MEAS Y/N? " <Y> for height measurement.

BACK OBJ Enter point number for reference station.
Pno=101= (102 in the example)

STATION Enter point number for start point. (Station)
Pno=102= (101 in the example)

STN-P=101 You have now established the traverse start. For
BACK-P=102 each new station, PSION displays the station-
point and backsight point.

Ih=1.493 Enter instrument height (only if You selected
height measurement)

Ha=7.2389	Bearing, distance and height difference to back-
Hd=221.604	object are displayed.
Dh=-1.383	Press <EXE>.
Va=100.3974	
Sd=221.608	
BACK-P=102	Enter horizontal angle to back station.
Ha=0.0132	
Va=0	Enter vertical angle. "0" if no measurement.
Sd=0	Enter distance. "0" if no measurement.
Th=0.000=	Enter target height.
FORWARD	Enter point number of forward station.
Pno==105C	If it exists in the JOB-file you will be asked to
Ha=61.3980	connect.
Va=99.4150	Enter measurement to forward station.
Sd=243.325	
Th=0.000=1.500	
Pno=105C	Coordinates will be calculated and stored
Cod=PP(fly)	Now you can move to next station. If you don't
N=1369.331	switch off PSION, it will be automatically
E=2226.648	switched off after a few minutes.
Z=50.575	When you switch ON again it is ready for the
	next station.
	If you switch off by pressing <O> from the head
Stn-P=105C	menu, you must enter the JOB-file again when
Back-P=101	you switch on.
Ih=1.585	PSION remembers the previous point numbers
Ha=	for station and backsight stations.
.	Enter instrument height.
.	Bearing etc to backsight station is displayed.
Ha=0.0056	
Va=100.6064	Enter survey data to backsight station.
Sd=243.320	
dD=0.006	Deviation for distance and height.
dH=-0.003 Y/N?	Press <N> if you want to remeasure.
CORR P=105C	Press <Y> if you want to adjust station coord.
Y/N?	and survey data (average).
.....	
FORWARD	Measurement to KNOWN forward station.
Pno==103	
P=103 EXIST	Press <Y> to connect. Then make the normal
CONNECT Y/N ?	measurements to the known closing point.
N=0.011 E=-0.010	.. Coördinate deviations are displayed.
DIFF OK Y/N?	Press <Y> if it is OK.
.	If you don't want to make angle connection, you
.	can stop here.
.	In this example go now to the MENU and select

. ADJUST. To carry out an angle adjusted traverse continue to the known point and complete the closing angle measurement.

ANGLEDIFF
WORKING...

ANGLEDIFF Angle diff is displayed. Press <Y> to continue
0.0052 Y/N ? adjustment.

COORDDIFF
WORKING... Adjustment is in progress.

N=0.006 E=-0.003...
DIFF OK Y/N? Press <Y> if you are satisfied with the closure.

ADJUST If you answer <Y> all "hanging" points PP(fly)
Y/N ? will become adjusted points = PP(adj).

If you want to change known closing point coordinates, use program "EDIT" in your JOB file Then go to program "TRVRS" and select "ADJUST" from the MENU.

If you want to change SDATA, go to the main menu, enter GEODOS, JOB=your survey data file and select EDIT.
Return thereafter to JOB-file and re-adjust.

EXAMPLE

Stn 101	Ih=1.493			


102	Ha= 0.0132			
105C	Ha= 61.3980	Va= 99.4150	Sd=243.325	Th=1.500
Stn 105C	Ih=1.585			

101	Ha= 0.0056	Va=100.6064	Sd=243.320	Th=1.501
103	Ha=183.9739	Va= 98.1553	Sd=266.071	Th=1.498
Stn 103	Ih=1.530			

105C	Ha= 0.0025	Va=101.9900	Sd=266.090	Th=1.010
102	Ha= 35.1201			
Adiff= 0.0052				
dN= 0.006	dE=-0.003	dZ=-0.012	dR=0.013	
Pno=105C	Cod=TRP(adj)	N=1369.327	E=2226.648	Z=50.574 D=0.013

PNO	COD	HA	HD	VD	DIFF
102	str				
101	stp	61.3848	243.312	2.2385	0.006
105C	new	183.9683	265.959	7.8005	0.006
103	slp	35.1176	0.000	0.0000	0.000

PNO	COD	N	E	Z	D
102	TP	1474.381	2037.436	48.455	
101	TP	1254.208	2012.292	48.342	
105C	TRP(adj)	1369.327	2226.648	50.274	0.009
103	TP	1549.570	2422.217	58.369	
102	TP	1474.381	2037.436	48.455	
Ha=0.0052	COOR-DEV	0.006	-0.003	-0.012	0.018



```

* * * G E O D O S * * *      FUNCTION
* *   ANG INTERS      * *   Angle intersection from
                                two or three station
                                points in two or three
                                dimensions.
-----
INSTRUCTIONS
-----
Measurement can be made "ON LINE" (RMS) or by survey data
collection in two separat JOB-files (see POLMS). By height
measurement mean value will be calculated and deviations will
be displayed. Weighted mean value calculation.
-----
DISPLAY      COMMENTS.
-----
"RMS" MEASUREMENT.
-----
MANUAL-INPUT      Select total station (EXE>=manual input.
GDM-400...
HEIGHT MEAS      Press <Y> for height measurement.
Y/N ?

3 STN-POINTS      Press <Y> if you wish to measure from three
Y/N ?      stations.

STATION 1      Enter point number for station 1.
Pno=101=
Ih=      Enter instrument height above point.
      0.00 if Z is equal to instument height.

BACK OBJ 1      Enter reference object for station 1.
BACK READ      Enter reference reading (horisontal angle)
Ha=

STATION 2      As above.

After station establishment, enter survey data as follows:

Pno=101=      Enter point number for the survey object.
Cod=HC=      "   code      "   "   "   "

FROM STN 1
Ha=      Enter horizontal angle from station 1.
Va=      "   vertical angle   "   "
Th=0.000=      "   target height

FROM STN 2      Etc...
Ha=
WORKING...      Calculation will take maximum c:a 20 seconds..
N=0.005 E=0.004 Standard deviation is displayed scrolling
DIFF OK Y/N ?   Use the arrow keys to stop and back scroll.
      Press <Y> if OK.

Pno=101
Cod=HC      Coordinates will be stored in current JOB-file.

```

SURVEYDATA CALCULATION

SDTA STN 1
JOB=C:
SDTA STN 2
JOB=C:

Enter JOB-name for surveydata.
Data from the different stations must be stored
in two separate JOB:s with different names.
Do not mix this type of surveydata with other
types. Coordinates for station points must
be stored in the JOB you entered for calculation

STN P=1 P=2
OK Y/N ?

Station point names will be displayed.
Press <Y> to continue.

AUTOMAT
OK Y/N ?

Press <Y> if you want to calculate all measured
points. Coordinates will be stored in current
JOB. Press <N> to select separate points.
If printer is connected, the result will be
printed out as in the example below.
The angles are displayed for each calculated
point. The calculation takes a while, so before
you start a large computation with printer
connected, put in fresh batteries or connect a
power adapter.


350.011 99.123
45.454 101.322

===== GEODOS = version 5.45
VIKER DATA AB
===== 05 APR 1990 09:20:30 =====

ARB-NAMN : EXEMPEL ARB-NR : 12.3456 OPER: SOA

AVSKARNING
JOB : C:XMP

PNO	KOD	X	Y	Z	D
STN 1 MATDATA JOB : S105					
105	Stn	1369.334	2226.645	50.560	
101	Bobj	1254.208	2012.292	48.342	
STN 2 MATDATA JOB : S510A					
510A	Stn	1340.052	2391.091	97.009	
105	Bobj	1369.334	2226.645	50.560	
MATTA PUNKTER					
403A	HH	1280.873	2227.243	59.975	0.



* * * G E O D O S * * *	FUNCTION
* * DIST INTER * *	Distance intersection.
	Measurement from two known objects.

INSTRUCTIONS

Calculation of plane coordinates.(Northing, Easting)

Clockwise calculation. Seen from the intersected point, the first object must be on the left.

----- DISPLAY	COMMENTS. -----
OBJECT 1 Pno=101=102	Enter point number for object 1.. (102 in the example)
Pno=102 Cod=PP	Point number and code will be displayed. Use arrow keys to view the coordinates.
 OBJECT 2 Pno=103=	 Enter point number for object 2.. (103 in the example) etc...
 Pno=105=401A Kod=TP=HOUSE	 Enter point number and code for the inter- sected point. (401A in the example)
Hd-1= Hd-2=	Enter horizontal distance to object 1 and object 2.
Pno=401A Cod=HC	Coordinates will be calculated and stored in current JOB-file.
ERROR IN SDATA	If the sum av the distances is less than the distance between the two known points coordinates can not be calculated.


DISTANCES:

502A - 102 330.533

502A - 103 193.050

RESULT:

PNO	CODE	N	E
502A	HC	1370.101	2351.089



```

* * * G E O D O S * * *      FUNCTION
* *   HELM TRANS      * *      Helmert coordinate transformation
                                with scale adjustment and rotation
                                of coordinate system.

```

INSTRUCTION

Common points must be stored in DIFFERENT JOBS with SAME POINT NUMBERS.
The known points, ("TO-system") must be stored in the current JOB-file.
PSION asks for JOB-name where the "measured points" in ("FROM-system") are stored.
The program finds all points with common names in the two JOB-files, and makes a transformation formula.
All "NEW POINTS" in the "FROM-system" can then automatically be transformed and stored in current JOB-file.
Heights can be transformed to a mean value of the Z deviations

DISPLAY COMMENTS.

HEIGHTS Y/N?	Press <Y> if you also want to transform Z coord
-----------------	---

MEAS POINTS JOB=C:	Enter JOB-name in which the measured points in ("FROM-system") are stored.
-----------------------	--

WORKING...	It may take some seconds to find all common points if the JOB-files contain many points.
------------	--

4 KNOWN POINTS 101 102 103 104	The common points are displayed in scrolling display. Press <EXE> if they are OK, otherwise <ON/Clear> and use program "EDIT" to adjust the point numbers so that they match.
-----------------------------------	---

DEVIATION P=101 D=0.004.. N=0.004 E=0.000.. Z=0.000...	Deviations for the common points are displayed. scrolling. Press <EXE> to continue. If you want to edit or delete data, use program "EDIT".
---	--

SCALE=0.99999292 Y/N ?	Scale factor relationship between systems is displayed. Press <Y> to continue.
---------------------------	--

AUT TRANS ALL POINTS Y/N?	If you answer <Y>, all points in "FROM-file" will be transformed and stored in current JOB-file. If you answer <N> you can choose any point in "FROM-file" to transform. Use keys <F>, <L>, <R> or <X> as in "EDIT" to choose. Confirm with <Y>. Use <ON> to quit.
P=105 TRANS Y/N?	

8 TRANSF PNT	Total number of transformed and stored points is displayed.
--------------	---

===== GEODOS = version 4.93 =====
 VIKER DATA AB
 S-433 49 PARTILLE Sweden
 ===== 03 OCT 1988 11:00:41 =====

HEADER : HOUSE 4+5 ID-NO : 12.345 OPER: SOA

HELM TRANS
 JOB : C:LONDON

KNOWN POINTS

101	TP	5012.720	6361.840
102	TP	5225.620	6300.370
103	TP	5443.020	6626.630
104	TP	5091.480	6696.070


DEVIATION:

P=101	D=	0.004	N=	0.004	E=	-0.000	Z=	0.000
P=102	D=	0.003	N=	-0.003	E=	0.001	Z=	0.000
P=103	D=	0.002	N=	0.001	E=	-0.001	Z=	0.000
P=104	D=	0.003	N=	-0.003	E=	0.000	Z=	0.000

N=	3081.041	+	0.92307242	*	a	-	-0.38461146	*	b
E=	4986.732	+	0.92307242	*	b	+	-0.38461146	*	a

TRANSF POINTS

105	TP	5201.429	6515.425	50.560
401	HC	5000.001	6500.001	40.000
402	HC	5120.000	6500.000	60.000
403	HC	5119.999	6550.000	40.000
404	HC	5080.001	6550.000	



* * * G E O D O S * * *

FUNCTION

* * AREA CALC * *

Calculation of AREA
distances and bearings
in closed polygon.
ARCs may be included.

INSTRUCTIONS

Area will be calculated within a polygon described by point numbers. If a point is missing in current JOB-file, you will be asked to key in coordinates and the calculation will continue.

Distances and bearings will be printed out if printer is connected.

You can enter series of point numbers short e.g 101-104.

DISPLAY

COMMENTS.

PNO-SERIES	Enter series of point numbers delimited by
101 102 103...	<SPACE>.
alternatively	If point serie is in cosecutive order, you can
101-104	enter first and last point delimited by "-".
	Previous series remains, and you can edit
	single point numbers and recalculate.
	Quit by <CLEAR> <EXE>.
101 102 (500)...	Enter arc radius between two points within
	brackets. Arc may not be entered at the first
	two positions. Minus (-) gives negative area in
	that segment.
P=101 102 103...	Point numbers is displayed scrolling on first
A=102896.1 m2	line. Area is displayed on second display line.
	If printer is connected a print out of
	distances and bearings will be given.
	The point number string is limited to maximum
	255 characters.


===== GEODOS = version 4.93 =
VIKER DATA AB
S-433 49 PARTILLE Sweden
===== 02 OCT 1988 18:32:09 ==

HEADER : AREA NO 124-ABC ID-NO : 12.3456 OPER: SOA

AREA CALC
JOB : C:SDTA

PNO	COD	N	E	DIST	BEARING
101	TP	1254.208	2012.292		
102	TP	1474.381	2037.436	221.604	7.239
103	TP	1549.570	2422.217	392.058	87.715
104	TP	1198.366	2351.108	358.330	212.718
		1254.208	2012.292	343.387	310.399

AREA=102896.1 m2



* * * G E O D O S * * *	FUNCTION
* * POINT CHCK * *	Comparsion of coordinates. Deviation print out after control measurement.

INSTRUCTION

Printing of coordinates and differences by comparsion of two JOB-files. Points with the same number will be compared. Differences (D,N,E and Z) will be calculated and printed out if printer is connected.

DISPLAY COMMENTS.

** POINT CHCK ** Enter JOB-name of the file to be compared
JOB=C: with current JOB-file.

DEVIATION	Differences in three dimensions displayed
P=401 D=0.006..	scrolling.
N=0.002 E=-0.004	Press <EXE> for next point.
Z=-0.005	If printer is connected, the result will be automatically printed out for all points with common point numbers in both JOB-files.

```

===== GEODOS = version 4.93 =
VIKER DATA AB
S-433 49 PARTILLE Sweden
===== 02 OCT 1988 18:40:56 ==

```

```

HEADER : HOUSE 105A    ID-NO : 12.3456    OPER: SOA

```

```

POINT CHCK
JOB : C:SAMPLE

```

KNOWN POINTS

PNO	COD	N	E	Z	D
401	CC	1189.330 0.002	2134.930 0.005	40.005 -0.005	0.007
402	CC	1300.100 0.001	2181.090 -0.002	40.056 19.944	19.944
403	CC	1280.875 -0.005	2227.240 0.002	40.003 -0.003	0.006
404	CC	1243.950 -0.002	2211.859 -0.001	39.988 -39.988	39.988
405	CC	1224.712 0.005	2258.006 0.005	40.003 -0.003	0.008
406	CC	1178.560 0.003	2238.775 0.006	39.999 0.001	0.007
407	CC	1197.791 0.003	2192.629 -0.002	39.995 0.005	0.006
408	CC	1170.100 0.001	2181.095 -0.006	39.997 0.003	0.007

* * * G E O D O S * * *

FUNCTION

* * P R I N T * *

Print out coordinate list
of survey site data.

INSTRUCTIONS

You can use any serial or paralell printer.
Connection via COMMS-link or RS232 interface.
If your printer has paralell Centronic interface, you will also
need a converter (serial-paralell)
STANDARD SET UP paramteres:

Baud 9600
Parity NONE
Bits 8
Stop 1
Hand XON

If you want to keep other set up parameters for your printer, use
SETUP from COMMS-menu to set parameters and then select "SPECIAL"
in print menu to retain the new parameters. "SPECIAL" sends the
characters one by one and is therefore slower, mainly to support
printers without buffers.

DISPLAY COMMENTS.

STANDARD SPECIAL MENU. Select setup parameters.
PARALELL

HEADER Enter header line.
ID-NO Enter identification number
OPER Enter operator name

ALL PNO CODE MENU to select print out content.
ALL= All points in the JOB-file will be printed
PNO= Select point number series to be printed.
 e.g. 401-410.
 DO not enter areas containing to many
 points. Searching and sorting will take
 some time.
CODE= Select a certain code to be printed.

The printer starts directly. Form feed with new
header after 60 lines (default). This can be
changed in the USER definable parameter file.

NO CONNECTION The printer is not connected or off line.

NOTE. Be careful when you connect unknown printers.
If the current from the printer is too high, in some cases
you can damage data stored in the RAM-pack,
First make a test with unimportant data in your RAM-pack.

===== GEODOS = version 4.93 =
 VIKER DATA AB
 S-433 49 PARTILLE Sweden
 ===== 02 OCT 1988 18:27:31 ==

HEADER : HOUSES/ROADS ID-NO : 12.3456 OPER: SOA

POINT LIST
 JOB : C:SDTA

PNO	COD	N	E	Z	D
101	TP	1254.208	2012.292	48.342	
102	TP	1474.381	2037.436	48.455	
103	TP	1549.570	2422.217	58.369	
104	TP	1198.366	2351.108	49.988	
105	TP	1369.334	2226.645	50.560	
401	HC	1189.332	2134.935	40.000	
402	HC	1300.101	2181.088	60.000	
403	HC	1280.870	2227.242	40.000	
404	HC	1243.948	2211.858		
405	HC	1224.717	2258.011	40.000	
406	HC	1178.563	2238.781	40.000	
407	HC	1197.794	2192.627	40.000	
408	HC	1170.101	2181.089	40.000	
501	HC	1310.101	2351.088	37.000	
502	HC	1370.101	2351.088	37.000	
503	HC	1370.101	2431.088	37.000	
504	HC	1310.101	2431.088	37.000	
201	GP	1205.225	1999.645		
202	GP	1471.609	2137.629		
205	GP	1383.892	2246.399		
206	GP	1406.754	2451.076		
207	GP	1526.037	2543.459		
300	INT	1415.006	2164.619		
302	TP	1367.551	2140.038		
303	TP	1420.393	2217.732		
303A	CP	1321.557	2228.833		
301	TP	1182.228	2044.042		
304	TP	1434.489	2339.045		
105C	PP(adj)	1369.328	2226.649	50.572	0.009

```

* * * G E O D O S * * *           FUNCTION
* *   SEND DATA      * *           Transmit JOB-files to other
                                   computers or devices.

```

INSTRUCTIONS.

Data can be transmitted in different ways:

1. To MSDOS computer via program "CL" on the COMMS diskett.
2. To optional device by direct output on the serial port
3. To WILD REC module or GRE3/4 field data collector
4. To GEODAT or GEODIMETER internal memory
5. To SOKKIA CARD (option)

In case 1 and 2 data can be transfered in two different formats:

- ODB - "Organiser Data Base". It is the PSION internal compact format. Delimeter between the fields is Ascii(9) (HT)
- XYZ - The same logical content and order as "ODB" but data in fixed positions with SPACE in between.

For translation to other formats, "GEODOS-PC" is recommended. It also includes sophisticated DXF file conversion.

Check that the communication parameters are properly set.

As default PSION is set as follows.

```

          BAUD      9600
          PARITY    NONE
          BITS      8
          STOP      1
          HAND      XON
          PROTOCOL  NONE

```

Changes can be made with program "COMMS" "SETUP" or via program "CLSET" that exists on the GEODOS pack. "CLSET" resets the parameters to the above values and switch to PROTOCOL PSION.

DISPLAY COMMENTS.

```

GDOSODB GDOSXYZ  Select format/communication from the menu.
WILD-REC GDM400
SOCARD

```

```

CL-MSDOS SPECIAL Select communication protocol. If you select
ACKNAK           "CL-MSDOS", execute "CL" on the host computer.

```

```

PC-FILE:         By "CL-MSDOS", give the file name on PSION.
XMP.ODB          Default is the JOB name with extention .ODB
Sending...

```

The entire JOB-file will be transmitted to the receiving system in desired format as an ASCII file.

TOTALSTN GIF10 At WILD communication you can select direct
GRE3/4 communication via TOTAL STATION, via "GIF10"
 or GRE3/4 via "GIF2".

SET MODE 76 RUN When using WILD REC via totalstation, check
(Rep,Modul) RUN SETUP at the WILD totalstation.
OK? Press<EXE>

AREA JOB MENU to select FILE TYPE on GEODAT.
AREA= (JOB=) Enter AREA or JOB name.
 The keyboard is switched to numeric input

SETUP for GEODAT-400 (P51 Set protocol 0)

1.Baud=1200 2.Parity=2 3.Char len=7 4.Stop bits=2
5.Time out=10 6.Hardw.Hs=0 7.Softw.Hs=1 8.XON=17
9.XOFF=19 10.NAK=0 11.ACK=0 12.ENQ=0
13.STX=0 14.ETX=2.131 15.Nul=0 16.EOT=3.26131

Example on GEODOS.XYZ-format:

```
** GEODOS ** SUN 13 SEP 1987 17:40:44
101      PP      1254.208      2012.292      48.342
102      PP      1474.381      2037.436      48.455
103      PP      1549.570      2422.217      58.369
104      PP      1198.366      2351.108      49.988
```

PSION transmits two END OF FILE characters at
the end of transmission (ASCII 26 = ctrl Z)

* * * G E O D O S * * *

FUNCTION

* * RECEIVING * *

Receiving JOB-files
from other computers,
GEODAT 400, WILD-REC
or SOKKISHA CARD

INSTRUCTIONS

Reception of data works best using "ODB format".
Free format with any number of SPACES between the data fields
is also accaptable but take longer time. The order of the data
is important: PNO COD NORTH EAST (HEIGHT QUALITY REMARK). Data
within brackets are optional.
You can use the software "GEODOS-PC" to translate data from
other formats (e.g DXF).
WILD-REC, GEODAT and SOCARD is are special formats.

DISPLAY

COMMENTS.

CL-MSDOS SPECIAL Select communication protocol
WILD-REC GDT400
I-MEM SOCARD (SOCARD is an option)

PC-FILE: When using "CL-MSDOS", enter the file name
XMP.ODB to receive. Default is the JOB name+".ODB"
The file format must be "ODB format". Use the
software "GEODOS-PC" to convert from other
formats.

START This message appears if you selected "SPECIAL".
PSION than waits for data. The file format
must be "XYZ format".
At WILD-REC or SOCARD the transmission starts
directly after MENU selection.

AREA JOB At GEODAT-400, select AREA or JOB in the menu.
AREA= (JOB=) Enter AREA or JOB name. The keyboard is
switched to numeric input.
4=PP 5=123... Only coordinates is accepted. Other data
37=1234.567 is ignored by GEODOS.
38=2345.678

DATA FORMAT in PSION / GEODOS 5 och 6

The GEODOS database consists of a matrix with 7 columns of "Point data". The first two columns are alphanumerical. Next four are numerical. The last is an alphanumerical "remark field". A "Point" may contain maximum 255 characters including delimiters. In the two first alphanumerical fields the two first positions is a prefix that describes the data typ. The prefixes are hidden to the GEODOS user at printing, displaying etc. There is space for maximum 12 characters in each column, prefixes excluded. The numerical data and the remark field has no prefix. The "ODB-format" is a free format with delimiter ASCII 9, (HT) Horizontal TAB. End Of Line is <CR><LF> at transmission. (Standard) End Of File is ASCII 26 " " "

The following is valid for de most common data types.

POINTS.

Exaple:

Coordinates:

Pno	Cod	N	E	Z	Q	Rem
P=123ABC	C=123ABC	12345.678	12345.678	12345.678	0	REM

Survey data:

Pno	Cod	Ha(Ih)	Va	Sd	Th	Rem
P=123ABC	C=Stn	1.50				
P=123ABC	C=Bobj					
P=123ABC	C=123ABC	123.4567	123.4567	123.456	1.234	REM

Line element data

Example:

Element no	Type	N	E	Chn	
E=1	C=STR	12345.678	12345.678	123.456	0
E=2	C=CIR	12345.678	12345.678	12334.678	Radius -12345.678
E=3	C=TRN	12345.678	12345.678	12345.678	A-param -1000

```

* * * G E O D O S * * *      FUNCTION
* *   DIRECTORY      * *      Listing of JOB directory

```

INSTRUCTION

PSION displays all JOBS that exists in the external memory (C:)

It also displays the total number of points in each JOB-file and also the type of data.

If printer is connected, a print out will be provided.

DISPLAY	COMMENTS.
---------	-----------

C:XMP(48)	Job name, total number of points and
COORD+LINES	type of data is displayed. Press <EXE> to see information about next job.
	If question mark (?) appears the file contains information that not belongs to GEODOS.

If printer is connected a list will be printed out as follows:

```

===== GEODOS = version 5.96 =
VIKER DATA AB
433 43 PARTILLE
===== 12 DEC 1991 20:27:40 ==

```

JOB NAME : JOB-No : OPER:

JOBLIST

JOB :

NAME	TYPE	POINTS
C:XMP	COORD	46
C:ABC	COORD	24
C:BERGF	COORD	560
C:PBANK	COORD	45
C:OA	KOORD+LINE	36
C:AA	TYPSECT	11
C:KALLE	?	6
C:MMM	SURV-DATA	956
C:OAP	SECTION+LINE	145

* * * G E O D O S * * *

FUNCTION

* * ERASE JOB * *

Deleting JOB-files or
part of JOB-files.

INSTRUCTION

You can delete the entire JOB, part of a JOB by PNO series or all points with certain CODE.

By keying in the Psion command "RAMFORM" to the question JOB you can CLEAR ALL DATA stored in the RAM pack.

DISPLAY

COMMENTS

ALL PNO CODE	Menu to select what to erase ALL = all data in the JOB PNO = a serie of points by point number CODE = points with certain code
At "ALL": ERASE JOB=C:	Enter JOB name to be deleted. If you enter "X" you will be given a JOB-menu where you can select JOBS to be deleted with the arrow keys. Key in RAMFORM if you want to CLEAR ALL DATA. Press <N> to regret or <Y> to continue.
JOB=C:ABC SURE Y/N ?	Press <EXE> to return to GEODOS menu.
ERASE JOB=C:RAMFORM	Key in RAMFORM to format the RAM pack.
RAM FORMAT Y/N ?	Answer <Y> to continue. ALL DATA WILL BE ERASED
SURE Y/N ?	You are given one more chance to change your mind.
At "PNO": PNO-SERIES ex.10-99= ERASE 10-99 OK Y/N?	Enter PNO series to erase. Confirm with <Y>.
At "CODE": Code=HH= ERASE HH OK J/N?	Enter CODE to delete. Confirm with <Y>.

* * * G E O D O S * * *

FUNCTION

* * TRIG DIST * *

Calculation of horizontal and
vertical distance from angle
and distance measurement to
two objects.
(Cosine theorem)

INSTRUCTION

You can enter survey data manually or automatically
from total station.
Height difference will be corrected for refraction and
earth curvature.

DISPLAY COMMENTS

MANUAL Select from menu type of total station.
GEODIM-400
GEODIM-Serial...
Sokkisha Kern
Topcon Pentax
Zeiss Nikon

SLOPE DIST Press <Y> for slope distance measurement.
Y/N ? or <N> for horizontal.

HEIGHT MEAS Press <Y> for height measurement.
Y/N ? Otherwise <N>.

Ih= Press <EXE>
Th= Enter target height

OBJECT 1 Enter angles and distances or follow
Ha= the instructions for the total station.


Va=
Sd=
Th=0.000=
OBJECT 2
Ha=
Va=
Sd=
Th=0.000=

Hd= Result : Horizontal distance
DZ= Vertical distance.

Mätning av kastgren

S-BC-r=

$$\sqrt{(AB^2 + AC^2 - 2 AB \cdot AC \cdot \cos \alpha)} - r$$



* * * G E O D O S * * *

FUNCTION

* * ROAD DESGN * *

Calculation of line intersection
With arcs, calculation of tangent-
points and centerpoint.

INSTRUCTIONS

You define the center line with offset dimensions to known lines.
Whith arcs you give the radius to calculate tangent points and
centerpoint.

DISPLAY

COMMENTS

LINE 1 PNT 1 : Enter point 1 on the first line.
Pno=101=201 (Pno 201 in the example.)

LINE 1 PNT 2 : Enter point 2 on the first line
Pno=202= (Pno 202 in the example.)

OF=0.000= Enter offset distance <->=left of known line
PSION suggest previous distance.
LINE 2 etc.... (+50.00 in the example.)

INTERSECTION Press <Y> to calculate intersection point.
Y/N ?

Pno=203=3021 Key in point number and code for intersection
Cod=INT= point. Default code is "INT".

TANGENT Press <Y> to calculate tangent points.
Y/N ?

RADIUS= Enter arc radius. <->= left <+>= right curve.
(+100 in the example)
TP 1 Enter number and code for first tangent point.
Pno=302 (Pno 302 in the example Default code=TP.
Cod=TP=

Pno=302 Use the arrow keys to view the coordinates.
Cod=TP

TP 2 Enter number and code for second tangent point.
Pno=303= As above.


CENTERPOINT Press <Y> to calculate centre point.
Y/N ?

Pno=3021 Enter number and code for centre point.
Cod=CP= Default code="CP".

All calculated points will be stored in your
JOB file.

ROAD DESGN
JOB : C:XMP

PNO	COD	N	E	Z
LINE 1				
201	PRC	1205.225	1999.645	
202	PRC	1471.609	2137.629	
LINE 2				
	OF=50.000			
205	PRC	1383.892	2246.399	
206	PRC	1406.754	2451.076	
	OF=-40.000			
3021	INT	1415.006	2164.619	
	RADIUS=100.000			
302	TP	1367.551	2140.038	
303	TP	1420.939	2217.732	
3022	CP	1321.557	2228.833	
LINE 1				
205	PRC	1383.892	2246.399	
206	PRC	1406.754	2451.076	
LINE 2				
	OF=-40.000			
206	PRC	1406.754	2451.076	
207	PRC	1526.037	2543.459	
	OF=-60.000			
3041	INT	1441.535	2402.123	
	RADIUS=-150.000			
304	TP	1434.489	2339.046	
305	TP	1491.715	2440.986	
3042	CP	1583.562	2322.394	



```

* * * G E O D O S * * *      FUNCTION
* *   ROAD REGIS      * *      Road line registration
                                designed PLANE, PROFILE
                                and SECTION data.

```

INSTRUCTIONS

PLANE and PROFILE are stored together with other data in current JOB-file. SECTIONS are stored in separate JOBS for each section. "GENERAL" is general and can be used for all types of terraces and tunnel sections. You can define a section in two planes: Plan-T (top) and plan-G (ground). Automatic interpolation occur along the headline to get slope and slant transitions. "SLOPE" and "TUNNEL" are simplified section types.

The data base has the following appearance:

```

    PLANE: (Plane data, compulsory)
        Elm=      ; Element sequence number beginning with 1.
        Typ=      ; STRAight ARC or TRaNsition curve.
        N=        ; Northing for start point of element.
        E=        ; Easting      "      "      "      "
        S=        ; Section (chainage)      "      "
        R=(A=)    ; Radius or transition parameter.
    PROFILE: (Longitudinal profile, optional)
        Sec=      ; Section, (chainage) similar to PLANE-element
        Typ=      ; Section name=JOB-file for designed section.
        Ht=       ; Design height in current section.
        Sl=       ; Slope, decimal value e.g. -.01= -10 promille.
        Rv=       ; Radius for vertical curve in metres.
        Wt        ; Width to be used if no section is designed.

    SECTION: (Cross section, optional)
    GENERAL    (General cross section)
        Pno=     ; Consecutive point numbers from the left.
        Cod=     ; "PLAN-T" or "PLAN-G"
        OF=      ; Offset from headline
        Ht       ; Height from headline
        R=       ; Radius to next point (0=straight line)
    SLOPE      (Simplified road section)
        Sct=     ; Section file name
        Typ=     ; "SLOPE"
        Cmb=     ; Camber value at straight line in PERCENT(%).
        Slp=     ; Cross slope at arc in PERCENT(%).
        Bnk=     ; Slope of embankment in PERCENT(%).
    TUNNEL:    (Simplified tunnel section)
        Sct=     ; Section file name
        Typ=     ; "TUNNEL"
        Wt=      ; Tunnel width.
        Ht=      ; Height to valt (skew back).
        R=       ; Valt radius.
        D=       ; Valt center point (automatic calculatated)

```

DISPLAY	COMMENTS.
PLANE PROF SECT	Select Plane, Profile or Section.
CHECK PRINT	"Check" = Check of existing road alignment. "Print" = List of alignment on printer
PLANE	

ELEM NO=1	PSION takes care of the numbering of elements.
Pno=101=301	Enter point number for tangent point. (301 in the example)
Cod=Hp	
Ch=0.00=	Enter chainage for element start point.
STRAIGHT ARC	Select element type by using the arrow keys.
TRANSITION	(STR in the example).
ELEM NO=2	Enter point number for next tangent point
Pno=202=302	(302 in the example)
Ch=208.71=	PSION automatically calculates distance from previous point and suggests chainage, except at transition curve. Press <EXE>.
STRAIGHT ARC	Select element type (ARC in the example)
TRANSITION	
RADIUS=	Enter radius (100 in the example) minus=left curve.
ELEM NO=3	Next element etc.....
Pno=303=	
You cannot have more than one alignment in the same job. It may consist of a great number of elements. For fast searching it is recommended not to exceed 20 elements in one JOB. Conclude the last element as a "blind element", i.e. a straight line element with same start and end point.	
PROFILE	

Ch=	Key in change of section t.p. Chainage must be in the same system as PLANE design. <SPACE><EXE>=terminate.
Typ=	Key in NAME of section TYPE (standard). If such a section has been stored, (see below). It is not necessary to work with standard type sections. In such cases points are interpolated along the section line.
Ht=	Height in vertical tangent point.
Sl=	Slant or slope at vertical tangent point in forward direction. Key in as a decimal .e.g. -2.5 = 2.5 percent slope = fall of 2.5 m over next 100 meter.
Rv=	Radius of vertical curve +=convex, -=concave.
Wt=	You must enter WIDTH if you work with SLOPE sect or EMBANKMENT. Width is the total road width to top of road embankment.

TYPSECT

TYPSECT
JOB=C:

Key in JOB file name for storing a standard type section.

new JOB Y/N?

You can create a new section or edit an existing one. You can have only ONE section per file.

GENERAL SLOPE
TUNNEL

Select type of cross section. General (offset+ height), simplified cross slope or tunnel.

GENERAL (Of/Ht)

Pno=1 Plan-T

Of=

Key in offset for first point on top plane.

Ht=

Key in height difference from center line.

R=0=

Key in radius to next point. 0=straight line.

....etc.

Press <SPACE><EXE> after last point.

Pno=6 Plan-G

Of=

Key in offset for first point on ground plane

etc. Press <SPACE><EXE> after last point, or

directly if you do not give a ground plane.

Note that the points in the standard type sections must be given FROM THE LEFT to the right in each plane.


The following example shows the state when the standard type section forms a complex tunnel section. The example also shows the values you get from program POLMS with road line as REFLINE.

OF = Offset distance from center line.

TdZ = Height difference to the top plane.


GdZ = Height difference to the ground plane.

dR = Radius difference to the valt.




SLOPE.

 CAMBER Str% Key in camber value for straight lines in percent. Ex: 2.5
 Cmb=
 SLOPE Arc% Key in cross slope value for arcs in percent.
 Slp=
 CARR. WIDTHm Key in width of carriage way.
 Wt=
 TRANS.DIST Key in distance for slope transition.
 Hd=
 Thumb rule: 5-10 times the road width.
 Ex: 60



TUNNEL.

 TUNNEL WIDTH m Key in tunnel width
 Wt= Ex: 8.00
 VALT HEIGHT m Key in height from the baseline to the valt (skew back). Ex: 2.50
 Ht=
 VALT RADIUS m Key in the valt radius.
 R= Ex: 6.00
 The valt centerpoint will be calculated and stored together with the other data.



* * * G E O D O S * * *

FUNCTION

* * ROAD SETOUT * *

Calculation of 3 dimensional
radial setting out data

INSTRUCTION

Line data and station points can be stored in the same JOB file.
To store line data see program RLREG.(page 62)
You specify chainage and distance offset along the ROADLINE
ROADLINE consist of a series af straight lines, arcs and
transition curves, see program "RLREG"
Chainage interval can be set to automatic updating.
Height setting out with vertical angle and slope distance.
In the case of stored profiles and sections, heights will be
automatically interpolated. Optional setting out of slope top.

DISPLAY COMMENTS.

SLOPE SETOUT Press <Y> if you want TOP OF SLOPE setting out.
Y/N?

STATION Enter station point number.

Pno=101=105

HEIGHT MEAS Press <Y> if you want HEIGHT setting out.
Y/N ?

Ih= Enter instrument height.

Th= Enter target height.

BACK OBJ Enter reference object.

Pno=102= Bearing and distance to reference object.
is displayed.

BACK READ Enter angle reading to reference object.

Ha=332.2651= Default is bearing.

INTERVAL= Enter chainage interval for automatic updating.
Especially advantage when printer is connected.

Ch=0.000=200 Enter chainage of point to set out.
You can enter a series e.g. 200-250.

OF=0=-10 Enter offset distance (minus=left)

Z=0.000=50.00 Enter height. Only if you selected height meas
If you entered PROFIL and SECTION in "RLREG"
PSION automatically interpolates heights.

Ch=200>300 You may key in a series of chainage for
automatic printout or storing of calculated
coordinates.

PROFIL,TYPSECT PSION finds profile and section data. The name
TYP=A of the design section is displayed for a short
time.

Z=46.500 If you choosed SLOPE SETOUT, key in slope value
e.g (1:3). Default is 10:1. Press <EXE>.

S1=10:1 By slope setout you have to measure a point to
get a height value in the terrain. The program
MEASURE interpolates all data according to the point
Ha=54.85 you measured and shows the differences related
Va=100.232 to the the chainage and offset you entered
Sd=210.34
Th=1.500=

Ch=250 Of=-10

A=-0.53 B=0.11
dZ=-0.41 Sd=0.41

A=longitudinal diff, B=offset diff.
dZ=height diff to intersection with embankment
Sd=slope distance to embankment (bore depth).


PLAN Sec=200
Elm=1, STR
WORKING...
Ha=296.8588
Hd=99.614
Vd=-0.824
Va=100.5264
Sd=99.618
N=1364.417
E=2127.152
Z=50.000

If you did not select slope setout, you will
get ordinary polar setting out data.
PSION displays element type for current point.
Calculating...

Radial setting out data is displayed or printed.
Use arrow keys to view height setting out
data and coordinates.

Ch=220.00

Key in next chainage to set out etc...



* * * G E O D O S * * *	FUNCTION
* * DIGITIZE * *	Registration of points by digitizing from maps and drawings. Optional height registration

INSTRUCTIONS

Implemented digitizers: XPLAN 360i, PLANIX 5000, DIGICORD.
Connect PSION to digitizer via COMMS-link RS232.

Valid communication set up parameters:.

XPLAN: 1200 BAUD	PLANIX: 1200 BAUD	DIGICORD: 9600 BAUD
8 BITS	7 BITS	8 BITS
NO PARITY	NO PARITY	NO PARITY
2 STOP BITS	2 STOP BITS	1 STOP BIT

Device setting up:
XPLAN: Use default values.

PLANIX: 1 2 3 4 (Switch no)
 U U U D (U=up, D=down)
 Note that you have to switch pin 2/3 and 4/5 in
 the connector.

DIGICORD: 1 2 3 4 5 6 7 (Switch no)
 U D D D D D D (U=up, D=down)

Use set up functions on resp. digitizer for scale, origin etc.
Read the manual for applicable digitizer.
Some tips:

XPLAN:

1. Hold down CLEAR-key when you start XPLAN in order to reset all parameters.
2. Put XPLAN in "COMPUTER" "NO PRINT" mode.
3. Calibrate or select drawing scale.
4. Switch to "PRINT"-mode.

PLANIX:

1. Connect COMMS-link and PLANIX RS232 interface.
2. Check the DIP-switches in PLANIX interface (all ON)
3. Press ON at PLANIX.
4. Press ON at the INTERFACE.
5. Press ON at PSION.

Now you are ready to digitize and store in GEODOS.

You can increase the accuracy if you digitize several known points and afterwards make a coordinate transformation with program "HTRAN" in GEODOS. (page 44)

COMMENTS.

COMMENTS.

MENU. Use arrow keys to select digitizer.

heights (Z).

MENU. Use arrow
 You can select input of heights (Z).

Enter point number.
Enter code.
Enter value for t

Enter point number.
Enter code.
Enter Z value for the point to be digitized.
Only if you select height measurement.
Press the button for pointwise digitizing.
Point number will increment with 1 and the
code and Z will remain as previous for next
point to digitize.
Press <ON> to change Pno and/or code and Z.
will be stores in current

Press the **POINT** key. The point number will increase by 1. The code and Z will remain as previously set. Press **POINT** again to digitize.

Press **<ON>** to change Pno and/or Code and Z.

The coordinates will be stored in current JOB.

Error in data transmission. Try again.



* * * G E O D O S * * *

FUNCTION

* * PLOTTING * *

Automatic plotting of a JOB.

INSTRUCTION

Grafic language: HPGL.

Selectable scale, format (height/width) and plotting window. Different lines, symbols and text can be related to different codes by means of the CODE TABLE. It is also possible to automatic get lines between points with sequence numbers. Automatic plotting of grid with text and header. PSION suggests origin and size when you select the scale.

It is important to make a proper setup for your plotter. If you use a plotter without buffer, it is particular important to use a good handshake facility. Use "HAND ALL" if possible.

Also be aware of the SCALE FACTOR on your plotter. To check, plot a grid with SCX=1 SCY=1 (default) and measure with a good graduated rule. Then calculate scalefactors to insert in your USER file. See page 84.

Example of a good setup for HP7475:


		S2	S1	Y	US	A3	B4	B3	B2	B1
Baud	2400	-----								
Parity	EVEN	x				x	x			
Bits	7		x	x	x			x	x	x
Stop	1	-----								
Hand	ALL									

DISPLAY

COMMENTS.

A3/A4-PLOTTER	MENU to select plotter size. At A0/A1-PLOTTER
A0/A1-PLOTTER	PSION reads the inserted sheet size.
SCALE=1:	Enter PLOT scale
WORKING...	PSION calculates the extents in the JOB file.
CODE TABLE	Press <EXE> to plot WITHOUT code table, else
JOB=C:	enter the name of the code table.
HEIGHTS	Without code table you answer <Y> or <N> on
Y/N ?	the following questions:
ZZ DR TDZ GDZ	Heights will plotted with the decimalpoint
POINT-NAME	at the measured point.
Y/N ?	If you have used 3D REFLINE and stored coord-
COD	inates (sto%=1), you can select height diff.
Y/N ?	Point name will be plotted in the lower
LINES	left position.
Y/N ?	Code will be plotted in the lower right
	position
	Lines will be plotted between points with
	numbers in sequence order independent of
	measurement order. Points will be automatic
	sorted when plotting.
PLOT 1:1000...	This is a MENU with default values calculated
N=1000 E=2000	based on your scale, selected plotter, paper
Ht=240(230)mm	size and the values in your JOB file. The values
Wt=340(320)mm	within brackets is the size you need to get all
ROTATE=0 PLTMAN=	data on the same sheet. You may change any data
PLH%=2	in any order. When using ROTATE, check that your
	plotter also is in ROTATE MODE.

EXEMPEL:



* * * G E O D O S * * *

FUNCTION

* * CODE TABLE * *

Edit codetable for JOB-file
plotting.

INSTRUCTION

CODE TABLE is a table to define your drawing. You can define how to plot SYMBOLS, TEXT, LINES and ARCS. The code table will be stored as a normal JOB-file with optional name. You may have several different CODE TABLES. You can edit a code table with program EDIT on page 24.

DISPLAY COMMENTS.

CODE TABLE

JOB=C: Enter "JOB name" for the code table.

GEODOS

Cod= Key in the code that you have used in the

Job you will plot.

SYMBOL

Typ=(xo+.) You can select four types of symbols. Press

HEIGHT mm= one of this keys : <x>,<o>,<+> or <.>

Enter height of the symbol in mm.

TEXTHEIGHT

Pno=mm= Enter text heights in mm,

Cod=mm= for point number (lower left position)

 Z=mm= for code/text (lower right position)

for Z values (upper center position)

Key in 0 mm to omit text.

LINE

Typ=(0-7)= Enter line font number according to the manual

Pen=(1-8)= for your plotter. Default is type 7 (solid).

Key in pen number.

PNO-SERIE

Pno= Enter PNO series to define how to connect the
points. You can use the following special
characters:

* All points with sequence numbers are sorted
and automatic connected with straight lines

+ Line to next point in the list

, Space to next point in the list

() Arc to next point. Give radius within the
brackets. ex:...+302(100)303+...

Code table is stored as in following example:

Cod=GP

Feature code.

Smb=o1.0

Symbol circle 1.0 mm

Lin=4.3

Line font 4 pen 3

Pno=1.5

Point number hgt 1.5 mm

Cod=1.5

Code height 1.5 mm

 Z=0.0

No Z value will be plotted

Pno=301+302(100)303..

Line definition.

Pno=*,401+408,1201+..

"

"

CODE TABLE USED FOR THE EXAMPLE ON PAGE 71.

CODE	SYMBOLS	TEXTHEIGHTS			LINES
		Pno	Kod	Z values	
PP	o2.0	1.5	1.5	0.0	0.0
HP	+1.5	0.0	0.0	2.0	0.0
GP	o1.5 301+302(100)303+304,301+305(-500)306+307+304	1.5	1.5	0.0	3.2
HH	.0.0 *,401+408,1201+1204	1.2	0.0	0.0	4.2

```

* * * G E O D O S * * *      FUNCTION
* *   SDTA CALC      * *      Coordinate calculation of
                                radial surveydata stored
                                with program "POLMS".

```

INSTRUCTIONS.

Known points must be stored in current JOB or in JOB "PBANK".
If a station point is missing, the calculation will stop and
you can key in the station coordinates.

DISPLAY	COMMENTS.
---------	-----------

SURVEYDATA	Enter survey data JOB name.
JOB=C:	

P=101	Coordinates will be stored in current JOB-file.
P=102.....	Survey data does not change. The points appear in the display during calculation. You can edit survey data and/or your known station points and thereafter recalculate.

NO SURVEYDATA	Error message. The file is not a survey data file. You can not mix coordinates and raw survey data.
---------------	---

* * * G E O D O S * * *
 * * STN HEIGHT * *

FUNCTION
 Calculation of height of station
 point by angle and distance meas-
 urement. You can measure to one or
 several known height points.

 INSTRUCTIONS:

If the plane coordinates are stored in the JOB file, you can
 measure just the vertical angle. Otherwise you must measure also
 the distance. You can use an unlimited number of known points.
 Mean value and deviation is displayed and stored.

 DISPLAY COMMENTS.

MANUELL
 GDM-I/O....

Select totalstation <EXE>=manual.

STATION
 Pno=105=

Enter station point number.

SLOPE DIST
 Y/N ?
 HEIGHT MEAS
 Y/N ?

Press <Y> för slope distance measurement.
 Press <Y>.

Ih=
 Th=

Enter instr. height <EXE>=0.00 (instr.axis)
 Enter target height. You can change during
 measurement.

OBJECT nr 1
 Pno=101=

Enter point name for each known object.
 Press <SPACE><EXE> to quit.

Ha=
 Va=
 Sd=
 Th=0.000=

Enter "0".
 Enter vertical angle.
 Enter "0" or measured distance.
 Enter target height.

Pno=102=

Etc...Etc...

M Z=50.573
 dH=0.006
 1 Z=50.573
 2 Z=50.574
 etc...

After last measurement mean value and mean-
 deviation is displayed. You can use the arrow
 keys to look at the separate resulys.
 Press <EXE>.

P=105 Z=50.573.. Press <Y> if you accept the measurement.

OK J/N ?
 ...Z=0.003..
 DIFF OK J/N ?
 KEEP CHANGE
 MEAN

If there is a previous height on the point
 the difference is displayed.
 Select if you will keep the old height, change
 to the new or store a mean value.

* * * G E O D O S * * *

FUNCTION

* * REFER LINE * *

Definition of a 3D REFERENCE LINE.
You can combine this program with
RADIAL MEASUREMENT and SETOUT.
(POLMS and POLSO). This program
can be used for e.g. direct house
set out, tunnel control, profile
set out etc.

INSTRUCTIONS

Reference line may consist of STRAIGHT LINE, ARC, ROADLINE or
POINT with BEARING.
When using ROADLINE in combination with "POLMS" the result will
refer to the complete 3D designed line. (PLANE, PROFILE and
SECTION, see page 62). Automatic surface interpolation.
Setting out of the roadline is carried out with the program
"RLSO" (see page 66).
You can change or quit the reference line during measurement
by pressing <R> or <Q> after the result is displayed.

DISPLAY COMMENTS.

STRGHT ARC RDLIN MENU to select reference line type. Straight
TAN SLP POL QUIT line, Arc, Roadline, Tangent to roadl. arc
 Slope line, Polar sphere from centerpoint.

BASEPOINT Enter start point for reference line.
Pno=1=

TARG-POINT Enter end point for reference line.
Pno=2= Press <SPACE><EXE> if you want to enter
 BEARING instead of point number.

Ha= Key in BEARING in current angle unit.
Sl=ex 1:10= Key in slant. (ex 1:10 = 1m per 10 metres up-
 wards). This question appears only if "SLANT"
 is choosen in yhe menu above.

RADIUS= Enter curve RADIUS. <+>=right, <->=left.

REFER LINE STR
Ha= 225.1322 Bearing and distance on reference line
Hd= 50.000 is displayed..
Sl=1:1.32(3.12%) Slope value on reference line.
SECTION Diff Anser <Y> if you want to store the values
STORE Y/N ? from POLMS (A,B and height diff)

LINE MISSING If you choose to work with roadline and no
 line data has been previously registered.
 Use program "RLREG" to store roadline.

By result from Press <R> to change to another line or
POLSO or POLMS. press <Q> to return to "normal" measurement.

SAMPLE

BASE POINT

405 N=1224.717 E=2258.011 X=40.000

END POINT

406 N=1178.563 E=2238.781 Z=40.000


STN 105 Ih=1.550

101 Ha=268.6226

1000 Ha=175.2309 Va=108.8450 Sd=87.410 Th=0.000

N=1289.236 E=2259.483 Z=40.005

A= -60.123 B= 23.456 Dh= 0.005



* * * G E O D O S * * *

Function

* * PROFILE * *

PROFILE is the MAIN routine
for a number of program that
handles ROAD LINE PROFILES,
and SECTIONS.

INSTRUCTIONS

The base for profile and sections is the file "PROFILE" that is
stored in the C: pack. It is automatic created with the program
"CREATE" and will contain profile and section data.
It may also be directly created with the program "LEVEL".
REFERENCE LINE to profile data can consist of single lines or
arcs or a complete roadline with lines, arcs and transition curves

DISPLAY

COMMENTS

** GEODOS **
* REFLINE **

If you earlier did not give any reference
line, you automatically enter this
program. Press <EXE>.

STRGHT ARC RDLIN
TANG SLANT QUIT

Choose type of reference line. (see page 74)

CREATE PRINT
EDIT SECTPLT
PROFPLT LEVEL

Select program:
CREATE = Create JOB and calculate.
PRINT = Print out profile data
EDIT = Edit profile data
SECTPLT= Plot cross sections
PROFPLT= Plot profile
LEVEL = Levelling of profile data

CREATE :

Key in corridor WIDTH along the reference
line = centerline. See page 79

PRINT :

Print out of section data in the same way
as described on page 50.

SECTPLT :

Plotting of sections on HPGL compatible
plotter. Optional scale in height and plane
Selectable number of sections per sheet.
Detailed description on page 80.

PROFPLT :

Plotting of profile along reference line
with optional scale in height and length
in the same way as described on page 70.

EDIT :

List, search, edit etc in the same way as
described on page 24.

Note that with ROADLINE reference the calculation will go faster
if the measured point are stored in order along the alignment.

* * * G E O D O S * * *

Function

* * CREATE * *

Create PROFILE data as a base
for listing, and plotting of
profile and cross sections.

INSTRUCTIONS

The program calculates chainage and offset along the reference line and store the data in a JOB file. The data will be sorted in chainage order. Points will be renumbered from 1. The original point number will be added to the code.

The profile data are stored as follows:

PNO CODE CHAIN OFFSET HEIGHT DR TDZ GDZ.

Points with Z=0 will not be calculated.

If the reference line is a roadline, the alignment must cover the area to calculate.

Check that there is space enough in your datapack before you start the calculation.

DISPLAY

COMMENTS

** GEODOS **

* REFLINE **

If you earlier did not give any reference line, you automatically enter this program. Press <EXE>.

STRGHT ARC RDLIN

TANG SLANT QUIT

Choose type of line. (see page 74)

At ROADLINE, the line must cover all points. No automatic extension.

SECTION

JOB=C:PROFIL=

Enter JOB NAME for profile data. Default name = PROFIL

START resp END

Chn=

Enter START resp END chainage for profile to create.

CORRIDOR

Wdt=

Enter corridor width from reference line
All points with Z value within the corridor will be calculated in relation to the reference line.

SORT

OK Y/N?

If you answer <Y>, data will be sorted on chainage . Answer <N> if you want to keep the measurement order e.g. for tunnel profiles.

P=101

P=102...

You can follow the calculation in display
Along a roadline the calculation will run faster if the points are stored in order along the line. At the end a sorting will take place.

S=1

S=2...

* * * G E O D O S * * *

Function

* * SECTPLT * *

Plotting of cross sections

INSTRUCTIONS

Plotting of cross sections take place with "PROFIL DATA" as base. See page 79. You can choose to plot design section at the same plot as the ground section.
Optional number of sections per plot sheet.

DISPLAY

COMMENTS

SECTION
JOB=C:PROFIL=

Enter name of the job where profile data is stored. See page 79.

A3/A4-PLOTTER
A0/A1-PLOTTER

Select type of plotter. When using A0/A1 PSION automatic reads the paper size from the plotter.

SECTION SCALE
DIST 1:
HEIGHT 1:

Enter scale factor for length scale
Enter scale factor for height scale

SECTION
INTERVAL:
CORRIDOR:

Enter interval for cross sections to plot
Enter corridor width (tolerance) perpendicular to the reference line within the points belong to the current section. There will be no interpolating in this program. See "VOLUME" on page 82 for interpolating of cross sections.

SECTION
START:
END :

Enter chainage for the first section
" " " " last "

SECTIONS/SHEET
ROWS:
COLUMNS:

Enter number of sections in rows
" " " " " columns

REFLINE
JOB=C:

Enter name of JOB file where designed roadline is stored. Press just <EXE> if you don't wish to plot designed sections.

SECT=20...

The plotter starts and plot selected number of cross sections on each sheet. You may continue on next sheet directly after changing.

CHANGE SHEET

EXEMPEL: ▶

▶

===== GEODOS = version 5.89 ==

VIKER DATA AB
433 43 PARTILLE


===== 19 JUL 1991 10:46:30 ==

ARB-NAMN : MANUAL ARB-NR : 12.345 OPER: SOA

SKTIONERNG
JOB : C:OAP

REFLINJE ELEM	TYP	X	Y	SEKT	R/A
1	RAK	59585.501	87300.852	26082.694	
2	KLT	59369.938	87044.099	26417.939	775.468
3	CIR	59182.875	86809.658	26717.939	2004.500
4	KLT	58819.080	85407.220	28200.345	775.468
5	RAK	58868.598	85111.410	28500.344	
6	RAK	59397.444	82373.293	31289.065	

PNO/KOD	SEKT/A	SIDM/B	Z	DR	TDZ	GDZ
101/B	28023.701	7.993	39.220	-0.007	*****	2.191
102/B	28023.275	8.244	40.821	0.367	-0.294	3.791
103/B	28023.647	7.884	42.024	0.437	1.275	4.995
104/B	28023.227	6.788	43.545	0.458	0.662	6.515
105/B	28023.310	5.309	44.318	0.422	0.455	7.288
106/B	28023.006	4.018	44.497	0.211	0.217	7.466
107/B	28022.821	2.600	44.745	0.271	0.271	7.713
108/B	28022.889	2.116	44.754	0.274	0.274	7.723
109/B	28022.594	0.762	44.321	-0.019	-0.020	7.289
110/B	28023.296	-0.243	44.300	0.213	0.224	7.270
111/B	28023.000	-1.233	44.383	0.646	0.713	7.352
112/B	28023.189	-1.844	43.763	0.370	0.429	6.732
113/B	28023.878	-2.651	42.901	0.292	0.490	5.872
114/B	28023.195	-3.357	41.628	0.247	0.769	4.597
115/B	28023.009	-3.732	40.765	0.342	-0.309	3.734
116/B	28023.116	-4.000	40.127	0.507	-1.717	3.096



* * * G E O D O S * * *

Function

* * VOLUME * *

Calculation av average VOLUME
from the point base.
Interpolation of cross sections.

INSTRUCTIONS

The program interpolates cross sections and calculates section AREAS and VOLUMES along a straight reference line. You can select a FIXED or VARIABLE reference level. The variable level is the ground level on the measured outlines. You can also give a SLOPE when using fixed reference level. The interpolation is made along measured lines. The lines are defined with consecutive point numbers on the measured points in the same way as described in program "PLOT" on page 70. Use e.g. program POLMS or DIGI for data collection. You can store the sections for further plotting.

DISPLAY

COMMENTS

STORE PROFILE
Y/N?
BASEPONT
Pno=1A=

Press <Y> if you want to store section data in JOB=PROFIL for e.g. plotting.
Key in the START point = first cross sect
NOTE ! If the baseline has consecutive number, that line will also be contained in the interpolation and volume calc.

REFERPOINT
Pno=1B=

Key in the END point = last cross section.
The reference line must be within the area for the measured point. Otherwise you will get an error message during the interpolation.

REF LEVEL
Z=

Key in the reference level if desired.
Press just <EXE> if you want to use the outlines as variable level.

Sl=ex 1:10=

If you entered ref level above you can also give slope along the baseline.
Press just <EXE> for horisontal level.

INTERVAL=
SORTING...

Key in the interval for cross sections to interpolate. PSION sorts the points, and creates lines for the interpolation

Z=40.00 Int=20
#Sct=15 #LIN=5
5 min OK Y/N?

In the display you will see how many cross sections that will be interpolated and the number of lines. You can also see the time it will take to calculate.

> (Sct= 0) ^
-60.15 42.37

Press <Y> to continue or <N> to quit.
You can follow the interpolation in the display. Offset and height is displayed for each point. If a printer is connected you will get a printout. Press <ON> if you want to interupt.

Sct=852 m2
Vol=17032 m3

For each cross section the AREA and VOLUME from previous sections is displayed.

Vol=282531 m3
STORE OK Y/N?

TOTAL VOLUME is displayed. You can store the result in the current JOB file.

VOLUME
JOB: C:VOL

REFLINE			
PNO	COD	N	E
1A	BL	1063.250	2118.360
1B	BL	1306.100	2240.000

REFERENCE LEVEL Z=40.000 Sl=0

SECT	OFFS	HEIGHT

60.00		
	-56.73	52.27
	- 1.07	52.23
	57.45	52.34
	168.26	42.73
	168.26	40.00
	-56.73	40.00


ARER 2235.7 m2
VOLUM 38088 m3

etc etc.....

271.61		
	68.71	53.23
	127.51	43.88
	127.51	40.00
	68.71	40.00

AREA 503.1 m2
VOLUM 13683 m3

VOLUME 102497 m3



USER - The user parameter file.

 "USER" is a OPL PROCEDURE FILE where you can change GEODOS default parameters. You can define your own parameters with help of the variables seen below. Store the USER file in C: (RAM pack). These values (new parameter settings) will override the values (default values) in the system parameter file. You need only define the parameters you wish to change.

NAME	DEFAULT VALUE	REMARK
DC%	3	Number of decimals in printout and result display.
U%	0	Angle unit. 0 = gon 1 = grades + decimals 2 = grades min sec. 3 = radians
RAD%	60	# Lines per page for print out.
TID%	0	Point name at measurement replaced with TIME if 1. Format: HH.MM.SS
PN	1	Incremental value for automatic point numbering
PRINIT\$	CHR\$(27)+CHR\$(64)+CHR\$(27)+"5"+CHR\$(0)+CHR\$(27)+"1"+CHR\$(6) for DICONIX-150	Character string for initiation of printer, e.g. setting of left margin, font etc. Refer to printer manual.
KSTAT%	1	Setting of keyboard function for POINT CODE. 1= uppercase letters. 3= figures.
UTM%	0	With UTM%=1 set to 1, it is possible to compensate for scale factor in POLMS, POLSO e.g
DMAX	0.1	Tolerance for standard deviation in programs where mean value is calculated.
LMAX	100	Max offset distance at measurement related to roadline reference line.
JR	6375	Earth radius in km.
JK	0.14	Coefficient of refraction.
SCX	1	Plotter scale factor (easting)
SCY	1	" " " (northing)
PLH%	2	0= no grid or frame, 1= grid 2= grid and frame
NAM\$	" "	Name and adress of print out of headers etc.
ADR\$	" "	
DMH=	0.000	Length measurement intr. height above theodolite axis.
TM\$	"01020304050607080910"	STRING for MENU of total stations. Definition see table on next page. Each code must contain 2 char.

EXAMPLE:

If you want to set your own NAME and ADDRESS on print outs.

1. Start "PROG" from the main menu.
2. Select "NEW" in the next menu or "EDIT" if it is not the first time.
Display shows "NEW A:" Change to "C:" with <MODE>.
3. Key in "USER", Press <EXE>.
4. Display now shows "USER:" , Press <EXE>.
5. Key in e.g. NAM\$="GEOTRONICS LTD", Press <EXE>
6. Key in e.g. ADR\$="Box 64 18211 DANDERYD, Sweden"
7. Press <MODE>. Display shows TRAN SAVE QUIT.
Press <EXE>
8. Display shows SAVE C:USER. Press <EXE>

Now it is ready.

You can any time enter the USER file and append or change these parameters. However it does only work if it is carried out correctly. You will always be given an OK if everything is keyed in correctly, and when you enter GEODOS. A BEEP and YOUR NAME can be seen in the DISPLAY.

Some tips:

If you are using several RAM packs at the same time, mark them with different names (NAM\$) in the user file. You will than be given a reminder each and every time you enter GEODOS.

Table over TOTALSTATION CODES:

01 = MANUAL INPUT	Manual input of angles and dist
02 = LEICA	TD,TC,TC1,TC2,TC5,TM3,NA2/3
03 = GDM-I/O	Geodimeter 130-140,220,410-440 I/O
04 = GDM-SER	Geodimeter Serial
05 = SOKKIA	Sokkia SET3/4/5,SETC,SET5A
06 = TOPCON	Topcon GTS3/4/6,RS1-A,GTS300,CTS1/2
07 = PENTAX	Pentax PTSIII,PTS10
08 = NIKON	DTM-A/D, OLD
09 = ZEISS	Zeiss Elta3
10 = KERN	Kern DM500,RD20,DM

COPYING JOB-files..

You can in a very simple way copy JOB-files between different devices. Use "COPY" in the MAIN MENU.

Some samples:

1. Your friend wants to use your JOB "KALLE" that you have stored in your RAM-pack in slot C:.
 - Remove your RAM-pack in slot C:
 - Change it with the GEODOS-pack in your friends PSION.
 - Select "COPY" from the main menu.
 - PSION displays "FROM"
 - Type "B:KALLE" and press <EXE>.
 - PSION answers "TO"
 - Type "C:" och press <EXE>.

It takes a few seconds to copy 100 points.

The JOB-file will be named "KALLE" also at your friends PSION. You can change name if you want.

2. You want to make a temporary copy of JOB "KALLE" from the RAM-pack (C:) to the internal memory (A:) to be safe when you connect to an unknown computer.
 - Select "COPY" from the main menu.
 - PSION displays "FROM"
 - Type "C:KALLE", Press <EXE>
 - PSION displays "TO".
 - Type "A:BACK" and press <EXE>.

The JOB in the internal memory will be called "BACK" and is an exact copy of "KALLE"

NOTE. If JOB "KALLE" already exists, the new points will APPEND to the old JOB.

Learn how to handle "COPY" in a safe way. It is very useful. And first of all, train to make BACKUP copies of important data.

When you use DATA-packs of EPROM-type, use battery eliminator

TAKE CARE OF YOUR DATA !

Some rules for safe handling av data in RAM-packs

- When you connect power adapter to the COMMS-link you have to be careful. Do it in the following steps:
 1. Power off.
 2. Connect COMMS-link WITHOUT POWER ADAPTER.
 3. Press <ON>
 4. Connect power adapter to COMMS-link.
- When the computer is working, do not disconnect or remove any devices or power sources.
- Avoid magnetic fields close to RAM-packs.
- Do backup or print out important data before you remove a RAM-pack. The battery in the RAM-pack have a life of approximatly 3 years.

USER PROGRAMMING.

You can add your own software to the GEODOS system.
The program language is called OPL. Refer to PSION manual.
There is one access routine:

APROG:

Your programs will be very powerful because of access to "GPL",
Geodos Procedure Library.

It will not be described in this manual. Here only is an idea
as to how the system works by showing the following example:
The object code for the program listed below also exists in the
GEODOS program pack.

PROGRAM LISTING	COMMENTS

	Program: DIST Display distances, bearings height differences etc. when you ask for pointnumbers from the data base.
DIST:	: Procedure name
LOCAL i%	: Declaration coord array index
PR#(31)=" DISTANCE"	: Header text
LGO:	: Display header
DO	: Start loop
CLS	: Clear display
STR#="ENTER POINT"	: Header for procedure "FIN"
i%=i%+1	: Index for coord array
IF FIN:(i%)=0 :RETURN :ENDIF	: Find coord in database X(),Y()
IF i%=2	: After first time.....
PLU:(1)	: calculate radial data
i%=1	: Update array index
X(1)=X(2)	: Change coordinates for
Y(1)=Y(2)	: next calculation
ENDIF	: That's all.
UNTIL 0	

This procedure can not run outside GEODOS due to the use of
GEODOS common arrays.

You must therefore write the following procedure:

APROG: :Program name in GEODOS menu.
DIST: :Call up your own procedure.

You can store your procedure in A: or C: memory. The GEODOS-pack
(B:) is write protected.
To run the program, enter GEODOS and select "APROG" from the
GEODOS menu.

GEODOS Database

General

"Raw" data in PSION is stored in "ODB"-format.
"ODB" is short of "Organiser Data Base"

It is a compact ASCII-format with delimiter between the different data fields. The delimiter character is ASCII 9 (Horizontal TAB).
It is possible to convert the delimiter while sending or receiving. In "COMMS" "SETUP" you can change the parameter "TTRN". Default is "no conversion".

The GEODOS database is a matrix with 7 columns in each record.

The two first fields has a PREFIX to handle different data types
The prefix is a letter followed by an equalsign (=).
In the second field there are also important information for the data base as described in the following:

In general the following is valid:

Column 1	A/N with prefix	Max 14 char. incl. prefix
" 2	A/N with prefix	Max 14 char. incl. prefix
" 3	Numerical	Max 12 char. (+ - 0-9)
" 4	Numerical	" " " "
" 5	Numerical	" " " "
" 6	Numerical	" " " "
" 7	A/N without prefix	Max approx. 200 char.

One RECORD as above is MAXIMUM 255 characters. There is usually not more than 60 characters in a record.
Column 7 is mostly used as a REMARK field.
The first two columns is mainly used for POINT NUMBER and FEATURE CODE with prefix "P=" resp. "C="

Different data types may appear in the same FILE in any order. However it is NOT ALLOWED to mix polar survey data with rectangular coordinates.

In the GEODOS-software you can reformat data while sending or receiving, but it is an advantage if you use the ODB-format for communications.

The following is a list that describes the different data types.

1. COORDINATES

Column 1:	Point number	Prefix: P=
" 2:	Feature code	Prefix: C=
" 3:	X-coordinate	
" 4:	Y-coordinate	
" 5:	Z-coordinate	
" 6:	Quality value	
" 7:	Remark	

2. LINES

Column 1:	Elementnumber	E=1,E=2,E=3 etc.
2:	Elementtype	C=RAK,C=CIR,C=KLT
3:	X-coordinate startpoint	
4:	Y-coordinate startpoint	
5:	Chainage (Section)	
6:	Radius or clothoidparameter with sign (minus is left hand curve).	
7:	Not used.	

Remark:

Note that an element record is not complete by itself, but must always be followed by another element, that defines the end point. The last element in a road line must be stored twice.

The first and the last element must not be a clothoid. Two clothoides may be stored after each other in the inflexion point with different signs. (right/left) in column 6.

3. HEIGHT PROFILES

Column 1:	Chainage (Section)	Prefix: H=
" 2:	Name of TEMPLATE	Prefix: C=
" 3:	Height in chainage acc. to col 1	
" 4:	Slope in percent (minus is down)	
" 5:	Radius on vertical curve (minus=concave)	
" 6:	Not used	
" 7:	Nor used.	

Remark:

Note that the slope must appear in every record. "Slope" means slope in the starting point.

4. REFERENCE VALUES: (Local coordinate systems)

Column 1:	Order number	Prefix: A=+
" 2:	Pointno/Code	Prefix: C=
" 3:	Chainage alt	Abscissa (A)
" 4:	Offset	Ordinata (B)
" 5:	Diff (Radial dist to type sect, dR)	
" 6:	Height diff to "T-plane" (TdZ)	
" 7:	Height diff to "G-plane" (Gdz)	

Remark:

Reference values may be stored by eg. POLAR measurement with 3D road line as reference line.

5. TYPE SECTIONS (Templates)

There are three different ways to store type sections.

5.1 Offset/Heigh (General type section)

Column 1:	Order number	Pfx: T= eller G=
" 2:	"C=PLAN-T" or "C=PLAN-G"	
" 3:	Offset according to head line	
" 4:	Height according to head line	
" 5:	Radius to next point ("0"=straight linje)	
" 6-7:	Not used.	

Remark:

Two plane may be stored in the same file: Plane "T" and plane "G".

I each plane data is stored from left to right offset.

At first plan "T" is stored. The numbering is sequensial from "1".

The height in origin must exist (at offset=0.00).

This type of template is connected to the height profile. Interpolation between templates take place automatically along the headline.

5.2 Camber

Column 1:	File name	Pfx: B= ex: B=AA
" 2:	"C=Skevning%"	Fixed data..
" 3:	Camber on straight line (%)	
" 4:	Camber in curve (%)	
" 5:	Carriage widht	
" 6:	Transition distance	
" 7:	Not used.	

Remark:

This template is connected to PLANE data and automatically take care of the camber slope according to the plane curvature.

5.3 Valt (Simple tunnel roof)

Column 1:	Filname	Pfx: U= ex: U=BB
" 2:	"C=TUNNEL"	Fixed data
" 3:	Tunnel width	
" 4:	Height to valt center	
" 5:	Valt Radius	
" 6-7:	Not used.	

6. POLAR SURVEYDATA

The first line is a "HEADER" with some user definable data.

Header:

Column 1:	"P=MDTA"	Mandatory
" 2:	A/N info	Pfx: "C="
" 3-6:	Numerical info	
" 7:	A/N info	

Surveydata:

Column 1:	Point number	Pfx: "P="
" 2:	Feature code	Pfx: "C="
" 3:	Hor.angle or Ih.	If "C=Stn" Ih is valid.
" 4:	Vert. angle	
" 5:	Slope distance	
" 6:	Target height	
" 7:	Remark	

Remark:

At station point : Col 2 = "C=Stn"
At ref. target : Col 2 = "C=Bobj"