


GENERATOR (for DENSO Made)


COMPONENTS




CH

REMOVAL


1. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL
2. REMOVE V-BANK COVER (See page [ES-414](#))
3. REMOVE RADIATOR SUPPORT TO FRAME SEAL LH (See page [CO-15](#))
4. REMOVE FAN SHROUD (See page [CO-15](#))
5. REMOVE GENERATOR ASSEMBLY




- (a) Disconnect the wire harness.
 - (1) Remove the bolt and wire harness stay.
 - (2) Disconnect the connector from the generator assembly.
 - (3) Remove the terminal cap and nut.
 - (4) Disconnect the wire harness from terminal B.



- (b) Remove the 2 bolts, then separate the wire harness clamp bracket from the generator assembly.



- (c) Remove the 2 bolts, then remove the generator assembly.



DISASSEMBLY

1. REMOVE GENERATOR PULLEY
SST 09820-63010 (09820-06010, 09820-06020)
HINT:


| | |
|---------------|-------------|
| SST 1-A and B | 09820-06010 |
| SST 2 | 09820-06020 |

- (a) Hold SST 1-A with a torque wrench, and tighten SST 1-B clockwise to the specified torque.


Torque: 39 N*m (400 kgf*cm, 29 ft.*lbf)

NOTICE:

Check that SST is secured on the rotor shaft.



- (b) Mount SST 2 in a vise.
- (c) Insert SST 1-A and B into SST 2, and attach the pulley nut to SST 2.




- (d) To loosen the pulley nut, turn SST 1-A in the direction shown in the illustration.


NOTICE:

To prevent damage to the rotor shaft, do not loosen the pulley nut more than one-half turn.


- (e) Remove the generator from SST 2.




- (f) Turn SST 1-B, and remove SST 1-A and B.
- (g) Remove the pulley nut and pulley.


**2. REMOVE REAR GENERATOR END COVER**

- (a) Place the generator on the pulley.
- (b) Remove the 3 nuts, then remove the rear end cover.


**3. REMOVE TERMINAL INSULATOR**

**4. REMOVE GENERATOR BRUSH HOLDER ASSEMBLY**

- (a) Remove the plate seal.
- (b) Remove the 2 nuts, then remove the brush holder.
- (c) Remove the plate seal.


**5. REMOVE GENERATOR COIL ASSEMBLY**

- (a) Remove the 4 bolts.




- (b) Using SST, remove the coil.


SST 09950-40011 (09951-04020, 09952-04010, 09953-04020, 09954-04010, 09955-04071, 09957-04010, 09958-04011)

**6. REMOVE GENERATOR ROTOR ASSEMBLY**


- (a) Remove the generator washer and the generator rotor.

**7. REMOVE GENERATOR DRIVE END FRAME BEARING**


- (a) Check the bearing whether it is rough or worn. If necessary, replace the bearing.



- (b) Remove the 4 screws, then remove the retainer plate.



- (c) Using SST, tap out the bearing.
SST 09950-60010 (09951-00250), 09950-70010 (09951-07100)



INSPECTION

1. INSPECT GENERATOR BRUSH HOLDER ASSEMBLY

- (a) Using vernier calipers, measure the exposed brush length.

Standard exposed brush length:

10.5 mm (0.413 in.)

Minimum exposed brush length:

4.5 mm (0.177 in.)

If the exposed brush length is less than the minimum, replace the brush holder.

2. INSPECT GENERATOR ROTOR ASSEMBLY


- (a) Check the rotor for an open circuit.

- (1) Using an ohmmeter, measure the resistance between the slip rings.

Standard:

2.3 to 2.7Ω at 20°C(68°F)

If the result is not as specified, replace the rotor.



- (b) Check the rotor for ground.

- (1) Using an ohmmeter, measure the resistance between the slip ring and rotor.


Standard:


10 kΩ or higher

If the result is not as specified, replace the rotor.

- (c) Inspect the slip rings.

- (1) Check that the slip rings are not rough or scored. If rough or scored, replace the rotor.





- (2) Using vernier calipers, measure the slip ring diameter.


Standard diameter:

14.2 to 14.4 mm (0.559 to 0.567 in.)

Minimum diameter:


14.0 mm (0.551 in.)

If the diameter is less than the minimum, replace the rotor.



3. INSPECT GENERATOR ROTOR BEARING

- (a) Check the bearing whether it is rough or worn. If necessary, replace the generator rotor.



REASSEMBLY

1. INSTALL GENERATOR DRIVE END FRAME BEARING


- (a) Using SST and a press, press in a new bearing.
SST 09950-60010 (09951-00250), 09950-70010 (09951-07100)
- (b) Install the retainer plate with the 4 screws.
Torque: 2.2 N*m (22 kgf*cm, 19 in.*lbf)


2. INSTALL GENERATOR ROTOR ASSEMBLY

- (a) Place the drive end frame on the rotor.
 (b) Install the rotor and washer.


3. INSTALL GENERATOR COIL ASSEMBLY

- (a) Using a deep socket wrench 21 and a press, in the generator rectifier end frame carefully.






- (b) Install the 4 bolts.
Torque: 5.8 N*m (59 kgf*cm, 51 in.*lbf)




4. INSTALL GENERATOR BRUSH HOLDER ASSEMBLY

- (a) While pushing the 2 brushes to inside the brush holder, insert a pin (φ1.0 mm (0.039 in.)) into the brush holder hole.



- (b) Install the generator brush holder with the 2 screws.
Torque: 1.8 N*m (18 kgf*cm, 16 in.*lbf)
- (c) Pull out the pin (φ1.0 mm (0.039 in.)) from the generator brush hold.




5. INSTALL TERMINAL INSULATOR

- (a) Install the terminal insulator to the generator rectifier end frame.
NOTICE:
Pay attention the mounting orientation of the terminal insulator.

6. INSTALL REAR GENERATOR END COVER

- (a) Install the rear end cover with the 3 nuts.
Torque: 4.6 N*m (47 kgf*cm, 41 in.*lbf)




7. INSTALL GENERATOR PULLEY


SST 09820-63010 (09820-06010, 09820-06020)
HINT:

| | |
|---------------|-------------|
| SST 1-A and B | 09820-06010 |
| SST 2 | 09820-06020 |


- (a) Install the pulley onto the rotor shaft by tightening the pulley nut by hand.
- (b) Hold SST 1-A with a torque wrench, and tighten SST 1-B clockwise to the specified torque.
Torque: 39 N*m (400 kgf*cm, 29 ft.*lbf)

NOTICE:**Check that SST is secured to the rotor shaft.**

- (c) Mount SST 2 in a vise.
- (d) Insert SST 1-A and B into SST 2, and attach the pulley nut to SST 2.



- (e) Tighten the pulley nut by turning SST 1-A in the direction shown in the illustration.
Torque: 111 N*m (1,125 kgf*cm, 81 ft.*lbf)
- (f) Remove the generator from SST 2.



- (g) Turn SST 1-B, and remove SST 1-A and B.
- (h) Turn the pulley and check that the pulley moves smoothly.