


## INSPECTION


### NOTICE:

- **A/T:**  
Switch the 4 wheel drive control switch when the A/T shift lever is in the N position and the vehicle speed is 5 km/h or less.
- **M/T:**  
Switch the 4 wheel drive control switch when the clutch start switch is turned ON and the vehicle speed is 3 km/h or less.
- Do not change from H2 to H4 when the vehicle speed is 100 km/h or more.




### 1. INSPECT H2 (2WD) - H4 (4WD) SHIFT

- (a) Start the engine.
- (b) Turn the 4 wheel drive control switch from the H2 to the H4 position.
- (c) Check that the 4WD indicator light blinks and then stays on.
- (d) Turn the 4 wheel drive control switch from the H4 to the H2 position
- (e) Check that the 4WD indicator light blinks and then goes off.




### 2. INSPECT H4 (4WD) - L4 (4WD) SHIFT

- (a) Start the engine.
- (b) Turn the 4 wheel drive control switch from the H4 to the L4 position while pressing it.
- (c) Check that the 4LO indicator light blinks and then stays on.
- (d) Turn the 4 wheel drive control switch from the L4 to the H4 position while pressing it.
- (e) Check that the 4LO indicator light blinks and then goes off.



### 3. INSPECT H2 (2WD) - L4 (4WD) SHIFT

- (a) Start the engine.
- (b) Turn the 4 wheel drive control switch from the H2 to the H4 position.
- (c) Check that the 4WD indicator light blinks and then stays on.
- (d) Turn the 4 wheel drive control switch from the H4 to the L4 position while pressing it.
- (e) Check that the 4LO indicator light blinks and then stays on.




#### 4. INSPECT L4 (4WD) - H2 (2WD) SHIFT

- Start the engine.
- Turn the 4 wheel drive control switch from the L4 to the H4 position while pressing it.
- Check that the 4LO indicator light blinks and then goes off.
- Turn the 4 wheel drive control switch from the H4 to the H2 position.
- Check that the 4WD indicator light blinks and then goes off.


#### 5. INSPECT 4 WHEEL DRIVE CONTROL SWITCH

- Remove the center instrument cluster finish panel sub-assembly.
- Remove the 4 wheel drive control switch from the center instrument cluster finish panel sub-assembly.
- Using an ohmmeter, measure the resistance between the terminals.



Switch position	Tester connection	Specified condition
H2	5 (2-4) - 4 (GND)	Below 1Ω
H4	5 (2-4) → 4 (GND)	Below 1Ω
	5 (2-4) ← 4 (GND)	100 kΩ or higher
	2 (LO) → 4 (GND)	Below 1Ω
	2 (LO) ← 4 (GND)	100 kΩ or higher
L4	2 (LO) - 4 (GND)	Below 1Ω

If the results are not as specified, replace the 4 wheel drive control switch or bulb.



#### 6. INSPECT ACTUATOR RESISTANCE


- Using an ohmmeter, measure the resistance between terminals 1 and 2.  
**Standard resistance:**  
**0.3 to 100 Ω**
- Using an ohmmeter, measure the resistance between terminals 1 or 2 and the body ground.  
**Standard resistance:**  
**More than 0.5 MΩ**

If the results are not as specified, replace the shift actuator assembly.

**7. INSPECT ACTUATOR OPERATION**


(a) H2 (2WD) → H4 shift:


Connect the lines via the relay as shown in the illustration, then check that the actuator fork shaft moves from the H2 (2WD) to the H4 positions.




(b) H4 → H2 (2WD) shift:

Connect the lines via the relay as shown in the illustration, then check that the actuator fork shaft moves from the H4 to the H2 (2WD) positions.






- (c) H4 → L4 shift:  
Connect the lines via the relay as shown in the illustration, then check that the actuator fork shaft moves from the H4 to the L4 positions.




- (d) L4 →H4 shift:  
Connect the lines via the relay as shown in the illustration, then check that the actuator fork shaft moves from the L4 to the H4 positions.



**HINT:**  
When inspecting the operation described above, use a heater main relay.

**NOTICE:**  
Connect the terminals, being careful not to touch the neighboring terminals or metallic parts of the relay housing.

Actuator Side:



N

F007509E01

**8. INSPECT LIMIT SWITCH CONTINUITY**

- (a) Start the engine and lift the vehicle up.
- (b) With the actuator connector connected, after checking the operating sound, disconnect the connector and inspect the continuity between the terminals using an ohmmeter.


HINT:

When shifting the actuator fork shaft, connect the connectors.

Shift position	Tester connection	Specified condition
H2	3 - 4	100 kΩ or higher
	3 - 5	100 kΩ or higher
	3 - 6	100 kΩ or higher
	4 - 5	Below 1Ω
	4 - 6	100 kΩ or higher
	5 - 6	100 kΩ or higher
H4	3 - 4	100 kΩ or higher
	3 - 5	100 kΩ or higher
	3 - 6	100 kΩ or higher
	4 - 5	100 kΩ or higher
	4 - 6	Below 1Ω
	5 - 6	100 kΩ or higher
L4	3 - 4	Below 1Ω
	3 - 5	100 kΩ or higher
	3 - 6	100 kΩ or higher
	4 - 5	100 kΩ or higher
	4 - 6	100 kΩ or higher
	5 - 6	100 kΩ or higher

**9. INSPECT 4 WHEEL DRIVE CONTROL ECU**

- (a) Connect the wire harness side connector to the 4 wheel drive control ECU and inspect the wire harness side connector from the back side, as shown.



P

F044032

**STANDARD VALUE OF ECU TERMINAL**

Terminals (Symbols)	Condition	STD Voltage (V)
2 (TM1) - 1 (TM2)	<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• Differential lock switch in OFF position</li> <li>• 4 wheel drive control switch H2 position → H4 position</li> </ul>	10 to 14 or 0 to 14 pulse generation then less than 0.5
1 (TM2) - 2 (TM1)	<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• Keep pressing the differential lock switch for approx. 2 seconds to turn it ON</li> <li>• 4 wheel drive control switch L4 position → H4 position</li> </ul>	10 to 14 or 0 to 14 pulse generation then less than 0.5
3 (DM1) - 4 (DM2)	<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• A.D.D. FREE → LOCK</li> </ul>	10 to 14 or 0 to 14 pulse generation then less than 0.5
4 (DM2) - 3 (DM1)	<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• A.D.D. LOCK → FREE</li> </ul>	10 to 14 or 0 to 14 pulse generation then less than 0.5

TF

12 (GND) - Body ground	Ignition switch OFF	Below 1 $\Omega$
11 (IG) - 12 (GND)	Ignition switch ON	10 to 14
18 (DL2) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>A.D.D. LOCK → FREE</li> </ul>	1.5 or less → 10 to 14
19 (DL1) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>A.D.D. FREE → LOCK</li> </ul>	1.5 or less → 10 to 14
25 (2-4) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>4 wheel drive control switch L4 position → H2 position or H4 position</li> </ul>	10 to 14 → 2 or less
26 (SPD) - 12 (GND)	During driving	Pulse generation
28 (IND3) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>4 wheel drive control switch H4 position → L4 position</li> </ul>	10 to 14 → 1.5 to 3.5
32 (LO) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>4 wheel drive control switch H4 position → L4 position</li> </ul>	10 to 14 → 1.5 or less
42 (ADD) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>A.D.D. FREE → LOCK</li> </ul>	10 to 14 → 1.5 or less
23 (L4) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>4 wheel drive control switch H2 position or H4 position → L4 position</li> </ul>	10 to 14 → 1.5 or less
38 (4WD) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>4 wheel drive control switch H2 position → H4 position</li> </ul>	10 to 14 → 1.5 or less
39 (TL3) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>4 wheel drive control switch H2 position → L4 position</li> </ul>	10 to 14 → 0.88 or less
40 (TL2) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>4 wheel drive control switch H2 position → H4 position</li> </ul>	10 to 14 → 0.88 or less
41 (TL1) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>4 wheel drive control switch H2 position → H4 position or L4 position</li> </ul>	0.88 or less → 10 to 14
45 (IND1) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>4 wheel drive control switch H2 position → H4 position or L4 position</li> </ul>	10 to 14 → 0 to 3.5
48 (N) - 12 (GND)	<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Transmission shift lever other position → N position</li> </ul>	1.5 or less → 10 to 14