


ECU Power Source Circuit

DESCRIPTION

This circuit provides power to operate the transponder key ECU assembly.

WIRING DIAGRAM



1 INSPECT FUSES (ECU-B AND IGN)

- (a) Remove the ECU-B fuse from the engine room R/B and J/B.
- (b) Remove the IGN fuse from the driver side J/B.
- (c) Measure the resistance of the fuse.

Standard resistance:

Below 1Ω


- (d) Reinstall fuses.

NG

REPLACE FUSE

OK

2 INSPECT IGNITION SWITCH ASSEMBLY



- (a) Remove the ignition switch.
- (b) Measure the resistance of the switch.


Standard resistance

Tester Connection	Switch Condition	Specified Condition
5 (AM2) - 6 (IG2)	LOCK, ACC	10 kΩ or higher
	ON, START	Below 1 Ω

NG → **REPLACE IGNITION SWITCH ASSEMBLY**

OK

3 CHECK HARNESS AND CONNECTOR (TRANSPONDER KEY ECU ASSEMBLY - BATTERY AND BODY GROUND)



- (a) Disconnect the T10 ECU connector.
- (b) Measure the resistance and voltage of the wire harness side connector.

Standard resistance

Tester Connection	Condition	Specified Condition
T10-16 (GND) - Body ground	Always	Below 1 Ω

Standard voltage

Tester Connection	Condition	Specified Condition
T10-1 (+B) - Body ground	Always	10 to 14 V
T10-2 (IG) - Body ground	Ignition switch OFF	Below 1 V
	Ignition switch ON	10 to 14 V

- (c) Reconnect the ECU connector.

NG → **REPAIR OR REPLACE WIRE HARNESS AND CONNECTOR**

OK

REPLACE TRANSPONDER KEY ECU ASSEMBLY