


Connector Front Side:



T

E076078E01

MAP LIGHT ASSEMBLY

INSPECTION

1. INSPECT MAP LIGHT ASSEMBLY

(a) Check the resistance.

- (1) Measure the resistance using an ohmmeter, and check the results in accordance with the value(s) in the table below.

Standard

Tester Connection	Condition	Specified Condition
1-2	OFF	10 k Ω or higher
1-2	ON	Below 1 Ω

If the result is not as specified, replace the map light assembly.

(b) Check the light operation.

- (1) Connect the battery positive (+) lead to terminal 1 and the battery positive (-) lead to terminal 2, then check that the light comes on.

Standard:

Light comes on.

If the light does not come on, replace the bulb.