

CX75SR, CX80 AND CX135SR EXCAVATORS

OPERATOR'S MANUAL

Part Number: 6-34551NA

CASE TECHNICAL MANUALS

Manuals are available from your Dealer for the operation, service, and repair of your machine. For prompt convenient service, contact your Dealer for assistance in obtaining the manuals for your machine.

Your Dealer can expedite your order for Operator's Manuals, Parts Catalogs, Service Manuals, and Maintenance records.

Always give the Machine Name, Model, and P.I.N. (Product Identification Number) or S.N. (Serial Number) of your machine so your Dealer can provide the correct manuals for your machine.

NOTE: *CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.*






THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF DEATH OR SERIOUS INJURY

M171D

Safety Decals on this machine use the words **Danger, Warning, or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation that, if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW
- Prohibition symbols such as   and  if used, are RED.



WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE DEATH OR SERIOUS INJURY. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow CNH America LLC instructions on machine operation and maintenance.

WARNING_01_NA

CALIFORNIA

PROPOSITION 65 WARNING

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery post, terminals and related accessories contain lead and lead compounds.
Wash hands after handling.

TABLE OF CONTENTS

CHAPTER 1

GENERAL INFORMATION

To The Owner	1-1
Machine Components	1-3
Identification Numbers	1-5

CHAPTER 2

SAFETY, DECALS, AND HAND SIGNALS

Table of Contents	2-1
Safety Rules	2-3
Personal Safety	2-3
Safety Area	2-3
Utility Safety	2-3
Operator Precautions	2-4
Decals	2-9
Hand Signals	2-14

CHAPTER 3

INSTRUMENTS AND CONTROLS

Table of Contents	3-1
Cab Door	3-3
Steps and Access Handles	3-4
Position of the Operator's Compartment Controls and Accessories	3-5
Right-hand Control Arm	3-6
Instrument Panel	3-7
Left-hand Control Arm for CX75SR, CX80	3-9
Left-hand Control Arm for CX135SR	3-10
Working Light Switch	3-11
Windshield Washer Switch	3-11
Windshield Wiper Switch	3-11
High Speed Travel Switch	3-11
Heating, ventilation and air-conditioning control	3-12
Function cancellation Lever	3-13
Arm and upperstructure Swing Left-hand Control Lever	3-13
Boom and Bucket Right-hand Control Lever	3-13
Travel Control	3-14
Offset Boom Control Pedal (If Equipped)	3-15
Option Pedal	3-15
Unlocking and Locking of Pedals	3-15
Dozer Blade Control Lever (If Equipped)	3-16
Cab Light	3-16
Coat Hanger Hook	3-16
Rear Right-hand Side Window	3-16
Glove Compartment	3-16
Storage Tray	3-17
Ashtray	3-17
Cab Radio Compartment	3-17
Speaker Compartments	3-17
Fuse Box	3-17
Operator's Seat	3-18
Windshield	3-21
Lower Front Window	3-22
Window-Breaker Hammer	3-22
Air Vents	3-22
Rear View Mirrors - CX75SR, CX80	3-23

Rear View Mirrors CX135SR	3-23
Fuel Tank	3-24
Upper Hood - CX75SR, CX80	3-24
Engine Hood	3-25
Side Doors	3-26
Rotating Beacon Cable	3-27
Towing Point	3-27
Load Handling Eyes	3-28
Windshield Washer Reservoir	3-28
Tool Supply Valves (Optional)	3-29
Tool Flow Selector Valve (Optional)	3-29

CHAPTER 4

OPERATING INSTRUCTIONS

Table of Contents	4-1
Before Operating the Machine	4-3
Operating the Machine	4-3
Run-in Period	4-4
Starting the engine	4-4
Bringing the Machine up to Operating Temperature	4-5
Engine Operation	4-6
Stopping the Engine	4-6
Operating the Machine in Cold Weather	4-7
Operating the Machine in Hot Weather	4-8
Operation	4-8
Machine Travel	4-8
Transport Position for 2.85 m arm CX135SR	4-10
Transporting the Machine	4-11
Handling the Machine	4-14
Operating the Machine In Water	4-14
Parking the Machine	4-14
Operating the Machine on Sloping Ground	4-15
Towing the Machine	4-15
Operating the Bucket	4-16
Lowering the attachment in the event of a machine failure	4-16
Machine storage	4-20

CHAPTER 5

LUBRICATION, FILTERS, AND FLUIDS

Table of Contents	5-1
Servicing Instructions	5-3
Daily Inspections	5-3
hourmeter	5-4
Lubrication and Maintenance Chart For CX75SR, CX80	5-5
Lubrication and Maintenance Chart For CX135SR	5-7
Fluids and Lubricants	5-9
Fluid and Lubricant Capacities and Specifications	5-12
Lubrication Points	5-13
Fluid Levels	5-18
Engines - CX75SR, CX80	5-20
Engine - CX135SR	5-22
Cooling System - CX75SR, CX80	5-24
Cooling System - CX135SR	5-26
Fuel System	5-28
Releasing Pressure in the Hydraulic System	5-32
Hydraulic System	5-34
Air Filter	5-44

Swing Reduction Gear - CX135SR	5-47
Travel Reduction Gears - CX75SR, CX80	5-49
Travel Reduction Gears - CX135SR	5-50

CHAPTER 6

MAINTENANCE AND ADJUSTMENTS

Table of Contents	6-1
Tracks	6-3
Checking the Condition of Rubber Tracks (If Equipped)	6-6
Replacing the Rubber Tracks (CX75SR, If Equipped)	6-6
Track Rollers and Idler Wheels	6-8
Radiator and Oil Cooler	6-9
Fan and Alternator Drive Belt	6-10
Fuel Tank Filter	6-12
Inspecting and Cleaning the Machine	6-12
Checking for Cylinder Leakage	6-12
Replacing a Bucket - CX75SR, CX80	6-13
Replacing a Bucket - CX135SR	6-14
Fire Extinguisher (Not Supplied)	6-15
Welding on the Machine	6-15
Plastic and Resin Parts	6-15
Air conditioning	6-16
Hardware torque inspection	6-18

CHAPTER 7

ELECTRICAL

Table of Contents	7-1
Fuses	7-3
Battery	7-5
Connecting One Or Two Booster Batteries	7-8
Alternator	7-8
Starter Motor	7-8
Replacing a Bulb	7-9
Adjusting The Working Lights	7-10

CHAPTER 8

SPECIFICATIONS


Table of Contents	8-1
Engines	8-3
Electrical Systems	8-3
Hydraulic System - CX75SR, CX80	8-4
Hydraulic System - CX135SR	8-4
Undercarriage - CX75SR, CX80	8-5
Undercarriage - CX135SR	8-5
Capacity of Systems and Components	8-6
Weights	8-6
Ground Pressure	8-6
Booms	8-6
Arms	8-7
Esco Buckets	8-8
Machine Overall Dimensions - CX75SR	8-9
Machine Overall Dimensions - CX80	8-10
Machine Overall Dimensions - CX135SR	8-11
Working Range - CX75SR	8-12
Working Range - CX80	8-15
Working Range - CX135SR	8-16

CHAPTER 9
INDEX

Chapter 1

GENERAL INFORMATION

TO THE OWNER



CT02C001FX

Figure 1

HYDRAULIC CRAWLER EXCAVATORS SERIES CX75SR, CX80 AND CX135SR

Your machine has been designed and built to the highest standards of quality. It conforms to all current safety regulations. See Official documents. However, the risk of accidents can never be completely excluded. That is why it is essential to observe elementary safety rules and precautions.

Read this manual carefully, paying particular attention to the instructions concerning safety, operation and maintenance so as to avoid the risk of injury while operating or servicing the machine.

The standard attachments and tools of this machine are designed to carry out all kinds of earth moving and rehandling operations. If you want to use this machine to handle a load (pipes, culverts, framework, etc.), make sure that it is designed to carry out this kind of work. For this type of application, the machine must be equipped with safety valves, an overload indicator, a load handling chart corresponding to the type of machine and its attachment and a load fixing point. All legal requirements must also be strictly observed.

Do not use this machine for any application or purpose other than those described in this manual. If the machine is to be used for work involving the use of special attachments, accessories or equipment, consult your Dealer in order to make sure that any adaptations or modifications made are in keeping with the machine's technical specifications and with prevailing safety requirements.

Any modification or adaptation which is not approved by the manufacturer may invalidate the machine's initial conformity with safety requirements.

The machine must undergo regular inspections, the frequency of which varies according to the type of use. Consult your Dealer.


Before permitting a new operator on this machine, make sure:

1. That the operator has received the necessary training on how to operate the machine correctly and safely in one of our training centres or from an approved organization.
2. That the operator has read and understood the instructions given in this manual.

Always keep this manual in the operator's compartment (in the seat back, behind the operator's seat). Make sure it is always complete and in good condition. If you wish to obtain extra copies, or copies in languages other than that of the country of use, consult your Dealer.

Your Dealer is at your disposal for any further information. He will also provide any after-sales service you may require, and genuine CASE spare parts, your guarantee of quality and match.

MACHINE COMPONENTS



CT02C001

Figure 2

- | | | |
|-------------------------------|-----------------------------|---|
| 1. CAB/OPERATOR'S COMPARTMENT | 9. ARM CYLINDER | 17. IDLER WHEELS |
| 2. UPPERSTRUCTURE | 10. BACKHOE BUCKET | 18. TRACKS |
| 3. UNDERCARRIAGE | 11. BACKHOE BUCKET CYLINDER | 19. HYDRAULIC RESERVOIR |
| 4. STEPS | 12. ENGINE COMPARTMENT | 20. FUEL TANK |
| 5. ACCESS HANDLES | 13. COUNTERWEIGHT | 21. DOZER BLADE (IF EQUIPPED) |
| 6. BOOM | 14. UPPER ROLLERS | 22. DOZER BLADE CYLINDERS (IF EQUIPPED) |
| 7. BOOM CYLINDERS | 15. LOWER ROLLERS | |
| 8. ARM | 16. TRAVEL REDUCTION GEARS | |


MAIN COMPONENTS

The CX75SR, CX80 and CX135SR are fully hydraulic machines. They consist of an undercarriage fitted with tracks and a turntable bearing which supports the upperstructure frame. The upperstructure frame supports the attachment, at the front end of the machine, plus the engine, hydraulics and cab. When the operator works the controls, the engine-driven pump delivers hydraulic fluid to the control valves. The control valves distribute the hydraulic fluid to the various cylinders and motors concerned. A cooling system maintains the hydraulic fluid at normal operating temperature.

RIGHT, LEFT, FRONT AND REAR OF THE MACHINE

The terms Right-hand, Left-left, Front, and Rear are used in this manual to indicate the sides as they are seen from the operator's seat when the cab is over the idler wheels.

The illustration below shows the machine in normal TRAVEL position. In normal TRAVEL position, the cab is over the idler wheels. The travel reduction gears are at the rear of the upperstructure.



CT02D269

Figure 3

- 1. FRONT
- 2. REAR
- 3. RIGHT-HAND SIDE
- 4. LEFT-HAND SIDE
- 5. TRAVEL REDUCTION GEARS
- 6. IDLER WHEELS

IDENTIFICATION NUMBERS

TYPE, SERIAL NUMBER AND YEAR OF MANUFACTURE

When ordering parts, obtaining information or assistance, always supply your Dealer with the type and serial number of your machine or accessories.

Write the following in the spaces below: The type, serial number and year of manufacture of your machine, accessories and the serial numbers of the various hydraulic and mechanical components.

Machine





Figure 4

CX75SR, CX80 Engine




CT02C062

Figure 5

CX75SR, CX80 Engine	
➤	_____
	Make and Model
➤	_____
	Serial Number

CX135SR Engine



CT02C050

Figure 6

CX135SR Engine	
➤	_____
	Make and Model
➤	_____
	Serial Number

COMPONENT SERIAL NUMBERS

- Hydraulic pump.....
- Swing reduction gear.....
- Travel reduction gears
- Travel control valve
- Attachment control valve
- Swing control valve.....

NOTES

Chapter 2


SAFETY, DECALS, AND HAND SIGNALS

TABLE OF CONTENTS

SAFETY RULES	2-3
PERSONAL SAFETY	2-3
SAFETY AREA	2-3
UTILITY SAFETY	2-3
OPERATOR PRECAUTIONS	2-4
Personnel	2-4
General	2-4
Mounting and Dismounting Precautions	2-4
Starting and Stopping Precautions	2-5
Operating Precautions	2-5
Maintenance Precautions	2-6
Fuel Handling Precautions	2-7
Burn Prevention	2-7
Hazardous Chemical Precautions	2-7
Transporting Precautions	2-8
Wheel, Tire, and Track Safety	2-8
Roll-Over Protective Structure	2-8
Fire Extinguisher	2-8
Seat Belt Precautions	2-8
Specific Precautions to this Machine	2-8
DECALS	2-9
HAND SIGNALS	2-14

NOTES

SAFETY RULES



WARNING: *This safety alert symbol indicates important safety messages in this manual. When you see this symbol, carefully read the message that follows and be alert to the possibility of death or serious injury.*

M171C

Most accidents involving machine operating and maintenance can be avoided by following basic safety rules and precautions. Read and understand all the safety messages in this manual, the safety manual and the safety signs on the machine before you operate or service the machine. See your dealer if you have any questions.



RD98K305

Figure 1

1. OPERATOR'S MANUAL STORAGE BOX

READ THIS MANUAL COMPLETELY and make sure you understand the controls. All equipment has a limit. Make sure you understand the speed, brakes, steering, stability and load characteristics of this machine before you start to operate.

DO NOT remove this manual or the safety manual from the machine. See your dealer for additional manuals. Also see the manual information on the inside of the rear cover of this manual.

The safety information given in this manual does not replace safety codes, insurance needs, federal, state or local laws. Make sure that your machine has the correct equipment according to these rules or laws.




Additional safety messages are used in the text of the manual to show specific safety hazards.

IMPORTANT: *The safety messages in this chapter point out situations which can happen during the normal operation and maintenance of your machine. These safety messages also give possible ways of dealing with these conditions.*


PERSONAL SAFETY

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW

Prohibition symbols such as   and  if used, are RED.

SAFETY AREA



CS97M019

Figure 2

1. WORKING AREA
2. SAFETY AREA

The safety area is the space necessary for the machine to operate at the maximum range of the tool and a full 360° swing plus 6 feet (2 metres).

UTILITY SAFETY

Safety precaution **MUST** be followed when working near buried and over head Utility Lines.

During operation it is likely that you will be working around or near buried or over head utility lines which may include, but are not limited to:


- Electrical Power Line
- Gas Line
- Water Line
- Communication Line - Telephone or Cable Television

Before beginning any machine operation, it is your responsibility to be aware of all such utility lines buried and over head in the area of your project and to avoid them.

ALWAYS have all local utility companies mark the location of their lines.

In U.S.A. and Canada call one of many “One Call System Director” services. If you do not know the local number, call the national number (U.S.A. and Canada only): 1-888-258-0808.

Check with local authorities for laws, regulations and/or strict penalties requiring you to locate and avoid existing utilities.



RH99G001

Figure 3

CALL ALL LOCAL UTILITY COMPANIES BEFORE YOU PERFORM ANY MACHINE OPERATION

Know the utility color code (U.S.A. and Canada):

- Electric Red
- Gas, Oil, or Petroleum Yellow
- Communication, Telephone, Television Orange
- Water Blue
- Sewer Green/Brown
- Proposed Excavation White
- Surveying Pink
- Reclaimed Water and Slurry. Purple

After locating any buried utility lines, carefully dig a hole by hand and/or automatic vacuum equipment to the utility line to verify the location and depth of the line.

OPERATOR PRECAUTIONS

PERSONNEL

- Be prepared for emergencies. Always have a first aid kit and a working fire extinguisher with you and know how to use each.
- Avoid loose fitting clothing, loose or uncovered long hair, jewelry and loose personal articles.

- Know and use the protective equipment that is to be worn when operating this machine. Hard hats, protective glasses, protective shoes, gloves, reflector type vests, respirators and ear protection are examples of typed of equipment that may be required.
- Certain protective equipment should be replaced and renewed upon age and wear. Old hard hats may not afford the original users intention. Faded and soiled vest are no longer as highly visible as original intent. See the manufacture's recommendation.
- Do not rush. Walk, do not run.
- Know and use the hand signals required for particular jobs and know who has the responsibility for signaling.

GENERAL

- It is the responsibility of the operator to read and understand the Operator's Manual and other information provided and use the correct operating procedure. Machines should be operated only by qualified operators.
- Do not operate this machine or perform maintenance work if you have not had appropriate training and read and fully understand the instructions and warnings in this manual.
- Wear the seat belt to maximize the protection capability of a ROPS (Roll Over Protective Structure) when the machine is so equipped.
- Inspect the ROPS and seat belt mounting bolts on a daily basis to ensure their integrity.
- Do not permit riders on the machine if there is no manufacturer's designated place for a rider.
- Make sure that all protective guards, canopies, doors, etc. are in place and secure.
- Remove all loose object stored in the machine. Remove all objects which do not belong in or on the machine and its equipment.

MOUNTING AND DISMOUNTING PRECAUTIONS

- Use the recommended hand holds and steps with at least three points of support when getting on and off the machine. Keep steps and platform clean. Face the access system when climbing up and down
- Do not jump off the machine.
- Do not dismount while the machine is in motion.
- Foreign material or grease on the steps and hand rails can cause an accident. Keep the steps and hand rails clean.

STARTING AND STOPPING PRECAUTIONS

- Walk around the machine and warn all personnel who may be servicing the machine or are in the machine path prior to starting. Do not start until all personnel are clearly away from the machine. Sound the horn, if equipped, before starting.
- Walk around the machines tool, attachment, or furthestmost contact point to view operation danger area from the work site personnel view and angle.
- Check that the parking device is applied, place the transmission in neutral or park as specified by the manufacturer, and disengage the PTO, if so equipped, before starting the machine.
- Adjust, secure and latch the seat and fasten the seat belt before starting the machine.
- Start and operate the machine only from the operator's station.
- Do not bypass the machine's neutral-start system. The neutral-start system must be repaired if it malfunctions.
- Use jumper cables only in the recommended manner. Improper use can result in battery explosion or unexpected machine motion. Ventilate the battery area before using jumper cables. Make sure that using jumper cables will not interfere or harm electronic processing or computer devices.
- Do not operate the engine in an enclosed area without adequate ventilation.
- Park the machine on level ground whenever possible and apply the parking brake. On grades, park the machine with the wheels or track securely blocked.
- Before leaving the operator's station, place the transmission in the park position as specified by the manufacturer, lower the equipment to the ground or put in the locked position, disengage the PTO, if so equipped, set the parking device and shut off the engine.
- Remove the starter key or disconnect switch when leaving the machine parked or unattended.

OPERATING PRECAUTIONS


- Check brakes, steering and other machine control devices in accordance with the manufacturers instructions prior to starting operation. Observe all gauges or warning instruments for proper operation. Operate all controls to insure proper operation. If any malfunctions are found, remove the starter key or disconnect switch key. Place a do not operate tag on the machine until the malfunction is corrected.

- If a failure that causes loss of control such as steering, service brakes or engine occurs, stop the machine motion as quickly as possible, remove the starter key or disconnect switch key. Place a do not operate tag on the machine and keep it securely parked until the malfunction is corrected or the machine can be safely towed.
- Understand the machine limitations and keep the machine under control.
- Operate and drive the machine with care and at speed compatible with conditions. Use extra caution when operating over rough ground, on slopes, and when turning.
- Note and avoid all hazards and obstructions such as ditches, underground lines, trees, cliffs, overhead electrical wires or areas where there is danger of a slide.
- Carry loads in recommended positions for maximum stability.
- Never lift loads in excess of capacity.
- Use the recommended machine ballast and counterweighting.
- Know and understand the job site traffic flow patterns and obey signalmen, road signs and flagmen.
- Know and understand that job site conditions may change on an hourly basis. Hills of dirt, debris or obstructions may grow and change from the time you began the day. It is your responsibility to monitor the changes and keep the machine, tools and attachments, etc. a safe distance.
- Watch for bystanders and never allow anyone to be under or to reach through the machine and its equipment while operating.
- Select a gear that will prevent excessive speed when going downhill. Do not coast downhill.
- When roading a machine, know and use the signaling devices required on the machine. Provide and escort for roading where required.
- On machines with independently operated wheel brakes, lock the brake pedals together when roading to provide equalized brake application.
- Use the recommended transport devices when roading the machine.
- Use the approved drawbar and / or attachment point when using the machine for towing. If a cable or chain is used, keep people away from the tow line.
- Before you operate at night, check that all lamps illuminate.

- Engine exhaust fumes can cause death. If you operate this machine in an enclosed area, make sure there is ventilation to replace the exhaust fumes with fresh air.
- If your machine has a cab make sure that all windows are clean and that the windshield wipers work correctly.
- Check all controls in a clear area and make sure the machine is operating correctly.
- Dust, fog, smoke, etc., can decrease your vision and cause an accident. Stop the machine or decrease the speed until you can see.
- Contact with high voltage power lines, underground cables, etc., can cause serious injury or death from electrocution.
- Before you drive or operate in an area with high voltage lines, cables, or a power station, tell the power or utility company what you are going to do. You **MUST HAVE THE POWER DISCONNECTED OR KEEP A SAFE WORKING DISTANCE** from the lines, cables, or power station. Keep all parts of the machine at least 4.6 m (15 feet) away from the power source. You must also know any federal, state/provincial, or local safety codes or regulations that apply to the job site.
- If a part of the machine touches high voltage power:
 1. Warn other workers **NOT TO TOUCH THE MACHINE** and to stay away from the machine.
 2. If you can break contact, reverse the operation that caused contact with the high voltage power, and move the machine away from the danger area. If you cannot break contact stay in the machine until the utility company de-energizes the line and tells you that the power is off.
- If you have extreme conditions, such as a fire, etc., and you are forced to leave the machine, do not step off the machine. Jump as far from the machine as possible with your feet together and do not touch the ground with your hands.
- Do not operate the machine if you do not feel well. This can be dangerous for you and for the people around you.
- You must make a judgment if weather, road, or earth conditions will permit safe operation on a hill, ramp, or rough ground.
- Stay away from hazardous areas such as ditches, overhangs, etc. Walk around the work area before you start and look for hazards.
- Be alert and always know the location of all workers in your area. Keep all other persons completely away from your machine. Injury or death can result if you do not follow these instructions.

MAINTENANCE PRECAUTIONS

- Do not attempt repairs unless trained. Refer to manuals and experienced repair personnel for help.
- Before you service the machine, put a Do Not Operate tag on the key switch. The Do Not Operate tag is included with your new machine. Addition tags, part number 321-4614 are available from your Dealer.



321-4614

Figure 4

- Wear protective glasses and other required safety equipment when servicing or repairing the machine.
- Wear gloves to protect hands when handling cable.
- Disconnect the battery before working on the electrical system. Know the consequences of disconnecting any electronic or computer devices.
- Avoid lubrication or mechanical adjustments with the machine in motion or the engine operating. If the engine must be in operation to make certain adjustments, place the transmission in neutral, apply the parking device, place the equipment in a safe position, securely block the wheels and use extreme caution.
- Securely block the machine or any component that may fall before working on the machine or component. If possible, use a back up or secondary blocking device, also.
- To prevent unexpected movement, securely block working elements when repairing or changing working tool parts such as cutting edges.
- Never make repairs on pressurized components, fluid, gas or mechanical until the pressure has been relieved according to the manufacturer's instructions.
- Use extreme caution when removing radiator caps, drain plugs, grease fittings or pressure taps. Park the machine and let it cool down before opening a pressurized tank.

- Release all pressure before working on systems which have an accumulator. Use a piece of cardboard, newspaper, or wood to check for pressurized leaks to prevent fluid penetrating the skin. Pressurize accumulators with the proper gas according to manufacturers' recommendations.
- When inflating tires, use a self-attaching inflation chuck with remote shutoff and stand clear of the tire. Position yourself beside the tire and not beside the rim.
- When absolutely necessary to tow the machine, do not exceed the recommended towing speed. Be sure the towing machine has sufficient braking capacity to stop the towed load. If the towed machine cannot be braked, a towbar must be used or two towing machines must be used. - one in front pulling and one in the rear to act as a brake. Avoid towing over long distances.
- Observe proper maintenance procedures.
- Whenever servicing or replacing hardened pins, etc., use a brass drift or other suitable material between the hammer and pin. Alt: Use a brass hammer, drift or suitable material on the pin, etc.
- Keep the brakes and steering systems in good operating condition.
- Replace all missing, illegible or damaged safety signs. Keep all safety signs clean.

FUEL HANDLING PRECAUTIONS

- Do not smoke or permit open flames while fueling or near fueling operations.
- Never remove the fuel cap or refuel gasoline engine powered machines with the engine running or hot. Never allow fuel to spill on hot machine components. Never allow fuel to spill on the environment.
- To avoid spilling fuel maintain control of the fuel filler nozzle when filling the tank.
- Do not fill the fuel tank completely to the top. Allow room for expansion.
- Clean up spilled fuel immediately and dispose of contaminated material in an environmentally correct manner.
- Tighten the fuel tank cap securely. Should the fuel cap be lost, replace it only with the original manufacturer's approved cap. Use of a non-approved cap without proper venting may result in pressurization of the tank.
- Never use fuel for cleaning purposes.
- Use the correct fuel grade for the operating season.

BURN PREVENTION

WARNING: BATTERY ACID CAUSES SEVERE BURNS. Batteries contain sulfuric acid. Avoid contact with skin, eyes or clothing.

Antidote: EXTERNAL - Flush with water.

Antidote: INTERNAL - Drink large quantities of water or milk.

DO NOT induce vomiting. Seek medical attention immediately.



EYES - Flush with water for 15 minutes and seek medical attention immediately.

WARNING: BATTERIES PRODUCE EXPLOSIVE GASES. Keep sparks, flame, cigars and cigarettes away. Ventilate when charging or using in enclosed area. Always wear eye protection when working near batteries. Wash hands after handling. **KEEP OUT OF REACH OF CHILDREN.**

M144B

- When the battery electrolyte is frozen, the battery can explode if, you try to charge the battery, or you try to jump start and run the engine. To prevent the battery electrolyte from freezing, try to keep the battery at full charge. If you do not follow these instructions, you or others in the area can be injured
- Hot coolant can spray out if the radiator cap is removed. To remove the radiator cap, let the cooling system cool, turn to the first notch, wait until the pressure is released, then remove the radiator cap.

HAZARDOUS CHEMICAL PRECAUTIONS

- If you are exposed to or come in contact with hazardous chemicals you can be seriously injured. The fluids, lubricants, paints, adhesives, coolants, etc., used with your machine can be hazardous.
- Material Safety Data Sheets (MSDS) provide information about the chemical substances within a product, safe handling procedures, first aid measures and procedures to be taken when the product is accidentally spilled or released. MSDS are available from your dealer.
- Before you service your machine, check the MSDS for each fluid, lubricant, etc., used in this machine. This information indicates what the risks are and how to service the machine safely. Follow this information when servicing the machine.
- Before you service this machine and before you dispose of the old fluids and lubricants, always remember the environment. **DO NOT** put oil or fluids into the ground or into containers that can leak.

- Check with your local environmental or recycling center or your dealer for correct disposal information.

TRANSPORTING PRECAUTIONS

- Know the rules, laws, and safety equipment necessary for transporting this machine on a road or highway.

WHEEL, TIRE, AND TRACK SAFETY

- Explosive separation of the tire and/or rim parts can cause injury or death. When tire service is necessary, have a qualified tire mechanic service the tire.


ROLL-OVER PROTECTIVE STRUCTURE

- Do NOT modify the ROPS in any manner. Unauthorized modifications such as welding, drilling, cutting, or adding attachments can weaken the structure and reduce your protection. Replace ROPS if it is subjected to roll-over or damage. Do not attempt to repair.

FIRE EXTINGUISHER

It is recommended that you have a fire extinguisher on your machine. The fire extinguisher shown is available from your dealer and can be installed on the machine.

SEAT BELT PRECAUTIONS




CD00E032

Figure 5

1. RIGHT BELT STRAP
2. LATCH MECHANISM
3. RELEASE BUTTON


1. To latch the seat belt, pull the right belt strap from the retractor.
2. Insert the metal end into the latch mechanism on the left side of the seat.
3. To unlatch the seat belt, press the red button on the left side latch mechanism.
4. The seat belt will automatically retract.

WARNING: Before starting the engine ensure seat belts are securely fastened. The seat belt can help insure your safety if it is used and properly maintained. Never wear a seat belt loosely or with slack in the belt system. Never wear the belt in a twisted condition or pinched between the seat structural members.



M422A

WARNING: Securely fasten your seat belt. Your machine is equipped with a ROPS cab, ROPS canopy or ROPS frame for your protection. The seat belt can help insure your safety if it is used and maintained. Never wear a seat belt loosely or with slack in the belt system. Never wear the belt in a twisted condition or pinched between the seat structural members.





M437

SPECIFIC PRECAUTIONS TO THIS MACHINE


- Keep the load or tool as low as possible while moving the machine around the job site.
- Never smoke while refuelling.

DECALS



NOTE: When you clean the decals, use only a cloth, water and soap. Do not use solvents, gasoline, etc.

NOTE: This chapter only covers decals relating to safety and machine operation and servicing. For information on all decals for the machine, consult your authorized dealer.



KHP1537-00 Figure 6

This 3 panel decal explains the Danger of electrocution, the importance of reading and understanding the operator's manual and that attachment interference may cause damage to the operator's compartment.



BS00M141 Figure 7

This decal warns of Danger and to keep clear of swinging upperstructure to prevent serious bodily injury.



KHP1533-00 Figure 8

This decal warns of the hazard associated with rotating parts and components.

Figure 9




KHP1013 Figure 10

This decal instructs the operator to use diesel fuel only.



KHP1535 Figure 11

This decal cautions that some surfaces may cause burns.



321-6718

Figure 12

This decal warns that improper jumper cable connections may cause the machine to move out of control causing serious injury or death.



167327A1

Figure 14


This decal warns the operator or technician that grease may be under heavy pressure and cause serious injury or death.



321-7040

Figure 13


This decal warns that starting in gear can cause serious injury or death and the engine should be started from the operator's seat only.



167328A1

Figure 15


This decal reminds the operator or technician of procedures for checking the Hydraulic fluid level.



167324A1

Figure 16


This decal warns of the Danger if standing too close to a machine that becomes electrified.



KHP1536

Figure 17


This decal warns of the hazards that may be encountered when servicing the batteries and using jumper cables.



CS00F530

Figure 18


This decal shows the function of the left-hand and right-hand control levers.



BS02G143

Figure 19

This decal warns the operator to change the function decal in the cab to match the control pattern setting.




KHP1498

Figure 20

This decal shows the function of the travel control levers and pedals.

Part number:

- KHP1498 (standard)
- KHP1484 (standard and option)
- KHP1511 (standard + option + offset boom)
- KHP1572 (with dozer blade)
- KHP1573 (with dozer blade and option)



KHP0859

Figure 21


This decal shows the function of the backfill blade.



KHP1542

Figure 22

This decal warns that hot hydraulic fluid or hydraulic fluid under pressure may cause burns or bodily injury. See Releasing Hydraulic Pressure in this manual.



CT02C010

Figure 23


This decal warns that the radiator system must be allowed to cool and pressure must be released before removing the radiator cap.



321-3596

Figure 24


This decal warns to keep clear of rotating fans and belts.



CS98N560

Figure 25

This decal shows the location and way to use the emergency exit. (rear window)



BS00M132

Figure 26

This decal cautions that contact may be made between the attachment and backfill blade during certain digging operations.



KHP-1010-00

Figure 27

This decal cautions that the hood must be locked into position to avoid serious injury.



BS04H101

Figure 30


This decal cautions about stepping on exposed cylinder which could cause serious injury from falling.



KHP1011-00

Figure 28


This decal cautions not to walk on engine cover.



BS04H102

Figure 31

This decal cautions attachment impact hazard with cab during swinging.




BS04H100

Figure 29

This decal cautions of a crush hazard from a swinging boom which can cause serious injury or death.

HAND SIGNALS


When operating the machine, never attempt to carry out tasks calling for fine control or to work in areas where visibility is poor or impaired without seeking the assistance of a signalman. Make perfectly sure that you and the signalman understand the signals to be used.



PDE0002A

Figure 32


START THE ENGINE



PDE0004A

Figure 36


GO THIS FAR



PDE0002

Figure 33

SHUT DOWN THE ENGINE




PDE0005A

Figure 37

RAISE LOAD OR TOOL

Wave hands back and forth.




PDE0003A

Figure 34

COME TO ME


Wave hands back and forth (palms inwards).



PDE0004

Figure 38

ALL STOP AND HOLD




PDE0003

Figure 35

MOVE AWAY FROM ME

Wave hands back and forth (palms outwards).




PDE0005

Figure 39

EMERGENCY STOP


Wave hands back and forth.



PDE0006A

Figure 40

RAISE LOAD OR TOOL



PDE0009A

Figure 44


RAISE TOOL



PDE0006

Figure 41


LOWER LOAD OR TOOL



PDE0008A

Figure 45


TURN THE MACHINE TO THE LEFT (SWING LOAD LEFT)
To stop movement, stop moving hand and clench fist.



PDE0007A

Figure 42


SLOWLY RAISE THE LOAD OR TOOL



PDE0008

Figure 46


TURN MACHINE RIGHT (SWING LOAD RIGHT)
To stop movement, stop moving hand and clench fist.



PDE0007

Figure 43


SLOWLY LOWER THE LOAD OR TOOL



PDE0009

Figure 47


LOWER TOOL



PDE0010A

Figure 48


RAISE TOOL



PDE0011

Figure 51


EXTEND ARM



PDE0010

Figure 49


LOWER TOOL



PDE0012A

Figure 52


FILL TOOL



PDE0011A

Figure 50

RETRACT ARM



PDE0012

Figure 53

EMPTY TOOL

Chapter 3

INSTRUMENTS AND CONTROLS

TABLE OF CONTENTS

CAB DOOR	3-3
STEPS AND ACCESS HANDLES	3-4
POSITION OF THE OPERATOR'S COMPARTMENT CONTROLS AND ACCESSORIES	3-5
RIGHT-HAND CONTROL ARM	3-6
INSTRUMENT PANEL	3-7
LEFT-HAND CONTROL ARM FOR CX75SR	3-9
LEFT-HAND CONTROL ARM FOR CX135SR	3-10
WORKING LIGHT SWITCH	3-11
WINDSHIELD WASHER SWITCH	3-11
WINDSHIELD WIPER SWITCH	3-11
HIGH SPEED TRAVEL SWITCH	3-11
HEATING, VENTILATION AND AIR-CONDITIONING CONTROL	3-12
FUNCTION CANCELLATION LEVER	3-13
ARM AND UPPERSTRUCTURE SWING LEFT-HAND CONTROL LEVER	3-13
BOOM AND BUCKET RIGHT-HAND CONTROL LEVER	3-14
TRAVEL CONTROL	3-15
OFFSET BOOM CONTROL PEDAL (IF EQUIPPED)	3-16
OPTION PEDAL	3-16
UNLOCKING AND LOCKING OF PEDALS	3-16
Unlocking	3-16
Locking	3-16
DOZER BLADE CONTROL LEVER (IF EQUIPPED)	3-17
CAB LIGHT	3-17
COAT HANGER HOOK	3-17
REAR RIGHT-HAND SIDE WINDOW	3-17
STORAGE COMPARTMENT	3-18
STORAGE TRAY	3-18
ASHTRAY	3-18
CAB RADIO COMPARTMENT	3-18
SPEAKER COMPARTMENTS	3-18
FUSE BOX	3-18
OPERATOR'S SEAT	3-19
WINDSHIELD	3-22
Opening	3-22
Closing	3-22
LOWER FRONT WINDOW	3-23
WINDOW-BREAKER HAMMER	3-23
AIR VENTS	3-23
REAR VIEW MIRRORS - CX75SR, CX80	3-24
On the cab	3-24

On the upperstructure	3-24
Rear	3-24
REAR VIEW MIRRORS CX135SR	3-24
On the cab	3-24
On the upperstructure	3-25
Rear	3-25
FUEL TANK	3-25
UPPER HOOD - CX75SR, CX80	3-25
ENGINE HOOD	3-26
CX75SR, CX80	3-26
CX135SR	3-26
SIDE DOORS	3-27
Left-hand rear side door	3-27
Right-hand rear side door	3-27
Right-hand front side door	3-27
ROTATING BEACON CABLE (OPTION)	3-28
TOWING POINT	3-28
LOAD HANDLING EYES	3-29
WINDSHIELD WASHER RESERVOIR	3-29
TOOL SUPPLY VALVES (OPTIONAL)	3-29
TOOL FLOW SELECTOR VALVE (OPTIONAL)	3-30

CAB DOOR


WARNING: When seated in the operator's compartment, with the engine running, make sure that you do not operate the left-hand control lever inadvertently when unlocking the door. To prevent an incident, place the left-hand control arm in the raised position. See Function cancellation lever.

WARNING: Be careful not to get your hand or anything caught in the door when closing it.

WARNING: Do not leave the door ajar. Fix it in a latched position.


To open the door, use the handle (1) from the outside and use the handle (2) from the inside.

The door can be latched in completely open position. To unlatch the door, push the lever (3) downward.




CT02C032

Figure 3



CT02C030

Figure 1



CT02C031

Figure 2


STEPS AND ACCESS HANDLES

WARNING: Always maintain three point support while getting on and off the machine and entering or exiting the operator's cab. A three point support system has been provided that enables a person to use simultaneously two hands and one foot or two feet and one hand while ascending, descending or moving about the machine.

WARNING: To get in or out of the cab, it is imperative that the upperstructure frame is in line with the undercarriage.


WARNING: Clean the steps and access handles and remove all traces of grease, oil, mud, and (in winter) ice.

WARNING: Never jump down from the machine. When leaving the machine or upperstructure, always face the machine and use the steps and access handles.



CT02C051 Figure 4


CX75SR, CX80



CT02C033 Figure 5


CX135SR

When getting down from or getting onto the machine, use the steps, the tracks and the access handles.



CT02C034 Figure 6

POSITION OF THE OPERATOR'S COMPARTMENT CONTROLS AND ACCESSORIES




CT02C282

Figure 7

- | | |
|--|---|
| 1. OPERATOR'S SEAT | 9. INSTRUMENT PANEL |
| 2. FUNCTION CANCELLATION LEVER | 10. HEATING, AIR-CONDITIONING, AND OPTIONAL CONTROL |
| 3. LEFT-HAND CONTROL LEVER | 11. RIGHT-HAND CONTROL LEVER |
| 4. FOOT REST (PEDAL LOCKED) | 12. AIR VENTS |
| 5. LEFT-HAND TRAVEL CONTROL PEDAL AND LEVER | 13. RIGHT-HAND CONTROL ARM |
| 6. RIGHT-HAND TRAVEL CONTROL PEDAL AND LEVER | 14. LEFT-HAND CONTROL ARM |
| 7. DOZER BLADE LEVER (IF EQUIPPED) | 15. OFFSET PIVOT CONTROL PEDAL (CX80) |
| 8. OPTION PEDALS | |

WARNING: Before starting the engine, make sure that you are fully aware of the location of and the function of each control. Incorrect operation of the controls can cause serious injuries.

RIGHT-HAND CONTROL ARM



CT02C046

Figure 8

1. INSTRUMENT PANEL

For more details, see Instrument panel.

2. STARTER SWITCH

(CX136SR)

This switch has four positions, ON (contact), START (engine ignition), OFF (engine shut-down) and ACC (accessory current supply). See Starting the engine in the Operating Instructions section.

This key is also used to lock the cab door, the engine hood, the side doors, and the fuel tank cap.

(CX75SR, CX80)

This switch has five positions, "ON" (contact), "START" (engine ignition), "OFF" (engine shut-down), "ACC" (accessory current supply), and "HEAT" (preheating). See Starting the engine in the Operating Instructions section.

This key is also used to lock the cab door, the engine hood, the side doors, and the fuel tank cap.

3. ENGINE THROTTLE BUTTON

This button enables the increase or reduction in the engine speed. For LOW IDLE position, turn the button to the left. For MAXIMUM SPEED, turn the button to the right.

If there is no change in engine speed, press and release the engine automatic idle speed selector (See item 4).


4. ENGINE IDLE SPEED SELECTOR

This control enables automatic engine idle without operating the throttle button. For engine automatic idle, press and release the control and the engine will be in LOW IDLE position. Press once again on the control then release it, the engine returns to its initial speed.

5. DOZER BLADE CONTROL LEVER (If equipped)

This lever enables the operation of the dozer blade, see Dozer blade control lever.

INSTRUMENT PANEL



CT02C046

Figure 9

WARNING: The role of the instrument panel is to indicate the state of the machine and quickly warn the operator in case of any malfunction, through alarms. It should not be used for checking or maintenance.

The instrument panel is not waterproof. Make sure that it does not get wet

1. FUEL LEVEL INDICATOR

When the indicator needle moves closer to the E zone, fuel needs to be added in the reservoir. The indicator functions when the key switch is in the ON position.


2. ENGINE COOLANT TEMPERATURE INDICATOR

This indicator is divided into two zones: white zone, normal operating temperature and red zone: hot. The indicator functions when the key switch is in the ON position.

IMPORTANT: If the needle is in the red zone, move the machine to a safe location, lower the attachment to the ground, shut down the engine, remove the ignition key and check the cooling system to determine the source of the malfunction.

3. HOURMETER


The hourmeter enables service operations to be scheduled. Its indications are similar to those of a watch when the engine is running. Its operation is indicated by the blinking of a green indicator lamp. See section Servicing intervals.



135_TBD7

4. OVERHEATING INDICATOR LAMP
The audible warning device will sound
This indicator lamp shows that the engine coolant or hydraulic fluid temperature is abnormally high. Bring the engine to idle mode and reduce the water or fluid temperature. Check and clean the radiator.


Figure 10



135_TBD8


5. ENGINE OIL PRESSURE INDICATOR LAMP
The audible warning device will sound
This indicator lamps up when the engine oil pressure is too low. If the indicator lamps up during operation, move the machine to a safe location, lower the attachment to the ground, shut down the engine, remove the ignition key and determine the source of the malfunction.

Figure 11



CT02C046

Figure 12




6. FUEL LEVEL INDICATOR LAMP
The audible warning device will sound

This indicator lamps up when the fuel level in the reservoir is too low, fuel must be added as soon as possible.

IMPORTANT: *Do not wait until the fuel tank is completely empty before refilling or it will be necessary to bleed the fuel circuit.*

135_TBD9

Figure 13




7. BATTERY CHARGE INDICATOR LAMP
The audible warning device will sound

This indicator lamps up when the alternator/fan belt is broken or when the alternator is not charging the battery any more. If the indicator lamps up during operation, move the machine to a safe location, lower the attachment to the ground, shut down the engine, remove the ignition key and determine the source of the malfunction.

135_TBD10

Figure 14




8. ENGINE ELECTRIC CIRCUIT INDICATOR LAMP CX135SR
The audible warning device will sound

This indicator lamps up in case of failure of the engine electric circuit (short-circuit or disconnection). Check the electric circuits of the engine.

135_TBD11

Figure 15



9. PREHEATING INDICATOR LAMP
The audible warning device will sound


This indicator lamps up when the key switch is in the ON position and the temperature is low. Wait for the indicator lamp to go off before starting the engine.

135_TBD12

Figure 16

- 10. Windshield wiper switch**
See Windshield wiper switch for its use.
- 11. Windshield washer switch**
See Windshield washer switch for its use.
- 12. Working light switch**
See Working light switch for its use.
- 13. High speed travel switch.**
See High speed travel switch for its use.

LEFT-HAND CONTROL ARM FOR CX75SR, CX80



CT02C064

Figure 17

1. HORN

To sound the horn, press at the end of the Left-hand control lever.

IMPORTANT: *Always sound the horn before operating the machine.*

2. FUNCTION CANCELLATION LEVER

The shape of the function cancellation lever was designed to prevent the operator from leaving the operator's compartment without having raised the lever beforehand. See function cancellation lever.

WARNING: *To access or exit the operator's compartment, the function cancellation lever must be in the raised position. Never try to avoid this basic requirement.*

3. OPTION CONTROL (Optional)

This two-position switch enables the activation of options such as the hydraulic breaker, grab, shears, etc. Place the switch in one of the two positions depending on the accessories to be used. See Auxiliary hydraulic systems in the Operating Instructions section.


4. HEATING AND VENTILATION CONTROL

See Heating and ventilation control for its use.

5. HEATING, VENTILATION OR AIR-CONDITIONING CONTROL (Optional)

See Heating, ventilation or air-conditioning control for its use.

LEFT-HAND CONTROL ARM FOR CX135SR



CT02C047

Figure 18

1. HORN

To sound the horn, press at the end of the left-hand control lever.

IMPORTANT: Always sound the horn before operating the machine.

2. FUNCTION CANCELLATION LEVER

The shape of the function cancellation lever was designed to prevent the operator from leaving the operator's compartment without having raised the lever beforehand. See function cancellation lever.

3. OPTION CONTROL (Optional)

This two-position switch enables the activation of options such as the hydraulic breaker, grab, shears, etc. Place the switch in one of the two positions depending on the accessories to be used. See Auxiliary hydraulic systems in the Operating Instructions section.

4. EMERGENCY SHUT DOWN SWITCH

This switch shuts down of the engine in case of an emergency. See Shutting down the engine in the Operating Instructions section.

IMPORTANT: This switch should only be used in case of an emergency. Do not use it on a day-to-day basis.

5. HEATING AND VENTILATION CONTROL

See Heating and ventilation control for its use.


6. HEATING, VENTILATION OR AIR-CONDITIONING CONTROL (Optional)

See Heating, ventilation or air-conditioning control for its use.



WARNING: To access or exit the operator's compartment, the function cancellation lever must be in the raised position. Never try to avoid this basic requirement.

WORKING LIGHT SWITCH




CT02C053

Figure 19

This switch switches the working lights on or off. Press the button, the instrument panel as well as the working lights comes on. Press the button again to switch them off.

WINDSHIELD WASHER SWITCH




CT02C054

Figure 20

Press and hold the switch for the windshield washer and the windshield wiper to function, release the switch to stop this operation.

Never operate the windshield washer when the reservoir is empty, as this may damage the electric pump.

WINDSHIELD WIPER SWITCH




CT02C055

Figure 21

This switch has three positions: Shut down, Intermittent and Continuous. Press the switch for intermittent operation of the windshield wiper, the lamp (I) comes on. Press the switch again to obtain continuous operation of the windshield wiper, the lamp (II) comes on. Press the switch once more for the function to cease.

Do not operate the windshield wiper if the windshield is dry, as this may damage the windshield wiper.

HIGH SPEED TRAVEL SWITCH



CT02C056

Figure 22

When the switch is pressed, the travel speed goes from low to high. A red indicator lamps up when the travel is in high speed mode.

When the engine is started, low speed is automatically selected.


WARNING: *If the travel speed is changed during travel, the machine may veer off course. Shut down the machine before changing speeds.*

Low speed: Suited for travel on a slope or on difficult terrain.

High speed: Suited for travel on level ground.

As soon as the travel load becomes too great, the machine automatically returns to low speed.

HEATING, VENTILATION AND AIR-CONDITIONING CONTROL



CT02D158

Figure 23

1. ON/OFF

This push button (1) is for turning the system on or off.

When the system is turned on it will operate at the same setting as selected for previous use.

2. AIR-CONDITIONING SWITCH

This switch (2) turns the air-conditioning on/off. When it is on, the indicator lamp on the switch comes on.

3. VENTILATION

These push buttons (3) allows the air flow to be increased or reduced. To increase the flow of air, press the top button. To decrease the flow of air, press the lower button. The segments increase or reduce depending on the flow selected.

4. TEMPERATURE

These push buttons (4) help increase or reduce the temperature. To increase the temperature, press the Right-Hand button. To decrease the temperature, press the Left-Hand button. The temperature is controlled by the increase or reduction in the number of segments.

5. AIR FLOW DIRECTION

These push buttons (5) are used for the selection of three types of air flow direction:

Via the top front air vent.

Via the top front and rear air vents.

Via the top and lower rear air vents.

To select the type of air flow, press the button (5) relating to the type of air flow desired. Depending on the selected type, a built-in indicator lamp comes on.

6. WINDSHIELD DEFROSTER

This button (6) allows the windshield to be defrosted. Press the button, windshield defrosting is carried out and a built-in indicator lamp comes on. To stop, press the button again, the indicator lamp goes off.

7. AIR RECYCLING

This button (7) allows two different types of air circulation to be selected:

External air circulation.

Internal air circulation.


Each time the button is pressed, the type of circulation will be changed. Depending on the selected type, a built-in indicator lamp comes on.

FUNCTION CANCELLATION LEVER

The shape of the function cancellation lever was designed to prevent the operator from leaving the operator's compartment without having raised the lever beforehand.

The function cancellation lever cancels the hydraulic controls.


In the raised position, all hydraulic controls are stopped.



CT02C037

Figure 24

The left-hand control arm is raised along with the function cancellation lever for better access.



CT02C038

Figure 25

In the lowered position, all hydraulic controls are operational.




WARNING: To access or exit the operator's compartment, the function cancellation lever must be in the raised position. Never forget this basic requirement.

ARM AND UPPERSTRUCTURE SWING LEFT-HAND CONTROL LEVER

The speed of movement of the arm or the upperstructure swing depends on the control lever tilt angle. In the intermediate position both movements can be obtained simultaneously.


1. The arm extends.
2. The arm retracts.
3. The upperstructure turns towards the left.
4. The upperstructure turns towards the right.

NOTE: The movements of the machine are shown in the Control functions decal. See Decals.



CT02C039

Figure 26



CS98M554


Figure 27

BOOM AND BUCKET RIGHT-HAND CONTROL LEVER

The speed of movement of the boom or the tool depends on the control lever tilt angle. In the intermediate position both movements can be obtained simultaneously.


5. The boom lowers.
6. The boom raises.
7. The bucket retracts (filling).
8. The bucket extends (dumping).

NOTE: *The movements of the machine are shown in the Control functions decal. See Decals.*



CT02C040

Figure 28



CS98M554

Figure 29

TRAVEL CONTROL

Travel control is done by using the levers or the pedals. To travel in a straight line, both levers have to be simultaneously operated, either forward or backward. Change of direction is done either by operating a single lever, or by operating simultaneously one lever forward and the other backward, so that the machine pivots on the spot. See Moving the machine in the Operating Instructions section.


IMPORTANT: *In the normal travel position, the operator's compartment is above the idler wheels and the travel reduction gears are to the rear of the upperstructure. If the upperstructure is turned 180 degrees in relation to the undercarriage, to move the machine forward, the levers have to be pulled towards yourself (i.e. in reverse) and vice-versa.*

NOTE: *The forward or reverse travel speed depends on whether the high speed travel switch is used or not. See High speed travel switch.*

NOTE: *In the normal travel position, the dozer blade (if equipped) is in front of the machine.*


NOTE: *The movements of the machine are shown in the Control functions decal. See Decals.*

- 9. The left-hand track moves forward.
- 10. The left-hand track moves backward.
- 11. The right-hand track moves backward.
- 12. The right-hand track moves forward.



CT02C063

Figure 30




CS98M544

Figure 31

OFFSET BOOM CONTROL PEDAL (IF EQUIPPED) (CX75SR, CX135SR)

Press the front of the pedal, the offset boom rotates to the left.

Press the back of the pedal, the offset boom rotates to the right. Offset angle, see Working ranges in the Specifications section.




CT02C042

Figure 32

EQUIPMENT OFFSET PIVOT CONTROL PEDAL (CX80)

Press the front of the pedal, the equipment pivots to the right.


Press the rear of the pedal, the equipment pivots to the left. Offset angle, see "Working ranges" in the Specifications section.



CT02C042

Figure 33

OPTION PEDAL



CT02C043

Figure 34

This pedal is used for options such as hydraulic breaker, earth auger, etc.


WARNING: This pedal has to be locked when the option is not used.

UNLOCKING AND LOCKING OF PEDALS

IMPORTANT: The pedal must be locked into position shown in figure 35 to have the hydraulics in neutral.

UNLOCKING

Push the locking pin forward.




CT02C044

Figure 35

LOCKING

Pull the locking pin into the pedal notch as shown.



CT02C045

Figure 36

DOZER BLADE CONTROL LEVER (IF EQUIPPED)

This lever is used to operate the dozer blade.


Pull the lever, the dozer blade rises.

Push the lever, the dozer blade lowers.

The operation of the dozer blade stops when the lever is released. The lever returns to the neutral position.

With the engine stopped, if the dozer blade is in the raised position, it is still possible to lower it using the control lever until it touches the ground.

WARNING: Before operating the dozer blade, make sure that there is no one standing in its working area.




CT02C041

Figure 37

CAB LIGHT

Located on top of the cab on the left-hand side, the lighting is controlled by a switch built into the lamp bracket.

NOTE: To replace bulbs, see *Replacing a bulb in the Electrical system section.*




CT02C058

Figure 38

COAT HANGER HOOK

The coat hanger hook is located on the rear left-hand cab upright.




CT02C059

Figure 39

REAR RIGHT-HAND SIDE WINDOW

To open the window, pull the handle backwards.



CT02C060 Figure 40


To close the window, bring the handle back towards the inside of the cab.



CT02C061 Figure 41

STORAGE COMPARTMENT


The glove compartment is located on the right-hand side in front of the cab.



CT02C068 Figure 42

STORAGE TRAY


The storage tray is located behind the operator's seat.



CT02C069 Figure 43

ASHTRAY

The ashtray is located on the right-hand side in front of the cab.




CT02C070 Figure 44

CAB RADIO COMPARTMENT

Located on the rear right-hand side of the seat is a 12volt (CX75SR, CX80) or 24volt (CX135SR) car radio. For operating instructions see the radio manual provided by the manufacturer.

SPEAKER COMPARTMENTS


Located behind the cab, these compartments are designed for installing speakers.




FUSE BOX

The fuse box is located on the rear right-hand side of the cab.

NOTE: To replace a fuse, see *Fuses in the Electrical system section*.



OPERATOR'S SEAT



CT02C075

Figure 47


- | | | |
|-----------------------------|--------------------------------|-----------------------------|
| 1. SUSPENSION ADJUSTMENT | 4. SEAT BACK ANGLE ADJUSTMENT | 7. ARMREST ANGLE ADJUSTMENT |
| 2. FORE/AFT ADJUSTMENT | 5. LUMBAR SUPPORT ADJUSTMENT | 8. HEADREST |
| 3. SEAT POSITION ADJUSTMENT | 6. CONSOLE AND SEAT ADJUSTMENT | 9. SEAT BELT |

In order to operate the machine correctly and with maximum efficiency and comfort, adjust the seat to suit the weight and size of the operator.

NOTE: *The adjustment of the seat can be done correctly only when the operator is seated in the seat and the engine is shut down.*

1. Suspension adjustment

The adjustment can be done from 50 to 120 kg (110 to 264 lb.). Turn the switch (1) in the + or - direction.




CT02C076

Figure 48

2. Forward/reverse position adjustment

Hold the control (2) in raised position, slide the seat to the required position and then release the control.




CT02C077

Figure 49

3. Seat plate adjustment

To raise or lower the front of the seat, hold the lever (3) in raised position. Move with the seat to the desired position and then release the lever.

To raise or lower the rear of the seat, hold the lever (3) in lowered position. Move with the seat to the desired position and then release the lever.




CT02C078

Figure 50

4. Seat back angle adjustment

To adjust the seat back angle, hold the lever (4) in raised position. Move with the seat back to the desired position and then release the lever.

WARNING: Before tilting the seat back it is essential for the armrests to be in raised position to prevent them from fouling the control levers.




CT02C079

Figure 51

5. Lumbar support adjustment

Use the inflation bulb (5) to inflate the lumbar support. Press the button on the tip of the inflation bulb (5) to deflate the lumbar support.




CT02C080

Figure 52

6. Console and seat adjustment

Pull the lever (6) upwards, and slide the seat and control arm assembly to the desired position, then release the lever.




CT02C081

Figure 53

7 - Armrest angle adjustment

Lift the armrests, turn the knob (7) to get the desired angle then lower the armrest.




CT02C082

Figure 54

8 - Headrest adjustment

The headrest (8) can be adjusted upwards and downwards and backwards and forwards.

NOTE: To make the headrest return to its initial position (to the rear), tilt it completely forwards and then release it.



CT02C083

Figure 55

7. Safety belt

Sit comfortably on the seat, pull the seat belt out then engage it in the kink system (9).

If the section of belt pulled out is not long enough, release it, so it rolls up and then pull it out again.


To fasten the seat belt, insert the buckle in the slide closing of the opposite belt. To unfasten the seat belt, lift the slide closing of the opposite belt.

WARNING: Always fasten your safety belt before starting the engine. The safety belt will protect you effectively if you fasten it correctly and wear it at all times. The safety belt should not be too loose. It should not be twisted or caught in the seat.

To release the seat belt, press down on the releasing lever (9).

IMPORTANT: Inspect the seat belt. Make sure that it is not damaged, that the mounting screws are correctly tightened and replace any defective parts.

The seat belt must be kept clean. Use only soap and water to clean the belt, do not use bleach or dyes.



CT02C084


Figure 56

WINDSHIELD

WARNING: Make sure you follow the instructions below properly. If the windshield is not handled correctly it could slip and injure your fingers or hand.

OPENING


1. Fold back the sunshield, if equipped (1) against the windshield and pull the lever (2).



CT02C071


Figure 57

2. Hold the upper (3) and lower (4) handles and carefully raise the windshield. Push to the rear until it engages.



CT02C086


Figure 58



CT02C087

Figure 59

3. Engage the right-hand latch (5) in the cab upright.




CT02C088

Figure 60

CLOSING


1. Unlock the right-hand latch (5) of the cab upright



CT02C089


Figure 61

2. Hold the lower (4) and upper (3) handles and carefully lower the windshield. Make sure the window is completely down.




CT02C090

Figure 62



CT02C086 Figure 63

Make sure the top of the windshield is correctly latched.




CT02C091 Figure 64

LOWER FRONT WINDOW


The lower front window may only be removed when the windshield is open.

1. Pull the window upwards to remove it.



CT02C092 Figure 65


2. Place the window in the storage position provided to the left of the operator's seat and then engage it correctly.



CT02C093 Figure 66

WINDOW-BREAKER HAMMER

Located on the right-hand cab upright, the window-breaker hammer is to be used to break the rear window in case of an emergency.




CT02C094 Figure 67


AIR VENTS

The air vents (1) are located to the front and rear as well as under the operator's compartment, and allow the circulation and direction of air to be controlled. The air vents are opened and controlled manually.

NOTE: The air vents must always be open when the air conditioning is in use.




CT02C095 Figure 68



CT02C085

Figure 69




CT02C096

Figure 70

REAR VIEW MIRRORS - CX75SR, CX80

Before any travel operation, make sure that the rear view mirrors are correctly adjusted.


ON THE CAB



CT02C097

Figure 71


ON THE UPPERSTRUCTURE



CT02C098

Figure 72

REAR




CT02C099

Figure 73

REAR VIEW MIRRORS CX135SR

Before any travel operation, make sure that the rear view mirrors are correctly adjusted.


ON THE CAB



CT02C097

Figure 74


ON THE UPPERSTRUCTURE



CT02C100

Figure 75

REAR



CT02C101

Figure 76

FUEL TANK

NOTE: Clean around the fuel cap before refuelling and do not remove the filter located in the filler orifice. See Fuel tank filter in the Maintenance/Adjustments section.


NOTE: In cold weather, use fuel corresponding to the ambient temperature. See Ingredients in the Lubrication/Filters/Fluids section.

IMPORTANT: In cold weather, fill the fuel tank after each working day to prevent the formation of condensation.

WARNING: Never refuel when the engine is running. Never smoke when refuelling.

Capacity of the reservoir: 100 liters (21 gal).

Located under the upper hood on the right-hand side



CT02C103

Figure 77


CX75SR, CX80

Capacity of the reservoir: 165 liters (44 gal).

Located on the right-hand side of the machine.

When installing the fuel cap, make sure that it is correctly placed in the notches and then lock it by turning it up against the stop.

NOTE: Use the key switch to lock the fuel cap.



CT02C103


Figure 78

CX135SR

UPPER HOOD - CX75SR, CX80

This hood consists of two sections (1) and (2) and provides access to the fuel reservoir, hydraulic reservoir, windshield washer reservoir and the toolbox.


To open it, pull the handle, only the left-hand (1) section lifts up.



CT02D285

Figure 79

Lift the hood to the maximum so that it gets locked with the supporting prop.




CT02D287

Figure 80

To open the right-hand section (2), lift it manually until it folds back on the left-hand section (1).

NOTE: The left-hand section (1) has to be open to lift section (2).

To close, operate the screw of the supporting prop then pull down and slam the hood, both sections close.




CT02D070

Figure 81

ENGINE HOOD

CX75SR, CX80

To open, press the button and lift the hood.




CT02C104

Figure 82

Lift the hood to the maximum so that it gets locked with the compressed air cylinder.

To close, pull the hood down and slam it down to lock it.

Use the key switch to lock the hood.




CT02C105

Figure 83

CX135SR

To open, pull the handle and lift the hood.




CT02C106

Figure 84

Lift the hood to the maximum so that it gets locked with the supporting leg.

To close, lift the hood slightly, pull back the supporting leg then lower the hood and slam it down to lock it.

Use the key switch to lock the hood.



CT02C107


Figure 85

SIDE DOORS

LEFT-HAND REAR SIDE DOOR

The door gives access mainly to the batteries, the air filter, etc.


Use the outside handle to open the doors. To hold the doors, open, remove the struts from their storage position and install them in the holes provided. When closing, put the struts back into storage position.



CT02C108

Figure 86

CX75SR, CX80




CT02C109

Figure 87

CX135SR

RIGHT-HAND REAR SIDE DOOR


The door gives access to a number of hydraulic components (filters, etc.).



CT02C110

Figure 88

CX75SR, CX80




CT02C111

Figure 89

CX135SR

RIGHT-HAND FRONT SIDE DOOR


The door gives access to a number of components (fuel filter, windshield washer reservoir, etc.).



CT02C112

Figure 90

CX75SR, CX80




CT02C117

Figure 92

CX75SR, CX80


For 24-volt rotary light.



CT02C113

Figure 91

CX135SR



CT02C118

Figure 93

CX135SR



WARNING: Always install the struts when the doors are open.



WARNING: Before undertaking any travel, make sure the side doors are properly closed.



WARNING: Never leave tools or other objects behind the side doors.

ROTATING BEACON CABLE (OPTION)

Located in the battery compartment, this cable is designed to connect a rotating beacon (Optional).

For 12-volt rotary light.

TOWING POINT

Located behind the undercarriage.

This point is to be used for towing the machine, see Towing the machine in section Operating instructions.

Make sure that the slings, chains and accessories are in perfect condition and can bear the load to be moved.




WARNING: Towing is a delicate manoeuvre which is always carried out at the risk of the user. The manufacturer's warranty does not apply to incidents or accidents, which occur during towing.



WARNING: It is forbidden to use this point for towing another vehicle.



WARNING: *The machine must be towed very slowly, over a short distance and only if it is really unavoidable.*



CT02C183

Figure 94

LOAD HANDLING EYES


When lifting loads, the slings and chains must be attached to the load handling eye on the bucket. (Figure 95)

See Load handling in the Operating Instructions section.

IMPORTANT: *This attachment point will only carry the load indicated in the maximum lift capacities table. See Maximum lift capacities tables in the Operating Instructions section.*



WARNING: *Never weld hooks or lugs on the bottom plate of the bucket for handling operations. The only attachment point which may be used is the bucket eye.*




CT02C184

Figure 95

WINDSHIELD WASHER RESERVOIR

Located under the upper hood, this reservoir is equipped with an electric pump controlled by the windshield wiper, windshield washer control.



CT02C126


Figure 96

CX75SR, CX80

Located inside the front right-hand side door, this reservoir is equipped with an electric pump controlled by the windshield wiper, windshield washer control.

In cold weather, add anti-freeze to the windshield washer water.

Never operate the windshield washer control when the reservoir is empty. This could cause damage to the electric pump.




CT02C120

Figure 97

CX135SR


TOOL SUPPLY VALVES (OPTIONAL)

Located at the end on both sides of the dipper, these valves feed optional tools such as the hydraulic breaker, etc. These valves have two positions: open/closed. See Auxiliary hydraulic systems in the Operating Instructions section.




CT02C122

Figure 98



CT02C185

Figure 101




CT02C123

Figure 99

CX75SR, CX80

To access the valve, remove the upper plate.



CT02C217


Figure 102

CX135SR

TOOL FLOW SELECTOR VALVE (OPTIONAL)

This valve is used to select the type of flow to be used depending on the tool installed on the machine. See Auxiliary hydraulic systems in the Operating Instructions section.

IMPORTANT: Consult your Dealer before mounting optional tools.



CT02C186

Figure 100

To access the valve, remove the front plate.

Chapter 4

OPERATING INSTRUCTIONS

TABLE OF CONTENTS

BEFORE OPERATING THE MACHINE	4-3
OPERATING THE MACHINE	4-3
RUN-IN PERIOD	4-4
After the First 50 Hours	4-4
After the First 250 Hours	4-4
STARTING THE ENGINE	4-4
BRINGING THE MACHINE UP TO OPERATING TEMPERATURE	4-5
Bringing the engine up to operating temperature	4-6
Hydraulic Fluid Warm-up	4-6
ENGINE OPERATION	4-6
STOPPING THE ENGINE	4-6
In the Event of An Emergency	4-7
OPERATING THE MACHINE IN COLD WEATHER	4-7
Battery	4-7
Fuel	4-7
Engine Oil	4-7
Hydraulic Fluid	4-7
Coolant Solution	4-7
OPERATING THE MACHINE IN HOT WEATHER	4-8
OPERATION	4-8
MACHINE TRAVEL	4-8
TRANSPORT POSITION FOR 2.85 M (9 FT. 4 IN) ARM CX135SR	4-10
TRANSPORTING THE MACHINE	4-11
By Rail	4-11
On a Trailer	4-11
Unloading	4-13
HANDLING THE MACHINE	4-14
OPERATING THE MACHINE IN WATER	4-14
PARKING THE MACHINE	4-14
OPERATING THE MACHINE ON SLOPING GROUND	4-15
TOWING THE MACHINE	4-15
OPERATING THE BUCKET	4-16
Filling	4-16
Excavating method	4-16
LOWERING THE ATTACHMENT IN THE EVENT OF A MACHINE FAILURE	4-16
auxiliary hydraulic circuits	4-17
Configuring the Hydraulic Breaker, Demolition Grab to A Flow or Bucket	4-17
Two Flow Demolition Grab Configuration	4-18
MACHINE STORAGE	4-20
Preparation for storage	4-20
Periodical checks	4-20
Starting up after storage	4-21

BEFORE OPERATING THE MACHINE

WARNING: *Do not attempt to operate this machine unless you have first read and perfectly understood the safety messages and instructions appearing in this manual.*

Before operating this machine, be sure to do the following:

1. Check the level of all fluids (engine oil, hydraulic fluid and coolant) and make sure that the fluids and lubricants are suitable for prevailing conditions. See Ingredients in the Lubrication/Filters/Fluids section and Operating the machine in cold weather.
2. Carry out the daily maintenance operations. See section Servicing intervals.
3. Inspect the machine, look for any signs of possible leakage and check the hoses. Tighten or replace as necessary. See section Maintenance/Adjustments.
4. See Run-in period if the machine is new or if the engine has been reconditioned.
5. Check the track assemblies. See Tracks in the Maintenance/Adjustments section.
6. Clean the steps and access handles. Grease, oil, mud or ice (in winter) on the steps and access handles can cause accidents. Make sure they are kept clean at all times.
7. Clean or replace any decals which are illegible. See Decals in the Safety/Decals/Hand signals section.
8. Make sure that the engine hood and the side doors are properly closed and latched.
9. Secure the cab door in either fully closed or fully opened position.
10. Remove any obstructions which hinder visibility. Clean the windshield, the windows and the rear view mirrors.
11. Check that no tools or other items have been left on the machine (be it on the undercarriage or the upperstructure) or in the operator's compartment.
12. Make sure nobody is on or under the machine. The operator must be alone on the machine.
13. Make sure nobody is standing in the machine working area.
14. Find out about current safety measures in use on the work site.

15. Work out a convenient means of escape from the machine (emergency exit via the windshield, the rear window glass) in the event of the cab door being jammed or the machine turning over. See Windshield in the Controls/Instruments/Accessories section.
16. Before undertaking any travel or working operations during hours of darkness, make sure the lighting and signalling equipment is fully operative.

OPERATING THE MACHINE

WARNING: *Check all controls and safety devices in a safe, open area before starting work.*

When operating the machine, be sure to do the following:

1. When starting the engine, be sure to use the correct procedure for the prevailing weather conditions. See Starting the engine.
2. Regularly consult the hourmeter to ensure that all servicing operations are carried out punctually. See section Servicing intervals.
3. If you use your machine in particularly harsh conditions (dusty or corrosive atmosphere), the servicing intervals should be reduced accordingly.
4. Take note of the locations of pipes/cables before starting work.
5. Do not work near overhead high-voltage electric lines without checking beforehand that all necessary measures have been taken to respect the safest distances:
 - Less than 57 000 volts: 3 metres (10 ft.)
 - More than 57 000 volts: 5 metres (16 ft.)
6. When working on a public highway, use standard traffic signs and take into consideration the working range of the upperstructure and its attachments. Local regulations stipulate the number, type and location of reflector strips.
7. Never operate the working or travel controls unless you are properly seated in the operator's seat with the seat belt correctly fastened.
8. Modify your driving to suit the type of work and working conditions. See Operating instructions in the Job Site Operation section.
9. Do not allow anyone within the machine's operating radius. Stop all operations until everyone has moved away.
10. Operate all controls gradually to ensure smooth machine operation.

11. See Operating in water if the machine will be standing in water during use.
12. See Transporting the machine when driving the machine onto a trailer.
13. See Handling the machine when it is necessary to lift the machine.
14. In some configurations, the working range of the attachment allows the tool to interfere with the machine. Always maintain a safe minimum distance between the tool and the machine.
15. Never use the attachment for sweeping the ground to level out rubble or push objects (transversal stress on the attachment).
16. Avoid running the engine in a confined space. If there is no alternative, proper ventilation must be provided at all times.
17. Dust, smoke or mist can reduce visibility and cause an accident. Reduce speed or come to a complete halt until visibility has improved.
18. In the event of an operation problem or failure, move the machine to a safe place, lower the attachment to the ground, shut down the engine and remove the starter switch key. Locate the problem, report it if necessary and take the necessary steps to warn others not to attempt to operate the machine.
19. Do not stop the engine without taking prevailing weather conditions into consideration. See Stopping the engine.
20. See Parking the machine when you have to park the machine.
21. Whenever load handling operations are to be carried out, it is imperative to adhere strictly to the instructions given in this manual and local legislation. See Load handling.
22. When travelling with the hydraulic breaker (optional), make sure it is not too close and not pointing in the direction of the cab.

RUN-IN PERIOD

Your machine will last longer and will give better and more economical performance if you pay particular attention to the engine during the first twenty hours of operation.

During this period:

Warm up the engine before using it under load.

Do not run the engine for a long period at idle speed.

Frequently check the instruments on the instrument panel.

Check the oil levels and coolant solution level frequently.

During the run-in period, the following checks and servicing operations should be carried out in addition to those specified in the service schedule:

AFTER THE FIRST 50 HOURS

Replace the pilot circuit filter and the return filter. See Hydraulic system in the Lubrication/Filters/Fluids section.

Check the pad screws are tightened to the correct torque. See Tracks in the Maintenance/Adjustments section.

Check all nuts and screws are tightened to the correct torque. See Hardware torque inspection in the Maintenance/Adjustments section.

AFTER THE FIRST 250 HOURS

Change the oil in the travel reduction gears. See Travel reduction gears in the Lubrication/Filters/Fluids section.

CX135SR - Change the oil in the swing reduction gear. See Swing reduction gear in the Lubrication/Filters/Fluids section.


STARTING THE ENGINE

NOTE: *If the machine has been out of use for some time, see Starting up after storage in the Storage section.*

NOTE: *If you need to start the engine using a booster battery, see Connecting a booster battery in the Electrical system section.*

1. Take up position correctly in the operator's seat with the seat belt correctly fastened. See Operator's seat in the Controls/Instruments/Accessories section.
2. Make sure that the control function cancellation lever is in the raised position.


Sound the horn before starting the engine.



CT02C037

Figure 1


3. Make sure the engine throttle button is in low idle position. In cold weather, leave it in half-way position.



CT02C188

Figure 2

4. Insert the starter switch key then turn the key to the ACC position, the red indicator lamps on the instrument panel remain illuminated. The audible alarm device will sound.




CT02C189

Figure 3

5. Turn the starter switch key to the ON position and hold it there. The preheating indicator lamp comes on.

IMPORTANT: Do not keep the starter switch key in the preheating position for more than 6 seconds.



CT02D268


Figure 4

6. Turn the starter switch key to the START position. Release the key as soon as the engine starts to turn. If the engine stops, wait about a minute and recommence the operation.

IMPORTANT: Do not operate the starter motor for more than 20 seconds at one time. Do not operate the starter motor when the engine is running.

IMPORTANT: When the engine is running, let it heat up until the low idle mode is steady.


IMPORTANT: When the engine is running, check the indicators and lights on the instrument panel regularly.



CT02C191

Figure 5

7. Lower the function cancellation lever.




CT02C192

Figure 6

BRINGING THE MACHINE UP TO OPERATING TEMPERATURE

IMPORTANT: Normal operating temperature of the hydraulic fluid is between 50°C and 80°C (122° - 176° F) in the middle of the temperature indicator. If the machine is used with the hydraulic fluid at a temperature below 20°C (68° F) then damage can be caused.

After starting the engine and before using the machine, wait till the temperature of the hydraulic fluid reaches 20°C (68° F).




CT02C193

Figure 7

BRINGING THE ENGINE UP TO OPERATING TEMPERATURE

With the engine throttle button a quarter open, start the engine and allow it to run approximately for 5 to 10 minutes. When the coolant temperature increases, carry out the hydraulic fluid warm-up procedure.



CT02C188

Figure 8

HYDRAULIC FLUID WARM-UP

Turn the engine throttle button to half-open position. Operate the bucket control slowly until the bucket is completely closed. Operate the arm retracting control slowly until the arm is completely retracted and hold the control in this position for 30 seconds. During this time the temperature of the hydraulic fluid will increase.

After 30 seconds, extend the arm completely and hold the control in this position a further 30 seconds.

Repeat this operation of retraction and extension of the arm until the temperature increases.

Operate the travel and attachment controls three or four times to activate hydraulic fluid circulation.

ENGINE OPERATION

When the engine has started and before beginning work, the following procedure must be observed:

1. Let the engine idle for about five minutes until it has warmed up.
2. Move the engine throttle button to the maximum speed position.

Once normal operating temperature has been reached, check the following:

1. The exhaust smoke is normal.
2. There is no abnormal noise or vibration.
3. There are no oil, fuel or water leaks.

The engine should be run at full speed when operating conditions permit.

The operating speed of the machine and of the attachment should be controlled by means of the control levers.

Check the indicators and lamps on the instrument panel regularly.

IMPORTANT: Stop the engine immediately if one of the following situations occurs:


1. Sudden increase or decrease in engine speed.
2. Abnormal noise.
3. Black smoke at the exhaust.
4. Lighting up of oil pressure, battery, engine electrical circuit (if equipped) indicator lamps on the instrument panel during operation.
5. Lighting up of the overheating indicator lamp on the instrument panel during operation.

STOPPING THE ENGINE

1. Turn the engine throttle button to low idle position and let the engine run for a minute or so.

IMPORTANT: In cold weather, let the engine run for about five minutes at idle speed.

IMPORTANT: Always let the engine run at idle before switching off completely, except in emergency situations.




CT02C194

Figure 9

2. Turn the starter switch key to the OFF position.

IMPORTANT: When the engine is to be shut down for a considerable length of time, see *Parking the Machine*.



CT02C195


Figure 10

IN THE EVENT OF AN EMERGENCY

This switch, located under the operator's seat, enables the engine to be shut down in case of an emergency or when it is not possible to shut it down using the starter switch key. Pull on this pull rod, the engine shuts down, the audible alarm device sounds, the engine oil pressure and battery charge indicators light up. Bring the starter switch key back to the OFF position.

To restart the engine, push the pull rod back then turn the starter switch key.

IMPORTANT: This switch should only be used in case of an emergency. Do not use it on a day-to-day basis.



CT02C052

Figure 11


CX75SR, CX80

In case of an emergency or when it is not possible to shut down the engine using the starter switch key, press the emergency STOP switch located on the left-hand control arm.

The engine shuts down, the audible alarm device sounds and the engine oil pressure, battery charge and engine electrical circuit indicators light up. Bring the starter switch key back to the OFF position.

To restart the engine, press again on the STOP switch then turn the starter switch key.

This switch should only be used in case of an emergency. Do not use it on a day-to-day basis.



CT02C225

Figure 12

CX135SR

OPERATING THE MACHINE IN COLD WEATHER

Follow the following recommendations:

BATTERY

It must be fully charged.

FUEL

1. To prevent condensation forming and water getting into the fuel system, fill the fuel tank after each day's work and drain off any water before starting the next day's work.
2. To prevent crystals forming at -2°C , use fuel which is rated for the ambient temperature or add an appropriate antifreeze to the fuel. See Ingredients in the Lubrication/Filters/Fluids section.

ENGINE OIL

It should be of the right viscosity for the ambient temperature. See Ingredients in the Lubrication/Filters/Fluids section.

HYDRAULIC FLUID

The viscosity must correspond to the ambient temperature conditions. See Ingredients in the Lubrication/Filters/Fluids section.

COOLANT SOLUTION

It should be suitable for the ambient temperature and contain a minimum of 50% ethylene glycol solution. See Ingredients in the Lubrication/Filters/Fluids section.

OPERATING THE MACHINE IN HOT WEATHER

1. Follow the recommendations made below:
2. Keep the coolant at the correct level in the coolant reservoir and in the radiator.
3. Use the correct solution of ethylene glycol and water in the cooling system.
4. Test the radiator cap before hot weather starts. Replace the cap as required.
5. Clean all dirt and debris from the radiator, cooler and engine area.
6. Check the condition of the fan drive belt.
7. Check the dust valve in the air cleaner frequently during extreme dust conditions.
8. Use lubricants of the correct viscosity. See Fluids and lubricants in the Lubrication, Filters, and Fluids Chapter.

OPERATION

1. Take up position in the operator's seat and adjust it so that all the controls are readily accessible. See Operator's seat in the Controls/Instruments/Accessories section. Then fasten your safety belt.
2. Make sure the cab door is firmly latched in open or closed position.
3. Start the engine, taking into consideration the prevailing weather conditions. See Starting the engine.
4. Check all instruments are operating correctly.
5. Sound the horn.
6. Lower the function cancellation lever.
7. Try out all the controls in a safe, open area.

MACHINE TRAVEL



WARNING: In the normal travel position, the operator's compartment is above the idler wheels and the travel reduction gears are to the rear of the upperstructure. If the upperstructure is turned 180 degrees in relation to the undercarriage, the controls are reversed.

IMPORTANT: Before any travel operation, raise the attachment and the dozer blade (if equipped).

IMPORTANT: Be careful of interference with the blade. Take care when digging and folding the attachment for traveling or transporting because the bucket may hit the blade. **(CX80)**

NOTE: Travel speed depends on the tilting angle of the levers and the travel mode speed selected. See High Speed Travel Switch in Instruments and Controls.

1. Straight line travel (Forward Travel)

Press the two pedals (or push the two levers) forwards at the same time.




Figure 13

2. Straight line travel (Reverse Travel)

Press the two pedals (or push the two levers) rearwards at the same time.





Figure 14

3. Turning to the left (Forward Travel)


Simply press the right-hand pedal or the right-hand lever forwards.



CS98M548 Figure 15

4. Turning to the right (Forward Travel)


Simply press the left-hand pedal or the left-hand lever forwards.



CS98M551 Figure 16

5. Turning to the left (Reverse Travel)


Simply press the right-hand pedal or the right-hand lever rearwards.



CS98M549 Figure 17

6. Turning to the right (Reverse Travel)


Simply press the left-hand pedal or the left-hand lever rearwards.



CS98M550 Figure 18

7. Turning on the spot, to the right

Press the left-hand pedal or the left-hand lever forwards and at the same time press the right-hand pedal or the right-hand lever rearwards.




CS98M552 Figure 19

8. Turning on the spot, to the left

Press the right-hand pedal or the right-hand lever forwards and at the same time press the left-hand pedal or the left-hand lever rearwards.

IMPORTANT: *Turning on the spot cannot be done if high speed travel is selected.*




CS98M553 Figure 20

9. Gradual turn on the move

Press one of the pedals or one of the levers and, at the same time, press the other pedal or the other lever in the same direction, but slightly harder.

Stopping travel

To come to a complete halt, simply release the levers or pedals and they will return to neutral.




CS98M545

Figure 21

TRANSPORT POSITION FOR 2.85 M (9 FT. 4 IN) ARM CX135SR


1. Extend the attachment then place the bucket on the ground.
2. Stop the engine and remove the starter switch key.
3. Using a suitable lifting device, hold the arm cylinder.



CT02C200

Figure 22


4. Remove the retaining hardware from the shaft then drive the shaft out.
5. Start the engine, retract the arm cylinder rod to bring the cylinder head to the transport position.
6. Stop the engine and remove the starter switch key.



CT02C201

Figure 23


7. Install the shaft and its retaining hardware, lubricate the linkage.



CT02C202

Figure 24


IMPORTANT: In this configuration, the working range of the attachment allows the tool to interfere with the machine. When positioning the machine for transporting, handle with great care.



CT02C203


Figure 25

IMPORTANT: After transporting the machine, the arm cylinder must be returned to working position.



CT02C201

Figure 26



CT02C196

Figure 27

TRANSPORTING THE MACHINE



WARNING: If the machine is equipped with the 2.85 m (9 ft. 4 in) arm, for any transportation of the machine, the hooking point on the head of the arm cylinder must be in the transport position. See Putting the 2.85 m (9 ft. 4 in) arm in the transport position.

BY RAIL

Since transport by rail is subject to special regulations, consult an approved organization.

ON A TRAILER



WARNING: This machine could slip and fall from a trailer or ramp and cause serious injury. Make sure the trailer and ramps are clean. The machine should be in line with the trailer before being loaded.




WARNING: It is mandatory to remove the counterweight before undertaking any travel without the attachment or transporting the machine without the attachment.

Make sure you know the safety rules and regulations before transporting the machine. Make sure both trailer and machine are fitted with the right safety equipment.

1. Place a block behind the trailer wheels. Install the trailer side extensions (if equipped).

2. Select the engine auto idle function on the right-hand lever of the control arm.




CT02C227

Figure 28

3. Raise the dozer blade. (if equipped)
4. Machine with attachment


Place the machine in line with the trailer, with the travel reduction gears towards the access ramps. Raise the attachment and bring it to about twenty centimeters above the bed of the trailer.



CT02C197

Figure 29

IMPORTANT: In this position, the travel and steering controls are reversed.




PDH0248

Figure 30

5. Machine without attachment

Place the machine in line with the trailer, with the travel reduction gears towards the access ramps.

IMPORTANT: *In this position, the travel and steering controls are reversed.*




CS99B518

Figure 31

6. Machine with attachment

When moving from the ramps onto the trailer bed, raise the boom slightly as soon as the attachment touches the trailer so as to bring the machine level and then move forward until the machine is resting entirely on the trailer.




PDH0249

Figure 32

7. Machine with attachment

When the machine is completely on the trailer, raise the attachment slightly and swing the upperstructure so as to bring the attachment round to the access ramp side.




PDH0250

Figure 33

8. Machine with attachment

Place the machine completely in front of the trailer so that the attachment and the dozer blade (if equipped) rest on the floor of the trailer.




PDH0251

Figure 34

9. Machine without attachment


Place the machine completely in front of the trailer, rotate the upperstructure then place the dozer blade (if equipped) on the floor of the trailer.



CS99B519

Figure 35

10. Shut down the engine, remove the starter switch key, raise the function cancellation lever.
11. Make sure that all doors, hoods and access panels are correctly locked.
12. Fold the rear view mirrors inwards.



CT02C037


Figure 36

13. Machine with attachment

Use blocks and chains to fasten the machine and the attachment to the trailer.

14. Machine without attachment

Use blocks and chains to fasten the machine to the trailer.




PDF0360

Figure 37


15. Machine ready for transport

Measure the distance between the ground and the highest point of the machine. You must know the overall height. See Machine overall dimensions in the Specifications section.



PDH0251

Figure 38



CS99B519


Figure 39

UNLOADING

1. Remove the blocks and fastening chains.
2. Start the engine.
3. Lower the function cancellation lever and raise the dozer blade (if equipped).
4. Machine with attachment
 - A. Raise the attachment to bring it a few centimeters above the trailer bed.
 - B. Move slowly while raising the attachment so as to maintain it a few centimeters above the ground.
5. Machine without attachment

Move the machine slowly.
6. Turn the rear view mirrors back to their correct position.

WARNING: If the machine is equipped with the 2.85 m (9ft 4in) arm, for any work with the machine, the hooking point on the head of the arm cylinder must be in the work position. See Putting the 2.85 m (9ft 4in) arm in the transport position.



HANDLING THE MACHINE

Never handle the machine without contacting your Dealer beforehand. Your Dealer will provide you with the correct procedure to be followed to ensure the operation is carried out in perfect safety.

IMPORTANT: Before handling the machine, make sure the slings are in perfect condition and that they are capable of supporting the weight of the machine. See *Weights in the Specifications* section.

IMPORTANT: It is imperative to use the sling points indicated on the machine decals. See *Decals in the Safety/Decals/Hand Signals* section.

WARNING: Handling of the machine must be done very slowly.

WARNING: Make sure that there is nobody under or near the machine while it is being handled.

WARNING: The machine must be handled horizontally.


OPERATING THE MACHINE IN WATER

1. Make sure that the bottom of the stream, or stretch of water in which you will work, can support the weight of the machine.
2. Only the undercarriage must be below water level. The maximum water level can be up to the height of the tracks.

IMPORTANT: Never work in water if the water level is higher than the tracks.

3. Before immersing the machine, inject large quantities of fresh grease into the attachment linkages and the dozer blade (if equipped), also on the turntable and its gear teeth.

IMPORTANT: Do not operate in a fast flowing stream.




CT02C198

Figure 40

PARKING THE MACHINE


1. Position the machine on flat, level ground, away from soft ground, excavations or poorly shored cavities.
2. Place the upperstructure in line with the undercarriage.
3. Retract and position the attachment in the shaft of the undercarriage then dig the bucket into the ground and lower the dozer blade (if equipped) to the ground.
4. Turn the engine throttle button to low idle position and let the engine run for approximately five minutes.



CT02C194

Figure 41


5. Shut down the engine and remove the starter switch key.



CT02C195

Figure 42


6. Raise the function cancellation lever.



CT02C037

Figure 43

7. Lock the operator's compartment door and make sure that the hoods, lower panels and side doors are properly fastened.
8. Check that no part of the machine is encroaching on the highway. If this cannot be avoided, set up approved traffic signs.



CT02C187

Figure 44



WARNING: Never jump down from the machine. When leaving from the operator's compartment, or from the upperstructure, always face the machine and use the steps and access handles.

OPERATING THE MACHINE ON SLOPING GROUND



WARNING: Hillside operations can be dangerous. Rain, snow, ice, loose gravel, soft ground, etc. modify terrain conditions. It is up to you to decide if the machine can be used in perfect safety.

During hillside operations, be extra careful.

Make sure that the low speed travel is selected.

When digging on a slope, avoid swinging the upperstructure towards the bottom of the slope with the backhoe bucket full. Always keep the travel reduction gears pointing down towards the bottom of the slope.

Always travel in the same direction as the slope, to prevent the machine from turning over.

TOWING THE MACHINE

Towing is only authorized when the machine has broken down.

First, make sure that it can be towed without risk of further damage.

As far as possible try to carry out repairs on spot or contact your Dealer.



WARNING: Towing is a delicate manoeuvre which is always carried out at the risk of the user. The manufacturer's warranty does not apply to incidents or accidents which occur during towing. Where possible, carry out the repairs at the site.



WARNING: The machine must be towed very slowly, over a short distance and only if it is really unavoidable.




WARNING: The operator must be the only person on the machine when towing. Make sure that nobody else is on the machine or within its working range.

OPERATING THE BUCKET

FILLING


Fill the bucket by manoeuvring the arm. Keep the bottom of the bucket parallel to the cut. The bucket teeth and blade must cut the ground like the blade of a knife. The depth of dig varies depending on the type of material.

EXCAVATING METHOD



PDH0493M

Figure 45



PDH0494M


Figure 46

1. CORRECT
2. INCORRECT. THE BUCKET WILL DIG IN AND CAUSE A STALL
3. INCORRECT. THE BUCKET IS PUSHED UPWARDS. THIS WILL ALSO INCREASE THE CYCLE TIME

LOWERING THE ATTACHMENT IN THE EVENT OF A MACHINE FAILURE

If the engine fails, use the following procedure to lower the attachment:


1. Turn the starter switch key to the ON position.



CT02D268

Figure 47


2. Lower the function cancellation lever.



CT02C192

Figure 48

- Place the control lever (s) in the position corresponding to the downward movement required.



CT02C199

Figure 49


AUXILIARY HYDRAULIC CIRCUITS

Your machine has two types of auxiliary hydraulic circuits. One circuit is for single flow equipment, such as hydraulic breakers. The second type of circuit is designed for two flow use such as crushers.

Contact your authorized dealer in order to adjust the pressure and the flow required for the use of the option correctly.

CONFIGURING THE HYDRAULIC BREAKER, DEMOLITION GRAB TO A FLOW OR BUCKET


- Connect the accessory to the supply valves at the end of the arm.
- Using a hex wrench, turn the supply valves 90 degrees to the left (I) to open them.



CT02C287

Figure 50

- Remove the 2 screws (1) then the plate (2).




CT02C185

Figure 51

CX75SR, CX80

- Remove the 4 screws (1) then the plate (2).




CT02C217

Figure 52

CX135SR


- Remove the screw (1) then bring the flow selector valve to position (B), reinstall the screw (1) in position (B).



CT02C186


Figure 53

- Make sure that the switch (1) located on the left-hand arm is in the desired position.




CT02C236 Figure 54

7. Operate the option pedal. See Option pedal in the Controls/Instruments/Accessories section.



CT02C235 Figure 55


8. When removing the hydraulic breaker, turn the supply valves to the closed position (-), and plug them.



CT02C124 Figure 56


TWO FLOW DEMOLITION GRAB CONFIGURATION

1. Proceed to connect the accessory on the supply valves at the end of the arm.
2. Using a hex wrench, turn the supply valves 90° to the right (I) to open them.



CT02C287 Figure 57


3. Remove the 2 screws (1) then the plate (2).



CT02C185 Figure 58

CX75SR, CX80


4. Remove the 4 screws (1) then the plate (2).



CT02C217 Figure 59

CX135SR


5. Make sure that the flow selector valve is in position (C), if necessary, put it in position.



CT02D066A

Figure 60


6. Make sure that the switch (1) located on the left-hand arm is in the desired position.



CT02C124

Figure 63


9. Toggle the switch to the bucket position then bring the flow selector valve into position (B).



CT02C228


Figure 61

7. Operate the Option Pedal. See Option Pedal in the Controls/Instruments/Accessories section.



CT02C236

Figure 64



CT02C235

Figure 62

8. When removing the demolition grab, turn the supply valves to the closed position (-), and plug them.

MACHINE STORAGE

PREPARATION FOR STORAGE

The following procedure applies when the machine is to be stored for a month or more. Store the machine on flat, level ground, inside a building. If a building is not available, park the machine in a dry area on planks and cover the machine with a waterproof covering. Before storing the machine, carry out the following operations:

1. Clean the machine.
2. Retract the arm cylinder rod as far as possible and lower the boom until the attachment is resting on the ground.
3. Grease the machine thoroughly. The exposed surfaces of the cylinder rods should be greased or covered with a protective film. See your Dealer.

NOTE: *When the machine resumes service, the film will disappear automatically.*

4. Drain the fuel tank and fill with a mixture of 90% diesel fuel and 10% anti-corrosive oil. Run the engine at idle speed for five minutes to allow the anti-corrosive oil to reach the lines, filters, pump and injectors.
5. While the engine is still warm, drain the oil sump, fill with anti-corrosive oil and replace the engine oil filter.
6. When the engine is cold, clean the outer parts of the engine with diesel fuel.
7. Clean or replace the air filter element.
8. Drain the cooling system, leave the drain valves open and do not tighten the radiator cap.
9. Remove the batteries, clean the battery housings and make sure not to leave any traces of acid. Store the batteries in a cool, dry place, where temperature is always above freezing.
10. Paint any areas where the paint work is not good.
11. Plug the air filter inlet and the exhaust pipe.
12. Remove the starter switch key and place a "Do not operate" label on the right-hand control arm and then raise the function cancellation lever (safety bar in inward position).
13. Lock the hoods and the cab door.

PERIODICAL CHECKS

Every month, check:

1. The electrolyte level in the batteries and the battery charge. Recharge the batteries if necessary.
2. The grease on the cylinder rods.
3. The fuel level in the fuel tank and the corrosive oil level in the engine. Add more if necessary.
4. The condition of all lines, connectors and clamps (rust). Grease if necessary.
5. The condition of the paint work. Apply a coat of anti-rust treatment where necessary.

STARTING UP AFTER STORAGE

1. Close the drain valves and fill the cooling system.
2. Drain the fuel tank and fill with clean diesel fuel.
3. Drain the engine sump, fill with clean engine oil and check the oil level.
4. Change the fuel filter.
5. Install the batteries.
6. Grease the machine thoroughly.
7. Check the condition of the fan drive belt and replace it if necessary.
8. Check the hydraulic fluid level and add more fluid if necessary.
9. Check the travel reduction gears oil level and add more oil if necessary.
10. Clean the cylinder rods.
11. Unplug the air filter inlet and the exhaust pipe.
12. Remove the "Do not operate" tag and start the engine, following the starting up procedure.
13. Keep a careful watch on all systems display panel lamps and indicators.



WARNING: Check the machine for leaks or for any parts that are broken, defective or missing.



WARNING: Before starting the engine, make sure that all controls are in neutral position. This prevents the machine from moving unexpectedly or an electrical appliance from starting up.



WARNING: Avoid running the engine in a confined place. Make sure there is adequate ventilation at all times.

NOTES

Chapter 5

LUBRICATION, FILTERS, AND FLUIDS

TABLE OF CONTENTS

SERVICING INSTRUCTIONS	5-3
DAILY INSPECTIONS	5-3
HOURLY METER	5-4
LUBRICATION AND MAINTENANCE CHART FOR CX75SR	5-5
LUBRICATION AND MAINTENANCE CHART FOR CX135SR	5-7
FLUIDS AND LUBRICANTS	5-9
Engine oil	5-9
Oil viscosity/Oil range	5-11
Fuel	5-11
Coolant solution	5-11
Environment	5-11
FLUID AND LUBRICANT CAPACITIES AND SPECIFICATIONS	5-12
LUBRICATION POINTS	5-13
Boom / ARM / bucket lubrication	5-13
CX75SR, CX80	5-13
CX135SR	5-14
Offset Boom /arm Lubrication	5-15
Machine Lubrication	5-15
Greasing the Turntable Teeth	5-16
Greasing the Swing Reduction Gear CX135SR only	5-17
FLUID LEVELS	5-18
Every 10 hours	5-18
Every 250 Hours	5-19
ENGINES - CX75SR, CX80	5-20
Service specifications	5-20
Level	5-20
Draining, Replacing the Oil Filter, and Filling	5-20
ENGINE - CX135SR	5-22
Service Specifications	5-22
Level	5-22
Draining, Replacing the Oil Filter, and Filling	5-22
COOLING SYSTEM - CX75SR, CX80	5-24
Service Specifications	5-24
Coolant solution	5-24
Level	5-24
Draining	5-24
Rinsing	5-25
Filling	5-25
COOLING SYSTEM - CX135SR	5-26
Service Specifications	5-26
Coolant Solution	5-26
Level	5-26
Draining	5-26
Rinsing	5-27
Filling	5-27
FUEL SYSTEM	5-28
Service Specifications	5-28

Fuel System Air Bleed	5-28
Draining the Fuel Tank	5-28
Bleeding the Water Separator	5-29
Cleaning the Water Separator Filter	5-29
Replacing the Fuel Filter	5-30
Filling the Fuel Tank	5-30
RELEASING PRESSURE IN THE HYDRAULIC SYSTEM	5-32
HYDRAULIC SYSTEM	5-33
Service Specifications	5-33
Level in the Reservoir	5-34
Accessing the Hydraulic Reservoir - CX75SR, CX80	5-34
Filling the Hydraulic Reservoir - CX75SR, CX80	5-34
Filling the Hydraulic Reservoir - CX135SR	5-35
Pilot Filter Replacement	5-35
Cleaning and Replacement of the Inlet Filter	5-36
Return Filter Replacement	5-37
Ultra Clean Filter Replacement	5-37
Replacing the Reservoir Breather	5-38
Replacing the Hydraulic Fluid	5-39
Bleeding Air from the Hydraulic Components	5-39
Hydraulic Breaker (Optional) - Replacing Hydraulic Fluid and Filters	5-41
AIR FILTER	5-43
Service Specifications	5-43
Inspection	5-43
Air Filter Restriction Indicator	5-43
Removing the Elements	5-43
Cleaning the Primary Element	5-44
Cleaning the Element	5-44
Inspecting the Element	5-44
Cleaning the Element Housing	5-44
Installing the Elements	5-45
SWING REDUCTION GEAR - CX135SR	5-46
Service Specifications	5-46
Level	5-46
Draining and Refilling	5-46
TRAVEL REDUCTION GEARS - CX75SR, CX80	5-48
Service Specifications	5-48
Level	5-48
Draining and Refilling	5-48
TRAVEL REDUCTION GEARS - CX135SR	5-49
Service Specifications	5-49
Level	5-49
Draining and Refilling	5-49

SERVICING INSTRUCTIONS

Respect the maintenance intervals by checking the hourmeter every day. Before starting maintenance, park the machine on flat, firm ground, away from any obstacles, with the arm retracted and the bucket on the ground. Unless otherwise specified, all maintenance operations must be carried out with the engine stopped, and the key removed from the starter switch. It is preferable to wait for all circuits to cool down before starting work.

Clean the grease fittings before lubrication. Clean around plugs and filler holes before adding fluid. No dust or dirt must enter the components or the circuits. Wear suitable clothing and remember to use the necessary safety equipment.



WARNING: *There is a risk of serious injury if maintenance or repairs are not carried out correctly. If you do not understand maintenance procedures, consult your Dealer.*



WARNING: *If the attachment is raised or if the machine moves without an operator, serious injury can result. Before performing any maintenance, proceed as follows:*

1. *Park the machine on flat, level ground.*
2. *Lower the attachment until it is resting on the ground.*
3. *Lower the dozer blade (if equipped) until it rests on the ground.*
4. *Shut down the engine and remove the starter key switch.*
5. *Lock the tracks to prevent any machine movement.*



WARNING: *Be sure all the service operations in this section are carried out punctually at the intervals given, in order to ensure optimum performance levels and maximum safety when using the machine.*

When carrying out service work on the machine, place a Do Not Operate tag on the instrument panel. Never climb down from the operator's compartment leaving the engine running.

Any modification to this machine without prior authorization could cause serious injury. Do not make any modifications without authorization. Consult your Dealer.

IMPORTANT: *If you use your machine in particularly harsh conditions (dusty or corrosive atmosphere, etc.), the servicing intervals should be reduced accordingly.*

IMPORTANT: *Take particular care to replace all filters regularly. Clean filters mean longer engine running life.*

IMPORTANT: *Oil and fluid should not be thrown on the ground. They must be stored and removed by a company which is responsible for their recycling or their disposal.*

SERVICE SPECIFICATIONS

Intervals between overhauls are much more frequent for the following applications: construction of tunnels using a hydraulic breaker, scale stripping, foundry cleaning, operation under water etc. For special applications consult your Dealer.

DAILY INSPECTIONS

Every day, before starting work, it is necessary to inspect the machine and service certain of its components.

GENERAL REMARKS

Check for water or oil leaks.

Check that all screws and nuts are correctly tightened.

Wipe off any dust (engine, operator's compartment, etc.).

Check for damage.

ENGINE

Check the oil level and change the oil if necessary.

Check the coolant level.

Check for clogging or damage to the radiator.

Check the radiator fan belt tension.

Check the air filter is clean and not restricted.

Check for water or oil leaks on the components.

Check the condition of all lines.

UPPERSTRUCTURE

Check the fuel tank level.

Check the hydraulic reservoir level.

Check that the hydraulic oil is clean.

Check for water or oil leaks on the components.

Check the condition of all lines.

Check for electrical short-circuits.

Check the battery connections are properly tightened.

Adjust the rear view mirrors.

UNDERCARRIAGE

Check the pad hardware.

Check the condition of the tracks.

Check that the upper and lower rollers and the idler wheels are not leaking oil.

ATTACHMENT

Check for oil leaks on the cylinders.

Check the condition of all lines.

Check the condition of the bucket teeth.

AFTER STARTING THE ENGINE

Did the engine start correctly? Are the exhaust fumes normal? Any strange noises?

Check for abnormal noise on the hydraulic components.

Check for water or oil leaks on the components.

Check the audible alarm devices, working lights and windshield wipers.

Check that all circuits (travel, swing and tool) are functioning correctly.


IMPORTANT: *If the slightest defect is found, repair it immediately before using the machine or see your Dealer.*

HOURMETER

The hourmeter enables service operations to be scheduled. Its hourly indications are the same as those of a clock when the engine is running.

Servicing intervals are carefully calculated to guarantee safe and efficient machine operation.

Be sure to carry out all the servicing operations properly as defined in this manual.



CT02C243

Figure 1

LUBRICATION AND MAINTENANCE CHART FOR CX75SR, CX80

SERVICE INTERVAL	PAGE NUMBER	SERVICE POINTS	NUMBER OF POINTS	FREQUENCY IN HOURS					
				CHECK	CLEAN	CHANGE	DRAIN	LUBRICATE	REPLACE
As Required (AR)	6-3	Tracks (see note 13)	2	AR	AR				
	6-12	Fuel tank filter (see note 13)	1		AR				
	6-12	Machine inspection (see note 13)	1	AR	AR				
	6-15	Fire extinguisher (see note 14)	1	AR					
	6-16	Air conditioning (see note 10)	1	AR					
Daily or Every 10 Hours	5-20	Engine oil level	1	10					
	5-24	Coolant level	1	10					
	5-34	Hydraulic reservoir level	1	10					
	6-6	Rubber track pads (optional)	2		10				
	6-9	Radiator and oil cooler	1	10					
	6-10	Fan / Alternator belt	1	10					
Every 50 Hours	5-13	Boom cylinder bottom pin	1					50	
	5-13	Boom cylinder top pin	1					50	
	5-13	Arm cylinder bottom pin	1					50	
	5-13	Arm cylinder top pin	1					50	
	5-13	Bucket cylinder bottom	1					50	
	5-14	Arm / Connecting rod pin	1					50	
	5-14	Arm / Bucket pin	1					50	
	5-14	Connecting rod / Cylinder top pin	3					50	
	5-14	Connecting rod bottom pin	1					50	
	5-15	Offset boom / Arm pin	9					50	
	5-16	Blade	6					50	
	5-28	Drain fuel tank sediment	1				50		
	5-29	Drain water separator	1				50		
	5-42	Hydraulic system lines		50					
	6-17	Air-conditioning air inlet filter	1		50				
6-17	Air-conditioning air recycling filter	1		50					
Every 100 Hours	5-41	Hydraulic breaker return filter (optional)	1						100

- NOTE 1:** Have this checked by your Dealer every 600 hours or once a year.
NOTE 2: Or every 6 months.
NOTE 3: Or every 2 years or twice a year (Autumn/Sprint) if anti-freeze is used.
NOTE 4: Or every week.
NOTE 5: Every 2 years or 4000 hours (Whichever comes first.)
NOTE 6: Or every day.
NOTE 7: After the first 50 hours during the run-in period.
NOTE 8: Or when central zone of the clogging indicator turns red.
NOTE 9: Or after cleaning 6 times.
NOTE 10: Have this checked by your Dealer every 6 months.
NOTE 11: After the first 250 hours during the run-in period.
NOTE 12: Periodically and when the machine has been working in mud.
NOTE 13: Periodically.
NOTE 14: Check once a month and have checked every 6 months by a specialist.

Lubrication and Maintenance Chart For CX75SR, CX80

SERVICE INTERVAL	PAGE NUMBER	SERVICE POINTS	NUMBER OF POINTS	FREQUENCY IN HOURS					
				CHECK	CLEAN	CHANGE	DRAIN	LUBRICATE	REPLACE
Every 250 Hours	6-9	Radiator and oil cooler	1		250				
	6-9	Tighten clamps and radiator hoses (see note 2)		250					
	5-33	Drain hydraulic reservoir sediment	1				250		
	5-43	Primary air filter element (see note 8)	1	250	250				
	5-48	Travel reduction gears oil level	1	250					
	6-5	Track shoe bolt torque (see note 7)		250					
	6-8	Idler wheel and rollers		250					
	6-10	Fan / Alternator belt tension	1	250					
	6-18	Bolt and nut torque (see note 7)		250					
Every 500 Hours	5-15	Turntable bearing	2					500	
	5-16	Turntable bearing teeth	1					500	
	5-20	Engine oil	1				500		
	5-22	Engine oil filters	1						500
	5-30	Fuel filter	1						500
	5-29	Water sediment bowl filtering element	1						500
	5-30	Water sediment bowl filter	1		500				
Every 1000 Hours	5-13	Boom foot pin	1					1000	
	5-43	Primary air filter element (see note 8&9)	1						1000
	5-13	Boom / Arm pin	1					1000	
	5-24	Cooling system (see note 3)	1				1000		
	5-33	Hydraulic fluid condition		1000					
	5-35	Pilot circuit filter (see note 7)	1						1000
	5-38	Hydraulic reservoir breather	1						1000
	5-48	Travel reduction gear (see note 7&12)	1				1000		
	6-10	Alternator	1	1000					
	7-8	Starter motor	1	1000					
Every 2000 Hours	5-36	Suction filter	1		2000				
	5-37	Return filter	1						2000
	5-37	Ultra Clean filter	1						2000
	5-44	Secondary air filter element	1						2000

NOTE 1: Have this checked by your Dealer every 600 hours or once a year.

NOTE 2: Or every 6 months.

NOTE 3: Or every 2 years or twice a year (Autumn/Sprint) if anti-freeze is used.

NOTE 4: Or every week.

NOTE 5: Every 2 years or 4000 hours (Whichever comes first.)

NOTE 6: Or every day.

NOTE 7: After the first 50 hours during the run-in period.

NOTE 8: Or when central zone of the clogging indicator turns red.

NOTE 9: Or after cleaning 6 times.

NOTE 10: Have this checked by your Dealer every 6 months.

NOTE 11: After the first 250 hours during the run-in period.

NOTE 12: Periodically and when the machine has been working in mud.

NOTE 13: Periodically.

NOTE 14: Check once a month and have checked every 6 months by a specialist.

LUBRICATION AND MAINTENANCE CHART FOR CX135SR

SERVICE INTERVAL	PAGE NUMBER	SERVICE POINTS	NUMBER OF POINTS	FREQUENCY IN HOURS					
				CHECK	CLEAN	CHANGE	DRAIN	LUBRICATE	REPLACE
As Required (AR)	6-3	Tracks (see note 13)	2	AR	AR				
	6-12	Fuel tank filter (see note 13)	1		AR				
	6-12	Machine inspection (see note 13)	1	AR	AR				
	6-15	Fire extinguisher (see note 14)	1	AR					
	6-16	Air conditioning (see note 10)	1	AR					
Daily or Every 10 Hours	5-9	Engine oil level	1	10					
	5-24	Coolant level	1	10					
	5-34	Hydraulic reservoir level	1	10					
	6-6	Rubber track pads (optional)	2		10				
	6-9	Radiator and oil cooler	1	10					
	6-10	Fan/alternator belt	1	10					
Every 50 Hours	5-13	Boom cylinder bottom pin	1					50	
	5-13	Boom cylinder top pin	1					50	
	5-13	Arm cylinder bottom pin	1					50	
	5-13	Arm cylinder top pin	1					50	
	5-13	Bucket cylinder bottom	1					50	
	5-14	Arm / Connecting rod pin	1					50	
	5-14	Arm / Bucket pin	1					50	
	5-14	Connecting rod / Cylinder top pin	3					50	
	5-14	Connecting rod bottom pin	1					50	
	5-15	Offset boom / Arm pin	9					50	
	5-16	Blade	6					50	
	5-28	Drain fuel tank sediment	1				50		
	5-29	Drain water separator	1				50		
	5-42	Hydraulic system lines		50					
	6-16	Air-conditioning air inlet filter	1		50				
6-16	Air-conditioning air recycling filter	1		50					
Every 100 Hours	5-41	Hydraulic breaker return filter (optional)	1						100

- NOTE 1:** Have this checked by your Dealer every 600 hours or once a year.
NOTE 2: Or every 6 months.
NOTE 3: Or every 2 years or twice a year (Autumn/Sprint) if anti-freeze is used.
NOTE 4: Or every week.
NOTE 5: Every 2 years or 4000 hours (Whichever comes first.)
NOTE 6: Or every day.
NOTE 7: After the first 50 hours during the run-in period.
NOTE 8: Or when central zone of the clogging indicator turns red.
NOTE 9: Or after cleaning 6 times.
NOTE 10: Have this checked by your Dealer every 6 months.
NOTE 11: After the first 250 hours during the run-in period.
NOTE 12: Periodically and when the machine has been working in mud.
NOTE 13: Periodically.
NOTE 14: Check once a month and have checked every 6 months by a specialist.

Lubrication and Maintenance Chart For CX135SR

SERVICE INTERVAL	PAGE NUMBER	SERVICE POINTS	NUMBER OF POINTS	FREQUENCY IN HOURS					
				CHECK	CLEAN	CHANGE	DRAIN	LUBRICATE	REPLACE
Every 250 Hours	6-9	Radiator and oil cooler	1		250				
	6-9	Tighten clamps and radiator hoses (see note 2)		250					
	5-33	Drain hydraulic reservoir sediment	1				250		
	5-44	Primary air filter element (see note 8)	1	250	250				
	5-46	Swing reduction gears oil level	1	250					
	5-48	Travel reduction gears oil level	1	250					
	6-5	Track shoe bolt torque (see note 7)		250					
	6-8	Idler wheel and rollers		250					
	6-10	Fan / Alternator belt tension	1	250					
6-19	Bolt and nut torque (see note 7)		250						
Every 500 Hours	5-15	Turntable bearing	2					500	
	5-16	Turntable bearing teeth	1					500	
	5-22	Engine oil	1				500		
	5-22	Engine oil filters	1						500
	5-30	Fuel filter	1						500
	5-29	Water sediment bowl filtering element	1						500
	5-29	Water sediment bowl filter	1		500				
Every 1000 Hours	5-14	Boom foot pin	1					1000	
	5-44	Primary air filter element (see note 8&9)	1						1000
	5-14	Boom / Arm pin	1					1000	
	5-24	Cooling system (see note 3)	1				1000		
	5-33	Hydraulic fluid condition		1000					
	5-35	Pilot circuit filter (see note 7)	1						1000
	5-38	Hydraulic reservoir breather	1						1000
	5-49	Travel reduction gear (see note 7&12)	1				1000		
	5-46	Swing reduction gear (see note 7)	1				1000		
	6-10	Alternator	1	1000					
7-8	Starter motor	1	1000						
Every 2000 Hours	5-37	Suction filter	1		2000				
	5-37	Return filter	1						2000
	5-37	Ultra Clean filter	1						2000
	5-44	Secondary air filter element	1						2000

- NOTE 1:** A - Have this checked by your Dealer every 600 hours or once a year.
NOTE 2: B - Or every 6 months.
NOTE 3: C - Or every 2 years or twice a year (Autumn/Sprint) if anti-freeze is used.
NOTE 4: D - Or every week.
NOTE 5: E - Every 2 years or 4000 hours (Whichever comes first.)
NOTE 6: F - Or every day.
NOTE 7: G - After the first 50 hours during the run-in period.
NOTE 8: H - Or when central zone of the clogging indicator turns red.
NOTE 9: I - Or after cleaning 6 times.
NOTE 10: J - Have this checked by your Dealer every 6 months.
NOTE 11: K - After the first 250 hours during the run-in period.
NOTE 12: L - Periodically and when the machine has been working in mud.
NOTE 13: M - Periodically.
NOTE 14: N - Check once a month and have checked every 6 months by a specialist.

FLUIDS AND LUBRICANTS

Lubricants must have the correct properties for each application.



WARNING: *The conditions of use for individual fluids and lubricants must be respected.*

Respect the maintenance intervals by checking the hourmeter every day. Before starting maintenance, park the machine on flat, firm ground, away from any obstacles, with the arm retracted and the bucket on the ground. Unless otherwise specified, all maintenance operations must be carried out with the engine stopped, and the key removed from the starter switch. It is preferable to wait for all circuits to cool down before starting work. Wear suitable clothing and remember to use the necessary safety equipment.

Clean the grease fittings before lubrication. Clean around plugs and filler holes before adding fluid. No dust or dirt must enter the components or the circuits.



WARNING: *Be sure all the service operations in this section are carried out punctually at the intervals given, in order to ensure optimum performance levels and maximum safety when using the machine.*



WARNING: *There is a risk of serious injury if maintenance or repairs are not performed correctly. If you do not understand the maintenance procedures, consult your Dealer.*



WARNING: *If the attachment is raised or if the machine moves without an operator, serious injury can result. Before performing any maintenance, the following steps must be carried out:*

1. *Park the machine on flat, level ground.*
2. *Lower the attachment until it is resting on the ground.*
3. *Stop the engine and remove the starter switch key.*
4. *Lock the tracks to prevent any machine movement.*

When carrying out service work on the machine, place a "Do not operate" tag on the right-hand control arm. Never climb down from the operator's compartment leaving the engine running.

Any modification to this machine without prior authorization could cause serious injury. Do not make any modifications without authorization. Consult your Dealer.

IMPORTANT: *If you use your machine in particularly harsh conditions (dusty or corrosive atmosphere, etc.), the servicing intervals should be reduced accordingly.*

IMPORTANT: *Take particular care to replace all filters regularly. Clean filters mean longer engine running life.*

IMPORTANT: *Oil and fluid should not be thrown on the ground. They must be stored and removed by a company which is responsible for their recycling or their disposal.*

HYDRAULIC FLUID

CASE AKCELA hydraulic fluid is specially designed for high pressure applications and for the CASE hydraulic system.

TRANSMISSION COMPONENT OIL

Extreme pressure oil used for enclosed transmission components.

Extreme pressure oil type API GL5 grade 80W90 or ISO VG 150.

GREASE

The type of grease to use depends on ambient temperature.

Temperate and hot climates

-20°C to +60°C

Extreme pressure grease EP NLGI grade 2 with molybdenum disulphide.

Cold climates

-40°C to +20°C


Extreme pressure grease EP NLGI grade 0.

FUEL

Use diesel fuel suitable for the ambient temperature conditions (ASTM-D-975).

ENGINE OIL

CASE No. 1 motor oil is the oil recommended for your engine. This oil ensures correct lubrication of your engine in all working conditions.



CT02D203

Figure 2

If CASE No. 1 Multi performance or Performance engine oil cannot be obtained, use only oil of the API/CG/CF category.


NOTE: Do not put any Performance Additive or other additive in the sump. Oil change intervals shown in this manual are based on tests carried out on CASE lubricants.



RB97F100

Figure 3

OIL VISCOSITY/OIL RANGE



CS98M561

Figure 4

- (A) FAHRENHEIT TEMPERATURE
 (B) CELSIUS TEMPERATURE
 (1) ALL SEASONS
 (2) WINTER
 (3) TROPICAL
 (4) ARCTIC
 (*) USE OF AN ENGINE OIL HEATER, OR AND ENGINE COOLANT HEATER IS REQUIRED.

FUEL

Use fuel which is to ASTM (American Society for Testing and Materials) D975 standard.

Use grade No. 2 fuel. The use of other types of fuel can result in a loss of power of the engine and may cause high fuel consumption.

In cold weather, it is tentatively approved to use a mixture of fuels No. 1 and No. 2. Consult your fuel supplier.

If the temperature falls below the fuel cloud point (point at which wax begins to form) the wax crystals will cause power loss or will prevent the engine from starting.

In cold weather, fill the fuel tank at the end of the day's work, in order to prevent the formation of condensation.

FUEL STORAGE

Long storage can lead to the accumulation of impurities and condensation in the fuel. Engine trouble can often be traced to the presence of water in the fuel.

The storage tank must be placed outside and the temperature of the fuel should be kept as low as possible. Drain off water and impurities regularly.

COOLANT SOLUTION

Put only ethylene-glycol coolant solution in the cooling system. Use good quality ethylene-glycol that has a high boiling point, with no additives to prevent leakage. Do not use non-approved anti-rust additives. Anti-rust additives and ethylene-glycol can mix and work against each other, thereby reducing anti-corrosion protection, forming deposits in the cooling system and causing damage to the cooling system and radiator.

Contact your Dealer who will supply you with the suitable coolant solution.

ANTI-FREEZE/ANTI-CORROSION

Use anti-freeze in all seasons to protect the cooling system from corrosion and all risk of freezing.

For areas where the ambient temperature is over -36°C , use a blend of 50% ethylene-glycol based anti-freeze.

For areas where the temperature is below -36°C , it is advisable to use a blend of 40% water and 60% anti-freeze.

ENVIRONMENT

Before carrying out any maintenance operation on this machine and before disposing of used fluids or lubricants, always think of the environment. Never throw oil or fluid on the ground and never place it in leaking receptacles.

Contact your local ecological recycling centre or your Dealer to obtain information on the correct method of disposing of these lubricants.

FLUID AND LUBRICANT CAPACITIES AND SPECIFICATIONS**CX75SR, CX80****ENGINE**

Type of oilCASE No. 1
 Capacity (with filter change) 9.6 liters (2.5 gal)

COOLING SYSTEM

System capacity 9.6 liters (2.5 gal)

FUEL SYSTEM

Reservoir capacity 100 liters (21 gal)

HYDRAULIC SYSTEM

Type of fluid CASE Hy-Tran Ultra (MS 1209)
 Total system capacity 95 liters (25 gal)
 Reservoir capacity 50 liters (13 gal)

TRAVEL REDUCTION GEARS

Type of oil API GL5 grade 80W90 or ISO VG 150
 Capacity (per reduction gear) 1.3 liters (.3 gal)

CX135SR**ENGINE**

Type of oilCASE No. 1
 Capacity (with filter change) 15 liters (4 gal)

COOLING SYSTEM

System capacity 17.7 liters (4.7 gal)

FUEL SYSTEM

Reservoir capacity 165 liters (44 gal)

HYDRAULIC SYSTEM

Type of fluid CASE Hy-Tran Ultra (MS 1209)
 Total system capacity 125 liters (33 gal)
 Reservoir capacity 81 liters (21 gal)

TRAVEL REDUCTION GEARS


Type of oil API GL5 grade 80W90 or ISO VG 150
 Capacity (per reduction gear) 2.5 liters (.7 gal)

SWING REDUCTION GEAR

Type of oil API GL5 grade 80W90 or ISO VG 150
 Capacity 3 liters (.6 gal)

LUBRICATION POINTS

BOOM / ARM / BUCKET LUBRICATION



CT02C259

Figure 5

Use the following grease:

EP NLGI grade 2 (for temperate and hot climates)
-20°C to +60°C

EP NLGI grade 0 (for cold climates) -40°C to +20°C

The numbers within brackets mentioned on the right of the description indicate the number of lubrication points.

EVERY 1000 HOURS

- 1. Boom foot pin (1)

EVERY 50 HOURS (CX75SR)

EVERY 1000 HOURS (CX80)

- 2. Boom cylinder bottom pin (1)


EVERY 50 HOURS (CX75SR)

EVERY 1000 HOURS (CX80)

- 3. Boom cylinder top pin (1)

EVERY 50 HOURS

- 4. Arm cylinder bottom pin (1)



CT02C274

Figure 7

EVERY 50 HOURS


- 5. Arm cylinder top pin (1)

EVERY 1000 HOURS

- 6. Boom / arm pin (1)


EVERY 50 HOURS

- 7. Bucket cylinder bottom pin (1)



CT02C272


Figure 6



CT02C275 Figure 8

EVERY 50 HOURS

- 8. Arm / yoke pin (1)
- 9. Arm / bucket pin (1)
- 10. Cylinder and connecting rod top pin (3)
- 11. Connecting rod bottom pin (1)



CT02C278 Figure 9


CX135SR

EVERY 1000 HOURS

- 1. Boom foot pin (3)

EVERY 50 HOURS

- 2. Boom cylinder bottom pin (2)




CT02C279 Figure 10

Figure 11

EVERY 50 HOURS

- 3. Boom cylinder top pins (2)
- 4. Arm cylinder bottom pin (1)



CT02C280 Figure 12

EVERY 50 HOURS


- 5. Arm cylinder top pin (1)

EVERY 1000 HOURS

- 6. Boom / arm pin (2)

EVERY 50 HOURS


- 7. Bucket cylinder bottom pin (1)



CT02C277 Figure 13

EVERY 50 HOURS

- 8. Arm / yoke (1)
- 9. Arm / bucket pin (1)
- 10. Cylinder and connecting rod top pin (3)
- 11. Connecting rod bottom pin (1)



CT02C281

Figure 14

OFFSET BOOM /ARM LUBRICATION


Use the following grease:

EP NLGI grade 2 (for temperate and hot climates)
-20°C to +60°C

EP NLGI grade 0 (for cold climates) -40°C to +20°C

EVERY 50 HOURS - CX75SR, CX80

Number of points (9)




CT02C283

Figure 15

EVERY 50 HOURS - CX135SR

Number of points (9)



CT02C284

Figure 16

MACHINE LUBRICATION

Use the following grease:


EP NLGI grade 2 (for temperate and hot climates)
-20°C to +60°C

EP NLGI grade 0 (for cold climates) -40°C to +20°C

The numbers within brackets mentioned on the right of the description indicate the number of lubrication points.

EVERY 500 HOURS - CX75SR, CX80

Turntable bearing (2)




CT02C245

Figure 17

EVERY 500 HOURS - CX135SR

Turntable bearing (2)




CT02C246

Figure 18

EVERY 5000 HOURS - CX135SR

Swing reduction gear (1)

See Greasing the swing reduction gear.




CT02C285

Figure 19

EVERY 50 HOURS - CX75SR, CX80

- Blade (2)
- Blade cylinder (4)




CT02C286

Figure 20

EVERY 50 HOURS - CX135SR

- Blade (if equipped) (2)
- Blade cylinder (if equipped) (4)



CT02C263

Figure 21

GREASING THE TURNTABLE TEETH

Every 500 hours, remove the first access plate (1) and the 2 screws (2), remove the second plate (3) and the 2 screws (4), check for damage on the gear teeth and also the general condition of the gear teeth.


If the gear surface is not well greased, add grease.

If the grease is white due to moisture content, etc. replace it with new grease.

If water accumulation is found:


1. Remove the protective panel from the lower central area.
2. Remove the plug.
3. Discharge the water or contaminated grease.
4. Install the plug.
5. Insert new grease through the port, then install the panel (3) and (1).

CX75SR, CX80



CT02D004


Figure 22



CT02C264


Figure 23

CX135SR



CT02D005

Figure 24




CT02C251

Figure 25

**GREASING THE SWING REDUCTION GEAR
CX135SR ONLY**

Every 5000 hours, remove the lower panel, remove the air bleed plug (1) and refill with grease through the grease point (2). A certain amount of grease should run out from the air bleed plug (1).

IMPORTANT: *When greasing, if the air bleed plug (1) is not removed, the inner seal will be damaged.*



CT02C285

Figure 26

EP NLGI grade 0 (for cold climates) -40°C to +20°C

Tool shank (1)


FLUID LEVELS

EVERY 10 HOURS

NOTE: The numbers within brackets mentioned on the right of the description indicate the number of levels.

CX75SR, CX80


Coolant solution expansion reservoir (1)
Ethylene-glycol and water



CT02C288 Figure 27

CX135SR


Coolant solution expansion reservoir (1)
Ethylene-glycol and water



CT02C289 Figure 28

CX75SR, CX80


Engine oil (1)
CASE No. 1



CT02C273 Figure 29

CX135SR


Engine oil (1)
CASE No. 1



CT02C290 Figure 30

CX75SR, CX80


Hydraulic reservoir (1)
CASE Hy-Tran Ultra (MS 1209)



CT02D001 Figure 31

CX135SR

Hydraulic reservoir (1)
CASE Hy-Tran Ultra (MS 1209)




CT02C291

Figure 32

EVERY 250 HOURS

CX75SR, CX80

Batteries (1)




CT02D002

Figure 33

CX135SR

Batteries (2)




CT02D003

Figure 34

CX75SR, CX80

Travel reduction gears (2)

Type API GL5 grade 85W90 or ISO VG 150




CT02D006

Figure 35

CX135SR

Travel reduction gears (2)

Type API GL5 grade 85W90 or ISO VG 150




CT02D007

Figure 36

CX135SR ONLY

Swing reduction gear (1)

Type API GL5 grade 80W90 or ISO VG 150



CT02D008

Figure 37


ENGINES - CX75SR, CX80

SERVICE SPECIFICATIONS

Engine oil level check	Every 10 hours or every day
Oil change	Every 500 hours
Oil filter replacement.....	Every 500 hours
Oil type	Case No. 1
Oil capacity	9.6 liters (2.5 gal)


LEVEL

1. Park the machine on flat, horizontal ground. Shut down the engine and remove the starter switch key.
2. When the engine has been stopped for fifteen minutes, remove the dipstick (1), wipe it with a clean cloth and replace it in the guide tube as far as it will go. Then take it out again.



CT02D009 Figure 38


3. If the level is situated between the marks (A) and (B) of the dipstick, the level is correct.



CS98M579 Figure 39

4. If the oil level is at mark (A) (min.) or below, remove the filling plug and add oil up to mark (B) (max) of the dipstick then install the plug.

NOTE: The level should not be higher than the mark (B) (maximum on the dipstick).




CT02D010 Figure 40

DRAINING, REPLACING THE OIL FILTER, AND FILLING


NOTE: Change the oil while the engine is still warm. The oil will flow more easily.

1. Park the machine on flat, horizontal ground. Shut down the engine and remove the starter switch key.
2. Remove the oil filler cap (1).



CT02D010 Figure 41


3. Place a receptacle of a suitable capacity under the engine sump drain plug, remove the plug (2) and allow the oil to flow out.
4. Put a new seal on the drain plug and install the plug.



CT02D031


Figure 42

5. Take a receptacle, place a pipe at the end (3), loosen the screw (4) in order to drain the oil cartridge (5).



CT02D301

Figure 44



CT02D011

Figure 43

6. Coat the seal of the new filter with a fine film of oil.
7. Install the new filter. Turn the filter until the seal comes into contact with the filter head then tighten an extra half turn by hand.

IMPORTANT: Do not use a filter wrench to tighten the filter. Excessive tightening can damage the filter and their seals.

Fill the engine with new engine oil (9.6 liters). Install the filling plug.

Run the engine for a few minutes and check that there are no leaks. Check the level again and top up if necessary.

IMPORTANT: Always wait fifteen minutes to allow the oil to return to the sump before checking the oil level.


ENGINE - CX135SR

SERVICE SPECIFICATIONS

Engine oil level check	Every 10 hours or every day
Oil change	Every 500 hours
Oil filter replacement.....	Every 500 hours
Oil type	Case No. 1
Oil capacity	15 liters (4 gal)


LEVEL

1. Park the machine on flat, horizontal ground. Shut down the engine and remove the starter switch key.
2. When the engine has been stopped for fifteen minutes, remove the dipstick (1), wipe it with a clean cloth and replace it in the guide tube as far as it will go. Then take it out again.



CD02D017 Figure 45


3. If the level is situated between the marks (A) and (B) on the dipstick, the level is correct.



CS98M579 Figure 46

4. If the oil level is at mark (A) (min.) or below, remove the filling plug and add oil up to mark (B) (max) of the dipstick then install the plug.

NOTE: *The level should not be higher than the mark (B) (maximum on the dipstick).*




CT02D019 Figure 47

DRAINING, REPLACING THE OIL FILTER, AND FILLING


NOTE: *Change the oil while the engine is still warm. The oil will flow more easily.*

1. Park the machine on flat, horizontal ground. Shut down the engine and remove the starter switch key.
2. Remove the oil filler cap (1).




CT02D019 Figure 48

3. Place a receptacle of a suitable capacity under the engine sump drain plug, remove the plug and allow the oil to flow out.
4. Put a new seal on the drain plug and install the plug.



CT02D020


Figure 49



CT02D301

Figure 51

5. Clean the area around the oil filters (3) and remove them, using a filter wrench.



CT02D021

Figure 50

6. Coat the seal of the new filter with a fine film of oil.
7. Install the new filters. Turn the filters until the seals come into contact with the filter head then tighten an extra half turn by hand.

IMPORTANT: Do not use a filter wrench to tighten the filters. Excessive tightening can damage the filters and the seals.


8. Fill the engine with new engine oil (15 liters). Install the filling plug.
9. Run the engine for a few minutes and check that there are no leaks. Check the level again and top up if necessary.


NOTE: Always wait fifteen minutes to allow the oil to return to the sump before checking the oil level.

COOLING SYSTEM - CX75SR, CX80

SERVICE SPECIFICATIONS

Expansion tank reservoir check.....	Every 10 hours or every day
Checking the tightening of clamps, of radiator hoses.....	Every 250 hours or every 6 months
Draining the system (long duration).....	Every 1000 hours or every 2 years
Draining the system (with anti-freeze) (spring and autumn).....	Twice a year
System capacity	9.6 liters (2.5 gal)

 **WARNING:** Boiling coolant solution can spray out if the radiator cap is removed while the system is still hot. To remove the cap, allow the system to cool down, turn the cap to the first notch and wait until there is no more pressure. Then remove the cap.

 **WARNING:** Check and service the cooling system according to the instructions given in this manual.

COOLANT SOLUTION

Put only ethylene-glycol coolant solution in the cooling system. Use good quality ethylene-glycol that has a high boiling point, with no additives to prevent leakage. Do not use non-approved anti-rust additives. Anti-rust additives and ethylene-glycol can mix and work against each other, thereby reducing anti-corrosion protection, forming deposits in the cooling system and causing damage to the cooling system and radiator.

Consult your Dealer for suitable coolant solution.

LEVEL

The level of coolant solution should be checked when the engine is cold.

On flat, level ground, before using the machine (while the engine is still cold), the level in the expansion reservoir should be between the Full (1) and Low (2) marks. If not, see Filling.





Figure 52

DRAINING

 **WARNING:** Do not remove the radiator cap when the engine is hot. The system is still under pressure and you could be scalded.

1. Remove the radiator cap.




Figure 53

2. Remove the panel located under the upperstructure and open the radiator bleed plug.





Figure 54


3. Open the drain plug located on the engine block.

NOTE: Have a receptacle of a suitable capacity ready.



CT02D029

Figure 55



CT02D022


Figure 57

RINSING

1. Close the bleed plug when the radiator is completely empty. Install the plug on the engine block.
2. Fill the system with clean water. Install the radiator cap.
3. Start the engine. Let the engine run in low idle position for ten minutes to bring the engine temperature to about 80°C (176° F).
4. Drain the system once more.
5. Repeat Steps 1 to 4 until the water drained is clear.
6. Install the panel under the upperstructure.

FILLING

1. Fill with coolant solution via the radiator until overflowing and install the radiator cap.



CT02D022

Figure 56

2. Fill the expansion tank to the Full mark and install the plug.

IMPORTANT: Use the correct coolant solution.

3. Run the engine at idle speed for about five minutes. Add coolant solution if the level in the expansion reservoir drops.

IMPORTANT: Do not fill the expansion tank above the Full mark.

COOLING SYSTEM - CX135SR

SERVICE SPECIFICATIONS

Expansion reservoir level check	Every 10 hours or every day
Checking the tightening of clamps, of radiator hoses	Every 250 hours or every 6 months
Draining the system (long duration)	Every 1000 hours or every 2 years
Draining the system (with anti-freeze) (spring and autumn)	Twice a year
System capacity	17.7 liters (4.7 gal)

WARNING: Boiling coolant solution can spray out if the radiator cap is removed while the system is still hot. To remove the cap, allow the system to cool down, turn the cap to the first notch and wait until there is no more pressure. Then remove the cap.



WARNING: Check and service the cooling system according to the instructions given in this manual.




COOLANT SOLUTION

Put only ethylene-glycol coolant solution in the cooling system. Use good quality ethylene-glycol that has a high boiling point, with no additives to prevent leakage. Do not use non-approved anti-rust additives. Anti-rust additives and ethylene-glycol can mix and work against each other, thereby reducing anti-corrosion protection, forming deposits in the cooling system and causing damage to the cooling system and radiator.

Consult your Dealer for suitable coolant solution.

To access the expansion tank, remove the two thumb screws then completely lower the hood located at the front of the machine.




CT02D030 Figure 58

LEVEL

The level of coolant solution should be checked when the engine is cold.

On flat, level ground, before using the machine, (while the engine is still cold), the level in the expansion tank should be between the Full (1) and Low (2) marks. If not, see Filling.




CT02D032 Figure 59

DRAINING


1. Remove the radiator plug.

WARNING: Do not remove the radiator cap when the engine is hot. The system is still under pressure and you could be scalded.



CT02D033 Figure 60

2. Remove the panel located under the upperstructure and open the radiator bleed plug.




CT02D034

Figure 61

3. Open the drain plug located on the engine block.

NOTE: Have a receptacle of a suitable capacity ready.



CT02D035


Figure 62

RINSING

1. Close the bleed plug when the radiator is completely empty. Install the plug on the engine block.
2. Fill the system with clean water. Install the radiator cap.
3. Start the engine. Run the engine at a speed slightly higher than idle speed for ten minutes to bring the engine temperature up to about 80°C.
4. Drain the system once more.
5. Repeat Steps 1 to 4 until the water drained is clear.
6. Install the panel under the upperstructure.

FILLING

1. Fill with coolant solution via the radiator until overflowing and install the radiator cap.



CT02D033

Figure 63


2. Fill the expansion reservoir to the Full mark and install the cap.

IMPORTANT: Use the correct coolant solution.

3. Run the engine at idle speed for about five minutes. Add coolant solution if the level in the expansion reservoir drops.

IMPORTANT: Do not fill the expansion reservoir above the Full mark.

4. Close the hood then install the two thumb screws.



CT02D032

Figure 64

FUEL SYSTEM

SERVICE SPECIFICATIONS

Air bleed from the fuel system	As required
Fuel reservoir bleeding	Every 50 hours or every week
Water separator bleeding	Every 50 hours or every week
Fuel filter replacement	Every 500 hours
Replacing the filtering element of the water separator	Every 500 hours
Cleaning the water separator filter	Every 500 hours
Replacing the fuel hoses	Every 2 years or every 4000 hours (whichever comes first)
Fuel tank capacity CX75SR, CX80	100 liters (21 gal)
Fuel tank capacity CX135SR	165 liters (44 gal)
Type of fuel	Diesel


FUEL SYSTEM AIR BLEED

It is necessary to bleed the system when:

- The tank has been completely emptied.
- The fuel filter has been replaced.
- Parts of the fuel system have been removed for servicing or repair work.
- The machine has been in storage for a fairly long period.

1. Make sure that the fuel level in the reservoir is above the water separator filter level.
2. Loosen the knob of the priming pump (1). Loosen the air bleed screw (2). Move the handle of the priming pump (1) up and down until no bubbles come out of the air bleed screw.
3. When bubbles no longer come out, tighten the air bleed screw (2) and tighten the knob of the priming pump (1).
4. Completely wipe off any spilled fuel. Start the engine and check for possible leakage.


CX75SR, CX80



CT02D047

Figure 65

CX135SR




CT02D048

Figure 66



WARNING: Completely wipe off any spilled fuel after replacing a filter element or bleeding the system.



CS98M578


Figure 67

DRAINING THE FUEL TANK

1. Position a drain pan under the drain plug.
2. Open the drain valve located at the bottom of the tank and drain the accumulated sediment and water.
3. After draining, close the drain valve.

CX75SR, CX80

To access the valve, open the front right-hand side door.




CT02D041

Figure 68

CX135SR

To access the valve, remove the panel located above the upperstructure on the right-hand side of the machine.



CT02D043


Figure 69

BLEEDING THE WATER SEPARATOR

1. When the float reaches the level (A):
2. Position a drain pan under the drain plug.
3. Loosen the drain plug (1) and drain the water and sediment.
4. When the float (2) settles on the bottom, tighten the drain plug (1).
5. Verify that there are no fuel leaks.

CX75SR, CX80

To access the separator, open the front right-hand side door.




CT02D040

Figure 70

CX135SR

To access the separator, open the engine hood.



CT02D049

Figure 71

WARNING: Completely wipe off any spilled fuel. It may cause a fire.


CLEANING THE WATER SEPARATOR FILTER

IMPORTANT: Always protect your face before using compressed air.

Remove the socket head screw, then take out the filter and clean it using compressed air. Check the condition of the filter and replace it if necessary. Install the filter and the socket head screw.

CX75SR, CX80

To access the filter, open the front right-hand side door.




CT02D040

Figure 72

CX135SR

To access the filter, open the engine hood.



CT02D049

Figure 73

WARNING: Completely wipe off any spilled fuel. It may cause a fire.

REPLACING THE FUEL FILTER

1. Clean the area around the filter head.
2. Place a receptacle of a suitable capacity under the filter and remove the filter, using a filter wrench.
3. Coat the seal of the new filter with a fine film of oil or grease.


NOTE: Do not fill the new filter with fuel before installing.

4. Install the new filter. Turn the filter until the seal comes into contact with the filter head and turn an extra half turn by hand.

IMPORTANT: Do not use a filter wrench to install the filter. Overtightening the filter can damage the seal and filter.

NOTE: If the engine does not regain full power after replacing the filter, bleed the system.


CX75SR, CX80



CT02D042

Figure 74

CX135SR



CT02D044

Figure 75

WARNING: Completely wipe off any spilled fuel. It may cause a fire.

FILLING THE FUEL TANK

1. Clean carefully around the filling cap.
2. Fill the tank, make sure that no water or dust enters the tank.

IMPORTANT: Never remove the tank filter for filling.

WARNING: Never refuel when the engine is running. Never smoke when refuelling.

IMPORTANT: In cold weather, use fuel corresponding to the ambient temperature. See Lubrication and fluids. Fill the fuel tank after each working day to prevent the formation of condensation.


3. Install the filler cap.

IMPORTANT: Make sure that the cap is correctly locked.

CX75SR, CX80

To access the tank cap, open the upper hood on the front right-hand side of the machine.

NOTE: *The gauge (1) located beside the plug shows the fuel level in the tank.*




CT02D046

Figure 76

CX135SR

The tank cap is located on the right-hand underside of the machine.




CT02D045

Figure 77

RELEASING PRESSURE IN THE HYDRAULIC SYSTEM

IMPORTANT: Before carrying out any work on the hydraulic system, there should be no pressure in any of the circuits.


1. Place the machine on flat, level ground, lower the attachment to the ground and stop the engine.
2. Turn the starter switch key to the ON position.



CT02D268

Figure 78


3. Lower the function cancellation lever.



CT02C038

Figure 79


4. Operate the control levers from right to left and front to rear a dozen times approximately.



CT02D057

Figure 80

5. Turn the starter switch key to the OFF position (shut down).




CT02C195

Figure 81

CX75SR, CX80

6. Loosen the four screws (1) and the plate (2) to release any possible pressure.




CT02D068

Figure 82

CX135SR

7. Press the button (1) located above the breather to release any possible pressure.



CT02D050

Figure 83

WARNING: Stop the engine, press the pressure release button and completely bleed air from the reservoir.

WARNING: Make sure that you don't get scalded with the hydraulic fluid under high pressure. The temperature should not exceed 40°C.

HYDRAULIC SYSTEM

SERVICE SPECIFICATIONS


Check the hydraulic reservoir fluid level	Every 10 hours or each day
Check the lines	Every 50 hours
Replace the hydraulic breaker return circuit filter (optional)	Every 100 hours
Draining water and sediment from the hydraulic reservoir	Every 250 hours
Check the condition of the hydraulic fluid	Every 1000 hours
Replace the pilot filter	Every 1000 hours (after the first 50 hours during the run-in period)
Replace the reservoir breather	Every 1000 hours
Clean the inlet filter	Every 2000 hours
Replace the return filter	Every 2000 hours (after the first 50 hours during the run-in period)
Replace the Ultra Clean filter	Every 2000 hours
Replace the inlet filter	Every 5000 hours
Change the hydraulic fluid	Every 5000 hours
Capacity of the reservoir	
CX75SR, CX80	50 liters (13 gal)
CX135SR	81 liters (21 gal)
Total capacity of the system	
CX75SR, CX80	95 liters (25 gal)
CX135SR	125 liters (33 gal)
Oil type	Case Hy-Tran Ultra (MS 1209)
Replace the hoses	Every 2 years or every 4000 hours (whichever comes first)

NOTE: *If the machine is new or if a major component has been overhauled or replaced in the hydraulic system, replace the pilot filter and return filter after 50 hours of operation. After that, replace these filters at the stipulated interval.*


IMPORTANT: *Every 1000 operating hours, it is necessary to have the hydraulic fluid analyzed. See your Dealer.*

IMPORTANT: *After replacing the hydraulic fluid, it is necessary to bleed all air from the hydraulic components. See *Bleeding air from the hydraulic components*.*


IMPORTANT: *If metal filings are discovered in the replaced filters, see your Dealer.*



WARNING: *Before carrying out any service work on the hydraulic system it is necessary to allow it to cool down (the temperature should not be more than 40°C (104° F)).*




WARNING: *Hydraulic fluid or grease injected into your skin can cause severe injury or death. Keep your hands and body away from any pressurized leak. Use cardboard or paper to check for a leak. If fluid is injected into your skin, see a doctor immediately and have the fluid removed.*



WARNING: *Before carrying out any operation on the hydraulic filters or the hydraulic system, the pressure must be released from the system. Failure to observe this instruction can cause injury. See *Releasing pressure in the hydraulic system*.*

LEVEL IN THE RESERVOIR


1. Park the machine on flat, horizontal ground. Retract completely the bucket and arm cylinder rod. Raise the dozer blade (if equipped). Lower the attachment to the ground. Shut down the engine and remove the starter switch key.



CT02D051

Figure 84

2. Using the starter switch key, open the right-hand side door.
3. The oil must be located in the middle of the indicator. Top up if necessary. See Filling.




CT02D058

Figure 85

ACCESSING THE HYDRAULIC RESERVOIR - CX75SR, CX80


1. Open the 2 hoods (1) and (2) and lock them with the lever (3).



CT02D070

Figure 86


2. Remove the toolbox (1):
 - A. Loosen the 2 screws (2) by a few turns.
 - B. Move the toolbox (1) in one direction and lift it to remove it from its housing.



CT02D071

Figure 87

3. Lift the windshield washer reservoir upwards to remove it from its housing.




CT02D072

Figure 88

FILLING THE HYDRAULIC RESERVOIR - CX75SR, CX80

1. To access the hydraulic reservoir, see Accessing the hydraulic reservoir.
2. Clean the plate and also around the plate.

- A. Loosen the 4 screws (1) to release pressure from the reservoir.
- B. Remove the 4 screws (1) and the plate (2) then add hydraulic fluid as required.




CT02D068

Figure 89

3. Check the max and min. level by monitoring the dipstick.

Install the plate (2) and the 4 screws (1). Replace the cover seal if required.




CT02D058

Figure 90

FILLING THE HYDRAULIC RESERVOIR - CX135SR

1. To access the filling port, remove the screws and the upper plate.




CT02D073

Figure 91

2. Release pressure in the reservoir by pressing the button (1).

- A. Clean the cover and around the cover.
- B. Remove the 4 screws (2) and the cover to access the reservoir.




CT02D069

Figure 92

3. Fill the reservoir as required.

- A. Check the max and min. level at the dipstick.
- B. Replace the cover seal if required and install the cover.




CT02D078

Figure 93

PILOT FILTER REPLACEMENT

1. Release all pressure in the hydraulic system. See Releasing Pressure in the Hydraulic System.
2. Use a wrench on the bottom of the filter body (4) to unscrew and remove it.
3. Remove the old filter (3) and O-ring (2).
4. Clean the filter body (4) in solvent and wipe dry with a cloth.
5. Coat the new filter (3) and the new O-ring (2) with clean hydraulic fluid and install the filter on the head (1).
6. Install the filter body (4) and tighten with a wrench. Do not overtighten.




CS98M619

Figure 94

CX75SR, CX80

To access the filter, open the rear right-hand side door.




CT02D081

Figure 95

CX135SR

To access the filter, open the rear right-hand side door.



CT02D085


Figure 96

CLEANING AND REPLACEMENT OF THE INLET FILTER

1. Release all pressure in the hydraulic reservoir. See Releasing Pressure in the Hydraulic System.

2. Clean the top of the hydraulic reservoir and clean the inlet filter cover.
3. Remove the cover (1), O-ring (2) and spring on the top of the inlet filter rod assembly.
4. Remove the inlet filter (3) and clean with solvent. Dry it completely and check it for any damage. If there is any damage on the surface, replace it with a new one.
5. Install a new O-ring (2) and install the inlet filter (3), spring and rod assembly.
6. Install the cover (1).
7. Check the level of the hydraulic fluid and add more if necessary. See Filling the reservoir.

NOTE: Install a new inlet filter every 5000 hours of operation or when the hydraulic fluid is replaced.




CI98M156

Figure 97

CX75SR, CX80

To access the filter, see Accessing the Hydraulic Reservoir.

Loosen the 4 screws (1) and remove the plate (2).




CT02D068

Figure 98

CX135SR

To access the filter, remove the screws and the upper plate.



CT02D073


Figure 99

RETURN FILTER REPLACEMENT

1. Release all pressure in the hydraulic reservoir. See Releasing Pressure in the Hydraulic System.
2. Clean the top of the hydraulic reservoir and clean the return filter cover.
3. Remove the cover (1) and O-ring (2).
4. Take out the spring (3), valve (4) and return filter (5).
5. Install a new filter. Clean the spring (3) and valve (4) and install them.
6. Check O-ring (2) and replace it if worn or damaged.
7. Install the cover (1).
8. Check the level of the hydraulic fluid and add more if necessary. See Filling the reservoir.

CX75SR, CX80

To access the filter, see Accessing the hydraulic reservoir.




CI98M156

Figure 100

CX135SR

To access the filter, remove the screws and the upper plate.




CT02D073

Figure 101

ULTRA CLEAN FILTER REPLACEMENT

1. Release all pressure in the hydraulic reservoir. See Releasing Pressure in the Hydraulic System.
2. Clean the top of the filter with solvent.
3. Remove the four screws (1) from the cover and remove the cover (2). Remove the O-ring (3) and the spring (4).
4. Carefully lift the old filter element (6) out of the body (5).
5. Use a clean cloth and clean out the filter body (5).
6. Carefully install a new filter element (6) in the body (5).
7. Install the spring (4), new O-ring (3) and cover (2).
8. Start the engine and run it at low speed.
9. Loosen the vent plug (7) on top of the cover. When air free hydraulic fluid comes out of the vent hole, tighten the vent plug (7). Clean all fluid from the filter body.
10. Check the level of the hydraulic fluid and add more if necessary. See Filling the reservoir.




CS02A544

Figure 102

CX75SR, CX80

To access the filter, remove the screws and the front hood.




CT02D097

Figure 103

CX135SR

To access the filter, remove the 4 screws and remove the panel.




CT02D099

Figure 104

REPLACING THE RESERVOIR BREATHER

1. Press the button (1) to release all pressure in the hydraulic reservoir.
2. Remove the nut (2) and the cover (3) from the breather.
3. Remove and discard the used filter (4).
4. Install a new element, making sure the seal (5) is facing upwards.
5. Install the cover (3) as well as the nut (2).



CS00E528


Figure 105

CX75SR, CX80

To access the breather, see Accessing the hydraulic reservoir.

CX135SR

To access the breather, remove the screws and the upper plate.



CT02D073


Figure 106

REPLACING THE HYDRAULIC FLUID

1. Release all pressure in the hydraulic reservoir. See Releasing Pressure in the Hydraulic System.
2. Using a pump, remove the fluid from the hydraulic reservoir. Have a container with a suitable capacity ready.

CX75SR, CX80

1. Remove the reservoir filling cover (1).
2. To access the cover, see Accessing the hydraulic reservoir.
3. Remove the drain plug (2) to remove the remaining fluid from the reservoir.




CT02D103

Figure 107

CX135SR


1. Remove the reservoir filling cover (1).
2. To access the cover, remove the screws and the upper plate.



CT02D073

Figure 108

3. Remove the drain plug (2) to remove the remaining fluid from the reservoir.



CT02D104

Figure 109

Replace the inlet filter and the return filter. See Cleaning and replacement of the inlet filter and Return filter replacement.

Install the reservoir drain plug.

Put new hydraulic fluid into the reservoir. See Filling the reservoir.

Install the reservoir cover plate and seal.

IMPORTANT: Before you start the engine, it is very important that you bleed air from all the hydraulic components. See Bleeding Air from the Hydraulic Components.

Start and run the engine with no load for approximately five minutes.

Move each control several times to remove any air in the system.

Swing the upperstructure evenly left to right two complete turns or more.

Place the machine in position and then stop the engine.

Check the oil level in the hydraulic reservoir and add oil as required and check that there are no air bubbles in the hydraulic reservoir.

Bleed the components, see Bleeding the hydraulic components.

BLEEDING AIR FROM THE HYDRAULIC COMPONENTS

IMPORTANT: After bleeding air from the components, stop the engine for five minutes and check there are no bubbles at the surface of the hydraulic fluid in the reservoir.


HYDRAULIC PUMP

Using a solvent, clean the upper surface of the pump and the air bleed plug. Remove the air bleed plug (1).

Fill the pump with hydraulic fluid via port (1). Install and tighten the air bleed plug.

Start the engine and run it at low speed. Loosen the air bleed plug (1) on the pump. Tighten the plug when air free fluid comes out of the bleed plug hole. Clean the area completely.


CX75SR, CX80



CT02D109

Figure 110

CX135SR



CT02D110

Figure 111


ATTACHMENT CYLINDERS

Start and run the engine at low idle speed. Extend and retract the attachment cylinder rods four or five times without bringing them to end of stroke. Then repeat the operation three or four times, this time bringing the cylinder rods to end of stroke.

SWING REDUCTION GEAR

Start and run the engine at low idle speed. Loosen the air bleed plug (1) and make sure hydraulic fluid runs out through this port. If required, shut down the engine and top up via port (1). Install the plug without tightening, then start and run the engine at low idle, leaving it to run until oil begins to run from the orifice. Tighten the air bleed plug (1) completely. Swing the upperstructure three times completely to the right and three times completely to the left.


CX75SR, CX80



CT02D111

Figure 112


CX135SR



CT02D112

Figure 113

HYDRAULIC BREAKER (OPTIONAL) - REPLACING HYDRAULIC FLUID AND FILTERS WITH STANDARD HYDRAULIC FLUID



CS99A860A

Figure 114

1. PERCENTAGE OF USE 2. INTERVAL IN HOURS 3. REPLACING HYDRAULIC FLUID 4. REPLACING HYDRAULIC FILTERS

HYDRAULIC FLUID

- When using the hydraulic breaker, hydraulic fluid deteriorates more quickly than during ordinary digging. Check the hydraulic fluid level more frequently. In addition, when replacing the filters, also check the condition of the hydraulic fluid.
- Replace the hydraulic fluid and filter element using the following graph as a reference, depending on the operation frequency of the hydraulic breaker.
- Replace the return filter for the hydraulic breaker at the same interval as the element.

RETURN FILTER

Release all pressure in the hydraulic reservoir. See Releasing Pressure in the Hydraulic System.

IMPORTANT: *It is mandatory to use the option control pedal to release all pressure in the hydraulic breaker circuit.*

This filter is equipped with an indicator (7). When the filter is restricted, the filter must be changed.

Remove the drain plug (6) and drain the hydraulic oil.

Remove the four screws (1) on top of the case and remove the cover (2), indicator and O-ring (3) assembly.

Replace the filter (5) with a new filter.


Discard the used O-rings.

Insert new O-rings (3) and (4) and install the assembly.

Tighten the retaining screws (1) for the cover (2).

Install the drain plug (6).

Start the engine and run it at low speed. Operate the hydraulic breaker and check that there are no leaks.




CS98M622

Figure 115


CX75SR, CX80

To access the filter, remove the screws and the hood.



CT02D097

Figure 116




CT02D113

Figure 117


CX135SR

To access the filter, remove the 4 screws and the hood.



CT02D099

Figure 118



CT02D114

Figure 119

CHECKING THE HYDRAULIC SYSTEM LINES

Make sure there are no leaks from the hydraulic system hoses, pipes, plugs, connections and fittings and check that all nuts and screws are correctly tightened. In the event of problems, repair, replace or tighten the component(s) concerned.

AIR FILTER

SERVICE SPECIFICATIONS

Inspect and clean the primary element Every 250 hours or when central zone of the indicator turns red
 Replace the primary element Every 1000 hours or after cleaning six times
 Replace the secondary element Every 2000 hours

IMPORTANT: *The primary element can be cleaned. The secondary element cannot be cleaned and must be replaced.*

IMPORTANT: *Observe the air filter service intervals shown above. Clean filters mean longer engine life.*

INSPECTION

Be sure to carry out regular checks on the air filter, intake manifold, seals, and hoses. At the same time, check the intake manifold screws and hose clamps for tightness.

The hoses should be replaced before they are worn.


AIR FILTER RESTRICTION INDICATOR

Located above the air filter, this indicator (1) shows the state of the air filter elements. When the central zone of the indicator becomes red then the elements must be serviced, irrespective of the next scheduled service interval.

Once the elements have been serviced, press the button on top of the indicator to start a new indication cycle.

CX75SR, CX80

To access the air filter, open the left-hand side door and install the support strut (2).




CT02D115

Figure 120

CX135SR

To access the air filter, open the left-hand side door and install the support strut (2).




CT02D116

Figure 121

REMOVING THE ELEMENTS


1. Release the fasteners and remove the cover.



CT02D117

Figure 122

2. Remove the primary element.




CT02D118

Figure 123

3. Remove the secondary element if it needs replacing.

IMPORTANT: *The secondary element must be replaced, not cleaned.*



CT02D119


Figure 124

CLEANING THE PRIMARY ELEMENT

IMPORTANT: *Always protect your face before using compressed air.*

If the primary element is dry:

Blow compressed air from the inside towards the outside at very low pressure. The compressed air nozzle should be held at least 3^{cm} from the inside wall of the element. Cleaning is completed once no more dust comes out of the primary element.



CT02D120

Figure 125

CLEANING THE ELEMENT

IMPORTANT: *Always protect your face before using compressed air.*

If the element is dry:

Blow compressed air from the inside towards the outside at very low pressure. The compressed air nozzle should be held at least 3 cm from the inside wall of the element. Cleaning is completed once no more dust comes out of the element.


IMPORTANT: *Compressed air pressure should not exceed 7 bar (101 psi).*

NOTE: *Do not use compressed air if there is oil or soot in the element.*

If the cartridge is greasy:

Clean it in water with a suitable detergent (consult your Dealer). Instructions for using the detergent are printed on the packaging.

IMPORTANT: *Allow the element to dry completely before installing it. It is advisable to keep a spare, clean element ready for installation on the air filter while the cleaned element is drying.*




PDE0088

Figure 126

INSPECTING THE ELEMENT

Check the element for damage by placing an inspection lamp inside the element.

IMPORTANT: *Replace the element if light can be seen through a hole, however small.*




PDE0378

Figure 127

CLEANING THE ELEMENT HOUSING

Remove dust from the housing of the elements and its cover.




CT02D393

Figure 128

INSTALLING THE ELEMENTS


1. Install the secondary element.



CT02D119

Figure 129


2. Install the primary element.



CT02D118

Figure 130

3. Install the cover (with the word TOP at the top) and close the fasteners.




CT02D117

Figure 131

4. Check that the dust ejector under the filter is working correctly.
5. Press the red button on the indicator.

IMPORTANT: *If exhaust smoke is abnormal after cleaning, the air filter primary element must be replaced.*



CT02D117

Figure 132

SWING REDUCTION GEAR - CX135SR

SERVICE SPECIFICATIONS

Oil level check.....	Every 250 hours
Draining	Every 1000 hours (after the first 250 hours during the run-in period)
Grease.....	Every 5000 hours
Oil capacity	2.2 liters (.5 gal)
Oil type	See Fluids and lubricants




WARNING: Wait till all components have cooled down before carrying out any operation.



WARNING: Loosen the dipstick slowly to release pressure, otherwise there is a risk of oil spurting out.

1. Park the machine on flat, horizontal ground. Stop the engine and remove the starter switch key.
2. Remove the two thumb screws then lower completely the hood located in front of the machine.




CT02D030

Figure 133

LEVEL

1. Remove the dipstick. The level should come up to the hatched area. If necessary, top up through the filler port.
2. Install the dipstick after topping up the level, if required.




CT02D008

Figure 134

DRAINING AND REFILLING

1. Park the machine on flat, horizontal ground. Stop the engine and remove the starter switch key.
2. Remove the dipstick and the filling plug.



CT02D124


Figure 135

3. Place a receptacle of a suitable capacity under the upperstructure and remove the drain plug.
4. Allow the oil to drain.

NOTE: The oil takes a relatively long time to drain.

IMPORTANT: Check the condition of the drained oil. If it contains metal filings or foreign matter, see your Dealer.

5. Install the drain plug.




CT02D121

Figure 136

12. Add oil through the filler port until the level is correct.
6. Install the dipstick and the filling plug.
7. Wait ten minutes and then use the dipstick to check the level again. If necessary, top up through the filler port.

NOTE: *When greasing the swing reduction gear, see Greasing the swing reduction gear.*



CT02D124

Figure 137

TRAVEL REDUCTION GEARS - CX75SR, CX80


SERVICE SPECIFICATIONS

Oil level check.....	Every 250 hours
Draining	Every 1000 hours (after the first 250 hours of operation)
Oil capacity	1.30 liters (.3 gal)
Oil type	See Fluids and Lubricants

LEVEL


1. Park the machine on flat, horizontal ground.
2. Move the machine so that plug (1) is in the lowest possible position.

2. Move the machine so that plug (1) is in the lowest possible position.



CT02D006 Figure 138

3. Stop the engine and remove the starter switch key.
4. Remove the plug (2) and check the oil level. The level must come up to the lower edge of the orifice. If required, remove the plug (3) then top up through this port (3) until oil comes up to the bottom edge of the port (2).




CT02D006 Figure 140

3. Shut down the engine and remove the starter switch key.
4. Place a receptacle of a suitable capacity under the travel reduction gear and remove the three plugs (1), (2) and (3).
5. Allow the oil to drain.


IMPORTANT: Check the condition of the drained oil. If it contains metal filings or foreign matter, see your Dealer.

6. Install the plug (1), fill with oil through the port (3) until oil comes up to the bottom edge of port (2), then install the plugs (2) and (3).
7. Repeat Steps 2 to 6 for the other travel reduction gear. Travel slowly with the machine and make sure there are no leaks.



CT02D141 Figure 139

5. Install the plugs (2) and (3).
6. Repeat Steps 2 to 5 for the other travel reduction gear. Travel slowly with the machine and make sure there are no leaks.



CT02D141 Figure 141

DRAINING AND REFILLING

1. Park the machine on flat, horizontal ground.


TRAVEL REDUCTION GEARS - CX135SR

SERVICE SPECIFICATIONS

Oil level check.....	Every 250 hours
Draining	Every 1000 hours (after the first 250 hours of operation)
Oil capacity	2.50 liters (.7 gal)
Oil type	See Fluids and lubricants


LEVEL

1. Park the machine on flat, horizontal ground.
2. Move the machine so that plug (1) is in the lowest possible position.



CT02D007 Figure 142

3. Stop the engine and remove the starter switch key.
4. Remove the plug (2) and check the oil level. The level must come up to the lower edge of the orifice. If required, top up through this port (2) until oil comes up to the bottom edge of the port.
5. Install plug (2).
6. Repeat Steps 2 to 5 for the other travel reduction gear. Travel slowly with the machine and make sure there are no leaks.




CT02D142 Figure 143

DRAINING AND REFILLING


1. Park the machine on flat, horizontal ground.

2. Move the machine so that plug (1) is in the lowest possible position.



CT02D142 Figure 144

3. Shut down the engine and remove the starter switch key.
 4. Place a receptacle of a suitable capacity under the travel reduction gear and remove the two plugs (1) and (2).
 5. Allow the oil to drain.
- IMPORTANT:** Check the condition of the drained oil. If it contains metal filings or foreign matter, see your Dealer.
6. Install the plug (1), fill with oil through the port (2) until oil comes up to the bottom edge of port (2), then install plug (2).
 7. Repeat Steps 2 to 6 for the other travel reduction gear. Travel slowly with the machine and make sure there are no leaks.



CT02D142 Figure 145

NOTES

Chapter 6

MAINTENANCE AND ADJUSTMENTS

TABLE OF CONTENTS

TRACKS	6-3
Maintenance Specifications	6-3
Cleaning	6-3
Checking the Tension	6-3
Adjusting the Tension	6-4
To Reduce Tension	6-4
CHECKING THE CONDITION OF RUBBER TRACKS (IF EQUIPPED)	6-6
REPLACING THE RUBBER TRACKS (CX75SR, CX80 IF EQUIPPED)	6-6
Removal	6-6
Installation	6-7
TRACK ROLLERS AND IDLER WHEELS	6-8
Maintenance Specification	6-8
RADIATOR AND OIL COOLER	6-9
Maintenance Specifications	6-9
Cleaning	6-9
FAN AND ALTERNATOR DRIVE BELT	6-10
Maintenance Specifications	6-10
Checking the Tension	6-10
Adjusting the Tension	6-10
Replacing the Belt	6-10
FUEL TANK FILTER	6-12
Maintenance Specification	6-12
INSPECTING AND CLEANING THE MACHINE	6-12
Maintenance Specifications	6-12
CHECKING FOR CYLINDER LEAKAGE	6-12
REPLACING A BUCKET - CX75SR, CX80	6-13
Removal	6-13
Installation	6-13
REPLACING A BUCKET - CX135SR	6-14
Removal	6-14
Installation	6-14
FIRE EXTINGUISHER (NOT SUPPLIED)	6-15
WELDING ON THE MACHINE	6-15
PLASTIC AND RESIN PARTS	6-15
AIR CONDITIONING	6-16
MAINTENANCE SPECIFICATION	6-16
HARDWARE TORQUE INSPECTION	6-18
MAINTENANCE SPECIFICATION	6-18
(CX135SR)	6-19

TRACKS

MAINTENANCE SPECIFICATIONS

Clean Periodically and when the machine has been working in mud
 Check tension Periodically
 Check steel pad screw torques Every 250 hours (after the first 50 hours during the run-in period)
 Check the rubber track pads (optional) Every 10 hours or every day


IMPORTANT: If the tracks are too tight, they wear quickly. If tracks are not tight enough, they wear quickly and the links can catch on the sprocket wheel or slide off the idler wheel or the sprocket wheel. Clean the tracks after work.

IMPORTANT: For rubber tracks (Optional), avoid pivoting on the spot as this could cause the tracks to wear out quickly and could also cause jamming of stones, rocks, etc. Avoid working in an area full of rock rubble or debris, pieces of reinforced concrete or striated plates.

CLEANING

When the machine has been working in mud, a reduction in temperature can cause the mud to solidify.


1. Place the upperstructure at right angles to the undercarriage. Use the attachment to press on the ground and lower the boom until the track is raised off the ground.



CT02D176

Figure 1

2. Put the engine throttle button (1) on the maximum speed position and select the fast speed (2).




CT02D156

Figure 2

3. Operate the travel control lever for the raised track forwards and then in reverse, to remove the mud.
4. Repeat Steps 1 to 4 for the other track.

NOTE: For machines fitted with the dozer blade, the machine can be lifted by completely lowering the blade and by using the attachment as a support on the ground, opposite the blade.




CT02C063

Figure 3

CHECKING THE TENSION


1. Park the machine on flat, horizontal ground.
2. Clean the tracks.
3. Place the upperstructure at right angles to the undercarriage. Use the attachment to press on the ground and lower the boom until the track is raised off the ground.



CT02D176

Figure 4

4. Use the travel control lever to operate the raised track in reverse for a few moments.
5. Stop the engine and remove the starter switch key.




CT02C063

Figure 5

6. Measure the slack between the base of the undercarriage and the upper part of the track tread. See Track tension value.
7. Adjust the tension if necessary and then lower the raised track to the ground.
8. Repeat Steps 3 to 7 for the other track.

NOTE: For machines fitted with the dozer blade, the machine can be lifted by completely lowering the blade and by using the attachment as a support on the ground, opposite the blade.



CT02D176A


Figure 6

ADJUSTING THE TENSION

This operation is to be carried out after the tension has been checked.

TO INCREASE TENSION

1. With the track raised, clean the grease fitting adaptor and the grease fitting.
2. Connect the grease pump. Inject grease to obtain the right amount of track sag. See Track tension value.
3. Remove the grease pump and clean the grease fitting.
4. Repeat Steps 1 to 3 for the other track.



CT02D177

Figure 7

TO REDUCE TENSION

1. With the track in raised position, loosen the grease fitting adaptor about three turns to allow grease to flow out of the cylinder.




WARNING: Never unscrew the grease fitting adaptor completely to speed up the flow of grease. The grease in the cylinder is under high pressure.

2. As soon as the right track sag is obtained, tighten the adaptor. See Track Tension Value.

3. Clean the grease adaptor and fitting and then lower the raised track to the ground.
4. Repeat Steps 1 to 3 for the other track.

IMPORTANT: *If the grease fitting adaptor is damaged, grease may leak out. Check the condition of the grease fitting adaptor regularly and replace it if necessary.*



CT02D178

Figure 8

TRACK TENSION VALUE

The value (A) should be between:

Machines	CX75SR, CX80	CX135SR
Rubber tracks	125 - 135 mm (4.9 - 5.3 in)	
Steel tracks	180 - 205 mm (7.0 - 8.0 in)	240 - 269 mm (9.4 - 10.5 in)
Rubber tracks and steel chains	160 - 185 mm (6.2 - 7.2 in)	


TIGHTENING TORQUE OF THE TRACK SHOE

The tightening torque of the bolts should be between:

CX75SR, CX80 = 220 to 270 Nm (162 to 199 ft. lb.)

CX135SR = 390 to 430 Nm (287 to 317 ft. lb.)

Follow the prescribed order.




CS00E504

Figure 9

CHECKING THE CONDITION OF RUBBER TRACKS (IF EQUIPPED)

Replace the tracks in any of the following cases:

- The grousers (1) are worn out, $A = 5 \text{ mm min.}$
- The steel layer (2) is visible or broken.
- The metal hubs (3) are visible or worn out.



CS98A190


Figure 10

REPLACING THE RUBBER TRACKS (CX75SR, CX80 IF EQUIPPED)

REMOVAL

1. Slacken the track tension completely. See Adjusting the tension.
2. Place the upperstructure at right angles to the undercarriage. Use the attachment to press on the ground and lower the boom until the track is raised off the ground.

NOTE: For machines fitted with the dozer blade, the machine can be lifted by completely lowering the blade and by using the attachment as a support on the ground, opposite the blade.




CT02D176

Figure 11

3. Place the tubes in the notches of the track in front of the idler wheel.


WARNING: Make sure that the tension cylinder is completely slackened before undertaking any operation.



CS98B208

Figure 12


4. Operate the travel lever of the concerned track in the reverse travel direction. Stop the movement when the tubes are pressing against the idler wheel.
5. Stop the engine and remove the starter switch key.



CS98B209

Figure 13

6. Remove the track.




CS98B246

Figure 14

INSTALLATION


1. Place the track on the sprocket wheel and on the side-member.



CS98B246

Figure 15


2. Place the tubes in the notches of the track in front of the idler wheel.



CS98B247

Figure 16


3. Operate the travel lever of the track concerned in the reverse travel direction. Stop the movement when the tubes are pressing against the idler wheel.
4. Stop the engine and remove the starter switch key.



CS98B248

Figure 17


5. Place the track on the idler wheel.



CS98B209

Figure 18

6. Operate the travel lever of the concerned track to remove the tubes from the track.
7. Adjust the tension. See Track tension value.



CS98B249

Figure 19


TRACK ROLLERS AND IDLER WHEELS

MAINTENANCE SPECIFICATION

CheckEvery 250 hours

The upper (1) and lower rollers (2) and idler wheels (3) use a permanent floating seal type sealing mechanism. The service life normally lasts until overhaul, but check visually from time to time before work for oil leakage. If oil leakage is found, component replacement is necessary. See your Dealer.


CX75SR, CX80



CT02D180

Figure 20

CX135SR



CT02D181

Figure 21

RADIATOR AND OIL COOLER

MAINTENANCE SPECIFICATIONS

Check for leakage..... Every 10 hours or every day
 CleanEvery 250 hours

CLEANING

Shut down the engine, remove the starter switch key, open the rear left-hand side door and the engine hood.

Make sure your face is protected before using compressed air.


Clean the radiator and the oil cooler:

Dry dust: use compressed air.

Mud: use a water jet.

Greasy dust: use perchlorethylene.


The use of trichlorethylene is strictly forbidden.



WARNING: Before any travel operation make sure that the locking of the engine hood is correct.


CX75SR, CX80

1. Loosen the six wing nuts (1) and remove the three protective grilles (2) to access the radiator.
2. Install the grilles (2) and the wing nuts (1) then close the engine hood and the rear left-hand side door.



CT02D187

Figure 22




CT02D037

Figure 23


CX135SR

1. Loosen the four wing nuts (1) and remove the two protective grilles (2) to access the radiator.
2. Install the grilles (2) and the wing nuts (1) then close the engine hood and the rear left-hand side door.



CT02D195

Figure 24



CT02D036

Figure 25

FAN AND ALTERNATOR DRIVE BELT

MAINTENANCE SPECIFICATIONS


Visual check Every 10 hours or every day
 Check belt tension Every 250 hours

CHECKING THE TENSION

Use your finger to exert pressure of around 10 kg on the centre of the drive belt. The tension slack should be between about 8 and 12 mm (.3 to .4 in).

NOTE: Check if there are any signs of wear damage to the pulleys or the belt. Check carefully to ensure that the belt is correctly positioned in the pulley grooves. If the belt is stretched, cracked or frayed, it must be replaced.

IMPORTANT: If the engine runs with the belt slack, the belt can slip in its housing and cause the engine to overheat or the battery to receive insufficient charge.




CS98M560 Figure 26

ADJUSTING THE TENSION

Remove the mounting bolts (1). Use the adjustment screws (2) to move the alternator outwards until belt tension is correct. Tighten the alternator mounting bolts (1).

CX75SR, CX80


Only one belt.



CT02D201 Figure 27

CX135SR


Two belts.



CS99A852 Figure 28


REPLACING THE BELT

If one or more belts break, the battery load indicator lights up on the instrument panel. Shut down the engine, remove the starter switch key and change the belt.



CT02D204

Figure 29




CS99A852

Figure 31

CX75SR, CX80

1. Remove the mounting bolts (1). Use the adjustment screws (2) to push the alternator inwards.
2. Remove the belts that are worn out.
3. Install one or two new belts.
4. Adjust the belts using the screw (2).
5. Tighten the mounting bolts (1).
6. Run the engine for about an hour and then check the belt tension again.



CT02D201

Figure 30

CX135SR

IMPORTANT: *The two belts have to be changed at the same time.*

1. Remove the mounting bolts (1). Use the adjustment screws (2) to push the alternator inwards.
2. Remove the belts that are worn out.
3. Install one or two new belts.
4. Adjust the belts using the screw (2).
5. Tighten the mounting bolts (1).
6. Run the engine for about an hour and then check the belt tension again.

FUEL TANK FILTER


MAINTENANCE SPECIFICATION

Clean filterPeriodically

NOTE: To refill the fuel tank, see *Fluids and lubricants in the Lubrication/Filters/Fluids section.*

CX75SR, CX80

Remove the filter and clean it in diesel oil.




CT02D227

Figure 32

CX135SR

Remove the filter and clean it in diesel oil.



CT02D228

Figure 33

INSPECTING AND CLEANING THE MACHINE

MAINTENANCE SPECIFICATIONS

Inspect and cleanPeriodically

Or whenever oil or grease has been spilled on the machine. Clean off with steam or a high pressure water jet.

Look for any leaks and check the condition of all pipes and hoses.

Take the opportunity during this operation to make a visual check of all the welded components (in case of appearance of cracks), the attachment linkages and check the teeth and tooth tips for correct retention and for wear.

CHECKING FOR CYLINDER LEAKAGE


ROD APPEARANCE	TEST	CONCLUSION
Dry	Slight traces of oil when a piece of paper is wiped over 20 ^{cm} of the rod.	Normal
Slightly greasy	Paper remains stuck to rod when run over rod.	Normal
Oily	Paper remains stuck when placed on rod.	Normal
Very oily or weeping	Each time the cylinder rod is extended, a ring of oil can be seen on the rod.	See your Dealer
Leakage	Each time the rod retracts, the excess oil drips from the gland.	

A cylinder rod should be slightly oily. Check that there are no leaks after a period of work, when the whole hydraulic system is at normal operating temperature.

1. Wipe clean the rod and bearing on the cylinder to be cleaned.
2. Operate normally for five or ten minutes.
3. Extend the cylinder rod.
4. Carry out the leak test.

REPLACING A BUCKET - CX75SR, CX80**REMOVAL**


1. Place the bucket flat on flat, horizontal ground. Operate the attachment controls so that the arm/bucket linkage pin is not gripped by the weight of the arm.
2. Stop the engine and remove the starter switch key.
3. Remove the snap rings and retaining pins then remove the pins from the bucket.
4. Start the engine.
5. Disengage the attachment from the bucket and save the linkage seals.



CT02E005

Figure 34

5. Install the connecting rod/bucket linkage pin then the retaining pins and the snap rings.
6. Push the seals back into their housings.
7. Grease the linkage pins.




CT02E005B

Figure 36

INSTALLATION

1. Install the linkage seals on the arm bushing shoulders. Change them if necessary.
2. Start the engine. Extend the bucket cylinder rod to bring it into its housing. Stop the engine and remove the starter switch key.
3. Install the arm/bucket linkage pin, then the retaining pins and the rings.



CT02E005A


Figure 35

4. Start the engine. Remove the bucket cylinder rod to bring it in its housing, shut down the engine and remove the starter switch key.

REPLACING A BUCKET - CX135SR

REMOVAL


1. Place the bucket flat on flat, horizontal ground. Operate the attachment controls so that the arm/bucket linkage pin is not gripped by the weight of the arm.
2. Stop the engine and remove the starter switch key.
3. Remove the retaining rings and pins.



CT02D210

Figure 37


4. Remove the bucket pins.



CT02D211

Figure 38

5. Start the engine, disengage the attachment from the bucket and save the linkage seals for re-use.




CT02D212

Figure 39

INSTALLATION


1. Make sure the bucket is in a stable position.
2. Install the linkage seals on the arm bushing shoulders. Change them if necessary.
3. Start the engine. Extend the bucket cylinder rod to bring it into its housing. Stop the engine and remove the starter switch key.



CT02D212

Figure 40


4. Install the arm/bucket linkage pin and then install the retaining pin and ring.
5. Start the engine. Stop the engine and remove the starter switch key.



CT02D213

Figure 41

6. Install the connecting rod/bucket linkage pin and then install the retaining pin and ring.
7. Push the seals back into their housings.
8. Grease the linkage pins.



CT02D210

Figure 42

FIRE EXTINGUISHER (NOT SUPPLIED)


It is strongly recommended to have a fire extinguisher and to place it in the rear left-hand side compartment in the bracket designed for the purpose.

MAINTENANCE SPECIFICATION

Every month examine the fire extinguisher and make sure it is not damaged.

Every six months have an approved specialist empty and refill the powder in the fire extinguisher.

Every year have an approved specialist examine the fire extinguisher.



CS98M573


Figure 43

WELDING ON THE MACHINE

Whenever carrying out a welding operation on the undercarriage or upperstructure carriage as authorized by the manufacturer and in accordance with his instructions, disconnect the batteries, disconnect the alternator B+ and D+ terminal wires, and connect the welding apparatus ground cable to the component on which the welding operation is to be performed.

Never connect the welding apparatus to the undercarriage when welding on the upperstructure (or vice-versa).

Never connect the welding apparatus ground to a component of the hydraulic system.

	<p>WARNING: <i>Any unauthorized modifications made to this machine can cause serious injury. Do not undertake any modifications without first consulting your Dealer.</i></p>
---	--

PLASTIC AND RESIN PARTS

When cleaning the plastic windows, the console, the instrument panel, the indicators, etc. do not use gasoline, kerosene, paint solvents, etc. Only use water, soap and a soft cloth.

The use of gasoline, kerosene, paint solvents, etc. will cause discoloration, cracks or deformation of these parts.

AIR CONDITIONING

MAINTENANCE SPECIFICATION

Clean the intake filter	Every 50 hours
Clean the air recycling filter	Every 50 hours
Have checked by a specialist.....	Every 6 months

The components of the air conditioning system need servicing at regular intervals. Make sure these intervals are respected, in order to ensure the air conditioning functions correctly and with maximum effectiveness. The air conditioning system contains gas which is subject to strict legislation. Any defect in the system must be fixed rapidly.



WARNING

Never try to service the air conditioning system yourself. For any service work, consult your Dealer.

Operate the air conditioning system at least once a week, if only for a short time. See "Heating, ventilation or air-conditioning" in the "Controls/Instruments/Accessories" section.

INSPECTION


In order to ensure the air conditioning functions correctly, inspect the air conditioner using the procedure outlined below before starting work.

CLEANLINESS OF THE CONDENSER

If the condenser is dirty it will not dissipate heat properly. Clean the condenser in water.

Never use water under pressure to clean the condenser.

CHECKING THE BELT TENSION




CT02D230

Figure 44

Use your finger to exert pressure of around 10 kg (20 lbs) on the centre of the drive belt (1). The tension slack should be between about 8 and 10 mm (1/4 to 1/2 in). If necessary, adjust the belt tension.

Tension Adjustment



CT02D230


Figure 45

1. Loosen the pulley mounting bolt (1).
2. Use the adjustment screw (2) to move the pulley outward until belt tension is correct and tighten pulley mounting bolt (1).

CHECKING THE LINES


Make a visual check of the lines and make sure there are no accumulations of dust, grease, etc.

CLEANING THE AIR INTAKE AND AIR RECYCLING FILTERS



CT02D231 Figure 46


1. Remove the screws and the cover plate located under the operator's seat.



CT02D233 Figure 47

2. Take out the filters (1) and (2). Use compressed air to clean the filters. If they are damaged, replace them.


IMPORTANT: Always protect your face before using compressed air.



CT02D232 Figure 48

Put the filters (1) and (2) in their respective housings and install the cover plate shown in figure 46.

CHECKING THE CHARGE STATE OF THE SYSTEM



CT02D234 Figure 49

1. Turn on the air conditioning system, increase engine speed slightly (1400 to 1600 rpm) and look for bubbles through the sight glass (1).
2. This check should be made approximately one minute after turning on the air conditioning.
 - A. Very few bubbles observed, then transparent at first, then whitish: "Normal".
 - B. The bubbles are numerous: check the unions and consult your Dealer.
 - C. No bubbles are visible: check the unions and consult your Dealer.

Check if the hydraulic line and air-conditioning hose connectors are dirty, dusty or in need of replacing.

PLASTIC AND RESIN PARTS

When cleaning the plastic windows, the console, the instrument panel, the indicators, etc. do not use gasoline, kerosene, paint solvents, etc. Only use water, soap and a soft cloth.

The use of gasoline, kerosene, paint solvents, etc. will cause discoloration, cracks or deformation of these parts.

HARDWARE TORQUE INSPECTION**MAINTENANCE SPECIFICATION**

CheckEvery 250 hours
(after the first 50 hours during the run-in period)

At the end of each working day, check all mounting nuts and screws for tightness and tighten if necessary. Make sure no hardware items are missing. Replace them, if necessary.

(CX75SR, CX80)

Component	Screw (Ø)	Wrench (mm)	Torque setting (Nm)
Travel reduction gear (*)	M16	24	267-312
Drive sprocket (*)	M14	22	173-202
Idler wheel (*)	M10	17	62-73
Upper roller (*)	M16	24	267-312
Lower roller (*)	M20	30	521-608
Track shoe	M16	24	220-270
Counterweight	M14	22	220-270
Turntable (undercarriage)	M24	36	850-992
Turntable (upperstructure)	M16	24	252-283
Swing reduction gear (*)	M16	24	273-317
Engine (*)	M16	24	265-313
Engine mounts (*)	M10	17	64-74
Radiator	M10	17	64-74
Hydraulic pump (*)	M10 M12	17 Male	63-73 109-126
Hydraulic reservoir (*)	M12	19	69-78
Fuel tank (*)	M10	17	36-44
Control valve (*)	M12	19	53-64
Hydraulic swivel (*)	M10	17	63-73
Cab	M16	24	78-80
Batteries	M10	17	20-29

NOTE: Use Loctite 262, or the equivalent, on screws marked (*).

(CX135SR)

Component	Screw (Ø)	Wrench (mm)	Torque setting (Nm)
Travel reduction gear (*)	M16	24	267-312
Drive sprocket (*)	M16	24	173-202
Idler wheel (*)	M16	24	267-312
Upper roller (*)	M16	24	267-312
Lower roller (*)	M16	24	267-312
Track shoe	M16	24	390-430
Counterweight	M30	46	1335-1550
Turntable (undercarriage)	M16	24	280-322
Turntable (upperstructure)	M16	24	280-322
Swing reduction gear (*)	M16	24	280-322
Engine (*)	M16	24	265-313
Engine mounts (*)	M10	17	64-74
Radiator	M12	19	64-74
Hydraulic pump (*)	M10 M12	17 Male	63-73 88-111
Hydraulic reservoir (*)	M16	24	233-276
Fuel tank (*)	M16	24	233-276
Control valve (*)	M16	24	267-312
Hydraulic swivel (*)	M12	19	109-127
Cab	M16	24	78-80
Batteries	M10	17	20-29

NOTE: Use Loctite 262, or the equivalent, on screws marked (*).

NOTES

Chapter 7
ELECTRICAL

TABLE OF CONTENTS

FUSES 7-3
 Function Of The Fuses - CX75SR, CX80 7-4
 Function Of The Fuses - CX135SR 7-4

BATTERY 7-5
 Maintenance Specification 7-5
 Access to The Batteries 7-5
 Checking A Battery 7-6
 Replacing A Battery - CX75SR, CX80 7-6
 Replacing the Batteries - CX135SR 7-7

CONNECTING ONE OR TWO BOOSTER BATTERIES 7-8

ALTERNATOR 7-8
 Maintenance Specification 7-8

STARTER MOTOR 7-8
 Maintenance Specification 7-8

REPLACING A BULB 7-9
 Operator's Compartment Lighting 7-9
 Working Lights On The Cab and On The Attachment 7-9

ADJUSTING THE WORKING LIGHTS 7-10
 Cab 7-10
 Attachment 7-10

NOTES

FUNCTION OF THE FUSES - CX75SR, CX80

FUSE	AMP	FUNCTION
1	10	Memory
2	10	Key switch
3	20	Air conditioning, heater
4	10	Overload indicator controller
5	20	Working lights
6	10	Swing brake relay
7	10	Not used
8	15	Windshield wiper/washer
9	10	Horn
10	15	2 flow breaker/grab option
11	15	Accelerator motor
12	15	Cigarette lighter
13	10	Air-conditioning (optional) and instrument panel lighting
14	10	Rotary light relay
15	10	Hydraulic control cancellation
16	20	Optional power connector
17	10	Travel mode relay
18	10	Fuel filling pump (optional)
19	10	Optional power connector
20	10	Optional power connector

FUSE LOCATION - CX75SR, CX80

①	10A	15A	⑪
②	10A	15A	⑫
③	20A	10A	⑬
④	10A	10A	⑭
⑤	20A	10A	⑮
⑥	10A	20A	⑯
⑦	10A	10A	⑰
⑧	15A	10A	⑱
⑨	10A	10A	⑲
⑩	15A	10A	⑳

CT02D248

Figure 3

FUNCTION OF THE FUSES - CX135SR

FUSE	AMP	FUNCTION
1	10	Memory
2	10	Key switch
3	20	Air conditioning, heater
4	10	Overload indicator controller
5	20	Working lights
6	10	Swing brake relay
7	10	Not used
8	15	Windshield wiper/washer
9	10	Horn
10	15	2 flow breaker/grab option
11	15	Engine electronic box
12	15	Operator's seat compressor (optional)
13	10	Air-conditioning (optional) and instrument panel lighting
14	10	Rotary light relay
15	10	Hydraulic control cancellation
16	30	Glow plugs
17	10	Travel mode relay
18	10	Fuel filling pump (optional)
19	10	DC-DC (24 V - 12 V) converter
20	15	Engine emergency shut down

FUSE LOCATION - CX135SR

①	10A	15A	⑪
②	10A	15A	⑫
③	20A	10A	⑬
④	10A	10A	⑭
⑤	15A	10A	⑮
⑥	10A	30A	⑯
⑦	10A	10A	⑰
⑧	15A	20A	⑱
⑨	10A	10A	⑲
⑩	15A	15A	⑳

CT02E010

Figure 4

BATTERY

MAINTENANCE SPECIFICATION

Checking the charge state Every 50 hours

NOTE: If the machine needs to be started using a booster battery, see *Connecting One Or Two Booster Batteries*.

WARNING: Batteries give off explosive gases. Keep all open flames, sparks and cigarettes away. Ensure adequate ventilation when charging batteries or when using in a confined place. Always protect your eyes when working near batteries.

WARNING: Do not reverse battery terminals. Connect positive cable ends to positive (+) terminals and negative cable ends to negative terminals (-).

WARNING: Before you service a battery, always wear face protection, protective gloves and protective clothing. Battery acid or battery explosion can cause serious injuries.

SA046

WARNING: Battery acid causes severe burns. Batteries contain sulfuric acid. Avoid contact with skin, eyes or clothing. Antidote - EXTERNAL: flush with water. INTERNAL: drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Call physician immediately. EYES: flush with water for 15 minutes and get prompt medical attention.

SB032

WARNING: When the battery electrolyte is frozen, the battery can explode if, (1) you try to charge the battery, or (2) you try to jump start and run the engine. To prevent the battery electrolyte from freezing, try to keep the battery at full charge. If you do not follow these instructions, you or others in the area can be injured.

SA033

WARNING: Before any operation on the components of the electrical circuit, put the key switch in the shut down position. When disconnecting the battery cables, always disconnect the negative (-) cable first. When reconnecting the battery cables, always connect the negative (-) cable last.

WARNING: Connecting auxiliary cables wrongly or short-circuiting batteries terminals can cause an accident. Connect auxiliary starting cables as per the following instructions.

WARNING: Sparks or flame can cause hydrogen gas in a battery to explode. To prevent an explosion, do the following:

1. When you DISCONNECT the battery cables, always disconnect the negative (1) battery cable first.
2. When you CONNECT the battery cables, always connect the negative (-) cable last.
3. Do not short circuit the battery posts with metal items.
4. Do not weld, grind, or smoke near a battery.

SB034


WARNING: Always store batteries in a safe place, out of the reach of children.

ACCESS TO THE BATTERIES

To access the batteries, open the rear left-hand side door.

CX75SR, CX80 - ONE BATTERY

Lift the protective mat from the battery.



CT02D251

Figure 5

CX135SR - TWO BATTERIES

Remove the thumb screw, the washer and the protective matting from the batteries.




Figure 6

CHECKING A BATTERY

Make sure the battery terminals are clean and coated with grease and that the cables are properly tightened.

Checking the charging state and the electrolyte level is carried out using the indicator:

- Green: Normal.
- Black: Recharge the battery.
- White: Change the battery.




Figure 7

**REPLACING A BATTERY - CX75SR, CX80
REMOVAL**

1. Remove the terminal sleeves, disconnect the cable (negative terminal) then the cable (positive terminal).




Figure 8

2. Remove the nuts, the washers and the angle iron.




Figure 9

3. Remove the battery using the handle.
4. Clean the battery compartment, remove all foreign bodies, clean any spilled electrolyte.





Figure 10

INSTALLATION

1. Install a new battery. Clean the cables and battery terminals and coat them with grease.
2. Install the angle iron, the washers and tighten the nuts.
3. Connect the cable (positive terminal), the cable (negative terminal) then install the terminal sleeves.

WARNING: Do not invert battery terminals. Connect positive cable ends to positive (+) terminals and negative cable ends to negative terminals (-).

WARNING: Always store batteries in a safe place, out of the reach of children.




CT02D260

Figure 11

**REPLACING THE BATTERIES - CX135SR
REMOVAL**


1. Remove the terminal sleeves, disconnect the cables (negative terminal) then the cables (positive terminal).



CT02D254

Figure 12


2. Remove the nuts, the washers and the holding frame.



CT02D254

Figure 13

3. Remove the batteries using the handles.
4. Clean the battery compartment, remove all foreign bodies, clean any spilled electrolyte.




CT02D254

Figure 14

INSTALLATION


1. Install new batteries. Clean the cables and battery terminals and coat them with grease.
2. Install the holding frame, the washers and tighten the nuts.
3. Connect the cables (positive terminal), the cables (negative terminal) then install the terminal sleeves.



CT02D254

Figure 15

CONNECTING ONE OR TWO BOOSTER BATTERIES

 **WARNING:** *Connecting auxiliary cables wrongly or short-circuiting batteries terminals can cause an accident. Connect auxiliary starting cables as per the following instructions.*

Ask your Dealer to check the starter motor.

NOTE: *Make sure that the terminal protectors are correctly installed.*


Make sure that the booster battery voltage corresponds to the voltage system of the machine.

1. Remove the protective mat, if necessary.
2. Remove the terminal sleeves.
3. Connect the positive (+) auxiliary cable to the positive (+) terminal of the battery or the first battery of the machine.
4. Connect the negative (-) auxiliary cable to the negative (-) terminal of the battery or the second battery of the machine.
5. Start the engine.
6. Disconnect the negative (-) auxiliary cable then the positive (+) auxiliary cable from the booster batteries.
7. Install the terminal sleeves.
8. Install the protective mat, if necessary.

ALTERNATOR

MAINTENANCE SPECIFICATION

Check Every 1000 hours

 **WARNING:** *Whenever carrying out a welding operation on the machine (authorized by the manufacturer and in accordance with his instructions) or any repairs on the electrical system, disconnect the B+ and D+ wires from the alternator. When reconnecting, check the markings on the wires.*

Do not use steam cleaning equipment or a cleaning solvent to clean the alternator.

Ask your Dealer to check the alternator.

Make sure that the terminal protectors are correctly installed.

STARTER MOTOR


MAINTENANCE SPECIFICATION

Check Every 1000 hours

REPLACING A BULB

OPERATOR'S COMPARTMENT LIGHTING


1. Remove the cover.



CT02C058

Figure 16

2. Remove the bulb and install a bulb of the same wattage (6 W).
3. Install the lens.




CT02D267

Figure 17

WORKING LIGHTS ON THE CAB AND ON THE ATTACHMENT


1. Remove the 4 retaining screws.



CT02D261

Figure 18

2. Tilt the working light and disconnect the plug.



CT02D262

Figure 19


3. Pull the clip outwards, remove the bulb and install a bulb of the same wattage:

CX75SR, CX80: 55 W for lights on the cab and on the attachment.

CX135SR: 55 W for lights on the cab and 70 W for light on the attachment.

IMPORTANT: *Never put your fingers on a tungsten iodide bulb.*

4. Install the clip and reconnect the plug.
5. Put the working light back into position and install the mounting screws.




CT02D263

Figure 20

ADJUSTING THE WORKING LIGHTS

CAB

Cab working lights are adjusted manually.




CT02D265

Figure 21

ATTACHMENT

Attachment working lights are adjusted manually.



CT02D264

Figure 22

Chapter 8 SPECIFICATIONS

TABLE OF CONTENTS

ENGINES	8-3
CX75SR, CX80	8-3
CX135SR	8-3
ELECTRICAL SYSTEMS	8-3
CX75SR, CX80	8-3
CX135SR	8-3
HYDRAULIC SYSTEM - CX75SR, CX80	8-4
Control Valves	8-4
Swing	8-4
Travel	8-4
HYDRAULIC SYSTEM - CX135SR	8-4
Control Valves	8-4
Swing	8-4
Travel	8-4
UNDERCARRIAGE - CX75SR, CX80	8-5
UNDERCARRIAGE - CX135SR	8-5
CAPACITY OF SYSTEMS AND COMPONENTS	8-6
CX75SR, CX80	8-6
CX135SR	8-6
WEIGHTS	8-6
CX75SR, CX80	8-6
CX135SR	8-6
GROUND PRESSURE	8-6
BOOMS	8-6
ARMS	8-7
ESCO BUCKETS	8-8
CX75SR, CX80	8-8
CX135SR	8-8
MACHINE OVERALL DIMENSIONS - CX75SR	8-9
MACHINE OVERALL DIMENSIONS - CX80	8-10
MACHINE OVERALL DIMENSIONS - CX135SR	8-11
WORKING RANGE - CX75SR	8-12
WORKING RANGE - CX80	8-15
WORKING RANGE - CX135SR	8-16
LIFTING CAPACITIES	8-19
cx75sr with 1.71 m (5 ft. 7 in) arm	8-19
cx75sr with 2.12 m (6 ft. 11 in) arm	8-19
cx75sr with 1.75 m (5 ft. 9 in) arm with offset boom	8-19
cx135sr with 2.39 m (7 ft. 10 in) arm	8-20
cx135sr with 2.85 m (9 ft. 4 in) arm	8-20

ENGINES

CX75SR, CX80

Make ISUZU
 Type CC-4JG1
 Number of cylinders 4
 Bore/stroke 95.4mm x 107 mm (3.76" x 4.21")
 Displacement 3059 cm3 (187 CID)
 Power EEC 80/1269 39.1 kW/53 HP
 Speed rating 2100 rpm

CX135SR

Make ISUZU
 Type BB-4BG1T
 Turbo yes
 Electronically controlled injection
 Number of cylinders 4
 Bore/stroke 105 mm x 125 mm (4.13" x 4.92")
 Displacement 4329 cm3 (264 CID)
 Power EEC 80/1269 65.6 kW/89 HP
 Speed rating 2100 rpm

ELECTRICAL SYSTEMS

CX75SR, CX80

Circuit 12 volts
 Battery 1 x 12 volts/72 Ah
 Alternator 50 A

CX135SR

Circuit 24 volts
 Batteries 2 x 12 volts/64 Ah
 Alternator 24 volts/50 Ah
 Circuit fitted with watertight connectors.

HYDRAULIC SYSTEM - CX75SR, CX80

Variable flow double pumps, with axial pistons supplying the attachments, the swing and the travel.

Main pump max flow 2 x 71.4 l/min. (2 x 18.9 gpm)

Single pump supplying the dozer blade

Dozer blade pump max flow 25.4 l/min. (6.7 gpm)

Safety valves pressure

Attachments 294 bar (4,264 psi)

Swing 226 bar (3,277 psi)

Travel 294 bar (4,264 psi)

Dozer blade 226 bar (3,277 psi)

CONTROL VALVES

Five control valve sections for left-hand travel, boom, arm, auxiliary circuit and swing acceleration.

Four control valve sections for right-hand travel, boom, arm and bucket acceleration.

(CX75SR) Two sections for dozer blade and offset boom.

(CX80) Two sections for dozer blade and equipment offset.

Boom/arm load holding valves.

SWING

Fixed flow, piston-type pump.

upperstructure swing speed 10 rpm

TRAVEL

Variable flow hydraulic motors with axial pistons.

Planetary reduction gears.

Two speeds controlled from the instrument panel.

Low speed 0 to 3.4 km/h (0 to 2.1 mph)

High speed 0 to 4.9 km/h (0 to 3 mph)

HYDRAULIC SYSTEM - CX135SR

Variable flow double pump with axial pistons.

Max flow 2 x 117.2 l/min. (2 x 30.9 gpm)

Safety valve max pressure.

Attachment 343 bar (4,974 psi)

upperstructure swing 280 bar (4,061 psi)

Travel 343 bar (4,974 psi)

CONTROL VALVES

Four control valve sections for left-hand travel, boom/bucket and arm acceleration.

Five control valve sections for right-hand travel, swing, arm, auxiliary attachment and boom acceleration.

Boom/arm load holding valves.

SWING

Fixed flow, piston-type pump.

Max upperstructure swing speed 10 rpm

TRAVEL

Variable flow hydraulic double motors with axial pistons.

Planetary reduction gears, automatic multiple disk brake.

Two speeds controlled from the instrument panel.

Low speed 0 to 3.2 km/h (0 to 1.9 mph)

High speed 0 to 5 km/h (0 to 3.1 mph)

UNDERCARRIAGE - CX75SR, CX80

SPECIFICATIONS PER TRACK ASSEMBLY

Number of upper rollers	1
Number of lower rollers	5
Number of track pads	39
Type of track pads	Triple lobe
Width of standard track pads.....	450 mm (17.7 in)
Rubber tracks	optional
Grade ability	70%

DOZER BLADE

Width	2.32 m (7 ft. 6 in)
Height.....	0.45 m (1 ft. 4 in)
Maximum elevation height.....	0.41 m (1 ft. 3 in)
Maximum depth below ground level	0.20 m (6 in)

UNDERCARRIAGE - CX135SR

SPECIFICATIONS PER TRACK ASSEMBLY

Number of upper rollers	1
Number of lower rollers	6
Number of track pads	43
Type of track pads	Triple lobe
Width of standard track pads.....	600 mm (23.6 in)
Grade ability	70%

DOZER BLADE (IF EQUIPPED)

Width	2.59 m (8 ft. 4 in)
Height.....	0.57 m (1 ft. 8 in)
Maximum elevation height.....	0.44 m (1 ft. 4 in)
Maximum underground depth	0.52 m (1 ft. 7 in)

CAPACITY OF SYSTEMS AND COMPONENTS

CX75SR, CX80

Hydraulic reservoir.....	50 liters (13 gal)
Hydraulic system	95 liters (25 gal)
Travel reduction gear (each)	1.3 liters (0.3 gal)
Engine (with filter change)	9.6 liters (2.5 gal)
Fuel reservoir.....	100 liters (26 gal)
Cooling system	9.6 liters (2.5 gal)

CX135SR

Hydraulic reservoir.....	81 liters (21 gal)
Hydraulic system	125 liters (33 gal)
Travel reduction gear (each)	2.5 liters (0.7 gal)
Swing reduction gear.....	3 liters (0.8 gal)
Engine (with filter change)	15 liters (4.0 gal)
Fuel reservoir.....	165 liters (44 gal)
Cooling system	17.7 liters (4.7 gal)

WEIGHTS

CX75SR

With 450 mm (17.7 in) shoes, monobloc boom, 1.70 m (5 ft. 7 in) arm, 210 kg (460 lb.) bucket, 1 220 kg (2 690 lb.) counterweight, operator and full fuel tank.....	7660 kg (16 900 lbs)
With 450 mm (17.7 in) shoes, offset boom, 1.75 m (5 ft. 9 in) arm , 210 kg (460 lb.) bucket, 1 220kg (2 690 lb.) counterweight, operator and full fuel tank.....	8060 kg (17 800 lb.)

CX80

With 450 mm (17.7 in) track pads, one-piece boom, 1.70 m (5 ft. 6 in) dipper, backhoe bucket, operator and full fuel tank.....	8 350 kg (18 408 lb.)
--	-----------------------

CX135SR

With 600 mm (23.6 in) shoes, monobloc boom, 2.40 m (7 ft. 10 in) arm , 380 kg (840 lb.) bucket, 3 330 kg (7 340 lb.) counterweight, operator and full fuel tank	13 200 kg (29 100 lb.)
--	------------------------

GROUND PRESSURE

CX75SR

With 450 mm (17.1 in) track pads , monobloc boom, 1.70 m (5 ft. 6 in) arm, backhoe bucket, operator and full fuel tank	0.34 bar (4.93 psi)
--	---------------------

CX80

With 450 mm (17.7 in) track pads, monobloc boom, 1.70 m (5 ft. 6 in) dipper, backhoe bucket, operator and full fuel tank.....	0.36 bar (4.93 psi)
---	---------------------

CX135SR

With 600 mm (23.6 in) track pads , monobloc boom, 2.40 m (7 ft. 9 in) arm, 380 kg (838 lb.) backhoe bucket, operator and the full fuel tank	0.36 bar (4.93 psi)
---	---------------------

BOOMS

CX75SR

Monobloc (length).....	3.87 m (12 ft. 8 in)
Offset boom	3.92 m (12 ft. 10 in)

CX80

Offset boom	3.92 m (12 ft. 10 in)
-------------------	-----------------------

CX135SR

Monobloc (length)4.75 m (15 ft. 6 in)

ARMS

CX75SR

Length..... 1.70 m (5 ft. 7 in), and 2.12 m (6 ft. 11 in)

Offset arm.....1.75 m (5 ft. 9 in)

CX80

Offset arm..... 1.70 m (5 ft. 7 in), and 2.10 m (6 ft. 9 in)

CX135SR

Length..... 2.40 m (7 ft. 10 in) and 2.85 m (9 ft. 4 in)

ESCO BUCKETS**CX75SR, CX80**

STDP			
CAPACITY	.24 cu. yd.	.35 cu. yd.	.45 cu. yd.
WIDTH OUTSIDE LIP	18 in (457 mm)	24 in (610 mm)	30 in (762 mm)
WEIGHT	403 lb. (183 kg)	473 lb. (215 kg)	542 lb. (246 kg)

DITCH	
CAPACITY	.61 cu. yd.
WIDTH OUTSIDE LIP	42 IN (1 067 mm)
WEIGHT	596 lb. (270 kg)


CX135SR

STDP				
CAPACITY	.50 cu. yd.	.66 cu. yd.	.82 cu. yd.	.98 cu. yd.
WIDTH OUTSIDE LIP	24 in (610 mm)	30 in (762 mm)	36 in (914 mm)	42 in (1 067 mm)
WEIGHT	791 lb. (351 kg)	889 lb. (359 kg)	1 007 lb. (457 kg)	1 110 lb. (503 kg)

HDP				
CAPACITY	.50 cu. yd.	.65 cu. yd.	.81 cu. yd.	.89 cu. yd.
WIDTH OUTSIDE LIP	24 in (610 mm)	30 in (762 mm)	36 in (914 mm)	39 in (991 mm)
WEIGHT	1 064 lb. (483 kg)	1 183 lb. (537 kg)	1 331 lb. (604 kg)	1 390 lb. (631 kg)

DITCH		
CAPACITY	.86 cu. yd.	.96 cu. yd.
WIDTH OUTSIDE LIP	60 in (1 524 mm)	66 in (1 676 mm)
WEIGHT	970 lb. (440 kg)	1 040 lb. (472 kg)

MACHINE OVERALL DIMENSIONS - CX75SR




BC02H004

Figure 1

A. Overall height (transport position)	2.95 m (9 ft. 8 in)
with 1.70 m arm	2.70 m (8 ft. 10 in)
B. Cab height.....	2.70 m (8 ft. 10 in)
C. Overall length (transport position)	5.91 m (19 ft. 5 in)
with offset boom	5.97 m (19 ft. 7 in)
D. Length from swing pivot to end of arm (transport position)	4.45 m (14 ft. 5 in)
E. Overall width of upperstructure	2.23 m (7 ft. 4 in)
F. Length from track to end of dozer blade.....	3.27 m (10 ft. 7 in)
G. Tail swing radius	1.21 m (4 ft. 0 in)
H. Overall track length	2.85 m (9 ft. 4 in)
I. Idler to sprocket (center to center)	2.21 m (7 ft. 3 in)
J. Track gauge.....	1.87 m (6 ft. 2 in)
K. Track Shoe width.....	450 mm (17.7 in)
L. Track overall width (with 450 mm shoes)	2.32 m (7 ft. 7 in)
M. Minimum ground clearance	0.36 m (1 ft. 2 in)

MACHINE OVERALL DIMENSIONS - CX80




CT04D004

Figure 2

A. Overall height (transport position) with 1.71 m (5 ft. 6 in) arm	2.70 m (8 ft. 10 in)
with 2.12 m (6 ft. 9 in) arm	2.75 m (9 ft. 0 in)
B. Cab height.....	2.70 m (8 ft. 10 in)
C. Overall length (transport position) with 1.71 m (5 ft. 6 in) arm	6.63 m (21 ft. 8 in)
with 2.12 m (6 ft. 9 in) arm	6.72 m (22 ft. 1 in)
D. Length from swing pivot to end of arm (transport position) with 1.71 m (5 ft. 6 in) arm	5.00 m (16 ft. 4 in)
with 2.12 m (6 ft. 9 in) arm	5.09 m (16 ft. 7 in)
E. Overall width of upperstructure	2.23 m (7 ft. 4 in)
F. Length from track to end of dozer blade.....	3.28 m (10 ft. 8 in)
G. Tail swing radius.....	1.63 m (5 ft. 4 in)
H. Overall track length	2.85 m (9 ft. 4 in)
I. Idler to sprocket (center to center)	2.21 m (7 ft. 3 in)
J. Track gauge.....	1.87 m (6 ft. 2 in)
K. Track shoe width	450 mm (17.7 in)
L. Track overall width (450 mm (17.7 in) shoes).....	2.32 m (7 ft. 7 in)
M. Minimum ground clearance.....	0.36 m (1 ft. 2 in)

MACHINE OVERALL DIMENSIONS - CX135SR




BC02H005

Figure 3

A. Overall height (transport)	2.75 m (9 ft. 0 in)
B. Cab height.....	2.75 m (9 ft. 0 in)
C. Overall length	7.24 m (23 ft. 9 in)
D. Length from swing pivot to end of arm (transport)	5.49 m (18 ft. 0 in)
E. Overall width of upperstructure	2.42 m (7 ft. 11 in)
F. Length from track to dozer blade (not shown on diagram).....	4.02 m (13 ft. 2 in)
G. Tail swing radius	1.48 m (4 ft. 10 in)
H. Overall track length	3.51 m (11 ft. 6 in)
I. Idler to sprocket (center to center)	2.78 m (9 ft. 2 in)
J. Track gauge.....	1.99 m (6 ft. 5 in)
K. Track shoe width	600 mm (23.6 in)
L. Track overall width (with 600 mm (23.6 in) shoe)	2.59 m (8 ft. 6 in)
M. Minimum ground clearance	0.44 m (1 ft. 5 in)

WORKING RANGE - CX75SR

1.71 M (5 FT. 7 IN) ARM




CT02D273

Figure 4

WORKING RANGE FOR 1.71 M (5 FT. 7 IN) ARM

A. Maximum reach	6.50 m (21 ft. 5 in)
B. Maximum reach at ground level	6.40 m (21 ft. 0 in)
C. Maximum digging depth	4.15 m (13 ft. 9 in)
D. Maximum digging depth over a length of 2.44 m (8 ft.)	3.80 m (12 ft. 6 in)
E. Maximum dump height	5.25 m (17 ft. 3 in)
F. Maximum working height	7.35 m (24 ft. 1 in)
G. Minimum attachment swing radius	1.80 m (5 ft. 10 in)
H. Maximum digging depth - vertical wall	3.65 m (11 ft. 11 in)

CX75SR WITH 2.12 M (6 FT. 11 IN) ARM




CT02D273

Figure 5

WORKING RANGE FOR 2.12 M (6FT 11 IN) ARM

A. Maximum reach	6.90 m (22 ft. 8 in)
B. Maximum reach at ground level	6.75 m (22 ft. 3 in)
C. Maximum digging depth	4.55 m (14 ft. 10 in)
D. Maximum digging depth over a length of 2.44 m (8 ft.).....	4.25 m (14 ft. 0 in)
E. Maximum dump height	5.55 m (18 ft. 2 in)
F. Maximum working height	7.60 m (25 ft. 0 in)
G. Minimum attachment swing radius	2.10 m (6 ft. 10 in)
H. Maximum digging depth - vertical wall	4.10 m (13 ft. 5 in)

CX75SR - OFFSET ATTACHMENT - 1.75 M (5 FT. 9 IN) ARM




CT02D274 / CT02D275

1. MAXIMUM WORKING RANGE (ZERO OFFSET)
2. TRENCH WITH VERTICAL WALLS (MAXIMUM OFFSET)

WORKING RANGE FOR OFFSET ATTACHMENT WITH 1.75 M (5 FT. 9 IN) ARM

A. (Maximum reach)	6.10 m (20 ft.) maximum offset 6.50 m (21 ft. 3 in) zero offset
B. (Maximum reach at ground level)	5.95 m (19 ft. 6 in) maximum offset 6.35 m (20 ft. 10 in) zero offset
C. (Maximum digging depth).....	3.75 m (12 ft. 4 in) maximum offset 4.20 m (13 ft. 9 in) zero offset
D. (Maximum digging depth over a length of 2.44 m) (8 ft.)	3.40 m (11 ft. 2 in) maximum offset 3.80 m (12 ft. 5 in) zero offset
E. (Maximum dump height)	4.85 m(15 ft. 11 in) maximum offset 5.15 m (16 ft. 10 in) zero offset
F. (Maximum working height).....	6.85 m(22 ft. 5 in) maximum offset 7.20 m (23 ft. 7 in) zero offset
G. (Minimum attachment swing radius)	1.95 m(6 ft. 5 in) maximum offset 2.25 m (7 ft. 4 in) zero offset
H. (Maximum digging depth - vertical wall).....	2.85 m(9 ft. 4 in) maximum offset 3.25 m (10 ft. 8 in) zero offset

WORKING RANGE - CX80




CT04D007

Figure 6

.....	1.71 m (5 ft. 6 in) arm	2.12 m (7 ft.) arm
A (Maximum reach)	7.03 m (23 ft. 0 in)	7.40 m (24 ft. 3 in)
B (Maximum reach at ground level)	6.89 m (22 ft. 6 in)	7.27 m (23 ft. 8 in)
C (Maximum digging depth).....	4.18 m (13 ft. 7 in)	4.59 m (15 ft. 1 in)
D (Maximum digging depth over a length of 2.44 m) (8 ft.)	3.80 m (12 ft. 5 in)	4.23 m (13 ft. 9 in)
E (Maximum dump height).....	4.39 m (14 ft. 4 in)	4.60 m (15 ft. 1 in)
F (Maximum working height)	6.39 m (21 ft. 1 in)	6.60 m (21 ft. 7 in)
G (Minimum attachment swing radius)	2.75 m (9 ft. 1 in)	2.91 m (9 ft. 6 in)
H (Maximum digging depth on a vertical wall)	3.10 m (10 ft. 2 in)	3.55 m (11 ft. 7 in)
RH offset angle		50°
LH offset angle		80°

WORKING RANGE - CX135SR

2.39 M (7 FT. 10 IN) ARM




CT02D276

Figure 7

WORKING RANGE FOR 2.39 M (7FT 10 IN) ARM

A. (Maximum reach)	8.20 m (26 ft. 11 in)
B. (Maximum reach at ground level)	8.05 m (26 ft. 6 in)
C. (Maximum digging depth).....	5.45 m (17 ft. 11 in)
D. (Maximum digging depth over a length of 2.44 m) (8 ft.)	5.25 m (17 ft. 3 in)
E. (Maximum dump height)	6.90 m (22 ft. 8 in)
F. (Maximum working height)	9.30 m (30 ft. 6 in)
G. (Minimum swing radius)	2.26 m (7 ft. 5 in)
H. (Maximum digging depth - vertical wall)	4.85 m (15 ft. 11 in)

2.85 m (9 ft. 4 in) ARM




CT02D276

Figure 8

WORKING RANGE FOR 2.85 M (9 FT. 4 IN) ARM

A. (Maximum reach)	8.57 m (28 ft. 1 in)
B. (Maximum reach at ground level)	8.43 m (27 ft. 8 in)
C. (Maximum digging depth)	5.93 m (19 ft. 5 in)
D. (Maximum digging depth over a length of 2.44 m) (8 ft.).....	5.70 m (18 ft. 9 in)
E. (Maximum dump height)	7.10 m (23 ft. 5 in)
F. (Maximum working height)	9.50 m (31 ft. 3 in)
G. (Minimum attachment swing radius)	2.23 m (7 ft. 4 in)
H. (Maximum digging depth - vertical wall)	5.05 m (16 ft. 8 in)

LIFTING CAPACITIES



B9408252

Figure 9

1. LOAD (LIFT) POINT HEIGHT
2. LOAD (LIFT) POINT RADIUS
3. SWING PIVOT
4. GROUND LINE
5. LOAD (LIFT) POINT ON BUCKET

- The lift point is the lifting eye on the back of the bucket.
- The mass of slings and any auxiliary lifting devices shall be deducted from the rated load to determine the net load that may be lifted.
- All rated lift capacities are based on the machine being level and on a firm supporting surface. For safe working loads, the user is expected to make due allowance for the particular job conditions such as soft or uneven ground, non-level conditions, side loads, hazardous conditions, experience of personnel, etc. The operator and other personnel should fully acquaint themselves with the operator's manual furnished by the manufacturer before operating this machine, and rules for safe operation of equipment shall be adhered to at all times.
- Lifting capacities are in compliance with SAE J 1097/IS 10567.
- Lifting capacities shown do not exceed 75% of minimum tipping loads or 87% of hydraulic capacities. Capacities marked with an asterisk (*) are limited by hydraulic capacities.
- These capacities apply to machines having correct bloomiest cylinder pressure.
- Least stable position is over the side.
- Capacities apply only to the machine as originally manufactured and normally equipped.

CX75SR WITH 1.71 M (5 FT 7 IN) ARM

Load (Lift) Point Height	Load Radius							
	End	Side	End	Side	End	Side	End	Side
	5 ft.		10 ft.		15 ft.		Lb. Cap. at Max. Reach	
15 ft.			3 600*	3 600*			3 450*	3 250
10 ft.	8 050*	8 050*	4 850*	4 850*	3 350	3 000	2 650	2 350
5 ft.			6 000	5 250	3 150	2 800	2 300	2 050
Ground Level			5 600	4 850	2 950	2 650	2 300	2 050
-5 ft.	8 500*	8 500*	5 500	4 800	2 900	2 600	2 750	2 450
-10 ft.			5 550*	4 950			4 850	4 250

NOTE: 3.87 m (12 ft. 8 in) Boom and 209 kg (462 lb.) bucket

CX75SR WITH 2.12 M (6 FT 11 IN) ARM

Load (Lift) Point Height	Load Radius							
	End	Side	End	Side	End	Side	End	Side
	5 ft.		10 ft.		15 ft.		Lb. Cap. at Max. Reach	
15 ft.					3 250*	3 150	3 000*	2 750
10 ft.			4 150*	4 150*	3 400	3 050	2 300	2 050
5 ft.			6 100	5 350	3 150	2 800	2 050	1 850
Ground Level			5 600	4 850	2 950	2 600	2 050	1 800
-5 ft.	7 350*	7 350*	5 400	4 700	2 850	2 550	2 350	2 100
-10 ft.	11 050*	11 050*	5 500	4 800			3 600	3 200

NOTE: 3.87 m (12 ft. 8 in) Boom and 191 kg (422 lb.) bucket

CX75SR WITH 1.75 M (5 FT 9 IN) ARM WITH OFFSET BOOM

Load (Lift) Point Height	Load Radius							
	End	Side	End	Side	End	Side	End	Side
	5 ft.		10 ft.		15 ft.		Lb. Cap. at Max. Reach	
15 ft.			3 550*	3 550*			3 400*	3 350
10 ft.			4 600*	4 600*	3 200	2 850	2 550	2 250
5 ft.			5 600	4 850	2 850	2 550	2 100	1 850
Ground Level			4 900	4 200	2 600	2 250	2 050	1 800
-5 ft.	8 450*	8 450*	4 750	4 050	2 500	2 150	2 450	2 100
-10 ft.			4 900*	4 300			4 600	3 950

NOTE: 3.92 m (12 ft. 10 in) Boom and 209 kg (462 lb.) bucket

IMPORTANT: Capacities marked with asterisk (*) are limited by hydraulic capacities.

CX135SR WITH 2.39 M (7 FT 10 IN) ARM

Load (Lift) Point Height	Load Radius									
	End	Side	End	Side	End	Side	End	Side	End	Side
	5 ft.		10 ft.		15 ft.		20 ft.		Lb. Cap. at Max. Reach	
20 ft.					6 150*	6 150*			4 600*	4 600*
15 ft.			8 150*	8 150*	8 050*	7 100*	4 950*	4 300	3 200*	3 200*
10 ft.			14 400*	12 950	9 600	6 650	5 950	4 100	3 250*	3 250
5 ft.			17 950	11 350	9 000	6 100	5 700	3 900	3 600*	3 000
Ground Level			17 000	10 550	8 550	5 700	5 500	3 700	4 200*	3 000
-5 ft.	11 450*	11 450*	16 800	10 400	8 350	5 550	5 400	3 600	5 000	3 350
-10 ft.	17 900*	17 900*	15 200*	10 600	8 400	5 600			6 450	4 350
-15 ft.			7 650*	7 650*					6 300	6 300

NOTE: 4.73 m (15 ft. 6 in) Boom and 398 kg (879 lb.) bucket

CX135SR WITH 2.85 M (9 FT 4 IN) ARM

Load (Lift) Point Height	Load Radius									
	End	Side	End	Side	End	Side	End	Side	End	Side
	5 ft.		10 ft.		15 ft.		20 ft.		Lb. Cap. at Max. Reach	
20 ft.					6 150*	6 150*			3 700*	3 700*
15 ft.					7 100*	7 100*	5 800*	4 400*	3 550*	3 550*
10 ft.	15 300*	15 300*	11 750*	11 750*	9 650*	6 800	6 000	4 200	3 650*	3 000
5 ft.			17 950*	11 650	9 100	6 200	5 750	3 950	4 000*	2 750
Ground Level			17 000	10 600	8 550	5 700	5 450	3 700	4 100	2 750
-5 ft.	10 700*	10 700*	16 650	10 250	8 300	5 450	5 350	3 550	4 500	3 000
-10 ft.	16 300*	16 300*	16 650*	10 350	8 250	5 450			5 650	3 750
-15 ft.			10 500*	10 500*					7 350	6 300

NOTE: 4.73 m (15 ft. 6 in) Boom and 338 kg (747 lb.) bucket

IMPORTANT: Capacities marked with asterisk (*) are limited by hydraulic capacities.

NOTES

Chapter 9

INDEX

A		F	
Adjusting the working lights	7-10	Fan and alternator drive belt	6-10
Air filter	5-44	Fire extinguisher	6-15
Air flow direction	3-12	Fluid and lubricant capacities and specifications	5-12
Air recycling	3-12	Fuel level indicator	3-7
Air vents	3-22	Fuel level indicator lamp	3-8
Air-conditioning switch	3-12	Fuel system	5-28
Alternator	7-8	Fuel tank	3-24
Ashtray	3-17	Fuel tank filter	6-12
B		Fuse box	3-17
Battery	7-5	Fuses	7-3
Battery charge indicator lamp	3-8	G	
Boom and bucket right-hand control lever	3-13	General Information	1-1
Booms	8-6	Glove compartment	3-16
C		Greasing the turntable teeth	5-16
Cab light	3-16	Ground pressure	8-6
Cab radio compartment	3-17	H	
Capacity of systems and components	8-6	Hand signals	2-14
Checking for cylinder leakage	6-12	Handling the hydraulic breaker	4-22
Checking the condition of rubber tracks	6-6	Handling the machine	4-14
Coat hanger hook	3-16	Hardware torque inspection	6-18
Components, Machine	1-3	Heating and ventilation control	3-10
Function cancellation lever	3-9, 3-10	Heating, ventilation or air-conditioning control	3-10
Cooling system (CX135SR)	5-26	High speed travel switch	3-8, 3-11
Cooling system CX75SR, CX80	5-24	Horn	3-9, 3-10
D		hourmeter	3-7, 5-4
Daily inspections	5-3	Hydraulic system	5-34, 8-4
Decals	2-9	I	
Dozer blade control lever	3-6, 3-16	Identification Numbers	1-5
E		Inspecting and cleaning the machine	6-12
Emergency shut down switch	3-10	Instrument panel	3-6, 3-7
Engine	8-3	L	
Engine (CX135SR)	5-22	Left-hand control arm (CX135SR)	3-10
Engine (CX75SR, CX80)	5-20	Left-hand control arm (CX75SR, CX80)	3-9
Engine coolant temperature indicator	3-7	Levels	5-18
Engine electric circuit indicator lamp (CX135SR)	3-8	Lower front window	3-22
Engine hood - CX75SR, CX80	3-25	Lubrication points	5-13
Engine idle speed selector	3-6	M	
Engine oil pressure indicator lamp	3-7	Machine Components	1-3
Engine operation	4-6	Machine lubrication	5-15
Engine throttle button	3-6	Machine overall dimensions (CX135SR)	8-11
Environment	5-11	Machine overall dimensions (CX80).....	8-10

Machine overall dimensions (CX75SR) 8-9
 Machine storage 4-20
 Machine travel 4-8

O

Offset boom control pedal 3-15
 On/Off 3-12
 One-piece boom/arm/bucket lubrication 5-13
 Operating temperature
 Bringing the machine up to 4-5
 Operating the backhoe bucket 4-16
 Operating the machine 4-3
 Operating the machine in cold weather 4-7
 Operating the machine in hot weather 4-8
 Operating the machine in water 4-14
 Operating the machine on sloping ground 4-15
 Operator's seat 3-18
 Option control 3-9, 3-10
 Option pedal 3-15
 Overheating indicator lamp 3-7

P

Parking the machine 4-14
 Personal Safety 2-3
 Plastic and resin parts 6-15, 6-17
 Position of the operator's compartment controls and accessories 3-5
 Preheating indicator lamp 3-8
 Product Identification Number 1-5
 Putting 2,85 m arm in transport position 4-10

Q

Quick coupler locking and unlocking switch 3-9

R

Radiator and oil cooler 6-9
 Rear right-hand side window 3-16
 Releasing pressure in the hydraulic system 5-32
 Replacing a backhoe bucket (CX135SR) 6-14
 Replacing a backhoe bucket (CX75SR, CX80) . 6-13
 Replacing a bulb 7-9
 Replacing the rubber tracks 6-6
 Retro-offset boom/arm lubrication 5-15
 Right-hand control arm 3-6
 Rotary light 3-10
 Run-in period 4-4

S

Safety Area 2-3
 Safety/Decals/Hand Signals
 Safety Rules 2-3

Utility Safety2-3
 Serial Numbers1-5
 Servicing instructions5-3
 Side doors3-26
 Sides of the machine
 Right-hand, left-hand, front, and rear1-4
 Speaker compartments3-17
 Starter motor7-8
 Starter switch3-6
 Steps and access handles3-4
 Stopping the engine4-6
 Storage tray3-17
 Storing the machine4-20
 Swing reduction gear5-47

T

Temperature3-12
 Towing point3-27
 Towing the machine4-15
 Track rollers and idler wheels6-8
 Tracks6-3
 Transporting the machine4-11
 Travel control3-14
 Travel reduction gears (CX75SR, CX80) . 5-49, 5-50

U

Undercarriage8-5
 Unlocking and locking of pedals3-15
 Upper hood (CX75SR, CX80)3-24
 Utility Safety Rules Message2-3

V

Ventilation3-12

W

Weights8-6
 Welding on the machine6-15
 Windshield defroster3-12
 Windshield washer reservoir3-28
 Windshield washer switch 3-8, 3-11
 Windshield wiper switch 3-8, 3-11
 Working light switch 3-8, 3-11
 Working range (CX135SR)8-16
 Working range (CX80).....8-15
 Working range (CX75SR)8-12