

Standalone recorder instruction

1,Product profile	2
2. Hardware interface.....	2
2.1 2 &4 &8 channel standalone recorder front panel.....	2
2.2 8&16 channel standalone recorder device interface	3
3, Hardware connection.....	3
2 port standalone recorder.....	3
4 port standalone recorder.....	4
8 port standalone recorder with SD card.....	4
8 port standalone recorder with hard disk.....	5
16 port standalone recorder.....	5
4, Standalone Recorder IP Instruction	6
4.1, If your computer IP is 192.168.0.x, directly add standalone recorder default IP on the software	6
4.2, If your computer IP is not 192.168.0.x, there are 2 ways to run the software at the first time.	6
Solution 1, Add IP: 192.168.0. x and gateway:192.168.0.1 in your computer	6
Solution 2, Use telephone key to change the standalone recorder IP and gateway	15
Change IP after connecting software successfully	16
5, WEB for Standalone recorder (only use in IE browser)	17
5.1, Security setting on IE browser	17
5.2, LAN: Login in WEB on IE browser	17
5.3 Install Active control files.....	17
5.4 Live time monitor	18
5.5 Search, Play, download.....	19
6, RDMC Software installation: manage one device.....	22
6.0, Standalone recorder RDMC software operation instruction.....	22
6.1 Run RDMC.exe in C:\RDMC.....	22
6.2 Add Standalone recorder IP address on the software	23
6.3, Software function introduction	25
6.3. 1 Main interface	25
6.3.2 Standalone recorder RDMC list interface	25
6.3.3 Monitor	26
6.3.3.1 Live monitor on the main software interface	26
6.3.3.2 Live monitor on the list software interface	26
6.3.4 Search.....	27
6.3.4.1 Terminal Search	27
6.3.4.2 Local Search.....	28
6.3.5 Statistics	29
6.3.6 Customer.....	29
6.3.7 System Setting	30
6.3.7.1 Permission Setting	30
6.3.7.2 Add Terminal IP:.....	32
6.3.7.3 Recording set	32


6.3.7.4 Update Embedded.....	34
6.3.7.4.1 Update terminal program files	34
6.3.7.4.2 Update terminal recording system time	34
6.3.7.4.3 Update Terminal IP	34
6.3.7.5 Embedded settings	35
6.3.7.6 Read embedded version	37
6.3.7.7 Database (only for second development)	37
7, G729 Voice decoder installation	38
8, Center Management software instruction (Manage multiple devices)	38
9, Others.....	43

1,Product profile


Standalone recorder does not need to connect the computer, only connect power to record. Adopt high resistance parallel connection, can record all kinds of analog telephone, audio signaling. Store the calls info in the SD card or SATA hard disk. The device develops on Linux OS. Anti-virus. It is more stable. There are 2/4/8/16 channels to choose. Support internet search, play, monitor, backup, multiple places to install, centralized management. It is easy to install and operate, stable and reliable. It widely use in finance security, public security, call center, electric power and traffic area and so on which need to record the telephone conversations.

2. Hardware interface

2.1 2 & 4 & 8 channel standalone recorder front panel



“LINE1 LINE2” : connect one-to-two connector, can be 4 port telephone line port.



“8 5 4 1” : connect one-to- four connector, can be 8 port telephone line port

RESET: reset default IP and default user and password (**Attention: when need to reset default setting(default IP, user name, user password, port number): press reset button over 4 seconds; less then 4 seconds, only restart the device).**

“ETHERNET” : connect RJ45 network connection line

“USB”: connect to serial port line to check the device when the device has error (This serial port line is specially

made by ourself)

“+5V/DC”: connect 5V direct-current power supply (5V/3A)


“SD” : connect SD card, maximum is 32G.

2.2 8&16 channel standalone recorder device interface

Front panel



Rear panel



On-off: Power switch (**Attention: When turn off device, you need to press “on-off” switch firstly, then pull out the power line after 4 seconds, or else the calls may miss or the hard disk may be broken**)

DC 12V/3A: connect power

Channel port: connect telephone line

SD card: can use SD card and hard disk store the voice files at the same time

RESET: reset default IP and default user and password and port number

SPK: do not use this port now

NET: connect network cable

VGA: invalid now

SMDR IN: Connect serial line to check the device when the device has error. Or connect serial port line on this port to record trunk line to get extension info.

USB: do not use this port now

3, Hardware connection

2 port standalone recorder: directly connect telephone line to Line1 and Line2.



4 port standalone recorder: one-to-two RJ11 connector connect to Line1-2 and Line3-4, put the telephone line parallel connect to one-to-two RJ11 connector. The maximum to connect is 4 telephone lines.




8 port standalone recorder with SD card: directly put the telephone line parallel connect from port 1 to port 8




8 port standalone recorder with hard disk: directly put the telephone line parallel

connect from port 1 to port 8



16 port standalone recorder: one-to-two RJ11 connector connect to Line1 and Line8, put the telephone line parallel connect to one-to-two RJ11 connector. The maximum to connect are 16 telephone lines.



Connect **network line** to **ETHERNET** port.


Connect **power** to "DC 12V/3A" port.

It will install ok after connect power. (8 and 16 port standalone recorder need to turn on the power switch)

4, Standalone Recorder IP Instruction

4.1, If your computer IP is 192.168.0.x, directly add standalone recorder default IP on the IE browser address bar or our software.

Standalone recorder default IP is 192.168.0.230.



4.2, If your computer IP is not 192.168.0.x, there are 2 ways to run the WEB/ software at the first time.


Solution 1, Add IP: 192.168.0. x and gateway:192.168.0.1 in your computer

(x can be set 2~255, not 230)


4.2.1 in Windows XP




Click Start -> My network Places->Properties




Right click Local Area Connection-> Properties




Click "Internet Protocol (TCP/IP)" -> "Properties"




Click "Advanced"





Click "Add"





// Add IP address: 192.168.0. x
Subnet mask as default value






// Add gateway: 192.168.0.1

// after add IP 192.168.0.X and gateway 192.168.0.1 in your computer, add the standalone recorder default IP (192.168.0.230) in the software.



4.2.2 in Windows 7


Add IP: **192.168.0. x** and gateway:**192.168.0.1** in your computer

(x can be set 2~255, not 230)




Right click network icon -> Open Network and Sharing Center







// Add IP address: 192.168.0. x
Subnet mask as default value



// Add gateway: 192.168.0.1



// after add IP 192.168.0.X and gateway 192.168.0.1 in your computer, add the standalone recorder default IP (192.168.0.230) in the IE browser or our software (RDMC or Center Manager software).



Solution 2, Use telephone key to change the standalone recorder IP and gateway

Ping the new IP you want to change on your PC: Click "Start" ->"Run"-> input "ping 192.168.1.230 -t"

After connecting telephone line to standalone recorder and connect device power, press the follow telephone key to change device IP and gateway (May need to press several times until ping the new IP ok):

Modify IP and gateway: press the follow key : **##1266666666#192*168*1*230#192*168*1*1##**

Attention: the IP you want to change instead of 192*168*1*230

the gateway you want to change instead of 192*168*1*1


Detail instructions:

Press key: "##12Standalone recorder hardware user password#ip address#gateway address##";

(For example: standalone recorder default user password: 66666666, standalone recorder IP change as 192.168.1.230, standalone recorder gateway change as 192.168.1.1, so press the follow key : ##1266666666#192*168*1*230#192*168*1*1##)

- Press ##
- press 12 (function code)
- press standalone recorder hardware user password (default password is 66666666; if you changed the device password, please press the modified password)
- press #
- Press IP address (format: 192*168*1*230, use "*" instead of ".")
- Press #
- Press gateway address (format: 192*168*1*1, use "*" instead of ".")
- Press ##

After change the new IP ok (ping new IP to test if change ok), connect the new IP on the software.



Change IP after connecting software successfully.

Firstly, open [RDMC](#)

Click **System setting** -> **Update Embedded**->click **IP**-> **change IP, Mask, Gateway**-> Start update
(When it show 'update file successfully).


IP address: standalone device new IP

Mask: standalone device subnet mask

Gateway: standalone device new gateway

Please set the above information to match your network settings (check you network IP:
Start-> run-> input "cmd" -> input "ipconfig /all")


Finally, you must click "Reboot Terminal" button. The new IP will come into effect after 1 minute.



After change IP, connect the new IP on the software to work.

5, WEB for Standalone recorder (only use in IE browser)

5.1, LAN: Login in WEB on IE browser: input standalone recorder IP on IE browser address bar (LAN): 192.168.0.230, then enter





Default user name: admin Password: admin, then click Connect.


5.2 Install Active control files: (Our plugin has been certified by Microsoft security, please feel free to

use)

gxem_ocx.cab,

LoadRD.cab





5.3 Live time monitor

Standalone Call Logger Web Management System

Real-time status

	Channel	Local No.	Ch Name	Mode	Status	I/O	Incoming No.	DTMF	Start Time	Duration
Monitor	1	001	aaa	Voltage	Disconnect					
Monitor	2	002	ivy	Voltage	Idle					

Login User: admin
Login Time: 17:25:47

Logout
Change Password
Change IP Address
Channel Settings
Update Device Time
Device Version
Restart Device

Voice Logger Search(Remote)

Play Download Backup All Export

Channel	Local No.	Ch Name	I/O	Start time	DTMF	Incoming No.	Duration	IP Address
---------	-----------	---------	-----	------------	------	--------------	----------	------------

Click "Monitor" to real time listen the voice file.

- Logout
- Change Password
- Change IP Address
- Channel Settings
- Update Device Time
- Device Version
- Restart Device

5.5.1 Logout : logout WEB

5.5.2 Change Login in password

Change Password Close

Current User: admin

Old Password:

New Password:

Input again:

5.5.3 Change device IP

IPAddress settings Close

IP Address Gateway

Mask

5.5.4 Channel parameter settings

Channel Settings		Close	
Channel	1	<input type="button" value="Read Channel Value"/> <input type="button" value="Save Channel Value"/>	
Local No.	001	Ch Name	aaa
Enabled Recording	Enabled	Record Mode	Voltage
Start Record Key	#1233	End Record Key	#999#
Voice Sensitivity	21	Voice Pick Off Time(s)	20
DTMF Sensitivity	Highest	Not receive key after(s)	0
Enabled AGC	Enabled	AGC Value	1400
Pick Up Time(ms)	120	Pick Off Time(ms)	500
Pick-up Voltage(V)	15	Pick-off Voltage(V)	24
Fixed Time Restart Device			
Work Time1	00:00-24:00	Work Time2	

Channel: select one channel in the standalone recorder

Read Channel Value: get the channel parameter value

Save Channel Value: save the channel new parameter value

Local No.: set the telephone line local number

Record mode: Voice: voice control

Voltage: Voltage control (default setting)

Key: key control

Start record key: when key recording control way, the keys to start record (default #111#)

End record key: when key recording control way, the keys to end record (default #222#)

Voice sensitivity: detect the voice when the voice volume reaches parameter value (default 20, be valid when use voice control)

Voice Pick Off time: the time length for each the channel's call finish recording. Unit is second (Be valid when use voice control)

Enabled AGC: Automatic gain control

AGC Value: Automatic gain control value (default value 1400)

Pick up time (ms) : After the time (parameter value) of hook-off, the standalone recorder judges it a pick up. The default value is 120 ms

Pick off time(ms): After the time (parameter value) of hook-on, the standalone recorder judges it a pick off. The default value is 500 ms

Pick up voltage (V): Pick up voltage (4~18V)

Pick off voltage (V): pick off voltage (18v ~46V)

Fixed time restart device: set the time to restart the device

Work time 1: set device recording time. Default recording time : 00:00-24:00

Work time 2: set device recording time.

5.5.5 Update device time to match with the computer time.



5.5.6 Check device firmware version




5.5.7 Restart device (need restart device after set new parameter)



6, RDMC Software installation: manage one device

You can get software installation application from our CD or downloading it from our company website. Open our software folder, click **setup.exe** to start to install, do it according to the prompt. Do not need to restart computer after finish installation. **The default installation directory: C:\RDMC.**



RDMC folder


6.0, Standalone recorder RDMC software operation instruction

6.1 Run RDMC.exe in C:\RDMC; or click Run-> all programs-> RDMC->Recording Manager System

Standalone recorder default IP address: 192.168.0.230

After install standalone recorder client software, it locates in C:\RDMC, default IP address" 192.168.0.230"


Run C:\RDMC\RDMC.exe, and login in “Central Manage system”
(Default user name: **admin**, password: **admin**), see the follow image




Default user name: admin, password: admin

The function menu show grey when do not login in the software. All the operations can be operated after login in the software.

6.2 Add Standalone recorder IP address on the software: after login in the software, click System-> Add Terminal IP, input IP address (default: 192.168.0.230), Terminal name and **Terminal password** (default:66666666), select “use default port”, click Add.



After adding IP address, Total channels , Line status and disk free space info will show on the main screen. It shows the standalone work ok.






Double click Minimize window, will return max window

6.3, Software function introduction:

6.3. 1 Main interface: Central management system manage a standalone recorder. It will show different telephone lines on the main screen. See the follow image



Start record Mode: voltage (default)




Start record Mode: Voice



Start record Mode: Key


6.3.2 Standalone recorder RDMC list interface

Click "Main screen" will enter list screen.




6.3.3 Monitor

6.3.3.1 Live monitor on the main software interface: click Monitor and click the telephone icon. The frame will become white colour when can monitor




6.3.3.2 Live monitor on the list software interface:

When need to monitor one channel calls, click Monitor-> double click the channel you want to monitor, then the channel will turn yellow.




6.3.4 Search Search

6.3.4.1 Terminal Search: search the recorded files in this standalone recorder



Can search according to different conditions.

Click  start to play the recorded files in the standalone recorder


Click  will download the recorded file you chose to the local computer's disk (Use this menu when do not choose real time download recorded files, and can use Shift or Ctrl key to choose several files to download).

The downloading progress will show on the interface.

File download progress



It is downloading file, it will close this form after finish.



9

Delete

Delete the recorded files from the standalone recorder (if not administrator, user need permission).

Extraction

Convert the voice file to .wav or MP3 format

Export

Export Excel, .txt file.

6.3.4.2 Local Search search the recorded files which have downloaded to the local computer.

The screenshot shows a software window titled "Search" with two tabs: "Terminal Search" and "Local Search". The "Local Search" tab is active, displaying a table with the following columns: Terminal name, Line No., Local No., I/O, Date, Time, Dial No., Incoming No., Length, and a partially visible column. Below the table, there are playback controls including a digital display showing "00:00:00", a volume control slider set to 159, and buttons for "Start A", "Mark as Important", "Mark as Reserve", "Mark as Read", and "Mark as Unread". A "Remark" field with a "Save remark" button is also present. At the bottom, there are buttons for "Search", "Delete", "Extraction", "Export", "Print", "UnanswerCall", "View Log", and "Exit". The "Call options" section includes "Begin Date" (2011-9-15) and "End Date" (2011-9-15) with time pickers, "Line No." (000), "I/O" ([ALL]), "Greater than" (0000) and "Less than" (9999) with "Second" units, and checkboxes for "Reserve", "Read", "Important", and "Unread". A "Specific" checkbox is followed by radio buttons for "Incoming No.", "Dial No.", "Local No.", "P Address", "Terminal name", "UserGroup", "UserName", and "Remark". A "Search Inof" text box is at the bottom right.

Extraction

Convert the voice file to .wav or MP3 format

Delete

Delete the recorded files from the computer (if not administrator, user need permission).



6.3.5 Statistics

statistics duration, call times and so on. Click Statistics to enter the follow interface.

Line No.	Phone No.	Hook-on Count	Talk time	Ave talk time	Dial Count
1		3	01:04	21	2
2		4	01:37	24	3
3		0	00	00	0
4		0	00	00	0
5		0	00	00	0
6		0	00	00	0
7		0	00	00	0
8		0	00	00	0
9		0	00	00	0
10		0	00	00	0
11		0	00	00	0
12		0	00	00	0
13		0	00	00	0
14		0	00	00	0
15		0	00	00	0
16		0	00	00	0
17		0	00	00	0
18		0	00	00	0
19		0	00	00	0
20		0	00	00	0
21		0	00	00	0
22		0	00	00	0
23		0	00	00	0
24		0	00	00	0
25		0	00	00	0
26		0	00	00	0
27		0	00	00	0
28		0	00	00	0
29		0	00	00	0

Begin Date: 2011-06-18 End Date: 2011-06-18 Dial No.

Line No.: 000 (000 : all line number) Local No. Incoming No.



6.3.6 Customer

Click "Customer" to manage the customer information.

Customer	Name	Phone No.1	Phone No.2	Phone No.3	Mobile1	Mobile2	Addresses

Customer: Name:
Addresses: Postalcode:
Phone No.1: Phone No.2:
Phone No.3: Fax number:
Mobile1: Mobile2:
Remark:



6.3.7 System Setting

Permission Setting: manage the system operator 's permission.

Add Terminal IP: can add, modify, delete standalone recorder device.

Recording set: Choose the language and set the store path for the recorded files.


Update Embedded: update standalone recorder hardware file and change IP by central manage system

Embedded setting: Channel parameter setting.

Read embedded version (need to click the right top triangle to get): can check the hardware version to see if the update is ok after system update.

Database (only for second development) : add My SQL, MS SQL or other SQL.

6.3.7.1 Permission Setting: manage the system operator's permission and modify terminal password.



Can add different user and give them login in software password and permission.

Permissions Setting

Login

User name: Password:

Name: Input again:

Permissions

<input checked="" type="checkbox"/> Search	<input checked="" type="checkbox"/> Statistics	<input checked="" type="checkbox"/> Monitor
<input checked="" type="checkbox"/> View Log	<input type="checkbox"/> Delete recording	<input checked="" type="checkbox"/> Extract/download
<input checked="" type="checkbox"/> System Set	<input checked="" type="checkbox"/> Add customer information	<input checked="" type="checkbox"/> Permissions Setting
<input checked="" type="checkbox"/> Add Remark	<input checked="" type="checkbox"/> Edit Remark	<input checked="" type="checkbox"/> Export/Print

Channels Permissions

Record Search

ALL

<input checked="" type="checkbox"/> _lines1	<input checked="" type="checkbox"/> _lines2	<input checked="" type="checkbox"/> _lines3	<input checked="" type="checkbox"/> _lines4	<input checked="" type="checkbox"/> _lines5	<input checked="" type="checkbox"/> _lines6	<input checked="" type="checkbox"/> _lines7	<input checked="" type="checkbox"/> _lines8	<input checked="" type="checkbox"/> _lines9	<input checked="" type="checkbox"/> _lines10
<input checked="" type="checkbox"/> _lines11	<input checked="" type="checkbox"/> _lines12	<input checked="" type="checkbox"/> _lines13	<input checked="" type="checkbox"/> _lines14	<input checked="" type="checkbox"/> _lines15	<input checked="" type="checkbox"/> _lines16	<input checked="" type="checkbox"/> _lines17	<input checked="" type="checkbox"/> _lines18	<input checked="" type="checkbox"/> _lines19	<input checked="" type="checkbox"/> _lines20
<input checked="" type="checkbox"/> _lines21	<input checked="" type="checkbox"/> _lines22	<input checked="" type="checkbox"/> _lines23	<input checked="" type="checkbox"/> _lines24	<input checked="" type="checkbox"/> _lines25	<input checked="" type="checkbox"/> _lines26	<input checked="" type="checkbox"/> _lines27	<input checked="" type="checkbox"/> _lines28	<input checked="" type="checkbox"/> _lines29	<input checked="" type="checkbox"/> _lines30

Modify standalone logger termin...

Terminal IP	Terminal Name
192.168.0.230	ivy

Terminal IP:

Terminal Name:


System user login password:

Terminal new password:

Input again:

You can modify the standalone recorder hardware password (The user can modify terminal device password which have Permissions setting rights.). **Standalone recorder hardware terminal password (default:66666666)**


6.3.7.2 Add Terminal IP: can add, modify, delete standalone recorder IP to connect hardware.



Input IP address (default: 192.168.0.230), Terminal name and **Terminal password (default:66666666)**, Select Use default port, click Add.

Attention: if your PC's IP is not 192.168.0.x, you can add a IP 192.168.0.X and gateway 192.168.0.1 on your PC firstly

6.3.7.3 Recording set (Set language , file path setting and download setting)



6.3. 7.3.1 Set language and file path

6.3.7.3.2 Choose language

Auto: show the language according the operation system's language.

ENG: English

USER: Software language can be edited by the user.

6.3.7.3.3 Embedded recording files save path

You can choose the save path (\\C\D\E\F\G\H\I\J\K\L\M\N:\Recorder). It will store the recorded files from standalone recorder by downloading.

6.3.7.3.4 Download setting.

-> Real time download the standalone recorder's recorded files

Only select this check box, will automatically download recorded files when the calls end.

-> Every day at * time to start to download (fixed time)

When select this check box, you must also need to select the above box (Real time download the standalone recorder's recorded files) to fixed time download the recorded files.

-> Download strategy

Automatically download the recent * days's recorded files.


Only click this check box, will automatically download the recent * days recorded files

->, **Click Save to set.**

When you choose "Real time download the standalone recorder's recorded files", you can search and play the recorded files after the calls end on the Local search interface.

6.3.7.4 Update Embedded (all the files need to update are in C:\RDMC\pubfile)

In Update standalone recorder interface, you can update hardware files, set system time, change IP address.



6.3.7.4.1 Update terminal program files: update the system file (such as: gxem_record, gxcfg.ini, gxv729.bin, gx_dsp_drv.ko) Browse and select the update file, then click Start Update.

When it show 'update file successfully', you must click "Reboot Terminal" button. It will come into effect after restart standalone recorder's recording system software.

6.3.7.4.2 Update terminal recording system time: firstly choose the IP address, then click "Start update" to renew the time of the standalone recorder.

6.3.7.4.3 Update Terminal IP

IP address: standalone device new IP


Mask: standalone device new subnet mask

Gateway: standalone device gateway

Please set the above information to match your network setting

When it show ‘update file successfully’, you must click “Reboot Terminal” button. It will come into effect after 1 minute.

6.3.7.5 Embedded settings



Choose the IP address on the left,

Upload configuration: show the channel setting

Download Configuration: write channel setting on the standalone recorder device.

Total channel: show the standalone recorder’s total channels (2/4/8/16)

Storage medium: SD card/ Hard disk

Device restart time: **: hh:mm :** the device will automatically self-inspection at this time.

Time Out Times(s): connect device timeout

Main Port:12345

Web Port:80

Local number: You can set the local number to easily recognize telephone user and search the calls record.

Channel Name: You can set the channel name to easily recognize telephone number user and search the calls record.

Channel Record: Yes (record); NO (This channel do not record)

Record mode: Voice: voice control

Voltage: Voltage control (default setting)

Key: key control

Keying start key: when key recording control way, the keys to start record (default #111#)

Keying over key: when key recording control way, the keys to end record (default #222#)

Audio sensitivity: detect the voice when the voice volume reaches parameter value (default 20, be valid when use voice control)

Audio hook on time: the time length for each the channel's call finish recording. Unit is second (Be valid when use voice control)

DTMF sensitivity: Normal/ high/ highest

AGC enabled: Automatic gain control

AGC Value: Automatic gain control value (default value 1400)

Cancel password: During talking, input this password, will stop recording and delete this recorded file. First and last word must be # (default value #3333#)


Dial length: Integer; When recording finish, will delete the recording files if the dial number length is less than the parameter value. Default value is 0 (0 means this setting do not invalid)

Hook-off time: After the time (parameter value) of hook-off, the standalone recorder judges it a pick up. The default value is 120 ms

Hook-on time: After the time (parameter value) of hook-on, the standalone recorder judges it a pick off. The default value is 500 ms

Hook off (V): Pick up voltage (4~18V)


Hook on (V): pick off voltage (18v ~46V)



No display prefix No. : when the first digital for income or out call is same as the added digital, it will do not display and delete these digitals. Such as firstly dial 9 when call out in the company. After setting it there will be not show 9 on the software interface and recorded files.


No Record No.: when the incoming and out call are same as the added the telephone number, it will do not record these telephone number calls. The maximum is to set 20 telephone numbers not to record. Every telephone number is less than 15 digitals.

6.3.7.6 Read embedded version



Click "Read embedded version", can check all standalone recorder's hardware version.

6.3.7.7 Database (only for second development)



7, G729 Voice decoder installation


You need to install voice decoder software **G729** (after installation, the recorded files can be directly played by Windows media player in the computer): open **G729** folder, right click **G729aACM.inf**, choose "install" to auto install.



G729 folder

8. Center Management software instruction

8.1 , No need install software. Only need to install SetupOCX.bat when run software at the first time.




8.2, Login in




Default use name: **admin**

Default password: **admin**


8.3, Add new area (Right click), and rename by yourself.





8.4, Add new device



8.5, input standalone recorder IP info




8.6, Device login in




Select “Auto login in device when run”. If do not select this option, you need to login in device firstly after you open software every time.


8.7, Show channel status after login in



8.8, Monitor



8.9, Play




8.10, Search

Record time	Channel num...	I/O	Incoming nu...	Dial number	Duration	Customer	Imp
2013-06-18 19:33:19	001	Out		9200	00:00:36		
2013-06-18 19:33:19	002	Out		9200	00:00:36		
2013-06-18 19:10:50	002	Out		9200	00:00:05		
2013-06-18 19:10:49	001	Out		9200	00:00:04		
2013-06-18 16:51:20	001	Out		6606	00:00:06		
2013-06-18 16:51:20	002	Out		6606	00:00:07		
2013-06-18 16:50:53	001	Out		6606	00:00:08		
2013-06-18 16:50:53	002	Out		6606	00:00:09		
2013-06-18 16:50:30	001	Out		6606	00:00:10		
2013-06-18 16:50:30	002	Out		6606	00:00:10		
2013-06-18 16:50:18	001	Out		6606	00:00:03		
2013-06-18 16:50:18	002	Out		6606	00:00:03		
2013-06-18 16:49:14	001	Out		6606	00:00:06		
2013-06-18 16:49:14	002	Out		6606	00:00:07		
2013-06-18 16:48:28	001	Out		6606	00:00:07		
2013-06-18 16:48:28	002	Out		6606	00:00:08		

8.11, Download

Default local PC path: C:\RecordFiles\


You can change the path by yourself




8.12, Backup

Default local PC path: **C:\RecordFiles**

You can change the path by yourself



8.13, Check hardware version



9, Others

9.1, RDMC and WEB can not run in a PC at the same time

9.2, RESET: reset device default IP and default user and password and port number (press this reset button over 4 seconds; less than 4 seconds, only restart the device).

9.3 On-off: Power switch: **need to press on-off switch firstly, then pull out the power line after 4 seconds. Or else the calls may miss or the hard disk may be broken.**