

## DIY WALLPAPERING CHECKLIST



Follow all the manufacturer's instructions on the materials and equipment you're using and then refer to these tips to hang wallpaper with confidence.

#### **BASICS**

- $\square$  Set a budget.
- ☐ Take careful measurements of your walls.
- ☐ Structures in older homes may not be plumb/square/ level. Detailed measurements will help you work with/ around those features.
- ☐ Is this a quick update or redecorating from scratch?
- ☐ Can existing furniture and decorative items be reused?
- ☐ Choose a theme/design/colour scheme that enhances your home.
- ☐ Consider the appearance of the wallpaper from within the room and from other rooms.
- ☐ Will new lighting be needed to make the most of the new look?
- ☐ What do you want to hide/emphasize?
- ☐ All paper, or paint and paper combination?
- ☐ Take samples of relevant carpet, fabric and paint colours shopping for correct matching.
- ☐ Work out timeline of work required, factor in prep and drying times etc.

#### **TYPES OF WALLPAPER**

- Vinyl coated paper
- Coated fabric
- Paper backed vinyl/solid sheet vinyl
- Fabric backed vinyl
- Solid vinyl
- Paper
- Glass beaded
- Grasscloth
- Woven, non-woven etc.
- Mural

- Digital prints
- Hand printed
- Wallpaper tiles
- Wall decals
- Pre or ready-pasted, paste-the-paper or paste-the-wall types of wallpaper etc

#### **CONSIDER**

- Light fastness
- Expected wear and tear (varieties go from very delicate to scrubbable)
- Ease of future redecoration (dry strippable, wet removal, peelable)
- Texture
- Metallic effects
- Dimensional effects like embossing
- Size of print
- Vintage, retro, modern designs etc

### **EXISTING SURFACE FOR PAPERING**

- Extensive repairs needed?
- Oil-based/gloss paint or existing wallpaper?
- Papering onto raw or painted timber, fresh plaster walls etc?
- Lining paper required? What type and weight?

### **BUYING**

- ☐ Purchase sufficient quantities for the job all with the same batch number.
- ☐ Allow an extra 10 per cent more if there is a large design / big repeat.







# **DIY WALLPAPERING CHECKLIST**

TC	OOLS, MATERIALS AND EQUIPMENT Wallpaper		Either loosen or remove faceplates of switches and power points etc. (paper can be slipped under a
	Size (wall sealer - if required)		loosened fitting).
	Paste (appropriate adhesive - if required)		Switch power off at the mains before working around anything electrical.
	Paste table		Some manufacturers note that the pH of your walls can
	Pasting brush		cause issues. Alkalinity can be a problem with foil papers
	Smoothing brush		
	Sponge	PA	APER PREPARATION
	Plumb bob		Roll out your wallpaper on a flat area in good
	Tape measure		natural light.
	Sharp knife		Check for any variations in pattern or colour.
	Wall paper shears or very sharp, long scissors		Check which way up the paper should be hung.
	Long metal ruler		Measure the height of your wall from skirting to ceiling.
	Bucket of clean water		
	Ladder	W	HEN CUTTING
	Seam roller		Mark the paper where you have to cut it.
	Wallpaper roller		Allow an extra 5cm top and bottom for neat trimming.
	Water-based clear coating and brush (if required)		Cut with a utility knife and metal rule (or whatever you find easiest).
GETTING STARTED			Mark the back of each length at the top with
	Engage paper hanger (if using one), check all references.		a "T" for top.
	Run your ideas by the paper hanger you will be using.		
	Ask hanger how much money-saving labouring you can do for them.	Cl	JTTING BOLD PATTERNS
			Start hanging at your chosen focal point.
	Make a list all tools and equipment required, then borrow, rent or buy those items.		Cut the first lenght to maximise the design by placing;
	Empty room as much as possible.		• a complete motif at the top and bottom of the wall or,
	Move remaining items to centre of room and cover		• the pattern distributed evenly up the wall or,
_	to protect them.		• a focal motif in the most advantageous place.
	Purchase and take delivery of all materials before you start.		Before cutting subsequent lengths, match pattern with previous length.
Sl	JRFACE PREPARATION		Expect some waste.
	Refer to our painting checklist for detailed surface	\A/	HERE TO START PAPERING
	preparation tips:		
	http://news.domain.com.au/domain/diy/		Avoid starting/ending in a corner.
	the-essential-diy-painting-guide-20120215-1t4ya.html		Begin where most appropriate for your job and wallpaper design:
	Start with a sound surface, clean, dry and smooth.		an inconspicuous spot e.g. behind a door
	Strip any old wallpaper that is rough and not perfectly adhered to the wall.		the middle of the wall
	Use size to seal porous surfaces if required.		a focal point
	Use lining paper for a really professional job (normally 1000 gms).		<ul> <li>25mm less than the width of the wallpaper from a corner (The extra 25mm will wrap into the corner,</li> </ul>
	Finish all painting in the room before wallpapering.		the final piece of wallpaper will overlap this).







# **DIY WALLPAPERING CHECKLIST**

	HERE TO START PAPERING (CONT.)		If the wallpaper rolls are numbered they should be hung in sequence.
	Wherever you chose to start, create a vertical line.  Never assume any architectural feature is straight.  Do a plumb line on every wall.		Certain types of wallpapers need to be hung in lengths alternating between one way up and then the next length inverted.
	Severely out-of-plumb walls will cause problems with obviously patterned papers.		Smooth down the middle with the smoothing brush. Work out towards the top and bottom edges, removing air bubbles.
PREPARE THE WALLPAPER			Press paper gently into corners at cornice and skirting
For	r ready-pasted paper		boards with the brush.
Fol	low the manufacturer's instructions which will usually be;		Use a wide straightedge to press the paper even more
	Fold it up into a loose concertina shape and place in a bucket of water until the paper is fully soaked.		tightly into corners for a professional finish. Use a sharp utility knife on the underside of the
	Book the paper and allow it to relax for 5 to 15 minutes to soften and activate the paste.		straightedge to trim the paper neatly.  Use a seam roller to get a perfect finish between lengths
For	r paste-the-paper wallpaper		Remove any excess paste with a clean, damp sponge.
Fol	low the manufacturer's instructions which will usually be;		Repeat process, working around the room.
	Mix the wallpaper paste.		Butt the edge of each new length of paper up as closely
	Lay the paper face down on a work surface.		to the previous one as possible.
	Use a brush to apply a smooth, even cover of paste.		Carefully match patterns as you go.
	Book the paper and allow it to relax for 5 to 15 minutes to soften and activate the paste.		Try to wrap wallpaper through corners and overlap with adjoining pieces.
	Wipe down your work surface between pasting each length of paper.	SA	AFETY TIPS
For paste-the-wall wallpaper		•	Wear sturdy, protective clothing and footwear.
Fol	low the manufacturer's instructions which will usually be;	•	Safety glasses.
	Mix the wallpaper paste.	•	Dust masks.
	Use a brush or roller to apply a smooth, even cover of paste to the wall.	•	Make sure there are at least two of you to lift and manoeuvre heavy items.
	Make sure to apply paste a little more than the width of	•	Lift with your knees not your back.
	the wallpaper.	•	Be especially careful when using ladders.
		•	Ensure your work area is well ventilated and well lit.
HANGING THE WALLPAPER		•	Be very careful in older homes where there may be toxic
	Novices will probably need an extra pair of hands to help get the wallpaper perfectly vertical while they negotiate a ladder.	•	substances like lead paint, asbestos etc.  Take care using hazardous materials and chemicals, always follow the manufacturer's instructions.
	Ensure the pattern is the right way up.		diways follow the manaractarer's mistractions.
	Hold the top of the wallpaper with the 5cm overhang at the top.		
	Stick it to the top of the wall in line with the plumb line.		This information is general in nature.
	Avoid moving the paper around too much, it can stretch, wrinkle and tear.		Consult the relevant experts to get
	Joints should be butted together closely and		specific advice about your project.



never overlap.

