


AeroElectric Connection P.O. Box 130 Medicine Lodge, KS 67104-0130

AEC9051 Series Filtered LED Drivers



1.0 FEATURES

- **1.1** The AEC9051 Series LED driver assemblies were crafted to offer the OBAM aircraft owner a means by which the popular "Buck-Puck" by LED Dynamics could be integrated into a noise free, do-it-yerself LED illumination project. The stand-alone Buck-Pucks are reported to generate considerable radio noise in the VHF Comm band. These would certainly be a problem for VHF OMNI radios also.
- **1.2** The AeroElectric Connection crafted radio noise filters for both the 14v input and LED output leads and assembled them onto an etched circuit board along with a 9-pin D-sub connector and a Buck-Puck. The finished assembly is illustrated above.
- **1.3** Electrical characteristics of the AEC9051 Series LED drivers is determined by the Model of Buck-Puck innstalled. The AEC9051-1 LED Driver and AEC9051-99 Filter Assemblies are normally stocked. Dash 2, 3 and 4 Drivers are available on special order.

AEC9051 Series Kits Dash Numbers versus Output Current				
Dash No.	Output Current mA	Buck-Puck Installed		
-1	1,000	3021-D-E-1000		
-2	700	3021-D-E-700		
-3	500	3021-D-E-500		
-4	350	3021-D-E-350		
-99	Filter Only No Buck-Puck Installed			

1.4 Complete application and performance data on the various Buck-Puck drivers may be downloaded from:

http://www.leddynamics.com/LuxDrive/drivers.php

2.0 INSTALLATION

2.1 Parts Supplied

AEC9051-X LED Driver Kit Contents			
Qty	P/N	Description	
1	9051-100-X	LED Driver or Filter Assembly	
9	S604S20	D-Sub Sockets, 20AWG Machined	
1	S604F9	Connector, 9-Pin D-sub Crimp Pins	
1	S604H9	Hood, 9-Pin D-sub Connector	
1	9051-700	Installation Manual (This document)	

2.2 Materials Needed but Not Supplied.

- **2.2.1** 22AWG or 20AWG Tefzel wire is recommended for user installed wires as required to install this product.
- **2.2.2** Four each 4-40 thread mounting screws of length appropriate for installation on intended mounting surface. Head style optional.
- **2.2.3** The installer may find it useful to wrap wires with plastic or silicone tape under the wire support clamp inside the D-Sub connector hood as shown in adjacent figure.
- **2.2.4 Dash 99 Filter Assembly:** If assembling your own Buck-Puck onto a -99 Filter Assembly, use electronic grade 60/40 or 63/37 solder. Use a pea-size spot of E6000 or similar adhesive under the Buck-Puck before seating it down on the board. Solder the connections from the bottom side and trim the Buck-Puck pins off flush with the top of the solder joint.

2.3 Special Tools


- **2.3.1 Machined Connector Pins** supplied with this kit are installed with a 4-Quadrant crimp tool for 20AWG pins (M39039/64-369) and sockets (M39029/63-368). See websites for B&C Specialty Products, Steinair, and/or Marlin P. Jones for low cost D-sub machined pins crimp tools.
- **2.3.2** Alternatively, the user may opt to replace the removable crimped-pins connector with a solderable 9-pin, female device from a local supplier
- **2.3.3** The installer may also find it useful to possess a D-Sub pin insertion/removal tool. Radio Shack sells suitable tools. The adjacent figures illustrate techniques for installation of the D-Sub connector hood.

2.4 Connector Installation

2.4.1 Refer to wiring diagram in this document for connector pin functional identification. and identification



of pin numbers for the wire entry side of the mating



connector.

2.4.2 The connector hood is installed and assembled and retained on the mating ECB connector as shown above.


3.0 System Checkout

- **3.1.1** The Buck-Puck LED Driver is a product of LED Dynamics. AeroElectric Connection's contribution adds only radio noise filtering and an aircraft friendly packaging. Performance of this product should be benchmarked against the Buck-Puck data cited earlier in these instructions.
- **3.1.2** To test the installed driver independently of the LEDs, use a 5 ohm, 5 watt resistor to dummy load theLED(+) and LED(-) pins on the connector. Connect a voltmeter across the resistor. A properly functioning driver will develop a voltage across the resistor that is commensurate with the rating of the installed Buck-Puck.


Test Voltage for 5-Ohm Dummy Load			
Dash No.	Buck-Puck Installed	Test Voltage	
-1	3021-D-E-1000	5.0±0.25V	
-2	3021-D-E-700	3.5±0.18V	
-3	3021-D-E-500	2.5±0.13V	
-4	3021-D-E-350	1.75±0.1V	

4.0 Conditions for Continued Airworthiness

4.1 The LED Driver Assembly requires no periodic calibration. Repair or replacement is made on condition of damage or failure.







SCHEMATIC AND PINOUT

