

HINT:

- Use the same procedures for the RH and LH sides.
- The procedures listed below are for the LH side.



- (a) Install the front No. 1 speaker assembly with the 3 screws.
- (b) Connect the connector.



- 3. INSTALL FRONT DOOR LOWER FRAME BRACKET GARNISH LH (See page ED-49)
- 4. INSTALL FRONT DOOR WINDOW REGULATOR HANDLE ASSEMBLY (See page ED-49)
- 5. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

Torque: 3.9 N*m (40 kgf*cm, 35 in.*lbf)



