

WX-SX Sounds Disks

Compatibility list:

WX2 - WX400 - WX Expander - SX2 - SX3

WK4 - SK76 - SK88 - PS2500 - GPS2500

44 Rock & Pop Killer Drums 955044

Acoustic Tom 1,2	Big Tom
Cabasa	Chinoise
Cup 90	Electric Tom
HH Clds 1,2,3	HH Noise
HH Open	HH Short
Hit Clap	Kick (1 to 10)
Reverse	Reverse Tom
Rider	Rim Shot
SD Acid	Sd Flam
SD Hip Hop 1,2	SD Power
SD Rock 1,2	SD Room
SD Shot	SD Splash
Splashy	Zappshot

69 World: Oriental Percussions 955069

Closed Sagt	Doff Dom
Doff Sak	Doff Tak
Doholla Dom	Doholla Sak
Doholla Tak 1,2	Nakr Zn Dom
Nakr Zn Sak	Nakr Zn Tak
Open Sagt	Req Bell 1,2
Req Sad	Req Taq 1,2,3
Reqdom	Tablah 1,2,3,4,5,6,7,8

121 Church Organs 956121

Church	Church Pan
Pedale High	Pedale Low
Pieno	Recitativo
Trb Church	Tutti
Tutti Pan	

52 Pop Collection Vol.1 955052

B3 Organ	B3 Perc.
Bellpad 1,2,3	Crescendo Brass
FM Piano 1,2	Fretless
Fuzzie 1,2	Modern Brass
Pad 1,2,3,4,5,6,7,8	Syn Bend
Synth Horns	Synth Strings
Synthone	

83 Rock Organs 955083

B3 fast 1	B3 fast 2
B3 slow	B3-2
Classico	Distorg 1
Distorg 2	Dyn - Perc.
Efx Organ 1	Efx Organ 1
Highhhhh	Padorgan 1
Padorgan 2	Padorgan 3
Padorgan 4	Percussion Organ
Percussion Reso	R. Organ fast
R. Organ slow	Rotary 1
Rotary 2	Short Percussion
Slow - Dist	Slow - Fast

148 On stage Piano 956148

Dyn Piano	El.Grand Piano
Honky Piano	Live Piano
Stage Piano	

66 Atmospheres of the '80 955066

Fairl. Choir	Fantasy 1,2,3
Guitar Pad	Lyle Mays
Obx DG 1,2,3,4,5,6,7	Synth Strings
X Fantasy Synth	

104 Classic Orchestra 956104

Bassoon 1,2	Boosted Timpani
Cello 1,2	Clarinet 1,2
French Horns 1,2	Oboe 1,2
Orchestra Snare	Piatti 1,2
Trombone Swell 1,2	