

Social Science Building Multi Media Instructions

1. To use this system press the PROJECTOR ON button. This will lower the screen and start up the projector. You will not be able to select any sources until the projector has warmed up. (This takes about 60 seconds)
2. You can select between sources by pressing the buttons marked COMPUTER 1, VIDEO, and VHS.
3. The VHS is located inside the box on the wall and is accessible from the side.
4. You can connect a computer to the inputs under the COMPUTER 1 button. The large plug is for a VGA cable and the smaller plug is for an audio cable.
5. To use another video source, connect it using an S-Video cable for video and RCA cables for the audio.
6. To adjust the volume, use the VOLUME UP and VOLUME DOWN buttons.
7. When you are finished, remember to press the PROJECTOR OFF button to raise the screen and turn off the projector.

**IF YOU HAVE ANY QUESTIONS, PLEASE VISIT US
ON THE WEB AT**

<http://www.tcnj.edu/~mtss>

OR CALL THE HELP DESK AT x2660