










PC BOARD

TUNER (X02-1080-11)




Qb2: 2SC535(B) or 2SC381(O), Qb3~6,9~15: 2SC945(R) or (Q) or 2SC828(P) or (Q), Qb7: 2SA733(R) or (Q), Qb8: 2SC1983, ICb1: TA7060P, ICb1~11,22,24: 1S1555 or 1S2076, Db12~16: W06B, Db17,18: YZ140, Db19~21: GD-4-203CD, Db23: 1N60





b1: TA7060P, ICb2,3: LA1222, ICb4: HA1137W, ICb5: HA1196, ICb6: NJM4558D(A)or(B), ICb7: HA1197



HA-1137W
HA-1196
HA-1197

