

华秦游乐，让生活更快乐

# 沙滩车（成人版）说明书

Description of beach vehicle



 广州市华秦游乐设备有限公司  
Guangzhou Huaqin Playground Equipment Co.,LTD.

地址：广州市番禺市沙头街汀根村大板工业区1街22号8号厂房2-5楼  
Add: Floor 2-5, 8th building No.22 first street Daban industrial zone Satou  
street Panyu district, Guangzhou

电话(Tel) : 020-87365415 全国免费热线 : 400-000-3909

传真(Fax) : 020-23885188

网址 ( web ) : [www.cnhuaqin.com](http://www.cnhuaqin.com)



微信公众号



移动端网站

Please auspicious read this instruction manual before  
installation and use, after reading, please keep for later use.  
敬请在安装和使用前详阅此说明书，阅后请妥善保管，以备后用

广州市华秦游乐设备有限公司  
Guangzhou Huaqin Playground Equipment Co.,LTD.

## 公司简介/Coperating instructions

广州市华秦游乐设备有限公司创建于2003年，座落在世界最大的游艺设备、游乐设施生产基地——广州番禺，是一家集研发、生产、制造、销售服务于一体的游乐设备公司，多年来专业生产各类室内、户外游乐设施，历经10载的锐意拼搏，在游乐业迅速崛起已初具规模，产品涵盖室内外大型机动类、摇摆类、旋转马类、电动类、儿童碰碰车、乐吧车-乐逍遥等系列。30多项自主设计专利，在同行业中遥遥领先。这一切无不倾着我们每个华秦人的心血。

公司自创建以来，不断引进国内外一流的设备与工艺技术，通过导入国际先进的管理理念和标准规范的认证体系，通过了ISO2000质量体系认证，CE，UL认证。“专业、专注、持续创新”是公司多年来的核心竞争力，在科技高度发达的今天，公司始终以“健康、安全”发展为第一要素，华秦乐吧车等产品销往全国各地并远销欧美、东南亚等50多个国家和地区。公司通过加大技术创新，产品创新和人才培养的投入力度，致力打造创新型企业的良好形象，争创国际一流品牌和行业共享美好明天。

Huaqin Playground Equipment Co.,Ltd. was founded in 2003, is located in the world's largest amusement, recreation production base -- Guangzhou Panyu, is a collection research and development, production, manufacturing, sales and service in one of the recreation equipment company, for many years specializing in the production of all kinds of indoor and outdoor recreational facilities, after 10 years of hard struggle, forge, the rapid rise in tourism has begun to take shape, the product covers both inside and outside the class room large motor, swing class, horse type, electric type, bumper cars and other six series. More than 30 independent design patents, be way ahead in the same industry. All without leaning we each Hua Qin people's effort.

Since the inception of the company, and constantly introducing domestic and foreign first-class equipment and technology, through the introduction of the international advanced management concepts and standards system certification, through the ISO2000 quality system certification, CE certification, UL. "Professional, dedicated, continuous innovation" is the core competitiveness of the company for many years, in the highly developed science and technology today, the company has always been to "health, safety" development is the first factor, Hua Qin products are sold throughout the country and exported to Europe and the United States, Southeast Asia more than 50 countries and regions. The company through increased technological innovation, product innovation and personnel training efforts, efforts to create a good image of innovative enterprises, striving for the international first-class brand and industry share beautiful tomorrow.

全国免费热线  
Free Hotline **400-000-3909**

## **为防止意外发生** In order to avoid accidents happens

- 使用时必须坐稳并抓紧方向盘。  
Must be grasp the steering wheel and sit well when using
- 禁止撞向人体。  
Not allowed to hit human.
- 只能在平整地面上行驶。  
Can only run on flat ground.
- 使用时远离陡坡、水源、沟槽。  
Stay away from steep slope, water and ditch.
- 驾驶车辆时，必须由成人或家长看护和指导，且看护人不得离开，并确保您的孩子一直在您的视野范围之内。  
When driving, children must be accompanied by adults or parents, please make sure your children always stay in your vision.
- 禁止在非安全地带驾驶本车辆，如道路、车辆附近，台阶上等。  
Not allowed to driving in non-safety zone such as road, near the cars, steaps and so on

## 常见故障/FAQ (Normal malfunction)

故障描述/Problems	解决方法/Solutions
1.机台不通电 Machine no electricity	1.检查电瓶上面的保险管是否烧断，是，更换保险管。Please check if the fuse on Battery burned out or not,if yes,change the fuse 2.检查总电源开关导线有无松脱，或开关损坏。Check the cable of power switch is loose or not, or check if the power switch is good or not
2.显示屏花屏 The LCD screen showed blurred screen	1.检查显示屏线有无松出。Check if the cable of the LCD screen is loose or not 2.更换显示屏。Change the lcd screen
3.充不进电 Battery fails to charge	1.检查充电接口背面的焊接头有无脱落。有，用电烙铁焊接牢固。Check the backside connector of the charger plug plumbed well or not,if loose,plumbed firmly 2.检查充电接口至电瓶输出的连接的保险管，有无烧断，有，更换保险管。"Check the fuse between the charger plug and battery input burned out or not,if yes,change the fuse
4.不启动机台 Machine can not start	1.按遥控的数字与机台指拨开关的拨号是否相同，参见遥控的指拨开关说明进行审核。Check if the NO of remote control is the same as the machine dip switch,please refer to the remote control dip switch instruction to confirm the same as the machine dip switch,please refer to the remote control dip switch instruction to confirm 2.更换学习模块或重新设置。"Change the learning module and reset it
5.启动机台后加油门 机台不走 Start the machine and speed up but the machine not moving	1.检查刹车把手有无损坏油门控制线接口有无松出。Check if the brake is damaged or not,or check the speed up control line connector loose or not


# 目录 Content

一.公司简介.....	1
Company introduction	
二.产品分解.....	3
Product details	
三.规格参数.....	4
Parameters	
四.设置说明.....	5
Operation instruction	
五.遥控说明.....	8
Remote control instructions	
六.故障排除.....	9
Failure recovery	

## 产品分解/Product details



## 遥控说明/Remote control instructions



遥控按1代表控制1号机台，遥控按2表示控制2号机台，如此类推。

如下是主板指拨开关遥控控制机台编号说明。

Press 1 On remote control means control NO.1 machine, Press 2 means control NO.2 machine, the rest can be done in the same way.

Blow is the motherboard DIP Switch remote control the machine NO instruction:

遥控数字 Remote Control NO.	指拨开关/Dip switch			
	1	2	3	4
1	OFF	OFF	OFF	ON
2	OFF	OFF	ON	OFF
3	OFF	OFF	ON	ON
4	OFF	ON	OFF	OFF
5	ON	ON	ON	OFF
6	OFF	ON	ON	OFF
7	OFF	ON	ON	ON
8	ON	OFF	OFF	OFF
9	ON	OFF	OFF	ON
10	ON	OFF	ON	ON
11	ON	OFF	ON	OFF
12	ON	ON	OFF	OFF
13	ON	ON	ON	ON
14	ON	ON	OFF	ON
15	OFF	ON	OFF	ON

## 功能开关/Function switch




启动开关/Start switch 方向开关/Directional switch 电门锁/Electric door lock



## (2) 操作界面/Operation interface

液晶屏界面显示当前 LCD screen displays the current interface  
游戏时间 play time 当前速度 Surplus coins 电量状态 \ 音量 power state / volume



## (3) 按键功能/Keyboard function


**播放:** 按下一首播放音乐,再按可停止播放 上一首PREV,下一首NEXT  
音量+、音量-、可以加减音量大小

**速度调节:** 可选慢\中\快三档速度

**菜单MENU:** 按一次可鸣叫喇叭  
Press the Play button can play music, Press one more time to stop the music, previous song press PREV, next songs please press NEXT, Press Volume +, Volume - can adjust the volume

**Speed adjustment:** You can select Slow/Mid/High Speed

**MENU:** Press once for speaker function




## 规格与参数/Specifications and Parameters

规格[Size]	1520*990*1010mm
包装规格[Packing size]	1560*1030*1050mm
净重[Net weight]	115KG
最大承重[Max Bearing Weight]	100kg
刹车配置 [Brake Configuration]	前后碟刹 [Electronic brake]
配套电机[Matching Motor]	48V\250W
配套铅酸电池[Matching Lead Acid battery]	12V-20A\4PCS
续航时间[Useing time]	5-6小时[Hours]
配套彩灯[Matching colorful Light]	射灯 [Lamp]
配套充电器[Matching Charger]	48V-4A\1PCS
配套控制器[Matching controller]	智能控制器[Intelligent Controller]
启动方式[Start mode]	无线遥控[Remote control]
电压显示[Voltage display]	标准配置电池电压显示 [Standard battery voltage display]
外壳材料[Shell material]	五金+塑胶
颜色[Color]	迷彩绿/迷彩粉/迷彩红
速度设置[Speed setting]:	高/中/低速 15/12/8km/h

## 设置说明/Set description:

在待机模式下,按下下一首NEXT键开启开关,进入后台设置页面,声音-Vol-为选择键,可循环选择需设置项目,下一首NEXT键可进入所选的功能项,设置完成后按上一首PREV键进行确认后关闭电源即可保存。


In standby mode, pressing Next button to open the switch meaning entering into the background setting mode ,VOL- is selection button, Pressing NEXT can enter into function selection. After finishing all settings, please press PREV button for confirmation. Turning off the power to save all information



### (1)后台设置/General Settings

常规模式下可设置: 1 币值 2 时间 3 查账 4 打码 5 演示 6 配卡


Under General setting mode can set up 1.Coin value, 2 Time. 3 Checking account 4. printing code 5.Demonstration 6. Matching Card



### ① 币值/Monetary Value

安装投币器时使用此功能,按+或-键可以调节几币一玩,可设0-95个数值。

Utilizing this function during installation of coin acceptor,press the +or - key to adjust coins numbers for each game, number from 0-95 coins




### ② 游戏时间设置/Playing time setting

后台设置/按+或-键移动光标,移到游戏时间设置项,按下一首键确认,进入调节数值界面,

可设置0-99分钟。按下一首确认后关电源退出。


On background setting press +,- to move the cursor,choose the game time setting,press Next Button to confirm and then enter into the numerical interface,at this time please adjust 0-99mins,press Next Button for confirmation and then turn off the power to exit the setting



### ③ 账目/Checking account

账目功能可查看当前的投币数,刷卡数和遥控数

Accounting function can review the total coins,playing times by swiping card and playing times by remote control




### ④ 打码/Printing code

此功能需要定制,出厂默认为不打码 (This function needs to be customized, the factory default setting is non-printing code.)

可查看机台号\总时间\次数\校验码条码相关信息


Can check machine No/Total time/Times/Verification Code



### ⑤ 演示时间/Presentation time

设置演示模式的自动表演时间(表演时间有0-95分钟可调)

Setting automatic show time in demo mode(Show time can adjust from 0-95mins)



### ⑥ 配卡/Match card

可查看机台当前已配卡数信息

Can review how many cards have been created on the machine

