

SERVICE BULLETIN

NO.: 1044 Revision A

TO: Marine, Recreation & Consumer Electronics Dealers and Customers

DATE: 29 November 2010

SUBJECT: Weather data may not appear on chartplotters that have a XM WX

Satellite Weather® subscription.

AFFECTED PRODUCTS

This issue applies only to the following chartplotter and XM® antenna software versions.

Chartplotter	Chartplotter Software Version	When Used with XM Antenna	Antenna Software Version
GPSMAP® 430x/430sx	4.30 or earlier	GXM [™] 30 or GXM 31	Any
GPSMAP 440x/440sx	4.30 or earlier	GXM 30 or GXM 31	Any
GPSMAP 530/530s	4.30 or earlier	GXM 30 or GXM 31	Any
GPSMAP 535/535s	4.30 or earlier	GXM 30 or GXM 31	Any
GPSMAP 540/540s	4.30 or earlier	GXM 30 or GXM 31	Any
GPSMAP 545/545s	4.30 or earlier	GXM 30 or GXM 31	Any
GPSMAP 421/421s	Any	GXM 51	2.20 or earlier
GPSMAP 441/441s	Any	GXM 51	2.20 or earlier
GPSMAP 521/521s	Any	GXM 51	2.20 or earlier
GPSMAP 541/541s	Any	GXM 51	2.20 or earlier
GPSMAP 526/526s	Any	GXM 51	2.20 or earlier
GPSMAP 536/536s	Any	GXM 51	2.20 or earlier
GPSMAP 546/546s	Any	GXM 51	2.20 or earlier
GPSMAP 4008	Any	GXM 51	2.20 or earlier
GPSMAP 4010	Any	GXM 51	2.20 or earlier
GPSMAP 4012	Any	GXM 51	2.20 or earlier
GPSMAP 4208	Any	GXM 51	2.20 or earlier

© Copyright 2010 Garmin Ltd. or its subsidiaries All Rights Reserved

Except as expressly provided herein, no part of this document may be reproduced, copied, transmitted, disseminated, downloaded or stored in any storage medium, for any purpose without the express prior written consent of Garmin. Garmin hereby grants permission to download a single copy of this document and of any revision to this document onto a hard drive or other electronic storage medium to be viewed and to print one copy of this document or of any revision hereto, provided that such electronic or printed copy of this document or revision must contain the complete text of this copyright notice and provided further that any unauthorized commercial distribution of this document or any revision hereto is strictly prohibited.

Chartplotter	Chartplotter Software Version	When Used with XM Antenna	Antenna Software Version
GPSMAP 4210	Any	GXM 51	2.20 or earlier
GPSMAP 4212	Any	GXM 51	2.20 or earlier
GPSMAP 5008	Any	GXM 51	2.20 or earlier
GPSMAP 5012	Any	GXM 51	2.20 or earlier
GPSMAP 5015	Any	GXM 51	2.20 or earlier
GPSMAP 5208	Any	GXM 51	2.20 or earlier
GPSMAP 5212	Any	GXM 51	2.20 or earlier
GPSMAP 5215	Any	GXM 51	2.20 or earlier
GPSMAP 720	Any	GXM 51	2.20 or earlier
GPSMAP 740	Any	GXM 51	2.20 or earlier
GPSMAP 6008	Any	GXM 51	2.20 or earlier
GPSMAP 6012	Any	GXM 51	2.20 or earlier
GPSMAP 6208	Any	GXM 51	2.20 or earlier
GPSMAP 6212	Any	GXM 51	2.20 or earlier
GPSMAP 7012	Any	GXM 51	2.20 or earlier
GPSMAP 7015	Any	GXM 51	2.20 or earlier
GPSMAP 7212	Any	GXM 51	2.20 or earlier

DESCRIPTION

XM radio has discontinued free audio broadcast on channel 247. This channel lineup change may impact graphical weather from being displayed on certain Garmin chartplotters.

RESOLUTION

If your chartplotter or XM antenna has a software version listed above and you have an XM WX Satellite Weather subscription, update your chartplotter or XM antenna to the latest software. Download the software update for free or purchase it on a preprogrammed SD card at http://www.garmin.com/support/software/marine.html.

CUSTOMER ACTION

To determine the chartplotter or GXM 30/31 software version, from the chartplotter Home screen, select **Configure > System > System Information**.

To determine the GXM 51 software version, from the chartplotter Home screen, select Configure > Communications > NMEA 2000 Setup > Device List > Garmin GXM51.

COMPLIANCE

Mandatory only if you have an XM WX Satellite Weather subscription for your chartplotter. Otherwise, compliance is optional.