

W-B

TOYOTA TACOMA (EM01D0U)

O : Parts Location

| Code | See Page | Code | See Page | Code | See Page |
|------|----------|------|----------|------|----------|
| 18 | 46 (*1) | 18 | 48 (*2) | J1 | 45 |

Sunction Block and Wire Harness Connector

| Code | See Page | Junction Block and Wire Harness (Connector Location) | |
|------|----------|--|--|
| 1D | 28 | Frame Wire and Driver Side J/B (Lower Finish Panel) | |
| 1E | 28 | Roof Wire and Driver Side J/B (Lower Finish Panel) | |
| 1H | 29 | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel) | |

7: Ground Points

| Code | See Page | Ground Points Location | |
|------|----------|----------------------------|--|
| IA | 54 | Left Kick Panel | |
| BD | 56 (*1) | Near the Rear Differential | |
| во | 57 (*2) | | |

* 1 : Double Cab * 2 : Access Cab * 3 : Regular Cab * 4 : Separate Seat * 5 : Bench Seat