





























# 1GR-FE ENGINE MECHANICAL

## SST

	<p>09011-38121</p>	<p>12 mm Socket Wrench for 12 Pointed Head</p>	
	<p>09032-00100</p>	<p>Oil Pan Seal Cutter</p>	
	<p>09201-01055</p>	<p>Valve Guide Bushing Remover &amp; Replacer 5.5</p>	
	<p>09201-10000</p>	<p>Valve Guide Bushing Remover &amp; Replacer Set</p>	
	<p>09201-41020</p>	<p>Valve Stem Oil Seal Replacer</p>	
	<p>09202-70020</p>	<p>Valve Spring Compressor</p>	
	<p>(09202-00010)</p>	<p>Attachment</p>	
	<p>09213-54015</p>	<p>Crankshaft Pulley Holding Tool</p>	
	<p>(91651-60855)</p>	<p>Bolt</p>	
	<p>09222-30010</p>	<p>Connecting Rod Bushing Remover &amp; Replacer</p>	
	<p>09223-78010</p>	<p>Crankshaft Oil Seal Replacer</p>	

PP

	<p>09226-10010</p>	<p>Crankshaft Front &amp; Rear Bearing Replacer</p>	
	<p>09330-00021</p>	<p>Companion Flange Holding Tool</p>	
	<p>09550-60010</p>	<p>Differential Side Bearing Replacer</p>	
	<p>(09951-00350)</p>	<p>Replacer 35</p>	
	<p>09843-18030</p>	<p>Tacho-pulse Pickup Wire No.2</p>	
	<p>09843-18040</p>	<p>Diagnosis Check Wire No.2</p>	
	<p>09950-50013</p>	<p>Puller C Set</p>	
	<p>(09951-05010)</p>	<p>Hanger 150</p>	
	<p>(09952-05010)</p>	<p>Slide Arm</p>	
	<p>(09953-05020)</p>	<p>Center Bolt 150</p>	
	<p>(09954-05030)</p>	<p>Claw No.3</p>	
	<p>09950-60010</p>	<p>Replacer Set</p>	

	(09951-00250)	Replacer 25	
	09950-70010	Handle Set	
	(09951-07100)	Handle 100	
	(09951-07150)	Handle 150	
	09992-00500	Compression Gauge Attachment	