



# FUEL PUMP COMPONENTS



FU

FU



● Non-reusable part