

PROPELLER SHAFT SYSTEM

PROBLEM SYMPTOMS TABLE

HINT:

Use the table below to help you find the cause of the problem. The numbers indicate the ranked order of probability of each of the possible causes. Check each part in order. If necessary, replace these parts.

Symptom	Suspected area	See page
Noise	1. Propeller shaft universal joint spider bearing (Regular Cab 2WD)	PR-3
	2. Propeller shaft universal joint spider bearing (Access Cab 2WD and Double Cab 2WD)	PR-8
	3. Front propeller shaft universal joint spider bearing (4WD)	PR-16
	4. Propeller shaft universal joint spider bearing (Regular Cab 4WD)	PR-22
	5. Propeller shaft universal joint spider bearing (Access Cab 4WD and Double Cab 4WD)	PR-27
Vibration	1. Propeller shaft (Runout) (Regular Cab 2WD)	PR-4
	2. Propeller shaft (Runout) (Access Cab 2WD and Double Cab 2WD)	PR-11
	3. Front propeller shaft (Runout) (4WD)	PR-18
	4. Rear propeller shaft (Runout) (Regular Cab 4WD)	PR-23
	5. Rear propeller shaft (Runout) (Access Cab 4WD and Double Cab 4WD)	PR-29
	6. Propeller shaft (Imbalance)	-

PR