

HOW TO PROCEED WITH TROUBLESHOOTING

1 VEHICLE BROUGHT TO WORKSHOP

NEXT

2 CUSTOMER PROBLEM ANALYSIS

- (a) Interview and confirm the trouble.
 - (1) Confirm the symptom of the trouble.

NEXT

3 BASIC INSPECTION

- (a) Conduct basic inspection.
 - (1) Check the battery voltage.
Standard:
11 to 14 V
- (b) Check the power supply to the radio receiver assembly.
 - (1) Turn the ignition switch to the ACC position.
 - (2) Check whether or not the display appears on the radio receiver assembly.

Result	Proceed To
Display appears	A
Display does not appears	B

B

PROCEED TO PROBLEM SYMPTOMS TABLE

A

4 DTC CHECK

A

DTC OUTPUT (Go to step 5)

B

DTC NOT OUTPUT (Go to step 6)

5 DTC CHART

NEXT

GO TO STEP 7

6	PROBLEM SYMPTOMS TABLE
---	------------------------

NEXT

AV

7	CIRCUIT INSPECTION AND PART INSPECTION
---	--

NEXT

8	IDENTIFICATION OF PROBLEM
---	---------------------------

NEXT

9	CONFIRMATION TEST
---	-------------------

NEXT

END
