


BACK WINDOW GLASS

COMPONENTS


for Double Cab:




WS

for Regular Cab:

for Bench Seat Type:




for Separate Seat Type:




WS


for Access Cab:





for Double Cab:




for Regular Cab:



for RH Side on Bench Seat Type:



for Access Cab:




WS

N*m (kgf*cm, ft*lbf) : Specified torque


for Access Cab:

WS






N*m (kgf*cm, ft*lbf) : Specified torque

for Double Cab:



WS

WS



N*m (kgf*cm, ft*lbf) : Specified torque