


KM-04

Micro Mixer

INSTRUCTIONS


- Please read these instructions carefully for proper operating procedures for the BOSS KM-04.

■ THE CONTROLS:




■ CONNECTING


- Multi-instrument or recording set-ups. Set the Channel volume according to the output level of each unit.




Set the stand as illustrated, and the body will remain unlifted after the cord is connected to the unit.



■ OPERATING




1. After connecting all the cords required, set all the Channel volumes to '0' and Power/Master Volume to 'OFF'.




2. Set Power/Master Volume to 5.

3. Turn on the Power Switch of the connected units (amplifier, taperecorder, etc.)



4. Set Channel volume to proper position. (Set the channel to '0' when it is not used.)



5. When LED Peak indicator lights up, which means the sound is distorted, turn down each Channel volume. If the sound is distorted without Peak indicator lighting up, decrease total volume by turning down Master Volume.

- Turn off Power/Master Volume when the unit is not in use.

- Avoid using the unit in the place of dust, humidity and heat.

 Roland®

17047231

UPC

17047231



10981

 **BOSS**