

# AUTOPAGE

The Leader In Real Automotive Solutions®

---

## PROGRAMMING

### REMOTE TRANSMITTER PROGRAMMING

#### Enter:

1. Turn the Ignition 'switch 'OFF/ON' 3 TIMES and stay in ON position. Within 15 seconds.
2. Push the Valet switch 2 times and hold in on the 2<sup>nd</sup> push, when a long chirp is heard then release the valet switch. You are now in the Transmitter programming mode.

#### Program:

1. Press the Lock button on transmitter 1 until the siren responds on Car with a confirming chirp; the first transmitter is now programmed to Car.

**Exit:** Turn Ignition to 'OFF' position, or leave it for 15 seconds. 3 long chirps will confirm exit.

**Note:** If more than 4 transmitters programmed, the system will only keep the last four.

**The Valet switch** is a little **Red Push Button** that should be mounted under the lower left side of you dash or in the lower left kick panel near the E-brake pedal.

