

GEN 2.4 LOCATION INDICATORS

Location Indicator is a four-letter code group formulated in accordance with rules prescribed by ICAO and assigned to the location of an aeronautical fixed station.

List of ICAO location indicators is contained in Doc 7910 — Location Indicators. ICAO codes are used by Air Traffic Services, and airline operations such as flight planning to identify place of departure or destination. They are also used by AIS to produce NOTAMs, and weather agencies to produce METAR weather reports.

1. ENCODE		2. DECODE	
Location	Indicator	Indicator	Location
AMMAN (ACC/FIC)	OJAC	OJAC	AMMAN (ACC/FIC)
AMMAN/ Marka	OJAM	OJAF*	King Abdullah the First Airbase (Royal Jordanian Air Force)*
AMMAN/ Queen Alia	OJAI	OJAI	AMMAN/ Queen Alia
AQABA/King Hussein	OJAQ	OJAM	AMMAN/ Marka
King Abdullah the First Airbase (Royal Jordanian Air Force)*	OJAF*	OJAQ	AQABA/King Hussein
King Abdullah the Second Airbase *	OJKA*	OJKA*	King Abdullah the Second Airbase *
King Faisal Airbase *	OJKF*	OJKF*	King Faisal Airbase *
King Hussein Air College*	OJKH*	OJKH*	King Hussein Air College*
Muwaffaq Salti Airbase	OJMS	OJMS	Muwaffaq Salti Airbase
Predetermined Address for NOTAM and SNOWTAM	OJZZ	OJPH*	Prince Hasan Airbase *
Prince Hasan Airbase *	OJPH*	OJRW*	Rwaished (H4) Airfield*
Rwaished (H4) Airfield*	OJRW*	OJZZ	Predetermined Address for NOTAM and SNOWTAM

Location Indicators marked with an asterisk (*) cannot be used in the address component of AFS messages.