


# Coming Next Month\*

## At last! The Nova 80 Computer



Yes folks, it has finally arrived! After seeing it in the DSE catalog a year ago, after all the rumours about the "Never 80", it has materialised and we shall present the first article on this highly competitive single-board Z80 computer with BASIC interpreter in the May 1981 issue. It will have been worth waiting for!

Some of the Nova 80's features are: full-sized ASCII keyboard, RF modulator output to TV monitor, S-100 buss, up to 48K of RAM.

## WIN A MARANTZ CASSETTE DECK or FM/AM TUNER!

We're having a competition and you can win either a Marantz ST-510 quartz-synthesized FM/AM tuner with microprocessor-controlled tuning or a Marantz SC-5010 stereo cassette deck. Two of these prizes are up for grabs so make sure you get your entry in.

\*Our planning for this issue is well advanced but circumstances may change the final content. However, we will make every attempt to include the articles mentioned here.


# ELECTRONICS

## AUSTRALIA

Volume 43, No. 5  
May, 1981

**AUSTRALIA'S HIGHEST SELLING ELECTRONICS MAGAZINE**

### Infrared remote control



Our new infrared remote control has two independent channels and a range of 20 metres, yet will cost you only about \$65. Details on p50.

### NOVA-80

Due to circumstances beyond our control, presentation of the Nova-80 computer project has been delayed. We apologise to readers for any inconvenience that this delay may cause.

### On the cover

Are you good at crossword puzzles? If you are, you could win either a magnificent Marantz SD5010 cassette deck or the high-performance ST510 AM/FM tuner. The details are on p43. For a full review of the SD5010 cassette deck, turn to p46.

### FEATURES

ELECTRIC VEHICLES MUST COME	<i>But don't hold your breath.</i>	12
INFO BANKS & THE HOME COMPUTER	<i>Instant information.</i>	18
PROBING THE STRUCTURE OF MATTER	<i>With Stanford's new accelerator.</i>	24
50 & 25 YEARS AGO	<i>From "Wireless Weekly" &amp; "Radio, TV &amp; Hobbies".</i>	35

### HIFI TOPICS AND REVIEWS

AUDIO/VIDEO ELECTRONICS	<i>Las Vegas consumer electronics show.</i>	36
EA/MARANTZ CROSSWORD CONTEST	<i>Win a cassette deck or AM/FM tuner.</i>	43
HIFI REVIEW	<i>Marantz SD5010 cassette deck.</i>	46

### PROJECTS AND CIRCUITS

TWO-CHANNEL INFRARED REMOTE CONTROL	<i>Mute TV commercials.</i>	50
BUILD A SOUND LEVEL METER	<i>Measure sound levels from 30-120dBA.</i>	62
THE INCREDIBLE PC BIRDIES	<i>One Schmitt trigger IC &amp; little else.</i>	68
SPEED SENTRY FOR YOUR CAR	<i>Cheaper than a radar detector.</i>	80
DREAM 6800 TAPE MOTOR CONTROLLER	<i>For error free tape loading.</i>	86
POWER SUPPLY FOR MICROPROCESSORS	<i>+5V, +12V and -12V.</i>	98

### MICROCOMPUTERS

THE PHILOSOPHY OF PROGRAMMING	<i>People should come first.</i>	94
COLUMN 80	<i>Floppy discs &amp; drives — your questions answered.</i>	132
MICROCOMPUTER NEWS & PRODUCTS		134

### AMATEUR RADIO, CB SCENE, DX

AMATEUR RADIO	<i>Airport "disaster" — WICEN was there.</i>	105
CB SCENE	<i>We can do without the "Russian Woodpecker".</i>	110
SHORTWAVE SCENE	<i>France plans four powerful relay bases.</i>	112

### COLUMNS


THE OFFICIAL LINE	<i>From the Department of Communications.</i>	8
FORUM	<i>Negative ion generators — the claims, doubts &amp; dangers.</i>	30
THE SERVICEMAN	<i>A country TV antenna too hot to handle!</i>	74
RECORD REVIEWS	<i>Classical, popular and special interest.</i>	126

### DEPARTMENTS

EDITORIAL 3 — NEWS HIGHLIGHTS 4 — CIRCUIT AND DESIGN IDEAS 77 — LETTERS TO THE EDITOR 102 — BOOKS AND LITERATURE 114 — NEW PRODUCTS 116 — INFORMATION CENTRE 146 — MARKETPLACE 150 — READER SERVICE 152 — NOTES AND ERRATA NIL
--

# Coming Next Month\*

The Super 80  
Computer — at last



*YES, it's finally here (note the name change, though). Presentation of the first article was delayed, but this highly competitive single-board Z80 computer is most definitely "on", and will be introduced in the August issue.*

*The Super 80 has features not found on computers costing twice as much. A powerful BASIC interpreter, up to 48K of RAM on board, a full-size keyboard, RF modulator for TV display and built-in S100 expansion capability are just some of its good points!*

## Musicolour IV

A rather special 4-channel colour organ, this one will really light up your music! Our new Musicolour design may be driven from a hifi amplifier or its own internal microphone, and can also be used as a sound triggered light chaser, with four distinctive patterns. It can handle a total of 2.4kW.

**AND MUCH MORE** — including TWO free catalogues, one from Sheridan Electronics and one from Altronics of Perth. Don't miss it!

**\*Our planning for this issue is well advanced but circumstances may change the final content. However, we will make every attempt to include the articles mentioned here.**

See article in this months E.A.  
KIT AVAILABLE THIS MONTH

# UNBELIEVABLE!

## THIS MUST BE AUSTRALIA'S BEST VALUE COMPUTER!



- Full size keyboard
- Video modulator
- 9K Super Basic
- 16K RAM
- Cassette Interface
- S-100 Expandable

THE  
EA/DICK SMITH  
**SUPER  
80**

Are you  
fed up with 'built up' projects?  
- why not build this professional  
quality computer & save over 50%  
on equivalent built units!

## A FULL SIZE 16K COMPUTER KIT

You are supplied with a full  
board including power-on  
EPROM monitor, 16K of RAM,  
cassette interface (relay  
activated) for universal control  
of any tape recorder, TV  
modulator and direct video  
output PLUS full size  
professional keyboard

Above photo shows  
some parts which are optional  
- not supplied in basic kit



**ALL THIS  
FOR ONLY \$289<sup>50</sup>**

SHORT FORM KIT

Cat. K-3600

P&P  
\$5.50

### EXTRAS

Transformer ..... M-2325 \$22.50  
BASIC interpreter on tape... K-3602 \$24.50  
IC socket set (Recommended) K-3603 \$12.50

Yes, this would make the full  
computer with 9K BASIC &  
16K RAM

**ONLY \$349.00**

**THAT'S  
\$50  
LESS**

than our advertised  
price 12 months ago!

PROFESSIONAL  
QUALITY  
KEYBOARD

**DON'T PAY  
OVER \$600 FOR A  
BUILT UP 16K COMPUTER  
WITH BASIC!**

THE  
**FANTASTIC  
SUPER  
80**

Supplied with re-print of EA article.

- Combined large Assembly and Technical manual \$12.50 B-3600
- 'Super' Basic Reference Manual \$14.50 B-3602

**DICK SMITH  
ELECTRONICS**




See our other advertisements in this  
publication for store addresses, phone  
numbers, post and packing etc.

# WIN A PRINTER!

for yourself or your school

To celebrate the runaway success of the Super-80 computer featured below, Dick Smith Electronics is sponsoring a competition with two DSE GP-80 printers as the prizes. (We reviewed this printer in our July 1981 issue and found it to be a little beauty.) If you have an interest in the Super-80 or computers in general you could win one of these nifty printers which have a retail value of \$495. Win one for yourself or one for your school.



## Conditions & what to do:

**WRITE A PROGRAM** to suit the Super-80 Computer. The program can be a game, control system, graphics display or anything you want. The program can be any length as long as it will fit into the maximum of 48K RAM on the Super-80 board.

**SEND A C60 CASSETTE** with one copy of your program on each side and **WRITE** a covering letter to tell us what it does.

**COMPLETE** the entry panel on this page or, in states where this requirement is illegal, make a clear, same-size photostat copy of the panel and enclose it with your program cassette. You may enter as an individual or on behalf of your school group.

**POST YOUR ENTRY** so as to reach our editorial office no later than 5pm on February 15, 1982.

**POSTAL ADDRESS:** Endorse your entry "Super-80 Competition" and post to Electronics Australia, PO Box 163, Chippendale 2008. Our street address: 57 Regent Street, Chippendale (near Central Railway).

**JUDGING** will be performed by the editorial staff of Electronics Australia. Chance will play no part in determining the winners. The judge's decision will be final and no correspondence will be entered into and no interview will be granted.

**THE WINNERS** will be notified accordingly and names will be published in the April 1982 or a subsequent issue of Electronics Australia.

**THE PRIZES** will be supplied to the winners, by arrangement, by Dick Smith Electronics, Cnr Waterloo and Lane Cove Roads, North Ryde, NSW 2113.

### OTHER CONDITIONS:

Entry to this competition is open to all residents and school groups in Australia and New Zealand with the exception of employees and their immediate families of Magazine Promotions, John Fairfax & Sons Ltd, Dick Smith Electronics and their associated advertising agencies and publications.

You may enter as many times as you wish. All entries become the property of Electronics Australia. The prizes are not redeemable for cash.

NAME .....

ADDRESS .....

CITY ..... STATE .....

COUNTRY ..... Please tick appropriate box

☐ Individual entry ☐ School entry

# HALF PRICE COMPUTER!

*it had  
to happen!*

Are you fed  
up with 'built up' projects?  
Why not build this very high  
quality kit computer and save  
over 50% on equivalent built  
up units!

## A FULL SIZE COMPUTER KIT

You are supplied with a full  
board including power-on  
EPROM monitor, 16K of RAM,  
cassette interface (relay  
activated) for universal control  
of any tape recorder, TV  
modulator and direct video  
output PLUS full size  
professional keyboard - not a  
'feel less' toy.

ALL THIS  
FOR ONLY \$ **295**

Cat. K-3600

### OPTIONAL EXTRAS

Transformer (M-2325) .....	\$23.00
BASIC interpreter (tape) (K-3602) ...	\$24.50
IC socket set (K-3603) .....	\$12.50
BASIC in EPROM (K-3604) .....	\$99.50
S-100 Expansion (K-3606) .....	\$19.50

Yes, this would make the fully assembled  
computer with above options.

**ONLY \$355.00**

**DICK SMITH ELECTRONICS**

See our other advertisements in this publication  
for address details

OUR MOST  
POPULAR  
KIT EVER!

THE  
FANTASTIC  
**SUPER 80**



Any extra parts  
shown in illustration  
are sold as  
separate, chargeable  
items.

Construction details and a full copy of the EA article is supplied  
with each kit. We also have available two very comprehensive  
manuals to assist in construction and programming:  
SUPER 80 Technical Manual (B-3600) ..... \$12.50  
SUPER 80 BASIC Handbook (B-3602) ..... \$14.50  
This book has over 50 separate versatile commands. Features  
arithmetic and integer functions, user-defined functions,  
machine language routines, text editing, string operations. Also  
contains 25 error codes to assist you in programming.


**STOP PRESS ... NEW ADDITION FOR**  
**YOUR SUPER 80.** Lower Case Generator Option avail-  
able February '82. **\$69.50.** Cat. K-3607



DSE/A163/PAI




# Microcomputer News & Products



## Lower case, inverse video for Super-80 computer

Many inexpensive microcomputers provide upper case (capital letters) only. While this is OK for programming, it is a serious handicap in many applications, such as word processing. Until now the popular do-it-yourself Super-80 computer was limited in this way — although no more! Dick Smith Electronics has come up with an ingenious add-on board for the Super-80 which provides both upper and lower case characters, and, as a bonus, inverse video.



*The Super Character Generator from Dick Smith Electronics provides both upper and lower case and inverse video for the Super-80 computer.*

The Super Character Generator from Dick Smith Electronics is a small printed circuit board (74mm x 74mm) which is mounted in piggy-back fashion on the Super-80 computer board. Five integrated circuits on the board provide the necessary latches and decoding circuitry to substitute a 2716 EPROM for the original character generator chip.

Programmed into the EPROM are dot patterns which provide the full upper and lower case ASCII character set and punctuation symbols, with both normal (white on black) and inverse (black on white) characters available.

In conjunction with a new Monitor EPROM, the Character Generator allows lower case letters to be entered from the keyboard and printed from Basic programs. Inverse characters can also be selected for high-lighting important information on the screen.

Installation of the board takes about five minutes, and is described in the instruction sheet accompanying the unit.

Three ICs must be removed from the Super-80 board. These are U23, U27 (the original character generator chip) and U34. Pin 11 of U35 is disconnected by removing the chip from the board, carefully bending pin 11 upwards and re-inserting the chip. If sockets have been used in the original construction this is simplicity itself.

A trailing wire from the Character Generator board is soldered to pin 11 of IC 31. It is not necessary to remove U31 from the board to make this connection. Both U23 and U34 are re-inserted in the sockets provided on the new board.

Although not apparent from the photograph, the two sockets on the lower right hand side of the board are

wire-wrap types, and the board is installed by inserting the long protruding pins of the wire-wrap sockets into the sockets left empty by the removal of the original character generator and ICs from the Super-80 board. Be warned that pushing the board too far down into the sockets may short out the input leads of the video modulator, resulting in loss of picture.

To use the new Character Generator a revised version of the Super-80 Monitor is required, and this is included in the price of the add-on board. Two versions will be available, a 2716 for use in systems without Basic EPROMs and a 2532 for Super-80s which are running Basic in EPROM. The Basic interpreter is being updated for use with the lower case Monitor and the new version will be available on an exchange basis from Dick Smith Electronics.

When you have installed the Character Generator Board, switch on the power and type in a few characters. The display should be in lower case. Press the shift key to get the familiar upper case (capital) letters.

Quality of the characters displayed is very good, with full descenders (the tails on the "j", "g" etc). No eyestrain here!

To fully test the Character Generator use the Monitor to enter the following program into memory:

```
06 FF      LD B FF
CD 19 C0   CALL SOUT
10 FB      DJNZ
C9         RET
```

The first line of this program loads FF into register B of the CPU. The second line calls the Monitor routine SOUT, which prints the character in the B register on the video display. The next line decrements the B register (subtracts 1) and jumps back to the previous line if the result is not zero. If the result of decrementing B is zero, the routine returns to the program which called it (in this case, the Monitor command input routine). The result is that the entire contents of the new EPROM is displayed as ASCII characters. Note that the screen will go blank as 0C and 8C are read out the EPROM, as these are control characters which clear the display. The routine is very fast, so set V equal to about 1000 for a readable display before running the program.

*Micronews con't p114*

# Electronics Australia/ DICK SMITH

## SUPER 80 Computer Kit

**NEW LOW PRICE**

Production costs have  
now been absorbed due to  
fantastic response —  
**YOU REAP THE BENEFIT!!**

**NEW SUPER LOW  
PRICES**

**was \$289.50**

**NOW**

**\$239.50**

**save \$50**

Photo shows the basic board with the following  
options: S-100 expansion, IC sockets and a full  
48K of memory.

Yes, this makes the full 16K  
computer with 9K basic on  
tape, transformer and IC  
sockets — only — **\$287**

### SHORT FORM KIT (Cat. K-3600)

Designed for computer applications where  
'Basic' programming is not required. Kit  
supplied with Eprom Monitor and 16K

RAM. NOW SAVE \$50 WAS \$289.50 \$239.50

CASE (Cat. H-3200) New and in stock \$39.50

Add the following items to make a fully operating  
computer system to your own requirements.

Transformer to suit M-2325 \$22.50

BASIC program (interpreter) on cassette

NOW SAVE \$12.00 WAS \$24.50 K-3602 \$12.50

IC socket set (recom) K-3603 \$12.50

BASIC program in EPROM (set of 3 IC's)

NOW SAVE \$40 WAS \$89.50 K-3604 \$49.50

S-100 Expansion K-3606 \$19.50

Character Generator (upper/lower case)

NOW SAVE \$20 WAS \$69.00 K-3607 \$49.00

Construction manual SAVE \$3.00 WAS \$12.50 B-3600 \$9.50

BASIC manual SAVE \$5.00 WAS \$14.50 B-3602 \$9.50

48K on board (2 sets of IC's) X-1186 \$59.90



# don't wait until June Available NOW! OVER 1300 SOLD!

The SUPER 80 is the proven computer kit with over 1200 sold and it is available ex-stock! Why wait for others — check out our prices with the competition and whilst you are doing that check out the features too! Dick Smith Electronics have reduced the price of the SUPER 80 as the enormous design costs have now been absorbed by the superb sales of this superlative kit computer — read on. . . .

Check the Super 80 against all others

- \* IS IT S-100 EXPANDABLE
- \* DOES IT EXPAND TO 48K ON BOARD
- \* DOES IT HAVE RF OUTPUT FOR TV CONNECTION
- \* WAS IT FEATURED IN ELECTRONICS AUSTRALIA — AUSTRALIA'S LEADING ELECTRONICS MAGAZINE
- \* IS IT AVAILABLE EX-STOCK
- \* HAS IT SOLD OVER 1300 AND BEEN PROVEN AGAINST TEETHING TROUBLES

SUPER 80	OTHER
<input checked="" type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/>	<input type="checkbox"/>

CHECK OUT THESE FEATURES: \* Relay operates cassette unit automatically \* 2K Monitor program supplied \* Character generator giving full 64 characters, 32 characters x 14 line screen \* Spare IC positions for prototyping and user customising \* RF modulator inbuilt, connects to your TV set \* Optional S-100 provision \* Keyboard can be remotely mounted if required \* 12MHz quartz crystal \* Optional 9K SUPER BASIC in ROM plug in facility \* Full size professional 60 key keyboard \* Inbuilt power supply \* 16K RAM on board plus provision for on board expansion to 48K \* Inbuilt cassette interface

## 'Sorry Dick, It Doesn't Work'

**DUE TO THE VERY LOW RETURN RATE (3%) WE HAVE REDUCED THE SERVICE FEE BY 50% TO ONLY \$50!!!**


If, after completion your Super 80 fails to operate, you may take advantage of our "Sorry Dick it doesn't work" service.

Our Service Centre will check and repair your Super 80 for the cost of \$50. This fee includes necessary replacement of components etc.

If you send your Super 80 to us under the "Sorry Dick, it doesn't work" service it must have been constructed using IC sockets.

## 7 Day Satisfaction Guarantee

Purchase this kit and inspect it for up to 7 days. If you do not wish to go ahead and construct this kit, simply return to us in the condition supplied and your money will be refunded in full.



*This is what Reg Hespe, Technical Officer of Gladesville had to say about 'Super 80' "I enjoyed building the Super 80 project and felt it worthwhile, of immense educational value and quite easy to construct. It worked as soon as I turned it on and has provided many hours of enjoyment".*



SEE OUR OTHER ADVERTISEMENTS IN THIS MAGAZINE FOR THE NEAREST DICK SMITH STORE ADDRESS AND PHONE NUMBER

## Very Advanced design — but works with any TV set!

The 'Super 80' offers a specification that we believe just cannot be bettered at the price. It uses the popular Z80 Microprocessor IC, a professional keyboard and has direct RF output so that you can use the computer with any TV set (you don't need to purchase a special video monitor).

## Easy to build

Even though we would not recommend this kit to the raw beginner, it is very easy to build. Any person who can use a small soldering iron and can solder neatly should have no difficulty in construction. This is because of the unique double side board design which means there is virtually no other wiring. The board is covered with professional 'solder mask'; this makes soldering much easier without the problems of bridges, etc. Once the components are soldered onto the board in their marked positions over 98% of the construction is completed. Even if you cannot get the completed kit to work, we have a special "Sorry Dick it doesn't work" repair service to assist you.

## NEW lower price, higher specification - how is it done?

Most computers sold in Australia are manufactured in the U.S.A. where extremely high labour rates prevail - and you pay dearly for this on built up units. With this computer kit, you provide the labour and therefore save a fortune. And remember, this computer does not have a small toy-like calculator keyboard but a full size professional typewriter keyboard.

## Advanced programming capability

One of the most popular computers in the world (the Tandy TRS-80 Level 1) only has 4K of BASIC. The BASIC we have with this unit is a large 9K. When you consider that our popular Sorcerer computer (over 2,000 sold) only has 8K BASIC and sells for over \$1,000, it is obvious that by building yourself, you are saving real money.

## Electronics Australia/Dick Smith design

This is not a half baked design with no back up. The resources of Electronics Australia, Australia's most popular electronics magazine, and Dick Smith Electronics have combined to design and bring you this kit in the interests of computer enthusiasts actually building and not just buying. The design is fully Australian.

## Imagine how much you will learn!

Most computer enthusiasts can program a computer but would have absolutely no idea of how to build one. By building this kit you will learn both the technical side of construction, how it works and then how to program. What a fantastic background for a future. . . . .

## Sectional construction

We have designed this kit not only for the serious computer user but also for first time users like the student or hobbyist. This is why we have a short form kit which may be added to as you build (and as you have the money!). For example, you may build the computer originally and operate it with 'BASIC on tape' and then add 'BASIC in ROM', add the S-100 and provide other parts at a later stage.

S-100 board has serial & parallel ports

# A printer interface for the Super-80

The long awaited Super-80 printer interface is here! Hard copy of programs and data is now easy to achieve, either with a Centronics type parallel printer or a serial input machine. Read on for details.

by PETER VERNON

Since we published the popular Super-80 computer project many readers have asked us about using a printer with the computer. Now Dick Smith Electronics has come up with a printer interface board which plugs directly into the S100 expansion slot of the Super-80. It is supplied as a complete kit of parts which can be put together inside an hour.

The big advantage of this printer interface is that it can be built in two forms: as a parallel printer port only, or as both a parallel and a serial RS232C port. Which version you build depends on the type of printer you will be using and on other capabilities required for your Super-80.

Use of the interface board is not restricted to printers. With the serial port you can use a 300 baud modem for telephone data communication, for example, or have two Super-80s linked together and transferring data to each other (great for games with a friend!).

The interface board measures 253 × 72mm. It features the familiar S100 circuit board connector at the bottom, a

34-pin section at the top to take the edge connector of a Centronics printer cable, and space for connector pins for the RS-232C interface at the right hand side. The board is double-sided with plated through holes, and the S100 pins have been gold flashed to ensure reliable contact with the connector on the main computer board.

One point is extremely important. The S100 connector on the Super-80 board is designed to take a motherboard, containing additional S100 slots. Because of this, the connector is installed "back to front", with pin 1 at the right hand side of the Super-80 board, looking from the front. The printer interface board is therefore installed with the component side towards the rear of the Super-80 board. Great sorrow will ensue if the board is plugged in the wrong way round, as the pins at the right of the S100 connector carry the unregulated +8V and ±16V, feeding the regulators on the printer board.

Before we go into a detailed description of how the board works, we should say that it is quite possible to construct


the parallel printer interface and get it working without understanding exactly what is happening. For this reason we will describe the construction and operation of the unit first, with the circuit description following for really dedicated enthusiasts.


Using the serial interface is a little more difficult. There are several links to be installed which control the parameters of the serial data transmission. These links must be set to match the parameters of the receiving device. Usually the manual which comes with the device will have these details while Table 1 shows the function of each link on the board required for the serial interface circuitry.

## Construction

If you haven't already done so, you will first have to assemble the S100 interface circuit on the Super-80 board. This involves installing capacitor C3 for additional power supply filtering, and five integrated circuits in the white cross-hatched area of the computer board, as well as the 100-pin S100 connector. Full details for this section of the Super-80

*Super-80 printer interface board when fully populated provides both Centronics interface and RS232C serial port.*





*Super-80 (yes, in a case!) working with the GP80 printer. Installation in a case will be covered in a later issue.*

were published in the October, 1981 issue.

Begin construction of the printer interface board with the passive components. There are 16 resistors and 12 capacitors, five of which are tantalum types which must be correctly orientated according to the component overlay. There are also four zener diodes and a multi-turn potentiometer to be installed. If you only require the parallel port, some of these components are omitted, as indicated in the parts list.

Power supply regulators are next. If you are only interested in the parallel printer interface, only U1, the +5V regulator, need be installed. Otherwise, install all three regulators, carefully bending the pins down about 5mm from the case. You may like to bolt the regulators down before soldering as a check on their fit. The 10mm threaded spacer included in the kit is fitted to the +5V regulator and serves as a heatsink. Install this regulator with the head of the bolt on the back of the board, and the spacer threaded on from the component side.

Following the regulators install the integrated circuits. For the parallel interface, install U4, U5, U6, U7, U8, U9 and U11. If you require the serial interface, install the remaining ICs as well. Note that there is a link on the underside of the board, beneath U12, which must be cut if this chip is installed. The link runs from pin 18 to pin 19, and should be left intact if only the parallel port is assembled (ie U12 is not installed). Use a 40-pin socket for the UART chip, U10.

Before using the board there are a number of links to be installed, as shown on the overlay diagram. Links J1 to J4 set the most significant half of the address of the devices on the board. For example, with all the links installed, comparator

U11 will select the printer port when address lines A7 to A4 are all zero. With no links installed (as on our board), the printer board will be selected when these four address lines are "1", giving the parallel printer port an address of "FC". The software given here is designed for this address. See "How it works" for details.

The cable used to connect a printer to the interface board must have a 34-way edge connector at one end and a standard Centronics connector at the other. We used a standard cable from Dick Smith Electronics catalog number X-4014, although you can wire your own, pin 1 to pin 1, pin 2 to pin 2 etc.

### Getting it up and running

With the board completed we can move on to actually using it. For our tests we used the Dick Smith Electronics GP80 dot matrix printer, a machine which is ideal for this application. It is a Centronics type printer, with the standard parallel input connector popularised by the Centronics company. A printer cable from DSE completed the set up.

With the Super-80 switched off, plug the printer interface board into the S100 connector. Remember that the component side of the interface board should face the rear of the computer. Don't use too much force to insert the printer board, as flexing the Super-80 board will place stress on the PCB tracks and socket connections. A little gentle wriggling and some patience will pay off here. It may also be an idea to include some additional support underneath the S100 connector such as two stick-on rubber feet, or similar.

Assuming that you are using a Centronics type printer, connect the edge connector of the printer cable to the circuit board fingers at the right hand side

of the interface board. The single colour-coded wire of the printer cable is "number one" and should be on the left hand side as you look towards the board. Install the Amphenol connector on the other end of the cable in the socket at the rear of the printer.


Switch on your video display and the printer, then the Super-80. The next step is to load the software for the parallel printer driver. Go to the Monitor (with the "MON" command from Basic). Use "E 0000" to enter the program in Listing 1. Begin with "55" and go on until you have entered "C9" in address location 000A. If you have left links J1 to J4 open, enter the program as shown. If you have used a different address for your printer board, change "FC" to whatever address you have used.

Return to Basic when you have finished entering the printer program. Now whenever you do an "LPRINT" or "LLIST" in Basic the printer will respond. "LLIST" is used for listing Basic programs on the printer, while "LPRINT" is used in the same way as a "PRINT" statement within a program, but instead of printing on the video screen it will direct the output to your printer.

Note that the Super-80 Basic interpreter is designed to automatically send a line feed after each carriage return. However, most printers are set up to also insert a line feed after a carriage return. The result: two line feeds at the end of each line and double spaced printing.

Fortunately, this is easy to avoid. "Automatic line feed" on most printers is controlled by a wire link or a DIP switch inside the printer. The manual accompanying your printer will have the details. Simply follow the directions to disable the automatic line feed of the printer for single spaced printing.





Note the position of the links on the overlay diagram. For a Centronics interface only some components may be left off.

## How it works

There are four main functions on the printer interface board which must be accessed by the computer. These are a port for parallel printer data, a parallel printer status port, and UART data and status registers.

"UART" by the way, stands for "Universal Asynchronous Receiver Transmitter". "Aysnchronous" in the designation refers to the UART's ability to transmit and receive data without being synchronised to the device at the other end of the serial line. In other words, the two parts of the system, the computer and, say, an RS232C printer, do not share a common clock frequency. Instead, data is synchronised by the transmission of a start bit at the beginning of each data byte.

The Z80 microprocessor on the Super-80 board addresses Input/Output devices separately from memory, and provides bus control signals which distinguish between memory operations and I/O operations. The lower eight bits of the address bus are used to specify I/O locations, giving 256 possible port addresses. The address of each device on the interface board consists of a unique combination of these eight address lines with either S1NP, the S100 bus signal which designates input to the processor, or SOUT, designating output from the processor.

The address decoding logic for the printer interface board consists of U8, part of U7 and U11, as shown on the main circuit diagram. When address lines A2 and A3 are high ("1"), comparator U11 will be enabled. The comparator will then compare the state of address lines A4 to A7 with the switch settings of links J1 to J4. If the address lines match the link settings, the comparator will produce an output labelled "BSEL" to select the devices on the printer board.

You can vary the top half of the address by closing combinations of the

### TABLE 1

ADDRESS	READ FROM	WRITE TO
FC	Produces Print Status Read PSR	Produces Print Data Write strobe PDW
FD	Produces UART Status Read USR	Produces UART Write USW
FE	Reads data from the UART UDR	Writes data to the UART UDW for transmission

### TABLE 2

LINK	FUNCTION
J5	Enables parity checking if installed
J6	Installed for 1 stop bit, open for 2 stop bits
J7	J7 only installed for 6 bit data
J8	Both J7 and J8 open for 8 bit data
J8	J8 only installed for 7 bit data
J8	Both installed for 5 bit data
J9	Odd parity if installed, even parity if open, provided that parity is enabled by installing J5

links. If you want the board to respond when A7 is "0", for example, close link J4 and leave the other three open. This would correspond to an address of "7C" (01111100). Open links place a "1" on the corresponding inputs of comparator U11, which produces a "true" signal when these match the four bits of the address on A4-A7.

In other words if we leave links J1 to J4 open, the comparator output will be true for an address which has all 1's for the upper 4 bits. Eight bit addresses which have bits 2 and 3 high are then FC, FD, FE and FF (convert these to binary for a check).

The Super-80 uses ports at addresses F0 to FB for its own purposes (reading the keyboard, controlling the video and cassette interface etc). Because of incomplete decoding on the board, the functions of these addresses are also

fulfilled by the block E0 to EB. Addressing the printer interface board with the four upper lines set to "F" will thus use the unreserved ports in the locations in the Super-80 I/O block. Leave J1 to J4 open to do this.

## Control strobes

The BSEL signal from the address comparator is gated with SOUT and PWR by one section of U8. PWR is an S100 bus status signal which indicates that the processor is currently sending data to the S100 bus connector.

PWR is an active low signal, inverted by one gate of U7, so that a "1" at pin 4 of U7 indicates valid data on the processor data bus. When gated with SOUT and BSEL by U8, the output enables one half of the dual one-of-four decoder U9 to

produce write strobes to each of the interface devices. SINP and BSEL are gated together by another section of U8, and this output enables the other half of U9 to produce read strobes, indicating that the processor is requesting data from the interface.

Address lines A0 and A1 are input to both halves of decoder U9. They determine which one of the three outputs of the relevant section of the decoder becomes active, and therefore, which specific device is read from or written to. The six strobe pulses which can be produced by this part of the circuit can write data to the parallel port or to the serial port, request status information from either port, or write status information to the serial port. All the possible combinations of strobe pulses, and the addresses which produce the appropriate strobe, are shown in Table 1.

### The parallel printer port

The parallel printer section consists of U4, U5 and part of U6. When the microprocessor performs a read operation from the printer port, a Printer Status Read (PSR) signal is produced at pin 4 of U9. This signal is applied to the enable input (pin 15) of U6, gating the printer busy bit onto bit 7 of the data bus. When this bit is "1" the printer is

busy, and no data is sent. When bit 7 goes to "0" the printer is ready for further data.

A write operation to the printer port produces a Printer Data Write (PDW) signal on pin 12 of U9, which triggers monostable U5 to produce a strobe pulse of the correct length for the printer. At the same time, the data on the Data Output bus will be latched into U4 and transmitted to the printer.

We are now in a position to understand the software for the printer driver (Listing 1). Initially, the character to be printed is in the A register, so first we save it by pushing it onto the stack. This frees the A register to receive the printer status, which we get by an Input instruction.

Having read the printer status we must check the state of bit 7 of the A register, and this is most easily done by rotating the contents of the register one place to the left, so that bit 7 moves into the Carry flag. If bit 7 is "1" (printer busy), the carry flag will be set, so the program loops around and checks the status again. It will keep looping until the printer status busy bit is "0".

If the carry flag is "0", the program does not loop and the next instruction is executed. This instruction "pops" the previous contents of A off the stack and places it back in the A register. This is the

character we want to print. Executing an OUT instruction to the printer port will generate the Print Data Write Strobe (PDW), latching the byte to be printed and sending the strobe pulse to the printer to initiate printing.

To help you understand the actual operations involved we suggest you read our series on "Programming in Machine Language". Although the articles deal with a different microprocessor they do explain the concepts of rotation, carry flags etc, and these concepts are universally applicable to microprocessor operations.

### The serial interface

For serial data communication the most important part of the circuit is the UART U10. This device is designed to take parallel data from the computer's data-out bus and convert it to serial form for transmission, and to receive serial data and assemble it into parallel format bytes for the computer's data-in bus.

Various outputs of the decoder U9 are used to enable the functions of the UART. In describing this section of the circuit we will work backwards from the software, shown in Listing 2.

The first step, after saving the contents of register A on the stack (PUSH AF), is to send a Request To Send (RTS) signal, setting this line to a "1" indicating that the computer is ready to transmit data. We do this by setting bit 6 of the A register and outputting the contents of A to the UART status port, addressed at FD. Bit 6 set, and all other bits "0" is 40 in hex.

An OUT instruction to port FD generates the UART Status Write strobe **USW** on pin 11 on U9, which clocks the data on bit 6 of the Data Out lines through flipflop U14. The RTS signal appears on pin 8 of U14 as a +5V TTL level, and is translated to the +12V RS232C level by the RS232C driver U13.

Following request to send, we read the status of the UART from port FD, checking the Clear To Send (CTS) line. When the device at the other end of the serial link is ready to receive a new character it will set this line high. The UART Status Read **USR**, will enable the Tri-state buffer U6 to gate this signal onto bit 6 of the Read Data (RD) line to the processor.

Note that CTS is also an RS232C level signal and is clamped by a 4.7V zener diode to convert it to TTL level. We read it by an IN operation from port FD, and test it with a BIT 6, A instruction, looping until the CTS bit is set.

Since the RS232C device is now ready to receive data we must check if the UART is ready to transmit. Inside the UART is a transmit buffer which holds the byte to be transmitted. Obviously,

### PARTS LIST

1 PCB  
1 74121 monostable  
1 74LS04 hex inverter  
1 74LS373 octal latch  
1 74LS367 hex bus driver  
1 74LS10 triple 3-input NAND gate  
1 74LS139 dual 2-to-4 line decoder  
1 74LS85 4-bit magnitude comparator  
1 LM7805 +5V regulator

#### CAPACITORS

1 0.47 $\mu$ F 35VW tantalum  
1 220pF ceramic  
4 0.1 $\mu$ F ceramic

#### RESISTORS ( $\frac{1}{4}$ W, 5%)

1  $\times$  22k $\Omega$ , 5  $\times$  4.7k $\Omega$

#### MISCELLANEOUS

1 6BA 10mm bolt  
1 6BA threaded spacer

#### EXTRA PARTS FOR SERIAL INTERFACE

1 MM5303 or AY-3-1015 UART  
1 MC1488 RS232C transmitter  
1 74LS74 dual flipflop  
1 74LS14 hex Schmitt trigger inverter

1 CD4024 binary counter  
1 74LS373 octal latch  
1 555 timer  
4 4.7V zener diodes  
1 LM7812 +12V regulator  
1 LM7912 -12V regulator

#### CAPACITORS

4 0.47 $\mu$ F 35VW tantalum  
1 .01 $\mu$ F ceramic  
1 680pF polystyrene

#### RESISTORS ( $\frac{1}{4}$ W, 5% unless stated)

1  $\times$  22k $\Omega$  1%, 5  $\times$  4.7k $\Omega$ , 4  $\times$  2.7k $\Omega$   
1 20k $\Omega$  multi-turn potentiometer


#### MISCELLANEOUS

2 6BA nuts and bolts  
9 circuit board pins.

#### COST

The complete kit of parts for the Super-80 Printer Interface (DSE catalog number K3610) costs \$69.50. This includes sales tax, but does not include the cost of the printer cable.





SUPER-80 PRINTER INTERFACE

we don't want to send new data to the UART until the previous data has been transmitted, so we check the status of the TBMT flag (Transmitter Buffer Empty).

As previously stated, reading from the UART status port generates the USR signal. In addition to gating the RS232C control signals onto the Read Data bus, this signal is also connected to the UART's Status Word Enable (SWE) input. In response to this input the UART places the status word on the Read Data bus.

TBMT is part of the status word and is placed on bit 7 of the Read Data bus in response to USR. We check the state of bit 7 with a Rotate Left instruction, which sets the Carry flag if TBMT is "1", indicating that the transmitter buffer is empty. The program loops until the carry flag is set.

With the status checks complete we can now send the character to be transmitted. Basic leaves this character in the A register before the serial driver routine is called, so we get it back from the stack with a POP AF instruction. Next we send the contents of A to the UART data port with an OUT (FE), A instruction.

The output operation to port FE generates the UDW strobe, which is applied to the UART's TDS input, pin 23, to latch the data on the data out bus into the transmit register, where it is converted to serial form and transmitted over our RS232C link.

After sending the character to the transmit buffer we clear the A register and send the contents out through the UART status port, which resets the RTS line, then return to the program which called the driver routine.

Receiving data is the reverse of the transmit process (Listing 3). First step is to read the status of the DSR input from the device sending the data. A "1" on this line indicates that the serial device has a byte of data to send. Again, the RS232C level is translated to a TTL level by a zener diode, and gated onto Read Data line 5 by the USR signal.

IN A,FD inputs the RD lines to the A register. By ANDing the contents of A with hex 20 (bit 5 "1", all others "0") the result will be non-zero only if there is a character to be received. If the result of the AND is zero the program jumps to a routine which sets up all the processor flags and returns to the calling routine.

Otherwise, we send the Data Terminal Ready (DTR) signal, by setting bit 7 of the A register and outputting it to port FD. This operation produces the UART Status Write signal which clocks bit 7 through flipflop U14 to produce the DTR. Once again, the output of the flipflop is converted to an RS232C signal by one gate of driver U13. At the other end of the

line this signal can be used to initiate transmission of the data.

Next we read the UART status, looking at the state of the Receiver Data Available line. This signal from the UART is "1" when an entire byte has been received. It is gated onto bit 0 of the Read Data lines by the Status Word Enable signal generated by reading the UART status.


If bit 0 is "0" at this stage the program loops until the line goes to "1". The data byte is in the receiver register of the UART, but before reading it into the processor there are other operations to be carried out.

These operations involve checking the UART status word, bits of which indicate various errors in transmission, so we first save the status word, pushing A onto the stack. Next we clear A and output it to the UART status port to reset the DTR

POE line are used together to select the type of parity check to be applied to the data. If even parity is selected, the UART will add all the bits in the data byte together and add 1 to the result if the sum is odd. If the sum is even nothing is added. The parity bit is stripped off at the other end of the line after the receiving device has checked the data.

When odd parity is selected, a bit is added only to those bytes which are even when summed. Obviously, when even parity is selected, a data byte arriving with an odd number of bits is an indication that some error has occurred in transmission, and vice versa. The receiving device can be programmed to take appropriate action (usually, to request that the data be re-transmitted).

We can check the status of the three error signals all at once by ANDing the status word with 0E (00001110 in



Another view of the interface board installed in the Super-80. Again note that the component side of the board is towards the rear.

line, indicating that the receiving device is busy and no more data should be sent.

After resetting DTR we recover the status word from the stack with a POP AF instruction and test the error bits. Three types of error are signalled by the UART on bits 1, 2 and 3 of the Read Data lines. Bit 1 signals ROR (Receiver Over-run) which is "1" if the previous character has not been read before the present character was transferred into the receiver buffer. In this case we have lost a character.

Bit 2 of the status word is RFE, and is "1" for a "framing error", indicating that the received character does not have a stop bit, and is incorrect. Bit 3 is RPE, for "parity error", which signals an error if parity checking is enabled.

A "parity bit" is an extra bit added to the data received and transmitted data as an error check. The NPB line and the

binary). If the result is zero, no error has occurred, so we read the receiver buffer. Reading the receiver buffer generates the UDR strobe, which is input to pin 4 and pin 18 of the UART. Pin 4 is the RDE input (Read Data Enable) which gates the received data onto the data bus to the computer. Pin 18 is RDAR, which resets the data available output of the UART, ready for the next data byte to be received.

If an error has occurred we still read the data into A, but the only purpose in doing this is to reset the Read Data Available flag, as previously described. Before returning to the calling program, A is cleared, and then ORED with itself to set the processor flags. The Z flag set indicates that no valid character has been received.

Any of the read strobes will enable U12, which is used as an 8-bit buffer.

# Printer Interface

Data to be read from the interface board, either status bits or data received by the UART, will be enabled onto the S100 data in bus by this latch.

If the serial interface is not installed then U12 will not be required, as the parallel interface only produces one status bit (the printer busy signal on data line 7) and this is already gated by one Tri-state gate of U6. If U12 is installed, however, be sure to cut the printed track between pins 18 and 19 of the chip, as previously mentioned.

The procedure for reading and writing serial data may sound complex, but the software published here takes care of the details. A thorough understanding of the process is required, though, if you want to write your own software drivers.

Note that in both Listings 1 and 2, the actual driver program is preceded by a 55 (hex) byte. This is a flag which the Basic interpreter reads to determine if a printer driver is in memory. If the flag is present, Basic will use the driver in response to "LPRINT" and "LLIST" statements.

The rate at which data will be received and transmitted (known as the baud rate) is controlled by the baud rate clock inputs of the UART, pins 17 and 40. These two inputs are connected together, since we want the transmitter and receiver both working at the same baud rate, and are driven from the output of the baud rate clock generator, ICs U16 and U17.

The clock rate must be 16 times the desired baud rate. Clock pulses are produced by U16, a 555 timer IC wired in astable configuration. A 20kΩ multi-turn potentiometer allows the output of the 555 (pin 3) to be accurately trimmed to 38.4kHz. The output of the 555 is then fed to a 4024 binary counter (U17), which divides down to produce the required clock rate via link J10 (300 baud), J11 (600 baud) or J12 (1200 baud). Note

## LISTING 1: CENTRONICS DRIVER

0000	55		Flag for Basic
0001	F5	PUSH AF	Save character on stack
0002	*1 DB FC	IN A,(FC)	Get printer status
0004	17	RLA	Rotate bit 7 into carry
0005	38 FB	JR C *1	If C=1 loop till C reset
0007	F1	POP AF	Get character off stack
0008	D3 FC	OUT (FC),A	And send to printer
000A	C9	RET	Then return to caller

## LISTING 2: RS232C TRANSMIT

0000	55		Flag for Basic
0001	F5	PUSH AF	Save character on stack
0002	3E 80	LD A,10000000B	Set bit 7 in A
0004	D3 FD	OUT (FD),A	Send it to UART status port
0006	*1 DB FD	IN A,(FD)	Read UART status
0008	CB 77	BIT 6,A	Test bit 6 in A
000A	28 FA	JR Z,*1	Loop until CTS is "1"
000C	17	RLA	Put TBMT bit in Carry
000D	30 F7	JR NC,*1	Loop until TBMT=1
000F	F1	POP AF	Get character from stack
0010	D3 FE	OUT (FE),A	Send it to UART data port
0012	AF	XOR A	Clear A
0013	D3 FD	OUT (FD),A	Reset the RTS line
0015	C9	RET	Then return to caller

## LISTING 3: RS232C RECEIVE

0000	DB FD	IN A,(FD)	Get UART status
0002	E6 20	AND 00100000B	Test Data Set Ready bit
0004	28 1A	JR Z,*1	If DSR=0 then return
0006	3E 80	LD A,10000000B	Set bit 7 in A
0008	D3 FD	OUT (FD),A	Send Data Terminal Ready
000A	*2 DB FD	IN A,(FD)	Get UART status
000C	CB 47	BIT 0,A	Test Data Available bit
000E	28 FA	JR Z,*2	Loop until data available
0010	F5	PUSH AF	Save UART status
0011	AF	XOR A	Clear A
0012	D3 FD	OUT (FD),A	Reset DTR
0014	F1	POP AF	Restore UART status to A
0015	E6 E0	AND 00001110B	Test error bits
0017	28 05	JR Z,*3	No errors, jump to get data
0019	DB FE	IN A,(FE)	Clear status bits by reading
001B	AF	XOR A	Clear A
001C	18 02	JR *1	And jump to return
001E	*3 DB FE	IN A,(FE)	Read UART data
0020	*1 B7	OR A	Set processor flags
0021	C9	RET	And return

Above: routines to use the interface board. For bi-directional communication via RS232C, Listing 3 should follow on from Listing 2 in memory.

```
00010 REM **** SCREEN DUMP ****
00020 REM
00030 B=48640
00040 FOR L=0 TO 15
00050 FOR C=0 TO 31
00060 P=B+L*32+C
00070 N=PEEK(P)
00080 LPRINT[A1 N];
00090 NEXT C:LPRINT
00100 NEXT L
```

```
00999 REM **** PRINTER DRIVER ****
01000 FOR L=0 TO 10
01010 READ A
01020 POKE L,A
01030 NEXT L
01040 DATA 85,245,219,252,23,56
01050 DATA 251,241,211,252,201
```

Above: this Basic program includes the Centronics printer routine in data statements. It will place the routine in memory at 0000-000A. At left is a Basic program which will print the contents of the video screen. Variable B should be adjusted depending on the size of memory of your system. For 32K it should be 32256, for 16K, 15872.

that only one of these links is installed, depending on which baud rate you want to use.


One signal yet to be discussed is the reset line, MR. This is an active high line, while the S100 Power on Clear (POC) is active low. For this reason the S100 signal is inverted before being applied to pin 21 of the UART.

Five other signal lines are also important to the operation of the UART: NPB (No Parity Bit), NSB (Number of Stop Bits), NDB1 and NDB2 (Number of Data Bits per character), and POE (Parity Odd or Even). These are used to program a set of operating parameters into the UART by means of links J5-J9, which should be set to match the parameters of the serial device with which the computer is to communicate.

NDB1 and NDB2 are used to select one of four possible word lengths — 5, 6, 7 or 8 bits. For 8-bit data, both J7 and J8 should be left open. The NSB line selects the number of stop bits used to indicate the end of each data byte. When closed, link J6 selects 1 stop bit, and when open 2 stop bits are sent. This link should also be set to match the requirements of the device you are communicating with. The parameters selected by these links are fed into the UART by the CS line, which is tied high in our circuit.

Links 5 and 9 set the parity parameters. Insert link J5 to enable parity checking. With link J9 in place, odd parity will be selected, while leaving J9 open selects even parity. Again, these parameters should be set to match the parameters of the device you want the computer to communicate with. See Table 2.

As soon as space permits, we will describe how to install the Super-80 in the metal case shown in one of the photographs. Together with the printer interface and a lower case character generator (see P111 Feb '82), it will turn your Super-80 into a full-feature computer. Don't miss out!



*"Of course, our technology is still in its infancy".*

*("Electronic Age")*

**"Why pay more when you can build your own computer & save \$\$\$!"**

**THE DICK SMITH**

**SUPER 80**

**No. 1 for quality & value!**

Imagine telling your friends that you actually built your own computer! Now you can with this superb kit. Not only do you end up with a powerful computer, you learn so much about computer technology while you are building it.

**LOOK AT THESE GREAT FEATURES:**

- Full size professional keyboard
- Cassette interface on board
- Budget tape 'BASIC' or optional 'EPROM BASIC'
- Supplied on board memory of 16K, expansion to 48K RAM
- On board video modulator - works on any TV
- All components on board except transformer
- S-100 expansion system for add-ons
- PLUS MUCH MUCH MORE!!!

**ACCESSORIES TO SUIT:**


Cassette BASIC to suit Super 80	Cat. K-3602	\$29.90
IC Socket Kit (recommended)	Cat. K-3603	\$18.50
ROM BASIC for Super 80	Cat. K-3604	\$120.00
\$100 Expansion System for Super 80	Cat. K-3606	\$39.75
Super 80 Character Generator	Cat. K-3607	\$109.50

**ONLY \$545 NZ**

Cat. K-3600 P&P \$5.50

**DATA SHEETS that save you time AND Money!**

How to Install your own Burglar Alarm	B-6000	\$1.95 NZ
How to Install your own TV or FM antenna	B-6010	75c NZ
A Guide to Printed Circuit Board Making	B-6005	75c NZ



**AM/FM TUNER MODULE**

Into low cost cost quality hi-fi? Then here's the one for your money!

- Loop stick antenna fitted for AM stage
- Accepts 12V-16V DC & has overload protection
- Built in FM muting, tuning & signal meter circuits
- Built in 19kHz & 38kHz notch filters for MPX stage
- Geared 5 gang variable capacitor
- High image rejection over 50 decibels.

**NZ \$139**

**COMPARE OUR PRICES SOLD ELSEWHERE FOR \$7.00!!!**

**57mm MINI SPEAKER**

This 57mm mini speaker has performance - in fact we found that it offered more performance than speakers up to 75mm in diameter! Nominal impedance of 8 ohms make it ideal for many purposes.

Cat C-2222  
**WHY PAY MORE THOUSANDS OF USES**

**\$2.95 NZ**



**DEMAGNETIZE IT!**

Demagnetizes tape recorder heads, removing excessive noise levels & saving your tapes from possible loss of quality.

**\$14.95 NZ**

Cat. C-7222 P&P \$2.00



**COMPUTER VERIFIED Cat. X-3502**

**CASSETTE TAPE**

Famous 'Microsette' C10 cassette gives 5 minutes per side - over 40K capacity per side!

**\$3.95 NZ** Cat. X-3502

One unnamed company sells a similar tape for \$18.00!!!




**LOW COST SIGNAL INJECTOR**

Check out both audio and RF circuits (harmonics extend to many MHz) simply and easily. Self contained, battery operated with probe and earth clips.

Cat Q-1270

**AND ONLY**

**\$11.50 NZ**



**INTERCOM PICK-UP**

Place suction cap to your phone or intercom etc. With lead & plug to connect to your amp or tape recorder.



C-7300

**\$4.50**

**FREE 2nd Edition NZ CATALOGUE!**

Packed with lots of goodies for Kiwi enthusiasts, hi-fi buffs, amateur & CB freaks, computer nuts etc etc etc.

If someone pinched yours from this magazine, don't worry. Just send \$1.05 to our address below. We'll take care of the rest!!!

DSE A269NZ

**DICK SMITH Electronics**

98 Carlton Gore Rd. Newmarket Auckland. Tel: (649) 50 4409

Mail Orders: PO Box 9452, Newmarket NZ

**WHY PAY MORE?**

Store Hours: Mon - Fri 8.30am to 5pm.





# A case for the Super 80 computer

Not many ready-built computers come with a steel case, but you can have one for your Super-80. Quite apart from the enhanced appearance of your system, the case is a useful protection against spilt coffee, the family cat etc . . . and it suppresses RF interference.

by PETER VERNON

Our article on the Super-80 printer interface showed our computer in a case (or rather, the bottom half of a case). We thought readers might be interested in how it was done, so this article covers the installation of the Super-80 computer in a steel case, which Dick Smith Electronics has had specially designed and produced for the Super-80.

First step, of course, is to get a case. The Super-80 Marviplate case costs \$39.95 and is available from Dick Smith Electronics. (Marviplate, by the way, is a trade name for a specially treated steel plate protected against corrosion and finished with a cladding of black vinyl). You will also need some insulated spacers and nuts, bolts and washers of various sizes. Apart from these, the various connectors, switches etc required for the Super-80 in a case are the same as those required for the "bare board" version.

Measurements of the case are 395mm wide x 400mm deep. It is 100mm high at the rear, with a front keyboard section 25mm high. There is not much clearance inside the case and positioning the Super-80 circuit board requires some careful thought.

The most difficult part of the operation is the positioning of the keyboard. If the board is mounted too far forward or back in the case there will not be sufficient clearance for the keys in the cut-out provided for the keyboard. If keys at the top or sides of the keyboard make contact with the edge of the keyboard cut-out the keys could be forced down. In this case your Super-80 will not work. The computer will interpret the stuck key as a key which is being pressed by

the operator, and will suspend processing until the key is released.

The case is supplied pre-drilled but a few extra holes were necessary in our prototype. Try a "dry run" first to establish the position of the PCB inside the case. Note the location of the two holes which must be drilled in the circuit board to match with the holes already drilled in the bottom of the case.

We found that the PCB must be drilled about 4mm in from the two rear corners of the board, but it is important to check this out for yourself and drill the holes to suit. Preferably use a hand drill, to prevent pieces of circuit board being scattered around the workings of the computer. Carefully clean up the circuit

board after each hole is drilled, and make sure that no printed circuit board tracks are cut by the holes you drill.

We used four spacers, two 20mm long at the rear of the board and two 25mm types to support the metal keyboard frame at the front of the case. The metal frame is already drilled to take the screws of the spacers. It may be necessary to use extra washers to raise the keyboard to a comfortable height in the opening provided.

Once you know where the circuit board will sit in the case remove the board and prepare to mount the transformer, rear panel connections and switches.


The case is pre-drilled to take the stan-



*Specially designed for the Super 80, the black vinyl finished steel case is an attractive enhancement to the do-it-yourself computer.*



*A complete Super 80 computer system with case, printer, and a green phosphor video monitor. (Monitor courtesy Paris Radio Electronics)*



dard Dick Smith Electronics transformer used by the Super-80, but we found that an extra hole must be drilled to mount the mains terminal strip so that the power cord is not kinked. If required, an extra hole should also be drilled and reamed in the left hand side rear of the bottom section of the case to take a standard 3AG fuse-holder.

Drill this hole mid-way between the top hole (where we put the power switch), and the hole provided for entry of the mains cable, then ream it out until the fuse holder can be mounted.

Use a rubber grommet to protect the power cord against chafing at the point where it enters the case. Clamp the cord securely inside the case (there is a hole provided for the cable clamp). Use an earth lug to secure the earth lead of the power cable to the case. One of the transformer mounting bolts provides a convenient earth point. Make the earth lead longer than either the active or neutral power connections, so that if any strain is placed on the power cord the earth lead will be the last to give way.

Terminate the active and neutral power lines to a mains terminal strip bolted to the bottom of the case. From the terminal strip take the neutral lead to one side of the transformer primary. The active lead goes first to the fuse-holder, if used, and then to the power switch. The other side of the power switch goes to the transformer primary.

To connect the transformer secondary to the PCB we used a Utilux connector, matching the female connector on the PCB. If this connector is unavailable though, it is quite permissible to solder the secondary leads directly to the PCB.


Having carefully checked the location of the PCB and the transformer in the case, put this assembly aside and mount the reset switch, video connector and cassette connector on the right hand side of the rear of the bottom section of the case. We put the reset switch at the top, the video connector in the centre and the cassette connector at the bottom, although this depends to some extent on personal preference. It may be necessary to enlarge some of the holes in this part of the case. Use a reamer, and make sure that no metal filings are left in the case at the completion of the operation.

We used a 4mm diameter pushbutton for the reset switch. It was necessary to


extend the leads between the switch and the circuit board before the switch could be mounted. We used a screw-in female RCA socket for the video connector. Use a length of shielded cable between the PCB and this connector.

For the cassette connections we used a 5-pin DIN socket, with the cables to the cassette recorder terminated to a 5-pin DIN plug. Earth connections for the three cassette cables (Ear, microphone and remote control) can be made to a common pin on the DIN socket, with signal connections to separate pins. Use shielded audio cable between the cassette connector and the connection points on the PCB, although this is not really necessary for the remote control signal.

*A close-up of the power supply wiring. Note the use of a terminal strip and cable clamp for mains connections, and the position of the fuse-holder and power switch.*



## A case for the Super 80



*Note the cassette and video cables and the position of connectors.*

Run the cassette cables from the PCB along the rear of the case to the connector and tie them into a neat bundle. Actual connections to the DIN socket will depend on the configuration of your existing cassette cables.

There is one final step, and that is the LED on the circuit board which indicates correct loading from the cassette recorder. With the top on the case it is obviously not possible to observe this LED, so it should be moved to the front of the case.

Drill a 5mm hole in the vertical front section of the top of the case, above the keyboard cut-out. Carefully remove the LED from the PCB and connect two insulated wires in its place. These leads go to the LED mounted on the front panel, making sure that the correct polarity of the LED is preserved. Use a 5mm plastic LED mounting bezel to secure the LED in the front panel.

With all holes drilled, brush out the bottom section of the case, making sure that no metal filings are left to complicate matters when the Super-80 board is installed. Mount the transformer, fuse-holder, power switch and mains cord. Mount the circuit board in the bottom of the case, again making sure that there is sufficient clearance around the keyboard when the top cover is in place.

Make the connections to the reset switch, video connector and cassette connector. Keep all wiring as short as possible without straining any connections.

Before connecting the power transformer secondaries to the Super-80 PCB check the voltages from these leads. Remember to observe the correct phasing of the 20V (nominal) secondary lines, as described in the September 1981

issue of Electronics Australia, p78.

When all is complete place the top cover of the case in position and secure it with the self-tapping screws provided. We suggest that you place screws at the front of the keyboard and at the rear top of the case. Screw these down tightly and then connect the computer to your video display and switch on. If the Super-80 does not perform as normal the most likely cause is obstruction of the keyboard by the case. Loosen the screws at the front of the case and try moving the keyboard slightly.

Make sure that all the keys are free to move up and down to their full extent. If everything is satisfactory, leave the computer on while you insert and tighten the remaining screws. If at any time the cursor stops flashing on the screen check the keyboard clearance again.

Note that there is another cut-out in the rear of the top section of the case. This rectangular opening is designed for the possible installation of an edge connector or as a convenient exit point for the cable from the Super-80 printer interface board described in a previous issue.

On the subject of the interface board, note that the case is not high enough to take a standard sized S-100 board. If you use such a board you could still use the bottom section of the case but would have to make your own arrangements for a top cover. The Super-80 serial and parallel interface board is a non-standard size S-100 board, and fits quite comfortably inside the case even with the edge connector for the printer cable in place.

That completes the installation of the Super-80 in its case. The result is an attractive unit, solidly protected from the vagaries of the environment — well worth the price of the case and a few hours of careful work.

# Adding graphics to the Super-80

EL Graphix, of Croydon, Victoria, has come up with a series of graphics add-on boards for the Super-80 that will interest all users of this popular do-it-yourself computer. Double screen resolution is just one possibility!

by PETER VERNON

Three kit versions of the board are available. One provides special graphics characters ranging from card suits, lines and stick figures to quarter character cell size blocks which allow a screen resolution of  $64 \times 32$ .

Kit number two provides "chunky" graphics similar to those of the TRS80 Model 1 and the Dick Smith System 80. This kit makes possible a screen resolution of  $64 \times 48$  blocks, but does not include the card suits and other games graphics of kit one.

A third version of the kit uses a 2732 EPROM to provide both the character sets of kits one and two. With this board either of 64 graphics characters can be

selected under software control, although only one set can be used at a time. Cost of kit three is \$49.50 as compared to \$39.50 for kits one and two. Post and packing costs \$2.

### Construction and installation


The kits replace the existing character generator of the Super-80 with a pre-programmed EPROM containing the standard alphanumerics and the new graphics characters. However, each of the graphics characters are designed on an  $8 \times 10$  dot matrix instead of the  $5 \times 8$  matrix of the original character generator, so the character scanning hardware must also be modified.

Each kit consists of a printed circuit board measuring  $80\text{mm} \times 66\text{mm}$ , an EPROM, a replacement for shift register U23 of the Super-80 and miscellaneous wires and sockets. Solder is provided.


Assembly is straightforward as long as the instructions are followed carefully. A low power soldering iron with a fine tip is essential for construction.

Once assembled the graphics PCB is connected to the Super-80 board by ribbon cable terminated by two DIP headers. A 24-pin DIP header replaces the original character generator supplied with the Super-80, while a 16-pin header replaces U23 on the main board. Two other flying leads from the add-on board are soldered directly to pins of ICs on the Super-80 board.

EL Graphix suggests that the add-on board be mounted on the video modulator of the Super-80, and provide nuts and bolts for this purpose. This method of mounting places the PCB over the sockets to which it is connected, and is "crude but effective", as



This screen display illustrates three sets of the 64 graphics characters provided by EL Graphix's kit 1.



The add-on board is installed above the existing character generator socket, bolted to the top of the video modulator.

the EL Graphix instruction sheets put it. Perhaps a better idea if your Super-80 is installed in a case is to mount the new board on a small bracket secured to the side of the case. Alternatively it could be mounted on the bottom of the case, using nuts and bolts with stand-offs.

Whatever method you use make sure that none of the tracks on the new board are short circuited by the mounting hardware, and make sure that the add-on board does not contact any part of the Super-80 PCB except for the connections specified.

## Testing and examples

On switching on the Super-80 with the new board installed you should see a new cursor, a small "EL" graphic, flashing in place of the usual Basic cursor.

Use the statement PRINT [A1 160] to see the first of the new graphics characters. The 64 characters have ASCII codes from 160 to 223, and can be printed or POKEd in the same way as any other ASCII character. The instruction sheets provide a number of sample programs for testing the graphics board.

## Double screen resolution

Using the 16 block graphics characters from kit one, it is possible to double the screen resolution of the Super-80; to 64 points horizontally by 32 points vertically. The second half of the assembly language program in listing 1 does this by taking a pair of co-ordinates and calculating the screen location. It then selects the appropriate graphics character to set or reset a quarter of a character block corresponding to the co-ordinates specified.

Since there are 16 possible combinations of the four points in each character cell, 16 separate graphics characters are used, selected from the table which concludes listing 1.

The origin of the co-ordinate system is in the upper left hand side of the screen, and the program as given is set up for a Super-80 with 48K of RAM. To use it in a machine with less memory, change the value at location 008D of the program from BE to 3E for 16K or 7E for 32K.

The first half of the program in listing 1 adds the capability to draw lines. Given the co-ordinates of the start and end points of the line it calculates all the points in between and calls the DOT routine to draw the line. Since this is an assembly language program, it is quite fast.

To allow us to erase dot points or lines, one byte of the program is a "flag" called MODE. When this location (196 in decimal) is set to "1" a point will be displayed. When MODE is "0" the

## Double screen resolution program

0000	11 00 00	LD DE,START
0003	21 00 00	LD HL,END
0006	CD 10 00	CALL LINE1
0009	C9	RET
000A	11 00 00	LD DE,POINT
000D	C3 70 00	JP 0070 PLOT POINT
0010	LINE1 01 00 00	LD BC,0000
0013	C5	PUSH BC
0014	7A	LD A,D
0015	BC	CP H
0016	DA 22 00	JP C,L2
0019	C2 21 00	JP NZ,L1
001C	7B	LD A,E
001D	BD	CP L
001E	DA 22 00	JP C,L2
0021	L1 EB	EX DE,HL
0022	L2 44	LD B,H
0023	4D	LD C,L
0024	21 43 00	LD HL,I4
0027	36 3C	LD(HL),3C
0029	7B	LD A,E
002A	B9	CP C
002B	DA 30 00	JP C,L3
002E	36 0C	LD(HL),0C
0030	L3 7A	LD A,D
0031	B8	CP B
0032	CA 49 00	JP Z,L5
0035	C5	PUSH BC
0036	80	ADD B
0037	1F	RRA
0038	47	LD B,A
0039	3C	INC A
003A	67	LD H,A
003B	7B	LD A,E
003C	B9	CP C
003D	CA 44 00	JP Z,L4
0040	L6 81	ADD C
0041	1F	RRA
0042	4F	LD C,A
0043	I4 3C	INC A
0044	L4 6F	LD L,A
0045	E5	PUSH HL
0046	C3 30 00	JP L3
0049	L5 7B	LD A,E
004A	B9	CP C
004B	CA 53 00	JP Z,G1
004E	C5	PUSH BC
004F	62	LD H,D
0050	C3 40 00	JP L6
0053	G1 CD 70 00	CALL DOT1

listing continued ►



# Super-80 graphics

specified point will be turned off. Since the dot routine is used by LINE, mode allows lines to be either plotted or erased as well.

LINE takes two pairs of co-ordinates, the starting point in the DE register of the processor and the end point in HL. The short routine at location 0000 to 0009 actually loads the co-ordinate pairs into the appropriate registers and then calls the line drawing routine.

For example, suppose that A and B are the X and Y co-ordinates of the starting point and C and D are the co-ordinates of the end point of a line. Put A in location 0002, B in location 0001, C in location 0005 and D in location 0004, then run the program from 0000. See the subroutine at line 1000 of listing 2.

To plot a single point put the X co-ordinate in location 000C and the Y co-ordinate in location 000B, then run the program from 000A. The subroutine at line 2000 of listing 2 does this. When using the assembly language program in your own Basic programs, don't forget to set "MODE" at location 00C4 (196 decimal) to display or erase.

The program in listing 2 first draws a border around the screen by reading a list of start and end points from DATA statements, then calling the subroutine at line 1000 which draws the lines. After the border the program displays 100 individual points at random co-ordinates using the subroutine at line 2000.

## Going on

The programs given here are just one example of what can be done with the graphics. By drawing lines and dots and combining them with other graphics characters provided by the kit complex pictures can be built up. By plotting in two or more areas of memory and displaying them in sequence, animated scenes can be constructed.

The EL Graphix kits seem like a worthwhile addition to the Super-80. Which version you choose depends on your own particular requirements, but they are all well designed, easy to install and simple to use. They can open up a whole new range of capabilities for your computer.

For more information contact EL Graphix, PO Box 278, Croydon, Vic 3136.

NOTE: The DOT portion of the program here is similar to a program for the Sorcerer computer which appeared in the US magazine "Creative Computing", January, 1981. The workings of the LINE routine are explained in a short article in "Byte" magazine for October, 1980 called "Vector graphics for Raster Displays".

0056		D1	POP DE
0057		7A	LD A,D
0058		B3	OR E
0059		C8	RET Z
005A		C1	POP BC
005B		C3 30 00	JP L3
005F		00	
0070	DOT1	AF	XOR A
0071		CB 3B	SRL E
0073		8F	ADC A,A
0074		CB 3A	SRL D
0076		8F	ADC A,A
0077		0E 01	LD C,01
0079		B7	OR A
007A		28 05	JR Z,P1
007C	P2	CB 21	SLA C
007E		3D	DEC A
007F		20 FB	JR NZ,P2
0081	P1	67	LD H,A
0082		6B	LD L,E
0083		3E 05	LD A,05
0085	P3	29	ADD HL,HL
0086		3D	DEC A
0087		20 FC	JR NZ,P3
0089		5A	LD E,D
008A		57	LD D,A
008B		19	ADD HL,DE
008C		11 00 BE	LD DE,BE00
008F		19	ADD HL,DE
0090		57	LD D,A
0091		5E	LD E,(HL)
0092		DD 21 C5 00	LD IX,TABLE
0096	P4	DD 7E 00	LD A,(IX+0)
0099		B7	OR A
009A		28 08	JR Z,S1
009C		BB	CP E
009D		28 06	JR Z,S2
009F		14	INC D
00A0		DD 23	INC IX
00A2		18 F2	JR P4
00A4	S1	57	LD D,A
00A5	S2	3A C4 00	LD A,(MODE)
00A8		B7	OR A
00A9		28 04	JR Z,S3
00AB		7A	LD A,D
00AC		B1	OR C
00AD		18 03	JR S4
00AF	S3	79	LD A,C
00B0		2F	CPL
00B1		A2	AND D
00B2	S4	57	LD D,A
00B3		DD 21 C4 00	LD IX,TABLE-1
00B7		14	INC D
00B8		DD 23	INC IX
00BA	S5	15	DEC D

listing continued on p 93 ►

```

00BB      20 FB      JR NZ,S5
00BD      DD 7E 00    LD A,(IX+0)
00C0      77          LD (HL),A
00C1      C9          RET
00C2      00
00C3      00
00C4 MODE  01 (01 TO PLOT , 00 TO ERASE)
00C5 TABLE 20
00C6      AB
00C7      AC
00C8      A0
00C9      AE
00CA      A6
00CB      AA
00CC      A7
00CD      AD
00CE      A9
00CF      A2
00D0      A1
00D1      A4
00D2      A5
00D3      A3
00D4      A8
00D5      00

```

## Listing 2: Basic example program

```

00010 CLS
00012 REM DRAW A SCREEN BORDER
00020 L=0
00030 READ A,B,C,D
00032 DATA 0,0,63,0
00034 DATA 63,0,63,31
00036 DATA 63,31,0,31
00038 DATA 0,31,0,0
00040 GOSUB 1000
00050 L=L+1:IF L<4 THEN GOTO 30
00060 REM
00070 REM DISPLAY 100 RANDOM DOTS
00072 D=0
00080 X=INT(RND*63)+1
00090 Y=INT(RND*31)+1
00100 GOSUB 2000
00110 D=D+1:IF D<100 THEN GOTO 80
00120 END
01000 REM SUBROUTINE FOR LINES
01010 REM
01020 POKE 1,B:POKE 2,A
01030 POKE 4,D:POKE 5,C
01040 POKE 196,1
01050 USR(0)
01060 RETURN
02000 REM SUBROUTINE FOR DOTS
02010 POKE 11,Y:POKE 12,X
02020 POKE 196,1
02030 USR(10)
02040 RETURN

```

# Attention all Super-80 owners!

A new book, "Software for the Super-80 Computer", will be available during September. Reserve your copy now.

This new book, presently at the printers, was compiled from submissions to the Super-80 Software Competition judged earlier this year. The book has 48 pages, of the same size as this magazine, featuring 17 Basic programs in printed listing form. They represent a useful range of exercises which will be of use to all Super-80 owners. The price: \$5 plus \$1 for postage anywhere in Australia.

To: Electronics Australia, PO Box 163, Chippendale, 2008

Please send me . . . . . copies of "Software for the Super-80 Computer" at \$6.00 each (includes post and packing)

NAME . . . . .

ADDRESS . . . . .

. . . . . POSTCODE . . . . .

☐ I enclose cheque/postal order to the value of \$ . . . . .

☐ Please charge my Bankcard \$ . . . . .

Bankcard Number 496 . . . . .

Expiry Date . . . . . Cardholder Signature . . . . .

If you are using Bankcard, be sure to include your full address (not a PO Box)

# Software for the Super-80 Computer

\$5.00\*

"Software for the Super-80" was compiled from submissions to the Super-80 Software Competition judged earlier this year. The book has 48 pages, of the same size as this magazine, featuring 17 Basic programs in printed listing form. They represent a useful range of exercises which will be of use to all Super-80 owners.

Available from "Electronics Australia", 57 Regent St, Chippendale. PRICE \$5.00 OR by mail order from "Electronics Australia", PO Box 163, Chippendale, 2008. PRICE \$5.00 plus \$1.00 for packaging and posting anywhere in Australia.

## Here Are The Program Headings:

- |                            |                                  |
|----------------------------|----------------------------------|
| 1 Poker machine simulation | 10 Lotto number selector         |
| 2 Printing demonstration   | 11 Triangle solutions            |
| 3 Calendar calculator      | 12 Mortar attack game            |
| 4 Othello game             | 13 Caves & Monsters              |
| 5 Investment analysis      | 14 Amateur radio Q-code tutorial |
| 6 Guessing game            | 15 Caravan park directory        |
| 7 List and sort            | 16 Super Pokey game              |
| 8 "Fred the shrink"        | 17 Tattslotto selector           |
| 9 Simple maths drill       |                                  |

To: Electronics Australia, PO Box 163, Chippendale, 2008

Please send me . . . . . copies of "Software for the Super-80 Computer" at \$6.00 each (includes post and packing)

NAME . . . . .

ADDRESS . . . . .

. . . . . POSTCODE . . . . .

☐ I enclose cheque/postal order to the value of \$ . . . . .

☐ Please charge my Bankcard \$ . . . . .

Bankcard Number 496 . . . . .

Expiry Date . . . . . Cardholder Signature . . . . .

If you are using Bankcard, be sure to include your full address (not a PO Box)

# Software for the Super-80

**Games**

**Education**

**Business**

**Who said there's no  
Super-80 software?**

Improve your maths skills or go adventuring with "Caves & Monsters"; run a business or perhaps win a fortune on Tattslotto! Our Super-80 programs book has something for everyone. Compiled from entries in the Super-80 program competition, earlier this year, these program listings will interest every Super-80 enthusiast.

Why be content with a tacky photocopy, when for just \$5 you can have your own brand new copy, clearly printed and a pleasure to use? (And it's legal, too).

Use the coupon at right (and add \$1 for postage and packing), or call in at Electronics Australia, 57 Regent St, Chippendale, and save the postage. We're conveniently close to Central railway and open during normal business hours.

Available from "Electronics Australia", 57 Regent St, Chippendale. PRICE \$5.00 OR by mail order from "Electronics Australia", PO Box 163, Chippendale, 2008. PRICE \$5.00 plus \$1.00 for packaging and posting anywhere in Australia.



**Note: This book is exclusive to "Electronics Australia" and is available only from the address listed in this advertisement.**

**To: Electronics Australia, PO Box 163, Chippendale, 2008**

*Please send me . . . . . copies of "Software for the Super-80 Computer" at \$6.00 each (includes post and packing)*

**NAME** . . . . .

**ADDRESS** . . . . .

. . . . . **POSTCODE** . . . . .

☐ **I enclose cheque/postal order to the value of \$** . . . . .

☐ **Please charge my Bankcard \$** . . . . .

**Bankcard Number 496** . . . . .

**Expiry Date** . . . . . **Cardholder Signature** . . . . .

*If you are using Bankcard, be sure to include your full address (not a PO Box)*



# Circuit modification gives inverse and . . .

## Chunky graphics for the Super-80

This modification to the Super-80 circuit adds "chunky" graphics and inverse video characters to the character set of the computer. Although inexpensive it does involve rather extensive modifications to the circuit board. We haven't performed these modifications on our own system, and the circuit and following description is offered "as is".

By REG WORL\*

Graphics can add enormous scope to computer applications. Video games such as Space Invaders use graphics symbols for those little alien monsters, bar graph displays depend on high resolution for accuracy, and plotting applications can produce neater, clearer displays with higher resolution graphics.

Another useful feature on VDUs is the inverse video capability. In normal operation using only alphanumeric characters, an inverse video feature enables key words on a page of text to be highlighted by printing them as black characters on a white background.

Both the above features can be added to the Super-80 microprocessor system. This article describes the necessary modifications and explains the way to use these features.

The changes to the Super-80 required for the inverse video feature are simple and easy to understand. However, modifications for the graphics facility are slightly more difficult and require the reader to be very careful when altering the existing Super-80 hardware.

### Super-80 video display

To assist the reader in understanding how these modifications will affect the Super-80 system, a brief description of the video display format is necessary.

The video circuitry of the Super-80 refreshes the screen once every 20ms. Throughout each frame interval the microprocessor is halted for 10ms to allow the contents of the video area of memory to be transferred to the video display circuitry. The video circuitry starts to write characters onto the screen

5ms after the start of each frame and complete its operation 10ms later. The screen is blanked during the beginning and end portions of the frame.

The active region of the monitor display is organised to allow 16 rows of text to be shown. Ten scan lines are used for each row of text with the separation between rows obtained by blanking lines numbered 0, 8 and 9. The centre portion of each row of text is divided into 32 character fields each of which consists of eight columns as shown in Fig. 1.

Separation is required between characters and this is produced by blanking columns numbered 0, 6 and 7. When the blanked lines and columns in each character field are disregarded, a 7 x 5 matrix remains in which a dot pattern is used to construct a character. Fig. 1 shows how the letter "A" is constructed using seven lines of dots.

The dot pattern generated on the screen is a function of the text stored in the video RAM and the line being scanned. The dots on any given line are pro-

duced for each character field by five parallel bits from the character generator U27 and are serially transmitted by the shift register U23 to the video mixer and modulator. A dot is produced on the screen whenever a logic "1" level appears at the output of the shift register. An inverse video display can be simply obtained by inverting the dot pattern sent from the shift register.

Finally, a brief examination of the video RAM contents is necessary before the Super-80 modifications can be detailed. The characters to be displayed on the monitor screen are stored in the video RAM as ASCII characters in the binary form 0XXX XXXX. There are 128 ASCII characters but only 64 characters can be displayed by the Super-80. Although bit 6 of these 64 ASCII characters contains either a 0 or 1, this bit together with bit 7 is not required by the character generator. Enough information exists in the remaining low-order bits, D0 to D5, to decode which of the 64 valid characters is required. Since bits 6 and 7 are unused by the character generator they are available to contain the display mode information which will be required by the circuits described below.

### The circuit modifications

The additional circuits required for the modifications consist of three sections; the decoding circuit, the inverse video generator, and the graphics generator.




Fig. 1




Fig. 3

Characters are built up in an 8x8 matrix.

Inverse characters are black on white.

\*67 Conrad St, St Albans, Vic 3021.




Fig. 2

"X" indicates a track to be cut on the existing board. "IC" prefix indicates a device to be added to Super-80 circuit.

The circuit diagram for the complete modifications is shown in Fig. 2.

The function of the decoding circuit is to determine from the encoded information in bits 6 and 7 of each video character word which of the three possible display modes (normal, inverse video, or graphics) is required to display that character. The selected display mode is then produced by enabling the respective circuits. The codes for the three display modes are given in Table 1 and have been so arranged that all characters written to the screen by the Monitor are displayed in their normal mode. This arrangement allows the user to retain the normal operation of the Super-80 without the need of any software changes.

The decoding circuit consists of four NAND gates and an exclusive OR gate IC4d. Gate IC1b activates the inverse-video circuit when required and gate IC1c controls the graphics circuitry. In the graphics mode the character generator is not required and is hence disabled by gate IC4d. Switch S1 is an option which may also be added although it would generally not be required. Operating this switch would completely disable the inverse video and graphics generator circuits allowing normal operation of the basic Super-80.

The inverse video generator is a simple circuit consisting of four components: the D flip-flops IC3a and IC3b, an ex-

clusive OR gate IC4c, and the inverter U39b. When this circuit is selected by the decoder circuit a logic 1 is applied to flipflop IC3a. The input signal is clocked through the flipflop at the beginning of each character field and controls the programmable inverter for the display duration of that character. Flipflop IC3b ensures that the inverse video is switched off after the last character on each row. The display produced by the inverse video generator is shown in Fig. 3.

FUNCTION	BIT 7	BIT 6
NORMAL OPERATION	0	0
NORMAL OPERATION	0	1
GRAPHICS	1	0
INVERSE VIDEO	1	1

TABLE 1

New features are accessed by setting data bits 6 or 7. Software is unchanged.

Note that the two separation lines at the bottom of the character field remain blanked.

To display a character in the inverse video mode, bits 6 and 7 of the character word must contain the code "11". Normal characters can be changed to this mode by "OR-ing" them with 1100 0000 binary or C0 hex before they are placed into the video RAM. Characters stored by the Monitor can be read and replaced by a user program to produce an inverse video display.

## Graphics mode

Unlike the normal and inverse video display modes, the graphics mode uses the entire character field by eliminating the previously blanked lines and columns used for row and character separation. The line blanking is controlled by the output of gate U39b. In order to disable the line blanking during a graphics character, U39b is replaced by the NAND gate IC1d which is enabled as required by the decoding circuit. Note that U39b must have both its input and output disconnected from this circuit because it is re-used in the inverse video circuit. The grounded shift register inputs 10, 11 and 17 which cause the blank columns must also be disconnected and connected to the two AND gates IC2a and IC2b. The decoding circuit activates these gates to inhibit column blanking during the graphics mode.

Each graphics character consists of six pixels which together occupy the entire character field. The pixels are numbered as shown in Fig. 4 and are controlled by the respective bits in the character code. Since the dot patterns are now directly controlled by the character codes, the character generator U27 is no longer required and has its output replaced by the Tri-state buffers IC6a to IC6d. The 74LS153 decoder selects which of the character code pairs b0-b1, b2-b3, or b4-b5 is required for each of the 10 lines

in every row. The selected bit pair is then loaded into all eight inputs of the shift register for transmission to the screen. The gates IC2c, 2d, 4a and 4b determine which bit pair is to be selected. Note that these modifications cause the prompt placed at the left of each row by the monitor to be displayed as a graphics character.

With this modification each character cell is divided into two blocks horizontally and three blocks vertically. Since normally 16 lines of 32 characters each are displayed on the screen, the effective resolution in the graphics mode in 64 blocks horizontally by 48 vertically.

When writing programs which will require the graphics facilities, it is best to obtain the codes for the various graphics characters from a table. Table 2 has been provided for this purpose. To use this table construct the required character by selecting the necessary pixel combinations from both parts of the table. The codes given with the selected combinations are then combined to give the character code.

To ensure that these modifications do not interfere with the operation of the microprocessor due to loading or incorrect construction, the data bus is isolated from the additional circuits through the buffer U12. The additional components required for these modifications can all be installed on the existing Super-80 board. The six packages IC1 to IC6 occupy the spare pads at the rear of the microprocessor board whilst IC U12 is added to the S-100 expansion area.

**Note, though, that if you elect to do this the S-100 expansion interface cannot be used, as U12 is normally used as a buffer for data to the S-100 expansion connector.**

## Care required

These modifications require fairly extensive "surgery" on the circuit board of the Super-80. There are nine tracks to be cut and 15 wire connections to the existing computer circuitry, apart from the inter-connection of the new ICs. This is not a project for the beginner.

The positions of the tracks to be cut or are shown by an "X" on the circuit diagram of Fig. 2.

If you are thinking of building a Super-80 but have not yet begun, finding and cutting the required tracks is relatively easy. If your Super-80 is already completed it will be necessary to remove ICs U27 and U23 to gain access to the tracks to be cut. For those who have used IC sockets a simple alternative to cutting tracks is to remove the ICs from their sockets, bend the pins to be disconnected upwards and re-install the

ICs. The necessary wire connections can then be made directly to these pins.

It is suggested that 30AWG insulated wire (as used for wire-wrapping) be used for the modified connections. This wire is thin enough to allow several pieces to be twisted together and soldered to a single printed circuit pad. Care must be

		COLUMN NUMBER							
		0	1	2	3	4	5	6	7
LINE NUMBER	0	b0				b1			
	1								
	2								
	3								
	4	b2				b3			
	5								
	6								
	7								
	8	b4				b5			
	9								

1 0 b5 b4 b3 b2 b1 b0  
GRAPHICS  
CHARACTER WORD

Fig. 4

Graphics are set by six lowest data bits.

taken to avoid solder bridges and connections made to wrong locations.

Where a cut needs to be made through a conductor it is recommended that two parallel cuts 2mm apart be made across the conductor with a sharp blade. A clean, hot soldering iron is then used to heat the strip between the cuts until it lifts away from the board. This procedure ensures that a reliable cut is obtained. Ensure that enough track remains on each side of the cut to allow a link to be soldered in should the cut ever need to be repaired.

After these modifications have been completed, the Super-80 video display should appear as normal but with the Monitor prompt displayed as a graphics character. These modifications can be tested by using the Monitor "E" command to place various character codes into the video RAM buffer. For a 16k system the monitor selects the memory block from 3E00 hex to 3FFF hex as the video RAM area. Any character code placed in this area will be displayed on the screen in the display mode determined by bits 6 and 7 of the code.

For a 32K Super-80 the video RAM area

SELECTION GUIDE FOR LEAST SIGNIFICANT DIGIT			
SELECTION GUIDE FOR MOST SIGNIFICANT DIGIT			

TABLE 2

Table shows each graphics shape produced.

is normally from 7E00 to 7FFF, while 48K machines place the video RAM at BE00 to BFFF.

## Editorial note

Super-80 owners should be aware of two other graphics add-ons. Dick Smith Electronics offers a board containing an EPROM providing lower case and inverse video characters which is installed in place of the existing character generator, with some modifications to the circuit character clocking circuitry. This board was reviewed in EA, February 1982, p111.

EL Graphix offers a similar board with a choice of three different EPROMs, one providing quarter-character sized graphics blocks and other symbols and another providing one-sixth sized blocks. The third EPROM provides both the character sets. This board was featured in EA, August 1982.

Neither of these two boards require extensive modifications to the Super-80 circuit board. Since they use an EPROM for character storage, however, they are more expensive than the approach described here.

## Software for the Super-80

**Here Are The Program Headings:** Poker Machine simulation, Printing Demonstration, Calendar Calculator, Othello Game, Investment Analysis, Guessing Game, List and Sort, "Fred the Shrink", Simple Maths Drill, Lotto Number Selector, Triangle Solutions, Mortar Attack Game, Caves & Monsters, Amateur Radio Q-code Tutorial, Caravan Park Directory, Super Pokey Game, Tattslotto Selector.

**NOTE:** This book is exclusive to "Electronics Australia" and is available only from "Electronics Australia", 57 Regent St, Chippendale. PRICE \$4.00 OR by mail order from "Electronics Australia", PO Box 163, Chippendale, 2008. PRICE \$4.00 plus \$1.00 for packaging and posting anywhere in Australia.

## Microcomputer News

### Programmable characters for the Super-80


A Queensland firm, the Computer Clinic, now has available a programmable character generator for the Super-80 computer.

The character generator adds an additional 4K of memory to the Super-80 in locations F000 to FFFF and provides standard upper and lower case characters and games graphics in EPROM and sufficient RAM to contain the definitions of an additional 128 characters formed on the standard  $8 \times 10$  grid used by Super-80 characters.

The kit arrives packed in a plastic bag with the PCB itself measuring 121mm  $\times$  145mm (less a small rectangular cut-out to clear the Super-80's RF modulator). The add-on board is well made and is double-sided with plated-through holes. All required parts are provided, including sockets for all ICs (a total of 13), a small length of solder and hook-up wire and comprehensive instructions.

The board is connected to the Super-80 by means of three wire-wrap sockets which protrude below the PCB. The pins of these sockets plug into the original socket of the Z80, video shift register and one IC in the timing chain while the chips originally on the Super-80 board are plugged into the new PCB.

The 2513 character generator provided with the Super-80 is also removed and is not used by the programmable character add-on. One wire link is required on the Super-80 board itself.



The 6116  $2K \times 8$  RAM is provided to store programmed character definitions while standard characters are stored in a 2516 EPROM. A socket is provided for a second, optional EPROM which can be installed by the user and used to store pre-programmed character definitions which can be transferred to the RAM character generator as required.

This facility allows the user to create customised character sets and store them permanently with the use of an EPROM programmer. Needless to say, the contents of the additional RAM can also be stored on tape and reloaded for later use with the Super-80 Monitor tape routines.

A 12-page instruction sheet is included with a kit containing assembly instructions for beginners and experienced hobbyists, circuit diagram and component

layout and a description of the principles of operation, with sample programs.

Assembly of the kit is straightforward although installation requires some care in ensuring that the pins of the three wire-wrap sockets are aligned and correctly inserted in the vacated sockets of the Super-80 board. This is the only tricky part of the entire operation. The kit fits without difficulty in the standard Super-80 case.

In short, an accessory which should be of interest to all users of the Super-80 computer.

Cost of a complete kit for the programmable character generator is \$89.95, while the character set EPROM, PCB and instruction manual are available for \$47.50. For further information contact the Computer Clinic, PO Box 68, Aspley, Qld 4034. Phone (07) 269 8573.

Hard copy at a soft price

# Super-80 Baudot teleprinter interface

Want to interface your Super-80 computer to a low-cost teleprinter? Surplus Baudot teleprinters can usually be obtained for about \$200 and the interface circuitry is not difficult.

by R. W. PITCHER, VK5AN

There are two types of teleprinter available to the hobbyist. Computer teleprinters such as the well-known Teletype model ASR-33 are most commonly used in business applications. These machines communicate via a 20mA current loop, at a rate of 110 baud (bits per second) and in the ASCII code.

While machines of this sort occasionally appear on the second-hand market, they are not cheap, usually ranging from \$600 up depending on condition. This is rather a lot to pay to communicate with a computer costing around \$400!

In contrast with these computer-type teleprinters, large supplies of the older Baudot-type teleprinters are currently available at much lower cost from companies dealing in surplus equipment. Prices for the Teletype model 15 teleprinter, for example, are around \$200.

While the price is attractive compared with the more modern ASCII teleprinters, these machines are not directly compatible with computer

systems, chiefly because they use a 5-bit Baudot code rather than the 7-bit ASCII code. While the code translation can be performed by software, not all ASCII characters have a Baudot equivalent.

The original program was written to make extra use of the Baudot printer I use for radioteletype, and so prints characters out at 45.45 baud. Machines currently available run at around 50 to 75 baud unless they have been converted. To change the character printing speed it is only necessary to change the byte at location 30DA hex in the listing given here. For 50 baud operation, insert 13 (hex) and for 75 baud the figure should be 0B (hex).

These figures should be considered as a guide only, as they have not been tried with a printer but were arrived at by checking the length of the mark and space pulses at the output port.

Newer teletypes run around 110 baud, with 11 bits per character, to give an effective printing speed of around 10 characters per second. In contrast

Baudot machines running at 50 baud and using 7.5 bits per character provide a maximum printing speed of around 6.5 characters per second.

In fact, because of the necessity to send special "letters" and "figures" characters interspersed with actual printing characters, the maximum rate of a 50 baud Baudot teleprinter is in practice around five characters per second.

The limitations in the character set will only be of concern when printing Basic programs. For assembly language or hex listings the range is quite adequate.

## The program

The program uses bit 4 of output port F0 of the Super 80. A connection can be found on the underside of the board, running from pin 12 of U18. On the area marked "port" on the board, near the cassette relay, this connection is the fourth hole counting from the end marked "1".

The required software is not straightforward. The Baudot code is best considered as a 6-bit code in which the normal sixth bit is sent only when it changes value. It is sent in encoded form as a special "letters" and "figures" character shift.

To initialise the printer routine, call 3500H (CD 00 35) in the program supplying the character to be printed, or enter C3500 before using. The character to be printed is passed in the C register, and is entered at 3508H (CD 08 35). All registers are preserved by the routine.

Figures and letters shifts are inserted automatically as required, and a line feed is inserted following every carriage return. A "tab" function is included, but any other control characters are ignored, since there are no Baudot equivalents.

Lower case ASCII characters are printed as their upper case equivalent, since there are no lower case letters on




Fig. 1 LOOP SUPPLY AND COMPUTER INTERFACE

To use a teleprinter as a dedicated computer peripheral a loop supply is required. Optoisolators are used for safety and to avoid ground loops.

# Super 80 Baudot teleprinter interface

the Baudot machine. Items on the look-up table given as COH are those with no Baudot equivalent and could be changed to print any desired character.

For instance, if you wish square brackets ([ ]) to print as normal brackets, then change location 3121H to E4H and 3124H to DEH. Any coding left as COH sends a blank to the machine and so prints nothing.

While a character is being sent to the printer the VDU is blanked to maintain timing accuracy, so the screen is only active while the printer routine is waiting for a character. Therefore the VDU will flicker at a rate depending on the rate at which characters are fed in. If the rate is fast enough the screen appears to remain blank.

## Interface circuitry

The printer will require a loop supply. If it is to be used only for program dumping, then the circuit of Fig. 1 is required. It has been found that most machines operate best with a minimum loop supply of about 70 volts, making input waveform distortion and timing errors less critical. The value of R1 is adjusted for the manufacturer's recommended loop current on "mark", (usually between 40 and 50 mA).




FIG. 2 INTERFACE TO SUIT RTTY TERMINAL UNIT

Circuit for use with an RTTY teleprinter.

An alternative circuit is given in Fig. 2 for those who already have an operating machine used for RTTY. In both cases, optoisolators are used to remove the risk of earth loop problems and to ensure complete isolation between the computer and any circuitry operating at high voltage.

To use the program for Basic LPRINT or LLIST, insert the following bytes from 0000H onwards:

0000H 55 4F CD 08 35 41 CD 19 C0 78 C9. Then G3500, return to Basic warm-start (GD003) and type LLIST or RUN for LPRINT. To disable the printer, change the byte at 0000H to anything but 55H. The monitor uses this routine to find out if a printer program is available and, if so, where it is located in memory.

The program has proved its worth

since I can now keep a permanent record of my programs without having to copy them from the screen with its attendant risk of errors. The print out of the program accompanying this article was obtained using the same program.

## Finding a teleprinter

The following companies handle second-hand computer equipment in Sydney: The Computer Exchange, 5/8 Pacific Parade, Dee Why, NSW, 2099 (02) 98 8111; CQ Electronics, Shop 9, 30 Campbell St, Blacktown, NSW (02) 698 8079.

Note that the availability of equipment is variable and depends on companies and government departments disposing of surplus equipment. It is not simply a matter of purchasing "off the shelf".

In Sydney, "The Trading Post" weekly paper often carries advertisements from individuals wishing to dispose of surplus equipment. It is a good place to start looking for a teleprinter.

The notice boards at electronics stores and computer clubs also occasionally display "FOR SALE" bulletins for teleprinters. You can also, of course, go "straight to the horse's mouth" as it were, and attend government auctions.

,45.45 BAUD PRINTER ROUTINE FOR SUPER 80  
,COPYRIGHT 1983, R.W.PITCHER VK5AN

```

3500          ORG      3500H
3500 F5      STRT    PUSH AF      ,SAVE REGISTERS
3501 E5      PUSH    HL
3502 C5      PUSH    BC
3503 D5      PUSH    DE

3504 3EFB    LD       A,0FBH
3506 D3FD    OUT      (0F0H),A ,TURN VDU OFF

3508 79      LD       A,C
3509 E67F    AND      7FH      ,SET BIT 7 TO ZERO

350B FE60    CP       60H
350D 3802    JR       C,C,R
350F D620    SUB      20H      ,SETS LWR TO UPPER CASE
    
```

,CR/LF ROUTINE

```

3511 FE0D    CR      CP       0DH
3513 2011    JR       NZ,TCOM
3515 3E00    LD       A,00H
3517 320D00  LD       (000DH),A,CHAR COUNT SET TO Z
351A 0660    LD       B,60H ,LOC ON LOOKUP TBL
351C CD9835  CALL     BOUT
351F 0661    LD       B,61H
3521 CD9835  CALL     BOUT
3524 1469    JR       ENDT
3526 FE09    TCOM    CP       09H
3528 2843    JR       Z,TAB
352A FE20    CP       20H
352C 0620    LD       B,20H
352E 2838    JR       Z,COUT
    
```

,BYPASS FOR CONTROL CHARACTER

```

3530 385D    JR       C,ENDT
3532 F5      PUSH    AF      ,SAVE CHARACTER
    
```

,IF FIGS OR PUNCTUATION THEN JUMP

```

3533 FE41    CP       41H
3535 3817    JR       C,FIGS
3537 FE5B    CP       5BH
3539 3013    JR       NC,FIGS
    
```

,IF LAST CHAR FIGS,SEND LTRS FIRST

```

353B 3A0C00  LD       A,(000CH),CHAR STATUS
353E FE00    CP       00H ,LAST CHAR LTRS?
3540 281D    JR       Z,RESC
3542 3E00    LD       A,00H
3544 320C00  LD       (000CH),A,CHAR STATUS TO LTRS
3547 0662    LD       B,62H
    
```

```

3549 CD9835  CALL     BOUT
354C 1811    JR       RESC
    
```

,IF LAST CHAR LTRS,SEND FIGS FIRST

```

354E 3A0C00  FIGS    LD       A,(000CH)
3551 FE00    CP       00H ,LAST CHAR LTRS?
3553 200A    JR       NZ,RESC
3555 3EFF    LD       A,0FFH
3557 320C00  LD       (000CH),A,CHAR STATUS TO FIGS
355A 0663    LD       B,63H ,LOC ON LOOK UP TBL
355C CD9835  CALL     BOUT
    
```

,INC CHAR COUNT FOR PRINTING CHARS ONLY

```

355F 3A0D00  RESC    LD       A,(000DH)
3562 3C      INC     A
3563 320D00  LD       (000DH),A,INC CHAR COUNT
    
```

,JUMP TO BAUDOT CONVERSION

```

3566 F1      POP      AF      ,GET CHAR BACK
3567 47      LD       B,A
3568 CD9835  COUT    CALL     BOUT ,BAUDOT OUT
356B 1822    JR       ENDT
    
```

,TAB ROUTINE

```

356D 3A0D00  TAB     LD       A,(000DH),CHAR COUNT
3570 F5      PUSH    AF      ,SAVE COUNT
3571 C602    ADD     A,02H
3573 E607    AND     07H
3575 D602    SUB     02H
3577 0620    LD       B,20H
3579 1E00    LD       E,00H
357B D5      TC      PUSH    DE
357C C5      PUSH    BC
357D F5      PUSH    AF
357E CD9835  CALL     BOUT
3581 F1      POP      AF
3582 C1      POP      BC
    
```

```

3583 D1      POP      DE
3584 1C      INC      E
3585 3C      INC      A
3586 FE08    CP       08H
3588 20F1    JR       NZ,TC      ,JP TO TAB COUNT
358A F1      POP      AF
358B 83      ADD      A,E
358C 320D00 LD       (000DH),A,UPDATE CHAR COUNT
358F 3EFF    LD       A,OFFH
3591 D3F0    OUT      (0F0H),A ,TURN VDU ON

,BACK TO MAIN PROGRAMME

3593 D1      POP      DE
3594 C1      POP      BC
3595 E1      POP      HL

3596 F1      POP      AF
3597 C9      RET

,GET BAUDOT EQU FROM LOOK-UP TABLE

3598 219E35 BOUT     LD      HL,LKUP-20H
359B 1600    LD      D,00H
359D 58      LD      E,B
359E 19      ADD     HL,DE
359F 56      LD      D,(HL)
,LOC ON LOOKUP TBLE

,GENERATE 8 PULSES DET BY BITS IN D REG

35A0 0608    LD      B,08H
35A2 C5      BITS    PUSH   BC
35A3 CB42    BIT     0,D
35A5 2004    JR       NZ,XX
35A7 3EEB    LD      A,0EBH
35A9 18Q2    JR       YY
35AB 3EFB    XX      LD      A,0FBH
35AD D3F0    YY      OUT     (0F0H),A
,NUMBER OF BITS
,SAVE BIT COUNT
,SET O/P PORT LOW
,SET O/P PORT HIGH
,SET PORT

,LENGTH OF PULSE FOR BAUDOT SPEED

35AF 3E86    PD      LD      A,86H
35B1 0616    LD      B,16H
35B3 10FE    DJNZ    $-0
35B5 3D      DEC     A
35B6 20F9    JR       NZ,PD
,DELAY TO SET SPEED
,JUMP BACK TO YOURSELF

35B8 C1      POP      BC
35B9 CB3A    SRL     D
35BB 10E5    DJNZ    BITS
35BD C9      RET
,RESTORE BIT COUNT
,MOVE IN NEXT BIT
,KEEP GOING FOR 8 BITS

,LOOK-UP TABLE

35BE C8C0    LKUP     DEFW   0C0C8H
35C0 CAC0    DEFW   0C0CAH
35C2 F4DA    DEFW   0DAF4H
35C4 C0CA    DEFW   0CAC0H
35C6 DEE4    DEFW   0E4DEH
35C8 D2E2    DEFW   0E2D2H
35CA D8C6    DEFW   0C6D8H
35CC F8FA    DEFW   0FAF8H
35CE ECEE    DEFW   0EEECH
35D0 E6C2    DEFW   0C2E6H
35D2 D4E0    DEFW   0E0D4H
35D4 EACE    DEFW   0CEEAH
35D6 CCFO    DEFW   0F0CCH
35D8 DCDC    DEFW   0DCDCH
35DA E4FC    DEFW   0FCE4H
35DC DEF2    DEFW   0F2DEH
35DE C0C6    DEFW   0C6C0H
35E0 F2DC    DEFW   0DCF2H
35E2 D2C2    DEFW   0C2D2H
35E4 DAF4    DEFW   0F4DAH
,(SP)
, ' £
,$ %
,$ '
,( )
, +
, -
, /
, 0 1
, 2 3
, 4 5
, 6 7
, 8 9
, :
, ( =
, ) ?
, A
, B C
, D E
, F G

35E6 E8CC    DEFW   0CCE8H
35E8 D6DE    DEFW   0DED6H
35EA E4F8    DEFW   0F8E4H
35EC D8F0    DEFW   0F0D8H
35EE ECEE    DEFW   0EEECH
35F0 D4CA    DEFW   0CAD4H
35F2 E0CE    DEFW   0CEE0H
35F4 FCE6    DEFW   0E6FCH
35F6 FAEA    DEFW   0EAFAH
35F8 E2C0    DEFW   0C0E2H
35FA C0C0    DEFW   0C0C0H
35FC C0C0    DEFW   0C0C0H
35FE D0C4    DEFW   0C4D0H
3600 FEF6    DEFW   0F6FEH
,H I
,J K
,L M
,N O
,P Q
,R S
,T U
,V W
,X Y
,Z (
, )
,: (DEL)
,(CR,LF)
,(LTRS)(FIGS)

3602      END

STRT      3500
CR        3511
TCOM      3526
FIGS      354E
RESC      355F
COUT      3568
TAB        356D
TC         357B
ENDT      358F
BOUT      3598
BITS      35A2
XX         35AB
YY         35AD
PD         35B1
LKUP      35BE

```



## **SUPER-80 USERS . . .**

### **Announcing the El Graphix Lower Case/Graphics Kit 4!**

Yes, after a year of waiting, this fabulous Kit 4 is now available. As well as giving you Upper/Lower case characters, this Kit gives you a vast array of extra functions and useful subroutines. Check the following for an impressive list ...

- 9 extra monitor commands!
- 300, 600 and 1200 baud tape operation!
- Upper/Lower case alphanumerics! (The full 96 character ASCII set!)
- Can fill any video page in Ram with any ASCII character!  
(Great for wiping or filling blocks of memory)
- Inbuilt Centronics and RS232 printer routines!
- If you are using a non-standard printer, you can still insert your customised routine into Ram!
- All these printer routines can be software selected!
- RS232 receive routine also in Rom . . . connect a modem!
- Full range of "Chunky" Graphics; even occupying the same ASCII addresses as Tandy's TRS80 and Dick's System 80!
- Also directly compatible with the "Gluyas" Levels 2+3 Basics!
- A total of 160 versatile Graphics characters!
- Inbuilt Line/Dot routines, easily driven via variables from Basic!  
(Plot lines, draw curves, etc ...)
- Inbuilt Bar Graph routine, also driven via variables!
- Bar Graph resolution of 160 lines. (32 verticle bars available!)
- VDU Dump routine. Draw a picture and dump it into Ram for later use or save it on tape!
- VDU Shift/Fill/Wipe/Rotate routines ... even scrolls Diagonally!

### ● All this for only ... **\$55.50**

If you have Kit 1, 2 or 3, these can be upgraded to Kit 4 for only \$25.00. Even the DSE "De luxe" kit can be converted to this versatile kit for only \$27.50.

































**Note:** This kit was designed primarily for a Super-80 fitted with 48K and Basic on Rom. Some of these routines will not work on a lesser beast!

The prices quoted are current as from May '83 and include post and packing charges. Interstate orders posted airmail at no extra charge.

**Send your cheque to ...**

## **El Graphix**

**PO Box 278, Croydon 3136, Victoria, Australia**  
**Phone enquiries (03) 725 9842 (after 7pm please!)**

			
0(00)	8(08)	16(18)	24(18)
			
1(01)	9(09)	17(11)	25(19)
			
2(02)	10(0A)	18(12)	26(1A)
			
3(03)	11(0B)	19(13)	27(1B)
			
4(04)	12(0C)	20(14)	28(1C)
			
5(05)	13(0D)	21(15)	29(1D)
			
6(06)	14(0E)	22(16)	30(1E)
			
7(07)	15(0F)	23(17)	31(1F)

---

## **Super-80 software and tutorials**

Bemak Pty Ltd is a Canberra based supplier of software for the Super-80 computer, with a product range which includes games, programmer's utilities and a word processing program. The company is currently investigating the extent of interest in learning Z80 assembly language on the Super-80. If sufficient interest is shown Bemak plans to run a correspondence course next year to cover the ins and outs of Z80

programming.

In addition to software and the planned correspondence course Bemak has available information on overhauling and servicing the Super-80, which it will make available to customers free of charge.

For further information on software or for details of the proposed programming course contact Bemak Pty Ltd, PO Box 218, Belconnen, ACT, 2616.

## **Super-80 Users . . .** **Announcing the El Graphix "XRAM" memory card.**

This versatile and useful addition to the range of El Graphix products gives the user something that has been needed since the Super-80 was first produced.

### **Battery-Backed Memory!!**

Yes, the El Graphix "XRAM" card gives the user 16K of non-volatile memory to store your most used programs or data in for all time.

**The "XRAM" card has the following features . . .**

- \* Contains up to 16K of extra memory.
- \* Uses industry standard 6116 CMOS static Rams.
- \* Resides in memory from C000 to FFFF.
- \* Block shift the existing monitor into XRAM, add your own routines and run it as your own personalised monitor.
- \* Save your own favourite program for instant running.
- \* Does not use S100 bus connector.
- \* Can be externally write protected.
- \* Double sided, plated through printed circuit board.
- \* Integral power-down circuit deselected XRAM within 15ms of loss of mains and protects XRAM contents.
- \* No modifications to the Super-80 PCB necessary to install XRAM card.
- \* Does not affect normal operation of computer.
- \* Draws microamps in standby mode.
- \* Backup battery is being charged whenever computer is running.
- \* Control circuitry provides for a second XRAM to be fitted for up to 32K storage.
- \* XRAM can also accept standard 2716/2516 Eproms instead.

Just think of what you could do, with 64K of Ram to play with.

Due to the several configurations in which the XRAM can be constructed, it will not be available as a complete Kit.

It will be supplied rather as a bare printed circuit board with full instructions for the construction, installation and use of the XRAM.

This allows you to construct the version you require at the lowest possible price to you.

And the price of the XRAM card with complete instructions?

Only . . . . . **\$30.00** (includes postage/packing).

### **Don't forget the El Graphix Lower case/Graphics Kit 4.**

Extensive graphics routines, 160 Graphics character, full 96 characters ASCII set, 13 extra monitor commands with Printer driver routines built into the most popular Graphics Kit on the market today.

Still available at **\$55.50** for the full Kit or

To upgrade El Graphix Kits 1, 2 or 3 . . . . . **\$25.00**

To upgrade Dicks "deluxe" Kit . . . **\$27.50**

To upgrade the Computer Clinic Kit **\$27.50**

**All prices include packing and postage charges. Interstate orders posted airmail at no extra cost. N.Z. customers please add \$2.00**

Send your cheque or money  
order to . . . . .

## **El Graphix**

**P.O. Box 278 Croydon 3136 Victoria Australia**  
**Phone enquiries (03) 725 9842 (after 7 pm please)**

**\*\*\* El Graphix still supports the Super-80. \*\*\***

(Kit 4 users . . . Checkout Mastersofts ELDRAW program . . . a must for serious  
graphics . . . see Marketplace of this issue)




# MICROCOMPUTER ENGINEERING

PO Box 258 Haymarket 2001, NSW

Phone (02) 660 2924

## UNIVERSAL FLOPPY DISK CONTROLLER CARD



**DO NOT THROW AWAY YOUR OLD Z80 BASED COMPUTER**

- UFDC is designed to be "piggy backed" to Z80 socket
- suits ANY Z80 CPU based computers
- can support up to four drives in any combination of 5¼, 8 inch, SSSD or DSDD
- design around WD2793 floppy disk controller (on chip PLL data separator, write precompensation logic and programmable clock rate)
- UFDC has got Z80 DMA chip
- matches any speed of CPU and can be used for mem-to-mem transfers
- you can adjust Head Load time and Write Precompensation to your disk drive requirements
- plug compatible with Shugart 400/450 drives
- no interrupt or wait states for programming simplicity
- simple assignment of the UFDC registers to any one of 16 banks of your computer's I/O ports
- full software support
- sample of the CP/M 2.2 BIOS
- dimension 120x90mm


The UFDC has been implemented for Super-80 and System-80 computers using simple DOS. CP/M 2.2 has been implemented for Super-80 computer and supports 80/40 trk DSDD Disk Drives. Reads Telcon 388K Televideo 802 342K, DEC VT-180x 340K, IBM PC, Osborne 90K, 8" IBM 3740 formats and can be expanded. With VDUEB installed emulates ADM-31 terminal.

For more information on how to install UFDC on YOUR System, contact M.C.E.

**PRICES \$299**

**assembled and tested  
\$4 P&P**

## SUPER-80 VDU EXPANSION BOARD



The VDUEB converts your Super-80 into a professional computer. The screen format is 80 x 25 and the raster dimensions are software programmable to 64 x 16, 32 x 16 or any other formats

- full lower and upper ASCII character set
- 32K ROM based graphics char's
- 128 fully programmable character set
- inverse character mode
- 560 x 225 dot addressable graphics
- sound routine for BELL and music
- new Monitor EPROM supplied with 1200 baud cassette interface
- fully compatible with existing BASIC and software.

**PRICES \$229 Assembled and tested**

**\$169 Kit form**

**\$99 PCB and EPROMS**

**\$4.50 Manual**

**\$4 P&P**

## SUPER-80 VDUEB SOFTWARE LIST

• CP/M 2.2 Super-80*	\$170	• Super-80 Invaders	\$20
• Super-80 DOS	\$10	• Martian Attack	\$8
• Edit-80	\$20	• Othello	\$10
• Debug-80	\$15	• Adventure (two prog)	\$
• EXMON monitor	\$8	• Wordprocessors (three prog)	\$10-\$40
• Z80 Disassembler	\$25	• Graphics tool kit	\$15
• Extended Monitor & Disassem	\$10	• Super-80 Chess	\$20
• Microbee Tape Loader	\$5	• Eng Progr for struc design	\$10
• Sprite Programmer	\$8	• UFDC CP/M BIOS*, only	\$70
• Dot & line graph driver	\$20	*Source code of all programs supplied. ADD	
• PACKMEN	\$20	\$1.00 for P&P.	

## SWITCHING POWER SUPPLY FOR SUPER-80

• PSA-2B 60VA +5V/6A, -5V/0.5A, +12V/2A, -12V/0.5A	\$139.00
• Controller-to-Drive Cable (supports two drives)	\$39.95
• Disk Drive Power Supply connectors 8, 5¼ inch	\$4.95
• WD2793 disk controller	\$76.95
• Z80A DMA	\$15.95

**ADD \$3 P&P**

For more information regarding FREE software and CP/M software please contact MCE or Super-80/VDUEB USER CLUB at 15 Bray Court, North Rocks 2151, NSW. Phone (02) 871 8394.



**All Prices Include Sales Tax and are subject to change.**

**Mail order: MCE, PO Box 258 Haymarket 2001, NSW. Phone order: (02) 660 2924.**