Bluestem Lap Steel string spacing chart

Nut and bridge spacing are shown for 6, 7, and 8 string lap steel guitars based on the calculations shown:

```
6 STRINGS / 5 SPACES
```

```
(11/32") .344" X 5 = 1.72 = 1-47/64" (NUT, when using standard guitar pickups)

(3/8") .375" X 5 = 1.875 = 1-7/8" (NUT, when using Chicago style 2.20" 6 string spacing)

(25/64") .39063" X 5 = 1.953 = 2.0"

(13/32") .40625" X 5 = 2.031 = 2-1/32" (BRIDGE, when using standard guitar pickups)

(7/16") .4375" X 5 = 2.1875 = 2-3/16"

(29/64") .453125" X 5 = 2.2656 = 2-1/4" (BRIDGE, when using Chicago style 2.20" 6 string spacing)
```

Standard 6 string spacing: 11/32" at nut to 13/32" at saddle (permits use of standard guitar pickups) Wide 6 string spacing: 3/8" at nut to 29/64" at saddle (using Chicago style 2.20" 6 string spacing)

```
7 STRINGS / 6 SPACES
```

```
(11/32") .344" X 6 = 2.064 = 2-1/16"
(3/8") .375" X 6 = 2.25 = 2-1/4"
(13/32") .40625" X 6 = 2.4375 = 2-7/16"
(7/16") .4375" X 6 = 2.625 = 2-5/8"
(29/64") .453125" X 6 = 2.71875 = 2-23/32"
```

8 STRINGS / 7 SPACES

```
(11/32") .344" X 7 = 2.41 = 2-3/8" (NUT, if a slight taper is desirable, otherwise 3/8") (3/8") .375" X 7 = 2.625 = 2-5/8" (BRIDGE, Stringmaster style 8 string spacing) (13/32") .40625" X 7 = 2.84375 = 2-27/32" (7/16") .4375" X 7 = 3.0625 = 3-1/16" (29/64") .453125" X 7 = 3.1719 = 3-11/64"
```

Standard 8 string spacing: 11/32" at nut to 3/8" at bridge (Stringmaster & Chicago style 8 string spacing)