# Inspiron 14 3000 Setup and Specifications



# Notes, cautions, and warnings



NOTE: A NOTE indicates important information that helps you make better use of your product.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2017 - 2018 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2018 - 01

Rev. A02

# **Contents**

Se	et up your computer	5
\ /i.	ews	٥
VI	Front	
	Left	
	Right	
	9	
	Base	
	Display	
	Back	IZ
Sp	pecifications	13
- [-	Dimensions and weight	
	System information	
	Memory	
	Communications	
	Audio	
	Storage	
	Media-card reader	
	Keyboard	15
	Camera	16
	Touch pad	
	Battery	16
	Display	
	Video	
	Power adapter	
	Ports and connectors	
	Computer environment	



Keyboard shortcuts	
Getting help and contacting Dell	22
Self-help resources	22
Contacting Dell	23



# Set up your computer

1 Connect the power adapter and press the power button.






**2** Finish operating system setup.

#### For Windows:

a) Connect to your network.



b) Sign-in to your Microsoft account or create a new account.



#### For Ubuntu:

Follow the instructions on the screen to finish setup.



#### **3** Locate Dell apps in Windows.

#### Table 1. Locate Dell apps in Windows



Register your computer

## Dell Help & Support








 ${\bf SupportAssist-Check\ and\ update\ your\ computer}$ 



# Views

## **Front**



#### Power and battery-status light/hard-drive activity light

Indicates the battery-charge status or the hard-drive activity.



NOTE: Press Fn+H to toggle this light between power and batterystatus light and hard-drive activity light.

#### Hard-drive activity light

Turns on when the computer reads from or writes to the hard drive.

#### Power and battery-status light

Indicates the power and battery-charge status.

**Solid white** — Power adapter is connected and the battery has more than 5% charge.

**Amber** — Computer is running on battery and the battery has less than 5% charge.

#### Off

- Power adapter is connected and the battery is fully charged.
- Computer is running on battery and the battery has more than 5% charge.
- Computer is in sleep state, hibernation, or turned off.

## Left





#### 1 Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

#### 2 Network port

Connect an Ethernet (RJ45) cable from a router or a broadband modem for network or internet access.


#### 3 **HDMI port**

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

#### 4 USB 3.0 ports (2)

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 5 Gbps.

## Right



#### 1 SD-card slot

Reads from and writes to the SD card.

#### 2 Headset port

Connect a headphone or a headset (headphone and microphone combo).

#### 3 **USB 2.0 port**

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 480 Mbps.

#### 4 Optical drive (optional)


Reads from and writes to CDs and DVDs.

#### 5 Security-cable slot

Connect a security cable to prevent unauthorized movement of your computer.



## Base



#### 1 Touch pad

Move your finger on the touch pad to move the mouse pointer. Tap to left-click and two finger tap to right-click.

#### 2 Left-click area

Press to left-click.

#### 3 Right-click area

Press to right-click.

#### Power button

Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.

Press to put the computer in sleep state if it is turned on.

Press and hold for 4 seconds to force shut-down the computer.



NOTE: You can customize the power-button behavior in Power Options. For more information, see Me and My Dell at www.dell.com/ support/manuals.



# Display



#### 1 Camera

Enables you to video chat, capture photos, and record videos.

#### 2 Camera-status light

Turns on when the camera is in use.

#### 3 Microphone

Provides digital sound input for audio recording, voice calls, and so on.



## **Back**



#### 1 Service Tag label

The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information.

#### 2 Regulatory label (in battery bay)

Contains regulatory information of your computer.

#### 3 Battery

Supplies power to the computer. It enables the computer to work without connecting to an electrical outlet for a limited time.

#### 4 Battery-release latch

Lock/unlock the battery in the battery bay. Slide the latch to the unlock position, to release the battery.



# **Specifications**

## Dimensions and weight

#### Table 2. Dimensions and weight

 Height
 23.35 mm (0.92 in)

 Width
 345 mm (13.58 in)

 Depth
 243 mm (9.57 in)

 Weight
 2 kg (4.41 lb)



NOTE: The weight of your laptop varies depending on the configuration ordered and the manufacturing variability.

## System information

#### Table 3. System information

Computer model Inspiron 14-3467

Processor · 7<sup>th</sup> generation Intel Core i3/i5/i7

6<sup>th</sup> generation Intel Core i3

Chipset Integrated in the processor

## Memory

#### **Table 4. Memory specifications**

Slots Two SODIMM slots

Type DDR4

Speed 2400 MHz





#### NOTE: The 2400 MHz memory works at 2133 MHz.

Configurations supported

Per memory module slot 2 GB. 4 GB. and 8 GB

4 GB, 6 GB, 8 GB, and 16 GB Total memory

## Communications

#### Table 5. Communication specifications

Ethernet 10/100 Mbps Ethernet controller integrated on system board

Wireless WiFi 802.11ac+Bluetooth 4.2

WiFi 802.11ac+Bluetooth 4.1

WiFi 802.11b/g/n+Bluetooth 4.0

Miracast



NOTE: Windows 10 supports up to Bluetooth 4.1.

## **Audio**

#### Table 6. Audio specifications

Realtek ALC3246 with Waves MaxxAudio Controller

Pro

Speakers Two

Speaker output Average – 2 W

Peak - 2.5 W

Microphone Single digital microphone in the camera

assembly

Volume controls Media-control shortcut keys



## **Storage**

#### Table 7. Storage specifications

Interface 

• SATA 6 Gbps for hard drive

SATA 6 Gbps for solid-state drive

· SATA 1.5 Gbps for optical drive

Hard drive One 2.5-inch drive Solid-state drive One 2.5-inch drive

Optical-drive One 9.5 mm DVD+/-RW drive

## Media-card reader

#### Table 8. Media-card reader specifications

Type One SD-card slot

Cards supported

SD card

· SD High Capacity (SDHC) card

SD Extended Capacity (SDXC) card

## Keyboard

#### Table 9. Keyboard specifications

Type Standard keyboard

Shortcut keys Some keys on your keyboard have two

symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.





NOTE: You can define the primary behavior of the shortcut keys by pressing Fn+Esc or by changing **Function Key Behavior in System** Setup.

Keyboard shortcuts

## Camera

#### Table 10. Camera specifications

Resolution Still image: 0.90 megapixels

Video: 1280 x 720 (HD) at 30 fps

Diagonal viewing angle 74.9 degrees

## Touch pad

#### Table 11. Touch pad specifications

Resolution Horizontal: 2040

Vertical: 1240

Dimensions · Width: 105 mm (4.13 in)

Height: 65 mm (2.56 in)

## **Battery**

#### Table 12. Battery specifications

4-cell smart lithium-ion (40 WHr) Type

Dimensions · Width: 270 mm (10.63 in)

> Depth: 37.5 mm (1.48 in) Height: 20 mm (0.79 in)

Weight (maximum) 0.25 kg (0.55 lb)

Voltage 14.80 VDC

Life span (approximate) 300 discharge/charge cycles

Temperature range • Operating: 0°C to 35°C

(32°F to 95°F)

• Storage: -40°C to 65°C

 $(-40^{\circ}F \text{ to } 149^{\circ}F)$ 

Coin-cell battery CR-2032

Operating time Varies depending on operating conditions

and can significantly reduce under certain power-intensive conditions.

## Display

#### Table 13. Display specifications

Type 14-inch HD non-touch screen

Resolution (maximum) 1366 x 768

Pixel pitch 0.2265 mm

Refresh rate 60 Hz

Viewing angle (Left/Right/Up/Down) 40/40/10/30 degrees

Operating angle 0 degrees (closed) to 135 degrees

Controls Brightness can be controlled using

shortcut keys

Dimensions:

Height (excluding bezel) 173.95 mm (6.85 in)
Width (excluding bezel) 309.40 mm (12.18 in)
Diagonal (excluding bezel) 354.95 mm (13.97 in)



## Video

Table 14. Video specifications

	Integrated	Discrete
Controller	<ul><li>Intel HD Graphics 520</li><li>Intel HD Graphics 620</li></ul>	AMD Radeon R5 M430 Graphics
Memory	Shared system memory	Up to 2 GB DDR3

# Power adapter

Table 15. Power adapter specifications

	45 W	65 W
Input current (maximum)	1.30 A	1.70 A
Output current (continuous)	2.31 A	3.34 A
Input voltage		100 VAC-240 VAC
Input frequency		50 Hz-60 Hz
Rated output voltage		19.50 VDC
Temperature range: Operating		0°C to 40°C (32°F to 104°F)
Temperature range: Storage		-40°C to 70°C (-40°F to 158°F)

## Ports and connectors

Table 16. Ports and connectors specifications

External:	
Network	One RJ45 port
USB	· One USB 2.0 port



# External: Two USB 3.0 ports Audio/Video One HDMI port One headset port (headphone and microphone combo)

Table 17. Ports and connectors specifications

Internal:	
M.2 slot	One M.2 slot for WiFi and Bluetooth
	combo card

## Computer environment

Airborne contaminant level: G1 as defined by ISA-S71.04-1985

Table 18. Computer environment

	Operating	Storage
Temperature range	0°C to 35°C (32°F to 95°F)	–40°C to 65°C (–40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non-condensing)	0% to 95% (non-condensing)
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G <sup>†</sup>	160 G <sup>‡</sup>
Altitude (maximum)	-15.20 m to 3048 m (-50 ft to 10,000 ft)	-15.20 m to 10,668 m (-50 ft to 35,000 ft)

<sup>\*</sup> Measured using a random vibration spectrum that simulates user environment.



<sup>†</sup> Measured using a 2 ms half-sine pulse when the hard drive is in use.

 $<sup>\</sup>ensuremath{\ddagger}$  Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.

# **Keyboard shortcuts**

#### Table 19. Keyboard shortcuts

Keys	Description
F1 «x	Mute audio
F2 w	Decrease volume
F3 (1)	Increase volume
F4 iee	Play previous track/chapter
F5 • II	Play/Pause
F6 → H	Play next track/chapter
F8 💆	Switch to external display
F9 P	Search
F11 *	Decrease brightness
F12 *	Increase brightness
$-$ + $\frac{\Pr{tScr}}{\binom{0}{N}}$	Turn off/on wireless
Fn + S	Toggle scroll lock
Fn + Esc D	Toggle Fn-key lock



Keys	Description
Fn + B	Pause/Break
Fn + Insert	Sleep
Fn + R	System request
Fn + Ctrl	Open application menu
Fn + H	Toggle between power and battery-status light/ hard-drive activity light
+	End
Fn + ← Home	Home
+	Page down
+	Page up



# Getting help and contacting Dell

## Self-help resources

You can get information and help on Dell products and services using these self-help resources:

#### Table 20. Self-help resources

Information about Dell products and services

Dell Help & Support app

Tips

Contact Support

Online help for operating system

Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.

Dell knowledge base articles for a variety of computer concerns.

www.dell.com





In Windows search, type Help and Support, and press Enter.

www.dell.com/support/windows www.dell.com/support/linux

www.dell.com/support

- Go to www.dell.com/support.
- Type the subject or keyword in the Search box.
- 3 Click **Search** to retrieve the related articles.

about your product:

- Product specifications
- Operating system

Learn and know the following information See Me and My Dell at www.dell.com/ support/manuals.



- Setting up and using your product
- · Data backup
- · Troubleshooting and diagnostics
- Factory and system restore
- BIOS information

To locate the *Me and My Dell* relevant to your product, identify your product through one of the following:

- · Select **Detect Product**.
- Locate your product through the drop-down menu under View Products.
- Enter the Service Tag number or Product ID in the search bar.

## **Contacting Dell**

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.



NOTE: Availability varies by country and product, and some services may not be available in your country.



NOTE: If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

